


This Owner's Manual is provided and hosted by [Appliance Factory Parts](#).



LG 73263 Owner's Manual

[Shop genuine replacement parts for LG 73263](#)




[Find Your LG Refrigerator Parts - Select From 834 Models](#)

----- Manual continues below -----



REFRIGERATOR SERVICE MANUAL

CAUTION
BEFORE SERVICING THE UNIT,
READ THE SAFETY PRECAUTIONS IN THIS MANUAL.



Model #s:

795-73962303
795-73969303
795-73964303
795-73966303
795-73963303
795-75952401
795-75959401
795-73262303
795-73264303
795-73263303
795-75259401
795-75954401
795-73269303
795-73266303
795-75252401
795-75254401

CONTENTS


| | |
|--|-------|
| SAFETY PRECAUTIONS | 2 |
| SPECIFICATIONS..... | 3 |
| PARTS IDENTIFICATION | 4 |
| DISASSEMBLY..... | 5-6 |
| DOOR..... | 5 |
| DOOR SWITCH..... | 5 |
| FAN AND FAN MOTOR..... | 6 |
| DEFROST CONTROL ASSEMBLY..... | 6 |
| LAMP..... | 6 |
| CONTROL BOX-REFRIGERATOR..... | 6 |
| ADJUSTMENT..... | 7-8 |
| COMPRESSOR..... | 7 |
| PTC-STARTER..... | 7 |
| OLP(OVERLOAD PROTECTOR)..... | 8 |
| THERMOSTAT..... | 8 |
| CIRCUIT DIAGRAM | 9-10 |
| TROUBLESHOOTING..... | 11-16 |
| COMPRESSOR AND ELECTRICAL COMPONENTS | 11 |
| PTC AND OLP | 12 |
| OTHER ELECTRICAL COMPONENTS | 13 |
| SERVICE DIAGNOSIS CHART..... | 14 |
| REFRIGERATION CYCLE..... | 15-16 |
| OPERATION PRINCIPLE & REPAIR METHOD OF ICE MAKER | 17-20 |
| DESCRIPTION OF FUNCTION & CIRCUIT OF MICOM | 21-35 |
| REFRIGERATOR EXPLODED VIEW & SERVICE PARTS LIST..... | 36 |

SAFETY PRECAUTIONS

Please read the following instructions before servicing your refrigerator.

1. Check the refrigerator for electrical faults.
2. To prevent electric shock, unplug before servicing.
3. Always check line voltage and amperage.
4. Use standard electrical components or cause your skin to freeze and stick to the surfaces inside the freezer.
5. Don't touch metal products in the freezer with wet hands. This may cause frostbite.
6. Prevent water from spilling onto electrical elements or the machine parts.
7. Close the top door before opening the bottom door. Otherwise, you might hit your head when you stand up.
8. When tilting the refrigerator, remove any material on the refrigerator, especially the glass shelves and stored food.
9. When servicing the evaporator, wear cotton gloves. This is to prevent injuries from the sharp evaporator fins.
10. Service on the refrigerators should be performed by a qualified technician. Sealed system repair must be performed by a CFC certified technician.

2. PARTS IDENTIFICATION




3.DISASSEMBLY


3-1 DOOR

● Freezer Door

1. Remove the hinge cover by pulling it upwards.
2. Loosen hexagonal bolts attaching the upper hinge to the body and lift the freezer door.




3. Pull out the door gasket to remove from the door foam assembly.



● Refrigerator Door


1. Loosen hexagonal bolts attaching the lower hinge to the body to remove the refrigerator door only.



2. Pull out the door gasket to remove from the door foam assembly.


3-2 DOOR SWITCH

1. To remove the door switch, pull it out with a slotted-type driver as shown in (Figure 4).
2. Disconnect the lead wire from the switch.



3-3 FAN AND FAN MOTOR

1. Remove the freezer shelf. (If your refrigerator has an icemaker, remove the icemaker first)
2. Remove the grille by pulling it out and by loosening a screw.
3. Remove the Fan Motor assembly by loosening 4 screws and disassemble the shroud.
4. Pull out the fan and separate the Fan Motor and Bracket.





3-4 DEFROST CONTROL ASSEMBLY

Defrost Control assembly consists of Defrost Sensor and FUSE-M.


Defrost sensor functions to defrost automatically. It is attached to metal side of the Evaporator and senses Temperature. At the temperature of 162°F(72°C), it stops the emission of heat from the Heater.

Fuse-M is a safety device for preventing over-heating of the Heater when defrosting.

1. Pull out the grille assembly. (Figure 6)
2. Separate the connector with the Defrost Control assembly and replace the Defrost Control assembly after cutting the Tie Wrap. (Figure 7)




3-5 LAMP



3-5-1 Refrigerator Compartment Lamp

1. Unplug the power cord from the outlet.
2. Remove refrigerator shelves.
3. Release the hooks on both ends of the lamp shield and pull the shield downward to remove it.
4. Turn the lamp counterclockwise.
5. Assemble in reverse order of disassembly. Replacement bulb must be the same specification as the original (Max. 60 W-2EA).




3-5-2 Freezer Compartment Lamp

1. Unplug refrigerator or disconnect power.
2. Reach behind light shield to remove bulb.
3. Replace bulb with a 40-watt appliance bulb.
4. Plug in refrigerator or reconnect power.

3-6 CONTROL BOX-REFRIGERATOR

1. First, remove all shelves in the refrigerator, then remove the Refrigerator Control Box by loosening 2 screws.



2. Remove the Refrigerator Control Box by pulling it downward.
3. Disconnect the lead wire on the right position and separate the lamp sockets.

4. ADJUSTMENT

4-1 COMPRESSOR

4-1-1 Role

The compressor intakes low temperature and low pressure gas from the evaporator of the refrigerator and compresses this gas to high-temperature and high-pressure gas. It then delivers the gas to the condenser.

4-1-2 Composition

The compressor includes overload protection. The PTC starter and OLP (overload protector) are attached to the outside of the compressor. Since the compressor is manufactured to tolerances of 1 micron and is hermetically sealed in a dust and moisture-free environment, use extreme caution when repairing it.

4-1-3 Note for Usage

- (1) Be careful not to allow over-voltage and over-current.
- (2) If compressor is dropped or handled carelessly, poor operation and noise may result.
- (3) Use proper electric components appropriate to the Particular Compressor in your product.
- (4) Keep Compressor dry.
If Compressor gets wet (in the rain or a damp environment) and rust forms in the pin of the Hermetic Terminal, poor operation and contact may result.
- (5) When replacing the Compressor, be careful that dust, humidity, and soldering flux don't contaminate the inside of the compressor. Dust, humidity, and solder flux contaminate the cylinder and may cause noise or improper operation even cause it to lock up.

4-2 PTC-STARTER

4-2-1 Composition of PTC-Starter


- (1) PTC (Positive Temperature Coefficient) is a no-contact semiconductor starting device which uses ceramic material consisting of BaTiO₃.
- (2) The higher the temperature is, the higher the resistance value. These features are used as a starting device for the Motor.

4-2-2 Role of PTC-Starter

- (1) The PTC is attached to the Sealed Compressor and is used for starting the Motor.
- (2) The compressor is a single-phase induction motor. During the starting operation, the PTC allows current flow to both the start winding and main winding.

4-2-3 PTC-Applied Circuit Diagram

● Starting Method for the Motor



4-2-4 Motor Restarting and PTC Cooling

- (1) It requires approximately 5 minutes for the pressure to equalize before the compressor can start.
- (2) The PTC device generates heat during operation. Therefore, it must be allowed to cool before the compressor can restart.

4-2-5 Relation of PTC-Starter and OLP

- (1) If the compressor attempts to restart before the PTC device is cooled, the PTC device will allow current to flow only to the main winding.
- (2) The OLP will open because of the over current condition. This same process will continue (3 to 5 times) when the compressor attempts to restart until the PTC device has cooled. The correct OLP must be properly attached to prevent damage to the compressor.

4-2-6 Note for Using the PTC-Starter

- (1) Be careful not to allow over-voltage and over-current.
- (2) Do not drop or handle carelessly.
- (3) Keep away from any liquid.
If liquid such as oil or water enters the PTC, PTC materials may fail due to breakdown of their insulating capabilities.
- (4) If the exterior of the PTC is damaged, the resistance value may be altered. This can cause damage to the compressor and result in a no-start or hard-to-start condition.
- (5) Always use the PTC designed for the compressor and make sure it is properly attached to the compressor.


4-3 OLP (OVERLOAD PROTECTOR)

4-3-1 Definition of OLP


- (1) OLP (OVERLOAD PROTECTOR) is attached to the Compressor and protects the Motor by opening the circuit to the Motor if the temperature rises and activating the bimetal spring in the OLP.
- (2) When high current flows to the Compressor motor, the Bimetal works by heating the heater inside the OLP, and the OLP protects the Motor by cutting off the current flowing to the Compressor Motor.

4-3-2 Role of the OLP


- (1) The OLP is attached to the Sealed Compressor used for the Refrigerator. It prevents the Motor Coil from being started in the Compressor.
- (2) For normal operation of the OLP, do not turn the Adjust Screw of the OLP in any way.




4-4 TO REMOVE THE COVER PTC



- 1) Remove the Cover Back M/C.
- (2) Remove the screw on Cover PTC.




- (3) Remove two Housings on upper part of Cover PTC.
- (4) Take out the cover PTC from upper to lower position like ①.



- (5) Turn 45° in the direction of ② and take it out.
- (6) Assembly in reverse order of disassembly.

5.CIRCUITDIAGRAM


Bestmodels




Nota: Los diagramas 3854JK1003A y 3854JK1003B fueron sustituidos por el diagrama 3854JK1005C

Bettermodels

DIAGRAMA ELECTRICO - CIRCUIT DIAGRAM



• P.T.C START OPTION




*P.T.C START OPTION. CAPACITOR PART, WATER VALVE PART, ICE MAKER PART, PLUG TYPE AND COMP' EARTH PART ON CIRCUIT DIAGRAM ARE SUBJECT TO CHANGE IN DIFFERENT LOCALITIES AND MODEL TYPE.

BK: NEGRO/BLACK BN: CAFE/BROWN RD: ROJO/RED BO: NARANJA/BRIGHT ORANGE
 YL: AMARILLO/YELLOW GN: VERDE/GREEN BL: AZUL/BLUE PR: VIOLETA/PURPLE GY: GRIS/GRAY
 WH: BLANCO/WHITE SB: AZUL CIELO/SKY BLUE PK: ROSA/PINK





Nota: Los diagramas 3854JK1002A y 3854JK1002B fueron sustituidos por el diagrama 3854JK1005B

6. TROUBLESHOOTING

6-1 COMPRESSOR AND ELECTRIC COMPONENTS




6-2PT CANDOLP






6-3 OTHER ELECTRIC COMPONENTS

▼ Not cooling at all




▼ Poor cooling performance



6-4 SERVICE DIAGNOSIS CHART

| COMPLAINT | POINTS TO BE CHECKED | REMEDY |
|--|---|---|
| No Cooling. | <ul style="list-style-type: none"> • Is the power cord unplugged from the outlet? • Check if the power Switch is set to OFF. • Check if the fuse of the power Switch is shorted. • Measure the voltage of the power outlet. | <ul style="list-style-type: none"> • Plug into the outlet. • Set the switch to ON. • Replace the fuse. • If the voltage is low, correct the wiring. |
| Cools poorly. | <ul style="list-style-type: none"> • Check if the unit is placed too close to the wall. • Check if the unit is placed too close to the stove, gas cooker, or in direct sunlight. • Is the ambient temperature too high or the room door closed? • Check if food put in the refrigerator is hot. • Did you open the door of the unit too often or check if the door is sealed properly? • Check if the Control is set to Warm position. | <ul style="list-style-type: none"> • Place the unit about 10 cm from the wall. • Place the unit away from these heat sources. • Lower the ambient temperature. • Put in foods after they have cooled down. • Don't open the door too often and close it firmly. • Set the control to Recommended-position. |
| Foods in the Refrigerator are frozen. | <ul style="list-style-type: none"> • Is food placed in the cooling air outlet? • Check if the control is set to colder-position. • Is the ambient temperature below 41°F(5°C)? | <ul style="list-style-type: none"> • Place foods in the high-temperature section. (front part) • Set the control to Recommended-position. • Set the control to Warm-position. |
| Condensation or ice forms inside the unit. | <ul style="list-style-type: none"> • Is liquid food sealed? • Check if food put in the refrigerator is hot. • Did you open the door of the unit too often or check if the door is sealed properly? | <ul style="list-style-type: none"> • Seal liquid foods with wrap. • Put in foods after they have cooled down. • Don't open the door too often and close it firmly. |
| Condensation forms in the Exterior Case. | <ul style="list-style-type: none"> • Check if the ambient temperature and humidity of the surrounding air are high. • Is there a gap in the door gasket? | <ul style="list-style-type: none"> • Wipe moisture with a dry cloth. It will disappear in low temperature and humidity. • Fill up the gap. |
| There is abnormal noise. | <ul style="list-style-type: none"> • Is the unit positioned in a firm and even place? • Are any unnecessary objects placed in the back side of the unit? • Check if the Drip Tray is not firmly fixed. • Check if the cover of the compressor enclosure in the lower front side is taken out. | <ul style="list-style-type: none"> • Adjust the Leveling Screw, and position in a firm place. • Remove the objects. • Fix the Drip Tray firmly in the original position. • Place the cover in its original position. |
| Door does not close well. | <ul style="list-style-type: none"> • Check if the door gasket is dirty with an item like juice. • Is the refrigerator level? • Is there too much food in the refrigerator? | <ul style="list-style-type: none"> • Clean the door gasket. • Position in the firm place and level the Leveling Screw. • Make sure food stored in shelves does not prevent the door from closing. |
| Ice and foods smell unpleasant | <ul style="list-style-type: none"> • Check if the inside of the unit is dirty. • Are foods with a strong odor unwrapped? • The unit smells of plastic. | <ul style="list-style-type: none"> • Clean the inside of the unit. • Wrap foods that have a strong odor. • New products smell of plastic, but this will go away after 1-2 weeks. |

● Other possible problems:




6-5 REFRIGERATING CYCLE

▼ Troubleshooting Chart

| CAUSE | | STATE OF THE UNIT | STATE OF THE EVAPORATOR | TEMPERATURE OF THE COMPRESSOR | REMARKS |
|-----------------------|---------------------|---|--|---|---|
| LEAKAGE | PARTIAL LEAKAGE | Freezer compartment and Refrigerator don't cool normally. | Low flowing sound of Refrigerant is heard and frost forms in inlet only. | A little higher than ambient temperature. | <ul style="list-style-type: none"> Refrigerant level is low due to a leak. Normal cooling is possible by restoring the normal amount of refrigerant and repairing the leak. |
| | COMPLETE LEAKAGE | Freezer compartment and Refrigerator don't cool normally. | Flowing sound of refrigerant is not heard and frost isn't formed. | Equal to ambient temperature. | <ul style="list-style-type: none"> No discharging of Refrigerant. Normal cooling is possible by restoring the normal amount of refrigerant and repairing the leak. |
| RESTRICTED BY DUST | PARTIAL RESTRICTION | Freezer compartment and Refrigerator don't cool normally. | Flowing sound of refrigerant is heard and frost forms in inlet only. | A little higher than ambient temperature. | <ul style="list-style-type: none"> Normal discharging of the refrigerant. The capillary tube is faulty. |
| | WHOLE RESTRICTION | Freezer compartment and Refrigerator don't cool. | Flowing sound of refrigerant is not heard and frost isn't formed. | Equal to ambient temperature. | <ul style="list-style-type: none"> Normal discharging of the Refrigerant. |
| MOISTURE RESTRICTION | | Cooling operation stops periodically. | Flowing sound of refrigerant is not heard and frost melts. | Lower than ambient temperature. | <ul style="list-style-type: none"> Cooling operation restarts when heating the inlet of the capillary tube. |
| DEFECTIVE COMPRESSION | COMP-RESSION | Freezer and Refrigerator don't cool. | Low flowing sound of refrigerant is heard and frost forms in inlet only. | A little higher ambient temperature. | <ul style="list-style-type: none"> Low pressure at high side of compressor due to low refrigerant level. |
| | NO COMP-RESSION | No compressing operation. | Flowing sound of refrigerant is not heard and there is no frost. | Equal to ambient temperature. | <ul style="list-style-type: none"> No pressure in the high pressure part of the compressor. |

▼ Leakage Detection

- Observe the discharging point of the refrigerant, which may be in the oil discharging part of the compressor and in a hole in the evaporator.




▼ General Control of Refrigerating Cycle

| NO. | ITEMS | UNIT | STANDARDS | PURPOSES | REMARKS | |
|-----|-------------------------------------|-----------------------------|--|--|--|--|
| 1 | Pipe and piping system opening time | Min. | Pipe: within 1 hour. Comp: within 10 minutes. Drier: within 20 minutes. | To protect moisture penetration. | The opening time should be reduced to a half of the standards during rain and rainy seasons (the penetration of water into the pipe is dangerous). | |
| 2 | Welding | Nitrogen pressure | Weld under Nitrogen atmosphere. (N ₂ pressure: 0.1~0.2 kg/cm ²) | To protect oxide scale formation. | - Refer to repair note in each part. - R-134a refrigerant is more susceptible to leaks than R-12 and requires more care during welding. - Do not apply force to pipes before and after welding to protect pipe from cracking. | |
| 3 | N ₂ sealed parts | Confirm N ₂ leak | Confirm the sound of pressure relief when removing the rubber cap. Sound: usable No sound: not usable | To protect moisture penetration. | - In case of evaporator parts, if it doesn't make sound when removing rubber cap, blow dry air or N ₂ gas for more than 1 min. and then use the parts. | |
| 4 | Refrigeration Cycle | Evacuation time | Min. | More than 40 minutes | To remove moisture. | |
| | | Vacuum degree | Torr | Below 0.03 (ref) | | Note: Only applicable to the model equipped with reverse flow protect plate. |
| | | Vacuum | EA | High and low pressure sides are evacuated at the same time for models above 200 l. | | Vacuum efficiency can be improved by operating compressor during evacuation. |
| | | Vacuum piping | EA | Use R-134a manifold exclusively. | To protect mixing of mineral and ester oils. | The rubber pipes for R-12 refrigerant will be melted when they are used for R-134a refrigerant (causes of leak.) |
| | | Pipe coupler | EA | Use R-134a manifold exclusively. | To protect R-12 refrigerant mixing. | |
| | | Outlet (Socket) | | R-134a manifold exclusively. | To protect R-12 refrigerant mixing. | |
| | | Plug | | R-134a manifold exclusively. | To protect R-12 refrigerant mixing. | |
| 5 | Refrigerant weighing | EA | Use R-134a exclusively. Weighing allowance: +5g Note: Winter: -5g Summer: +5g | Do not mix with R-12 refrigerant. | - Do not weigh the refrigerant at too hot or too cold an area. (77°F [25°C] is adequate.) - Make Copper charging canister (Device filling refrigerant) Socket: 2SV Plug: 2PV R-134a Note: Do not burn O-ring (bushing) during welding. | |
| 6 | Drier replacement | | - Use R-134a exclusively for R-134a refrigerator. - Replace drier whenever repairing refrigerator cycle piping. | To remove the moisture from pipe inside. | | |
| 7 | Leak check | | - Do not use soapy water for check. It may be sucked into the pipe by a vacuum. | Defect in refrigerant leak area. | - Check for an oil leak at the refrigerant leak area. Use an electronic leak detector if an oil leak is not found. - The electronic leak detector is very sensitive to halogen gas in the air. It also can detect R-141b in urethane. Practice many times before using this type of detector to avoid false readings. | |


7. OPERATION PRINCIPLE AND REPAIR METHOD OF ICE MAKER

7-1 OPERATION PRINCIPLE

7-1-1 Operation Principle of Ice Maker



1. Turning the ice making stop switch of (O) stops the ice making function.
2. Setting the ice maker switch to OFF and then turning it back on will reset the ice maker control.



7-2 CONTROL METHOD ACCORDING TO FUNCTIONS

7-2-1 Start Position

1. After POWER OFF for Power Cut, check EJECT OR's position with MICOM initialization to restart.
2. Control Method to check if it's in place:
 - (1) EJECT OR is in place,
 - The ejector must be in the park position before a new cycle can be initiated.
 - (2) EJECT OR is not in place:
 - A. If there is no ice formed in the icemaker, it should take approximately 2 minutes for the ejector blades to cycle through the harvest mode and return to the park position.
 - B. If there is ice formed in the icemaker, it can take up to 18 minutes for the ejector blades to cycle through the harvest mode and return to the park position.


7-2-2 Ice Making Mode

1. The Ice Making Mode starts once the ejector is in the park position and the icemaker mold is filled with water.
2. The Ice Making Mode is terminated when the icemaker sensor reaches 19 °F (-7°C). This may take between 1 and 4 hours.

7-2-3 Harvest Mode

1. The Harvest mode is initiated when the temperature is satisfied with the shut-off arm in the down position.
2. Once the Harvest mode is initiated, the heater is operated for 30 seconds.
3. After 30 seconds, the ejector blades are operated. (Pin 10 of micom from the hall sensor will read 5V.)
4. Once the ejector blades have reached the park position and the hall sensor is reading 0V, water fill will be initiated.






NOTE: If no movement is detected from the shut-off arm (detect lever), a Harvest mode will be attempted every 2 hours.




7-2-4 Fill/Park Position

1. Once an normal harvest mode has been completed, the water solenoid will be activated.
2. The amount of water is adjusted by pressing the water supply control switch. This changes the time allowed for fill as illustrated in the chart.

Water supply amount T ABLE

| STAGE | TIMET OS UPPLY | INDICATIONS | REMARKS |
|-------|----------------|---|---|
| 1 | 6sec. |  | The water amount will vary depending on the water control switch setting, as well as the water pressure of the connected waterline. |
| 2 | 7sec. |  | |
| 3 | 8sec. |  | |
| 4 | 9sec. |  | |
| 5 | 10sec. |  | |






NOTE: Below is an example used by another vendor as an explanation of what is taking place.



7-2-5 Function TEST



1. This is a compulsory operation for TEST, SVC, cleaning, etc. It is operated by pressing the water supply control KEY for 3 seconds.
2. It operates in the Icemaking mode, but not in the Ice-Removing mode or water supply process. (If there is an ERROR, it can only be checked in the TEST mode.)
3. If the water supply control KEY is pressed for 3 seconds in the Ice-Making mode (no matter what condition the Ice-Making tray is in) the Ice-Removing operation starts immediately. Water is not yet frozen, so water is poured instead of ice. If the control doesn't operate normally in the TEST mode, check and repair as needed.
4. After water is supplied, the normal CYCLE is followed: **ice making** → **Harvest** → **Fill** → **Park position**.
5. When Stage 5 is completed in the TEST mode, minimize MICOM in 5 seconds, the time needed to supply water resets to the previous status in the TEST mode.

Diagnosis TABLE

| STAGE | ITEMS | INDICATOR | REMARKS |
|-------|---|---|--|
| 1 | HEATER |  | Five seconds after heater starts, heater will go off if temperature recorded by sensor is 50°F(10°C) or lever is in up position. |
| 2 | MOTOR |  | Five seconds after heater starts, you can confirm that motor is moving. |
| 3 | HALL IC (detection of position) I |  | You can confirm Hall IC detection of position. |
| 4 | VALVE |  | Two seconds after detection of initial position, you can confirm that valve is on. |
| 5 | HALL IC (detection of full-filled Ice) II |  | You can check whether hall is sensing Full ice condition. (If there is a full-filled error, the fifth LED is not on.) |
| 6 | reset | Mark previous status on TEST mode | Five seconds after fifth stage is completed, the Icemaker reset at initial status. |

7-3 DEFECT DIAGNOSIS FUNCTION

7-3-1 ERROR CODES shown on Ice Maker water supply control panel

| NO | DIVISION | INDICATOR | CONTENTS | REMARKS |
|----|-------------------------------|---|--|--|
| 1 | Normal | Mark time to supply | None | Display switch operates properly |
| 2 | Ice-Making Sensor malfunction |  | Open or short-circuited wire | Make sure that the wire on each sensor is connected. |
| 3 | Ice Maker Kit malfunction |  | When ejector blades don't reach park position over 18 minutes since Harvest Mode starts. | Defects of HALL IC/MOTOR/ HEATER/RELAY |

ERROR indicators in table can be checked only in TEST mode.

8. DESCRIPTION OF FUNCTION & CIRCUIT OF MICOM


8-1 FUNCTION

8-1-1 Function



- When the appliance is plugged in, it is set to "37 °F" for the Refrigerator and "0 °F" for the Freezer (set to "4" for Refrigerator and "4" for Freezer).
You can adjust the Refrigerator and the Freezer control temperature by pressing the COLDER button or the COLD button.
- When the power is initially applied or restored after a power failure, it is automatically reset to "37 °F" and "0 °F" (set to "4" and "4").



Control range : 32°F ~ 47°F
0°C ~ 8°C



Control range : -6°F ~ 8°F
-21°C ~ -13°C



8-1-2 How to Change the Temperature Mode to °F / °C

- The setting temperature mode can be changed to °F / °C by pressing the " °F / °C " button.
- The initial setting is on °F. When the mode is changed the LED lights come on.

8-1-3 Key Lock

- The key pads can be locked by pressing and holding the KEY LOCK button for 3 seconds.
- The lock light will be displayed and the key pads will be inoperable.
- Pressing and holding the KEY LOCK button for 3 seconds will reactivate the key pads.


8-1-4 OFF Function

- To turn off the Best model, press and hold the °F/°C button for 3 seconds. To turn off the Better model, press and hold the OFF key for 3 seconds.
- In the Off mode, the Best model will display OFF in the control panel. The OFF light will be displayed on the Better model.
- To cancel the OFF function, press the same keys and hold for 3 seconds.

8-1-5 Alarm for Open Door

1. This feature sounds a buzzer when the freezer or refrigerator door is not closed within 1 minute after it is opened.
2. One minute after the door is opened, the buzzer sounds three times each for 0.5 seconds. These tones repeat every 30 seconds.
3. The alarm is cancelled when the freezer or refrigerator is closed while the buzzer sounds.

0



8-1-6 Buzzer Sound

When the button on the front Display is pushed, a "Ding~" sound is produced.

8-1-7 Defrost Cycle

1. A defrost cycle will be initiated after 4 hours of accumulated compressor runtime after the initial power up or power failure.
2. After the initial defrost, the defrost cycle is initiated after 7 hours of accumulated compressor runtime.
3. The defrost cycle will be terminated once the defrost sensor reaches 50 °F (10°C).

8-1-8 Electrical Parts Operates in Orders

Electrical parts such as COMP, defrost heater, freezer FAN, etc. operate in the following order to prevent noise and parts damage. Several parts are started at the same time at initial power on and are returned off together when TEST is completed.

| OPERATING | | ORDERS | | | | |
|--|---|-----------------------|-----------------|--------------------------|-----------------|---------------------------|
| Initial power on | Temperature of Defrost Sensor is 13°F (45°C) or more (when unit is newly purchased or when moved) | POWER ON | in 1/2 second → | COMP ON | in 1/2 second → | Freezer FAN ON |
| | Temperature of defrost sensor is lower than 113°F (45°C) (when power cuts, SERVICE) | POWER ON | in 1/2 second → | Defrost heater ON | in 10 second → | Defrost heater OFF |
| Reset to normal operation from TEST MODE | | COMP ON | in 1/2 second → | Freezer FAN ON | | |
| | | Total load OFF | in 7 minute → | COMP ON | in 1/2 second → | Freezer FAN ON |


8-1-9 Defect Diagnosis Function

1. Error codes will be displayed when defect occurs which can affect product performance.
2. When a defect occurs, the buttons will not operate; but the tones such as "ding" will sound.
3. When error code is resolved, the refrigerator will restart normally (Micom will be reset).
4. The error code shows on the refrigerator DISPLAY as temperature LED, and the other LED turns off.



-Show ERROR CODE on Refrigerator Temperature Panel and Freezer Temperature panel.

| NO | ITEM | ERROR CODE | | CONTENTS | REMARKS |
|----|--------------------------------------|-----------------------------------|------------------|---|---|
| | | REF. TEMP. PANEL | FRZ. TEMP. PANEL | | |
| 1 | Freezer sensor malfunctions | Er | F5 | Open or short-circuited wire | *Inspect connecting wires on each sensor |
| 2 | Refrigerator sensor malfunctions | Er | r5 | Open or short-circuited wire | |
| 3 | Defrost sensor malfunctions | Er | d5 | Open or short-circuited wire | |
| 4 | Room Temperature sensor malfunctions | On LED CHECK mode ERROR CODE sign | | Open or short-circuited wire | |
| | | Er | rT | | |
| 5 | Defrosting malfunctions | Er | dH | 2 hours after defrosting starts, the sensor is not above 50°F(10°C) | Temperature fuse open, Heater open, Drain is clogged, Heater starts but relay malfunctions. |



-Show ERROR CODE on Freezer Temperature panel.

○ :ON ● :OFF

| NO | ITEM | DEFECT SIGNS | | | | | | | CONTENTS | REMARKS |
|----|--------------------------------------|-------------------|----|----|----|----|----|----|---|---|
| | | F1 | F2 | F3 | F4 | F5 | F6 | F7 | | |
| 1 | Freezer sensor malfunctions | ● | ○ | ○ | ○ | ○ | ○ | ○ | Open or short-circuited wire | *Inspect connecting wires on each sensor |
| 2 | Refrigerator sensor malfunctions | ○ | ● | ○ | ○ | ○ | ○ | ○ | Open or short-circuited wire | |
| 3 | Defrost sensor malfunctions | ○ | ○ | ● | ○ | ○ | ○ | ○ | Open or short-circuited wire | |
| 4 | Room Temperature sensor malfunctions | On LED CHECK mode | | | | | | | Open or short-circuited wire | |
| | | ● | ○ | ● | ○ | ○ | ○ | ○ | | |
| 5 | Defrosting malfunctions | ● | ● | ● | ● | ○ | ○ | ○ | 2 hours after defrosting starts, the sensor is not above 50°F(10°C) | Temperature fuse open, Heater open, Drain is clogged, Heater starts but relay malfunctions. |

8-1-10 TEST Mode


1. The Test mode allows checking the PCB and the function of the product as well as finding out the Defective part in case of an error.
2. The test button is on the main PCB of the refrigerator (Test S/W). The test mode will be cleared in 2 hours regardless of the type of test mode.
3. While in the test mode, the function control button will not operate, though the recognition tone (beep~) sounds.
4. After exiting the test mode, be sure to reset by unplugging and then plugging in the appliance.
5. If an error (such as a sensor failure) is detected while in the test mode, the test mode is cleared and the error code is displayed.
6. While an error code is displayed, the test mode will not be activated even if the test button is pushed.

| MODE | MANIPULATION | CONTENTS | REMARKS |
|-------|---|---|--|
| TEST1 | Push the test button once. | <ol style="list-style-type: none">1. Continuous operation of the COMP2. Continuous operation of the freezer fan3. STEPPING DAMPER OPEN4. Defrosting Heater OFF5. Every DISPLAY LED ON | |
| TEST2 | Push the test button once while in TEST MODE 1. | <ol style="list-style-type: none">1. COMP OFF2. Freezer FAN OFF3. STEPPING DAMPER CLOSE4. Defrosting heater ON5. DISPLAY LED shows 222 | Reset if the temperature of the Defrosting sensor is 50°F(10°C) or more. |
| Reset | Push the test button once while in TEST MODE 2. | Reset to the default setting | The compressor will Start after a 7-minute delay. |

8-2PCBFUNCTION

8-2-1PowerCircuit

1.Powerissuppliedtothecontrolboardatpins1and3ofconnector#1.




The secondary part of the TRANSFORMER is composed of the power supply for the display, the BLDC FAN Motor drive (15.5 V), the relay drive (12 Vdc) and the MICOM and IC (5 Vdc).

The voltage for each part is as follows:

| PART | V A1 | CE 2 | CE 1 | CE 4 |
|---------|---------|--------|----------|------|
| VOLTAGE | 115 Vac | 12 Vdc | 15.5 Vdc | 5 V |

VA1 is a part for preventing over voltage and noise. When 385V or higher power is applied, the inside elements are short-circuited and broken, resulting in blowout of the fuse in order to protect the elements of the secondary part of the TRANSFORMER.


8-2-2 Oscillation Circuit



This circuit generates the base clock for calculating time and the synchro clock for transmitting logic elements of the IC1 (MICOM). Be sure to use specific replacement parts, since calculation may be changed. If changed, the OSC1 SPEC will not work.

data from and to the inside of the IC1 may be


8-2-3 Reset Circuit



The RESET circuit allows all the functions to start at the initial conditions by initializing various parts, including the RAM inside the MICOM (IC1) when the power is initially supplied or the power supply to the MICOM is restored after a momentary power failure. For the initial 10ms of power supply, LOW voltage is applied to the MICOM RESET terminal. During a normal operation, 5V is applied to the RESET terminal. (If a malfunction occurs in the RESET IC, the MICOM will not operate.)

8-2-4 Load/Buzzer Drive & Open Door Detection Circuit

1. Load Drive Condition Check




To measure outputs of the control board, check voltages between the pins for the following components:


| Circuit | PinNumber | PinNumber | OutputV oltag |
|---------------|-----------|-----------|---------------|
| Compressor | Con2pin7 | Con1pin1 | 115V AC |
| Condenserfan | Con2pin7 | Con1pin1 | 115V AC |
| Evaporatorfan | Con2pin5 | Con1pin1 | 115V AC |
| Defrostheater | Con2pin3 | Con1pin1 | 115V AC |
| F,R-lamp | Con2pin1 | Con1pin1 | 115V AC |

NOTE: Whenthe door of the freezer/refrigerator is left open for 7 minutes or longer , the lamp of the freezer/refrigerator turns off automatically .

8-2-5 Open Door Circuit (Door Monitor Circuit)




| Condition / Measurement Location | Tone (Ding~Dong~) when the button on the display is pushed. | Alarm for open door (beep-beep-beep) | OFF |
|----------------------------------|---|--------------------------------------|-----|
| IC1() (A) | | | 0V |
| IC1() (B) | | | 0V |



| | |
|-------------------------|--|
| Freezer or Refrigerator | Measurement between pins 4 and 3 at Con5 |
| Both Closed | 0volts |
| One door open | 5volts |

8-2-6T emperatureSensorCircuit

Voltagesuppliedtoeachsensorwilrangebetween0.5volts-22°F(-30°C)and4.5volts122°F(50°C)dependinguponthe temperatureinthe compartments. A measurementof0voltsindicatesashortinthesensorcircuit. A measurementof5 voltsindicatesanopeninthesensorcircuit.



TheupperCIRCUITreadsREFRIGERA TORtemperature,FREEZERT emperature,andDEFROST -SENSORtemperature fordefrostingandtheindoortemperatureforcompensatingforthesurroundingtemperatureintoMICOM. OPENINGorSHORTstateofeachTEMPERA TURESENSORareasfollows:


| SENSOR | CHECKPOINT | NORMAL(-30°C~50°C) | SHORT-CIRCUITED | OPEN |
|--------------------|------------------|--------------------|-----------------|------|
| FreezerSensor | POINTV(A) oltage | 0.5V~4.5V | 0V | 5V |
| RefrigeratorSensor | POINTV(B) oltage | | | |
| DefrostingSensor | POINTV(C) oltage | | | |

8-2-7 Motor Damper Circuit

A reversible DC motor is used to open and close the damper .


To open the damper , push test button once.

To close the damper , push test button twice.



8-2-8 Damper Heater


*The damper heater is attached to the baffle and always will be on if the unit is powered on. The damper heater uses 12VDC.




8-2-9 Key Button Input & Display Light On Circuit

LED CHECK MODE: When the COLDER (ADJUST) button in the refrigerator temperature control and the COLDER (ADJUST) button in the freezer temperature control are pushed and held for 1 second or longer, every LED on the display turns on at the same time. When the buttons are released, the previous mode is restored.

Best Model



Better Model



8-5 RESISTANCE SPECIFICATION OF SENSOR

| TEMPERATURE | RESISTANCE OF FREEZER SENSOR | RESISTANCE OF REFRIGERATOR & DEFROST SENSOR |
|------------------|------------------------------|---|
| - 20 °C (-4 °F) | 22.3 KΩ | 77 KΩ |
| - 15 °C (5 °F) | 16.9 KΩ | 60 KΩ |
| - 10 °C (14 °F) | 13.0 KΩ | 47.3 KΩ |
| - 5 °C (23 °F) | 10.1 KΩ | 38.4 KΩ |
| 0 °C (32 °F) | 7.8 KΩ | 30 KΩ |
| + 5 °C (41 °F) | 6.2 KΩ | 24.1 KΩ |
| + 10 °C (50 °F) | 4.9 KΩ | 19.5 KΩ |
| + 15 °C (59 °F) | 3.9 KΩ | 15.9 KΩ |
| + 20 °C (68 °F) | 3.1 KΩ | 13 KΩ |
| + 25 °C (77 °F) | 2.5 KΩ | 11 KΩ |
| + 30 °C (86 °F) | 2.0 KΩ | 8.9 KΩ |
| + 40 °C (104 °F) | 1.4 KΩ | 6.2 KΩ |
| + 50 °C (122 °F) | 0.8 KΩ | 4.3 KΩ |


- The resistance of the SENSOR has a $\pm 5\%$ common difference.
- Measure the resistance of the SENSOR after leaving it for over 3 minutes in the measuring temperature. This delay is necessary due to sensor response speed.

8-6T ROUBLESHOOTING

| COMPLAINT | SYMPTOM | POSSIBLE CAUSES | SOLUTION |
|--|--|--|---|
| Electronic Display not operating correctly | 1. No Display at all | <ol style="list-style-type: none"> 1. Supply voltage not within specifications 2. Open in wiring harness from PWB board 3. Open in door monitor switch circuit | <ol style="list-style-type: none"> 1. Check supply voltage to refrigerator 2. Check wiring and connectors to PWB board 3. Check door monitor circuit |
| | 2. Partial or abnormal display | <ol style="list-style-type: none"> 1. Supply voltage not within specifications 2. Open in wiring harness from PWB board | <ol style="list-style-type: none"> 1. Check supply voltage to refrigerator 2. Check wiring and connectors to and from PWB board |
| Not Cooling | <ol style="list-style-type: none"> 1. Display on but compressor not operating | <ol style="list-style-type: none"> 1. Compressor not operating 2. Open in compressor circuit | <ol style="list-style-type: none"> 1. Check for compressor operation by using the test key on main circuit board 2. Check for open on OLP, PTC, compressor, wiring, etc. |
| Not cold enough | <ol style="list-style-type: none"> 2. Display on compressor is operating | <ol style="list-style-type: none"> 1. Condenser fan motor not operating 2. Condenser coils blocked 3. Evaporator fan motor not operating 4. Damper not opening or internal air flow blocked 5. Sensor not operating properly 6. Door not sealing 7. Evaporator Frosted up 8. Sealed System related problem | <ol style="list-style-type: none"> 1. Check condenser fan motor and wiring circuit 2. Check air flow across condenser 3. Check evaporator fan motor and wiring circuit 4. Check damper motor circuit 5. Check refrigerator and freezer sensors 6. Check for proper door seal 7. Check defrost circuit components |
| | | Not defrosting | <ol style="list-style-type: none"> 1. Frosted up in Freezer |

8-5MAINPWBASSEMBLYANDPARTSLIST

8-5-1MainPWBAsembly



8-5-2 Replacement Parts List

| No | P/NO | DESCRIPTION | SPEC | MAKER | REMARK |
|----|-------------|--------------------------------|---|------------|-------------------------|
| 1 | 6870JB8078E | PWB(PCB) | H2K-PJT BEST MDL | DOO SAN | T=1.6 |
| 2 | 6170JB2002S | TRANSFORMER,LOW VOLTAGE | 117V 15V YES -- | TAE SUNG | TRANS |
| 3 | 6170JB2002T | TRANSFORMER,LOW VOLTAGE | 140V 15V YES - | TAE SUNG | TRANS |
| 4 | 6630AQ9106A | CONNECTOR (CIRC),WAFER | YW396-03AV | YEON HO | CON1 |
| 5 | 6630VM02707 | CONNECTOR (CIRC),WAFER | YW396 YEONHO 7P 3.96MM YW396-07 AV < 7P -2,4,6> | YEON HO | CON2 |
| 6 | 6630JB8007E | CONNECTOR (CIRC),WAFER | 917784-1 AMP 6P 2.5MM STRAIGHT SN | AMP | CON3 |
| 7 | 6630JB8007K | CONNECTOR (CIRC),WAFER | 917786-1 AMP 11P 2.5MM STRAIGHT SN | AMP | CON4 |
| 8 | 6630JB8007J | CONNECTOR (CIRC),WAFER | 917786-1 AMP 10P 2.5MM STRAIGHT SN | AMP | CON5 |
| 84 | 6630JB8007C | CONNECTOR (CIRC),WAFER | 917782-1 AMP 4P 2.5MM STRAIGHT SN | AMP | CON6 |
| 9 | 01ZZJB2023G | IC,DRAWING | TMP87C846N 42PIN SDIP BK H2K-BEST [MASK] | TOSHIBA | IC1<=01ZZJB2023H> |
| 10 | 01ZZJB2023J | IC,DRAWING | TMP87C846N 42PIN SDIP BK H2K-BETTER [MASK] | TOSHIBA | IC1<=01ZZJB2023K> |
| 11 | 01TD777400A | IC,TOSHIBA | TA7774AP 16 | TOSHIBA | IC8 |
| 12 | 01KE781200B | IC,KEC | KIA7812PI 12V 1A,KEC - - - - | KEC | IC2 |
| 13 | 01KE781200M | IC,KEC | KIA7812PI 3DIP BK 12V 1A REFOR | KEC | |
| 14 | 01KE780500A | IC,KEC | KIA78050P,3PIN,DIP. KEC | KEC | IC3 |
| 15 | 01STLM1001A | IC,STANDARD LOGIC | M54563FP MITSUBISHI 20 R/TP CONVERT | mitsubishi | IC6 |
| 16 | 01KE650030C | IC,KEC | KID65003AF 16SDP BK 7CH DRIVER | KEC | IC4 |
| 17 | 01KE650830B | IC,KEC | KID65083AF FLP-20 BK 7CH DRIVER | KEC | IC7 |
| 18 | 01KE704200A | IC,KEC | KIA7042P 3P BK RESET | KEC | IC5 |
| 19 | 6920000001A | RELAY | ALE15B12 MATSUSHITA 12V 16A 15.6V 1A | NAIS | RY2 |
| 20 | 6920JB2007A | RELAY | VSB-12TB TAKAMISAWA DC12V 60MA 250V 1C | FUJITSU | RY1 |
| 21 | 6920JB2003A | RELAY | G5N-1A OMRON(JAPAN) 12V 16.7MA - - | OMRON | RY3,RY4 |
| 22 | 6920JB2003A | RELAY | G5N-1A OMRON(JAPAN) 12V 16.7MA - - | OMRON | - |
| 23 | 6920JB2009A | RELAY | G5S-1 OMRON 12V 5A 277V 1C | OMRON | RY5 |
| 24 | 6212W5M002A | RESONATOR,CERAMIC | CST50400 MURATA 4MHZ +/- 0.5% 15PF TP NONE | MURATA | OSC1<J570-00012B> |
| 25 | 6102JB8001B | VARIATOR | INR14D621 ILJIN UL/VDE BK 620V | IL JIN | VA1 |
| 26 | 6102W5V006A | VARIATOR | INR14D331K ILJIN UL/CSA/VDE BK | IL JIN | VA1 |
| 27 | 0DD400709AA | DIODE,RECTIFIERS | 1N4007 TP MOTOROLA - - 1A - - - | DELTA | D1~5 |
| 28 | 0DD400409AC | DIODE,RECTIFIERS | RECTIN4004 TP | DELTA | D6,D7 |
| 29 | OCE22B6J610 | CAPACITOR,AL.ELECTROLYTIC | 2200 UF SMS,SG 35V M FL BULK | SAM HWA | CE1 |
| 30 | OCE1086J610 | CAPACITOR,FIXED ELECTROLYTIC | 1000UF SMS,SG 35V 20% FL BULK | SAM HWA | - |
| 31 | OCE1086H618 | CAPACITOR,AL.ELECTROLYTIC | 1000 UF SMS,SG 25V M FL TP 5 | SAM HWA | CE2 |
| 32 | OCE4776H618 | CAPACITOR,FIXED ELECTROLYTIC | 4700UF SMS,SG 25V 20% FL TP 5 | SAM HWA | CE3 |
| 33 | OCE4766H618 | CAPACITOR,FIXED ELECTROLYTIC | 47UF SMS,SG 25V 20% FL TP 5 | SAM HWA | CE5 |
| 34 | OCE2276F638 | CAPACITOR,FIXED ELECTROLYTIC | 220UF SMS,SG 16V 20% FMS TP 5 | SAM HWA | CE4 |
| 35 | OCE1076H638 | CAPACITOR,FIXED ELECTROLYTIC | 10UF SMS,SG 50V 20% FMS TP 5 | SAM HWA | CE6-CE9 |
| 36 | OCE1051K638 | CAPACITOR,FIXED ELECTROLYTIC | 1UF SMS,SG 50V 20% FMS TP 5 | SAM HWA | CE10 |
| 37 | 6908JB3002A | BUZZER | BM-20K BUJEON PIEZO 2KHZ 80DB | BUJEON | BUZZER |
| 38 | OCQ223IN409 | CAPACITOR,POLYESTER | 0.022 UF D 100V J PE TP | SAM HWA | - |
| 39 | OCK102DK96A | CAPACITOR,FIXED CERAMIC(HIGH | 1NF 2012 50V 80%,-20% R/TP X7R | SAM HWA | CC6 |
| 40 | OCK223DK96A | CAPACITOR,FIXED CERAMIC(HIGH | 22NF 2012 50V 80%,-20% R/TP X7R | SAM HWA | CC1~4,7~11 |
| 41 | OCK223DK96A | CAPACITOR,FIXED CERAMIC(HIGH | 22NF 2012 50V 80%,-20% R/TP X7R | SAM HWA | - |
| 42 | OCK104DK94A | CAPACITOR,FIXED CERAMIC(HIGH | 100NF 2012 50V 80%,-20% R/TP F(Y5V) | SAM HWA | CC5 |
| 43 | OCK104DK94A | CAPACITOR,FIXED CERAMIC(HIGH | 100NF 2012 50V 80%,-20% R/TP F(Y5V) | SAM HWA | - |
| 44 | OCK104DK949 | CAPACITOR,FIXED CERAMIC(HIGH | 0.1UF D 50V 80%,-20% F(Y5V) TA52 | SAM HWA | - |
| 45 | ORD2700H609 | RESISTOR,FIXED CARBON FILM | 270 OHM 1/2 W 5.00% TA52 | SMART | R7~R14 |
| 46 | ORD1002G609 | RESISTOR,FIXED CARBON FILM | 10K OHM 1/4 W 5.00% TA52 | SMART | RCR1,R24,R25 |
| 47 | ORD1000H609 | RESISTOR,FIXED CARBON FILM | 100 OHM 1/2 W 5.00% TA52 | SMART | - |
| 48 | ORJ2200E672 | RESISTOR,METAL GLAZED(CHIP) | 220 OHM 1/8 W 5% 2012 R/TP | ROHM | R1 |
| 49 | ORJ1001E672 | RESISTOR,METAL GLAZED(CHIP) | 1K OHM 1/8 W 5% 2012 R/TP | ROHM | R2 |
| 50 | ORJ2001E672 | RESISTOR,METAL GLAZED(CHIP) | 2K OHM 1/8 W 5% 2012 R/TP | ROHM | R18 |
| 51 | ORD2001G609 | RESISTOR,FIXED CARBON FILM | 2K OHM 1/4 W 5.00% TA52 | SMART | R19~23,18 |
| 52 | ORD2702G609 | RESISTOR,FIXED CARBON FILM | 27K OHM 1/4 W 5.00% TA52 | SMART | R17 |
| 53 | ORH4701L622 | RESISTOR,METAL GLAZED(CHIP) | 4.7K OHM 1/8 W 5% 2012 R/TP | ROHM | R6,R16 |
| 54 | ORJ4702E672 | RESISTOR,METAL GLAZED(CHIP) | 47K OHM 1/8 W 5% 2012 R/TP | ROHM | R15 |
| 55 | ORD4701G609 | RESISTOR,FIXED CARBON FILM | 4.7K OHM 1/4 W 5.00% TA52 | SMART | R3 |
| 56 | ORJ1002E672 | RESISTOR,METAL GLAZED(CHIP) | 10K OHM 1/8 W 5% 2012 R/TP | ROHM | R5,R26 |
| 57 | ORJ1000E672 | RESISTOR,METAL GLAZED(CHIP) | 100 OHM 1/8 W 5% 2012 R/TP | ROHM | - |
| 58 | ORJ2702E672 | RESISTOR,METAL GLAZED(CHIP) | 27K OHM 1/8 W 5% 2012 R/TP | ROHM | - |
| 59 | ORN1622G409 | RESISTOR,FIXED CARBON FILM | 16.2K OHM 1/8 W 1% 2012 R/TP | ROHM | RF1 |
| 60 | ORJ1004E672 | RESISTOR,METAL GLAZED(CHIP) | 1M OHM 1/8 W 5% 2012 R/TP | ROHM | R4 |
| 61 | ORN1002G409 | RESISTOR,FIXED METAL FILM | 10K OHM 1/4 W 1.00% TA52 | SMART | RR1 |
| 62 | ORN2612G409 | RESISTOR,FIXED CARBON FILM | 26.1K OHM 1/4 W 1.00% TA52 | SMART | RDI |
| 64 | ORJ2612E472 | RESISTOR,METAL GLAZED(CHIP) | 26.1K OHM 1/8 W 1% 2012 R/TP 3 | ROHM | RR1 |
| 63 | 6901JB8001A | FUSE ASSEMBLY | KORE-PJT N/S | SAM JU | - |
| 64 | 3J03565D | FUSE,DRAWING | 9A 250V - - | SAM JU | - |
| 65 | 6500JB3001A | SENSOR | JAMES-TEC RT_SENSOR | JAMES TEC | RT-SNR |
| 66 | OTR106009AC | TRANSISTOR | KRA106M(KRA2206) TP KEC | KEC | - |
| 67 | OTR106009AF | TRANSISTOR | KRC 106M KEC | KEC | - |
| 68 | OTR319809AA | TRANSISTOR | KTC3198-TP-Y (KTC1815)KEC | KEC | Q1 |
| 69 | 6600RRT001Z | SWITCH,TACT | JTP1280A6 JEIL 12V DC 50MA | JEIL | TEST |
| 70 | 6854B50001A | JUMP WIRE | 0.6MM 52MM TP TAPING SN | - | DP1<10MM> |
| 71 | 6854B50001A | JUMP WIRE | 0.6MM 52MM TP TAPING SN | - | DP2<10MM> |
| 72 | 6854B50001A | JUMP WIRE | 0.6MM 52MM TP TAPING SN | - | - |
| 74 | 6854B50001A | JUMP WIRE | 0.6MM 52MM TP TAPING SN | - | J01,05,10,12,13<10MM> |
| 75 | 6854B50001A | JUMP WIRE | 0.6MM 52MM TP TAPING SN | - | JP01<10MM> |
| 77 | 6854B50001A | JUMP WIRE | 0.6MM 52MM TP TAPING SN | - | J08<12.5MM> |
| 78 | 6854B50001A | JUMP WIRE | 0.6MM 52MM TP TAPING SN | - | J02~04,06,07,09,15<8MM> |
| 79 | 4920JB3007A | HEAT SINK | 23.3*17*25 DRIVE IC STR R-S64,65,73 2PIN | - | <IC2> |
| 80 | 1SBF0302418 | SCREW TAP TITE(S),BINDING HEAD | + D3.0 L8.0 MSWR3/FZY | - | - |
| 81 | 9VWF0120000 | SOLDER<ROSIN WIRE> RS0 | D1.20 | HEE SUNG | - |
| 82 | 49111004 | SOLDER,SOLDERING | H63A | - | - |
| 83 | 59333105 | FLUX | SG;0.825-0.830 KOREA F.H-206 | KOKI | - |
| 85 | 6170JB2002U | TRANSFORMER,LOW VOLTAGE | 240V 15V YES -- | TAE SUNG | TRANS |
| 86 | 6170JB2002V | TRANSFORMER,LOW VOLTAGE | 260V 15V YES - | TAE SUNG | TRANS |



REPAIR PARTS LIST

MODELS No.

- 795.73962304
- 795.73969304
- 795.73964304
- 795.73966304
- 795.73963304
- 795.75952402
- 795.75959402
- 795.75954402
- 795.73262304
- 795.73269304
- 795.73264304
- 795.73266304
- 795.73263304
- 795.75252402
- 795.75259402
- 795.75254402

The model number of your refrigerator is found on the serial plate inside.

All repair parts listed are available for immediate purchase or special order when you visit your nearest Sears Service Center, or the Service Department at most Sears stores. To order parts by phone, call the toll free parts number listed to the left.

When requesting service or ordering parts, always provide the following information:

- Product Type •Part Number
- Model Number •Part Description

To call
Toll Free
For Parts:

1-800-366-PART
(1-800-366-7278)

For Service:

1-800-4-MY-HOME
(1-800-469-4663)

Get it fixed, at your home or ours!

Your Home

For repair -in your home- of all major brand appliances, lawn and garden equipment, or heating and cooling systems, no matter who made it, no matter who sold it!

For the replacement parts, accesories and owner's manuals that you need to do-it-yourself.

For Sears professional installation of home appliances and items like garage door openers and water heaters.

1-800-4-MY-HOME® (1-800-469-4663)

Call anytime, day or night (U.S.A. and Canada)

www.sears.com www.sears.ca

Our Home

For repair of carry-in items like vacuums, lawn equipment, and electronics, call or go on-line for the location of your nearest **Sears Parts & Repair Center.**

1-800-488-1222

Call any time, day or night (U.S.A. only)

www.sears.com

To purchase a protection agreement (U.S.A.) maintenance agreement (Canada) on a product serviced by Sears:
1-800-827-6655 (U.S.A.) **1-800-361-6665** (Canada)

Parapedirserviciodereparación domicilio, y para ordenar piezas:
1-888-SU-HOGARSM
(1-888-784-6427)

Au Canada pour service en français:
1-888-LE-FOYERSM
(1-888-533-6937)
www.sears.ca




Sears, Roebuck and Co., Hoffman Estates, IL 60179 U.S.A.

© Registered Trademark / SM Trademark/© Service Mark of Sears, Roebuck and Co.
© Marca Registrada / SM Marca de Fábrica / SM Marca de Servicio de Sears, Roebuck and Co.
© Marque de commerce/© Marque déposée de Sears, Roebuck and Co.

© Sears, Roebuck and Co.

ICE MAKER PARTS



| LOC # | PART NUMBER | DESCRIPTION |
|-------|-------------|--------------------|
| 625A | 4930JA3054A | HOLDER, PIPE |
| 622A | 5210JJ3002A | TUBE, INLET |
| 616E | 5210JJ3003B | TUBE, INJECT |
| 616D | 5210JA3005J | TUBE, PE |
| 623A | 4770JA3001A | BAND (MECH) |
| 619A | 5220JA2009D | VALVE, WATER |
| 600A | 5989JA0002E | ICE MAKER ASSEMBLY |
| 602A | 4930JA3037A | HOLDER BRACKET |
| 262D | 4004JA3002A | CLIP |
| 131A | 5074JJ1007A | BANK, ICE |
| S28 | 3J05696W | SCREW, DRAWING |
| S29 | 1SZZJA3009A | SCREW, DRAWING |
| S30 | 4J00415D | SCREW, DRAWING |
| S31 | 1MTC0402618 | SCREW, MACHINE |

CAUTION: Use the part number to order part, not the location number.

#EV# **CASE PARTS**

PART NUMBER BY MODEL

| LOC # | PART NUMBER BY MODEL | | | | DESCRIPTION |
|-------|--|--|--|--|---------------------------------|
| | 795.75252402 795.75259402 795.75254402 | 795.75952402 795.75959402 795.75954402 | 795.73262304 795.73269304 795.73264304 795.73266304 795.73263304 | 795.73962304 795.73969304 795.73964304 795.73966304 795.73963304 | |
| 104B | 4930JJ3007A | 4930JJ3007A | 4930JJ3007A | 4930JJ3007A | HOLDER,BRACKET |
| 105A | 5251JA3003B | 5251JA3003B | 5251JA3003B | 5251JA3003B | DRAIN ASSEMBLY,PIPE-Z |
| 105F | 5070JJ3002A | 5070JJ3002A | 5070JJ3002A | 5070JJ3002A | SKIRT,LOWER |
| 106A | 4779JA2003A | 4779JA2003A | 4779JA2003A | 4779JA2003A | LEG ASSEMBLY,ADJUST |
| 113A | 4930JJ2008A | 4930JJ2008A | 4930JJ2008A | 4930JJ2008A | HOLDER,BRACKET |
| 113B | 4930JJ2005A | 4930JJ2005A | 4930JJ2005A | 4930JJ2005A | HOLDER,GASKET |
| 113C | 4970JA3016A | 4970JA3016A | 4970JA3016A | 4970JA3016A | SPRING,W |
| 113D | 4986JJ2003A | 4986JJ2003A | 4986JJ2003A | 4986JJ2003A | GASKET,BETTA |
| 120A | 4995JJ1003H | 4995JJ1003H | 4995JJ1003C | 4995JJ1003G | CONTROL BOX ASSEMBLY,R |
| 120B | 4994JJ0001A | 4994JJ0002A | 4994JJ0001A | 4994JJ0002A | CONTROL BOX,R |
| 145A | 4930JJ2003A | 4930JJ2003A | 4930JJ2003A | 4930JJ2003A | HOLDER,SHELF |
| 145B | 4930JJ2004A | 4930JJ2004A | 4930JJ2004A | 4930JJ2004A | HOLDER,SHELF |
| 158A | 3550JJ2019B | 3550JJ2019B | 3550JJ2019B | 3550JJ2019B | COVER,LAMP |
| 158C | 3550JJ2019A | 3550JJ2019A | 3550JJ2019A | 3550JJ2019A | COVER,LAMP |
| 175A | N/A | N/A | 3391JJ2005A | 3391JJ2005A | TRAY ASSEMBLY,PIZZA |
| 281B | 4775JJ2003B | 4775JJ2003B | 4775JJ2003B | 4775JJ2003B | HINGE ASSEMBLY,U |
| 282B | 4775JJ2002A | 4775JJ2002A | 4775JJ2002A | 4775JJ2002A | HINGE ASSEMBLY,C |
| 282C | 1PZZJJ3002F | 1PZZJJ3002F | 1PZZJJ3002F | 1PZZJJ3002F | PIN,DRAWING |
| 301A | 5421JJ0002A | 5421JJ0003A | 5421JJ0002A | 5421JJ0003A | EVAPORATOR ASSEMBLY |
| 304A | 3551JJ2008B | 3551JJ2008B | 3551JJ2008B | 3551JJ2008B | COVER ASSEMBLY,BACK-M/C |
| 305B | 4580JJ3001A | 4580JJ3001A | 4580JJ3001A | 4580JJ3001A | ROLLER |
| 305B | 4580JJ3001A | 4580JJ3001A | 4580JJ3001A | 4580JJ3001A | ROLLER |
| 305C | 4J04238A | 4J04238A | 4J04238A | 4J04238A | PIN,DRAWING |
| 305C | 4J04238A | 4J04238A | 4J04238A | 4J04238A | PIN,DRAWING |
| 307A | 2521JJ8004A | 2521JJ8004A | 2521JJ8004A | 2521JJ8004A | COMPRESSOR,SET ASSEMBLY |
| 308A | 6748JJ8002A | 6748JJ8002A | 6748JJ8002A | 6748JJ8002A | P.T.C ASSEMBLY |
| 309A | 6750JJ8002A | 6750JJ8002A | 6750JJ8002A | 6750JJ8002A | O.L.P |
| 310A | 3550JJ8003A | 3550JJ8003A | 3550JJ8003A | 3550JJ8003A | COVER,P.T.C |
| 312A | 5040JA3067A | 5040JA3067A | 5040JA3067A | 5040JA3067A | RUBBER,SEAT |
| 314A | 4620JA3009A | 4620JA3009A | 4620JA3009A | 4620JA3009A | STOPPER,COMP |
| 315A | 3103JJ1001K | 3103JJ1001K | 3103JJ1001J | 3103JJ1001K | COMP BASE ASSEMBLY,STD |
| 317A | 5851JJ2002B | 5851JJ2002B | 5851JJ2002B | 5851JJ2002B | DRIER ASSEMBLY |
| 318A | 4930JJ3002A | 4930JJ3002A | 4930JJ3002A | 4930JJ3002A | HOLDER,DRIER |
| 319A | 3390JJ0003A | 3390JJ0003A | 3390JJ0003A | 3390JJ0003A | TRAY,DRIP |
| 319C | 4974JJ1009A | 4974JJ1009A | 4974JJ1009A | 4974JJ1009A | GUIDE,FAN |
| 323B | 5403JJ1003A | 5403JJ1003A | 5403JJ1003A | 5403JJ1003A | CONDENSER ASSEMBLY,WIRE |
| 327A | 5006JA3034A | 5006JA3034A | 5006JA3034A | 5006JA3034A | CAP,RAIN PIPE |
| 328A | 4J04328A | 4J04328A | 4J04328A | 4J04328A | RUBBER,DAMPING |
| 328A | 4J04328A | 4J04328A | 4J04328A | 4J04328A | RUBBER,DAMPING |
| 328B | 4J03020A | 4J03020A | 4J03020A | 4J03020A | RUBBER,DAMPING |
| 329C | 5901JJ1004B | 5901JJ1004B | 5901JJ1004B | 5901JJ1004B | FAN ASSEMBLY |
| 401A | 4781JK2001A | 4781JK2001A | 4781JK2001A | 4781JK2001A | CONTROLLER ASSEMBLY |
| 409B | 6912JK2002A | 6912JK2002A | 6912JK2002A | 6912JK2002A | LAMP,[INCANDESCENT] |
| 410G | 0CZZJB2003H | 0CZZJB2003H | 0CZZJB2003H | 0CZZJB2003H | CAPACITOR,DRAWING |
| 411A | 6411JK1006A | 6411JK1006A | 6411JK1006A | 6411JK1006A | POWER CORD ASSEMBLY |
| 418A | 5300JK1003D | 5300JK1003D | 5300JK1003J | 5300JK1003D | HEATER,SHEATH |
| 420A | 4680JK1001B | 4680JK1001B | 4680JK1001B | 4680JK1001B | MOTOR,(MECH),COOLING |
| 501A | 6871JB1185B | 6871JB1185B | 6871JB1185A | 6871JB1185A | PWB(PCB) ASSEMBLY,MAIN |
| 501F | 3550JJ2016A | 3550JJ2016A | 3550JJ2016A | 3550JJ2016A | COVER,PWB |
| 503B | 6871JB2044A | 6871JB2044A | 6871JB2043A | 6871JB2043A | PWB(PCB) ASSEMBLY,DISPLAY |
| 503C | 6871JB2044B | 6871JB2044B | 6871JB2043B | 6871JB2043B | PWB(PCB) ASSEMBLY,DISPLAY |
| 503D | 3110JJ2002A | 3110JJ2002A | 3110JJ2001A | 3110JJ2001A | CASE,DISPLAY |
| 610A | 3550JL2004A | 3550JL2004A | 3550JL2004A | 3550JL2004A | COVER,SENSOR |
| 612A | N/A | N/A | 4974JJ2006A | 4974JJ2006A | GUIDE,RAIL |
| 619B | 3550JJ2024A | 3550JJ2024A | 3550JJ2024A | 3550JJ2024A | COVER,VALVE |
| 903B | 4930JJ2021A | 4930JJ2021A | 4930JJ2021A | 4930JJ2021A | HOLDER,COVER LOWER |
| 903D | 6500JK1003A | 6500JK1003A | 6500JK1003A | 6500JK1003A | SENSOR |
| 903E | 6500JK1004A | 6500JK1004A | 6500JK1004A | 6500JK1004A | SENSOR |
| B01 | J351-00004L | J351-00004L | J351-00004L | J351-00004L | SCREW,DRAWING |
| B02 | J351-00004R | J351-00004R | J351-00004R | J351-00004R | SCREW,DRAWING |
| B03 | 1BZZJA2002A | 1BZZJA2002A | 1BZZJA2002A | 1BZZJA2002A | BOLT,DRAWING |
| B04 | 1BZZJA2002A | 1BZZJA2002A | 1BZZJA2002A | 1BZZJA2002A | BOLT,DRAWING |
| S01 | 4J00415D | 4J00415D | 4J00415D | 4J00415D | SCREW,DRAWING |
| S02 | 4J00415D | 4J00415D | 4J00415D | 4J00415D | SCREW,DRAWING |
| S04 | 4J00415D | 4J00415D | 4J00415D | 4J00415D | SCREW,DRAWING |
| S05 | 4J00415D | 4J00415D | 4J00415D | 4J00415D | SCREW,DRAWING |
| S06 | 4J00415D | 4J00415D | 4J00415D | 4J00415D | SCREW,DRAWING |
| S07 | 1SAAC-0002A | 1SAAC-0002A | 1SAAC-0002A | 1SAAC-0002A | SCREW,DRAWING |
| S08 | 1SZZJJ3017A | 1SZZJJ3017A | 1SZZJJ3017A | 1SZZJJ3017A | SCREW,DRAWING |
| S09 | 1SZZJA3016A | 1SZZJA3016A | 1SZZJA3016A | 1SZZJA3016A | SCREW,DRAWING |
| S10 | 4J00415D | 4J00415D | 4J00415D | 4J00415D | SCREW,DRAWING |
| S13 | 1SZZJJ3010A | 1SZZJJ3010A | 1SZZJJ3010A | 1SZZJJ3010A | SCREW,DRAWING |
| S14 | 3J05696W | 3J05696W | 3J05696W | 3J05696W | SCREW,DRAWING |
| S15 | 4J00415D | 4J00415D | 4J00415D | 4J00415D | SCREW,DRAWING |
| S16 | 4J01424D | 4J01424D | 4J01424D | 4J01424D | SCREW,DRAWING |
| S17 | 4J00415D | 4J00415D | 4J00415D | 4J00415D | SCREW,DRAWING |
| S18 | 1TCL0302818 | 1TCL0302818 | 1TCL0302818 | 1TCL0302818 | SCREW,TAPPING,COUNTER SUNK HEAD |
| S38 | 1BZZJA2002A | 1BZZJA2002A | 1BZZJA2002A | 1BZZJA2002A | SCREW,DRAWING |


| LOC # | PART NUMBER | MODEL(S) | 795.75259402 | 795.75252402 | 795.75254402 | 795.75959402 | 795.75952402 | 795.75954402 | 795.73266304 | 795.73263304 | 795.73269304 | 795.73262304 | 795.73264304 | 795.73966304 | 795.73963304 | 795.73969304 | 795.73964304 | 795.73966304 |
|-------|-------------|----------|--------------|--------------|--------------|--------------|--------------|--------------|--------------|--------------|--------------|--------------|--------------|--------------|--------------|--------------|--------------|--------------|
| 103A | 3650JJ2003 | L | A | F | L | E | F | L | M | L | E | F | L | M | L | E | F | L |
| 103B | 3650JJ2003 | M | A | B | M | A | B | M | M | M | A | B | M | M | M | A | B | M |
| 103C | 3551JJ1015 | F | B | D | E | A | C | F | F | F | B | D | F | F | F | A | C | F |
| 281A | 3550JJ2013 | C | A | B | C | A | B | C | C | C | A | B | C | C | C | A | B | C |
| 282E | 5006JJ2001 | F | A | E | F | A | E | F | F | F | A | E | F | F | F | A | E | F |
| 282H | 5006JJ3004 | E | A | A | E | A | A | E | E | E | A | A | E | E | E | A | A | E |
| 283B | 4775JJ2013 | B | B | B | B | B | B | B | B | B | B | B | B | B | B | B | B | B |
| 406B | 6600JB2004 | B | A | A | B | A | A | B | B | B | A | A | B | B | B | A | A | B |
| 903A | 3550JJ0006 | C | A | B | C | A | B | C | C | C | A | B | C | C | C | A | B | C |
| 903A | 3550JJ0005 | | | | | | | | | | | | | | | | | |

CAUTION: Use the part number to order part, not the location number.

TO FIND OUT YOUR MODEL PART NUMBER, YOU MUST TO SELECT THE PART NUMBER AND CHOOSE THE LETTER THAT IS ALIGNED WITH THE MODEL THAT CORRESPOND TO YOUR REFRIGERATOR

FREEZER PARTS

CAUTION: Use the part number to order part, not the location number .



▲: MODEL(S):795.75952402,795.75959402,795.75954402,795.75252402,795.75259402,795.75254402
 ☆: MODEL(S): 795.73962304, 795.73969304, 795.73964304, 795.73966304, 795.73963304, 795.73262304, 795.73269304, 795.73264304, 795.73266304, 795.73263304


PART NUMBER BY MODEL

| LOC # | PART NUMBER BY MODEL | | | | DESCRIPTION |
|-------|----------------------|--------------|--------------|--------------|------------------------|
| | 795.75252402 | 795.75952402 | 795.73262304 | 795.73962304 | |
| 116A | 4901JK1001A | 4901JK1001A | 4901JK1001A | 4901JK1001A | DAMPER ASSEMBLY,MOTOR |
| 136A | N/A | N/A | 3390JJ1022A | 3390JJ1022A | TRAY,FREEZER |
| 143A | N/A | N/A | 4620JJ1001A | 4620JJ1001A | STOPPER,SHELF |
| 143B | N/A | N/A | 4974JJ2018A | 4974JJ2018A | GUIDE,STOPPER |
| 149A | 5026JJ1016B | 5026JJ1016A | 5026JJ1018A | 5026JJ1018A | SHELF,F |
| 149B | N/A | N/A | 5026JJ1017A | 5026JJ1017A | SHELF,F |
| 149F | 3806JJ3001B | 3806JJ3001A | N/A | N/A | DECO,SHELF |
| 158E | 3550JJ2017B | 3550JJ2017B | 3550JJ2017B | 3550JJ2017B | COVER,LAMP |
| 284A | 3550JJ2023A | 3550JJ2023A | 3550JJ2023A | 3550JJ2023A | COVER,GRILLE FAN |
| 284C | 5006JA3080A | 5006JA3080A | 5006JA3080A | 5006JA3080A | CAP,SCREW |
| 315B | N/A | N/A | 4580JJ3004A | 4580JJ3004A | ROLLER |
| 329A | 5901JJ1003A | 5901JJ1003A | 5901JJ1003A | 5901JJ1003A | FAN ASSEMBLY |
| 330B | 4998JJ1004A | 4998JJ1004A | 4998JJ1004A | 4998JJ1004A | SHROUD,F |
| 332A | 3531JJ1002B | 3531JJ1002A | 3531JJ1002B | 3531JJ1002B | GRILLE ASSEMBLY,FAN |
| 404A | 4681JB1016J | 4681JB1016J | 4681JB1016J | 4681JB1016J | MOTOR ASSEMBLY,REF FAN |
| 405A | 4810JJ3003A | 4810JJ3003A | 4810JJ3003A | 4810JJ3003A | BRACKET,MOTOR |
| 405C | 5040JA3049A | 5040JA3049A | 5040JA3049A | 5040JA3049A | RUBBER,MOTOR-N |
| 408A | 6621JK2001A | 6621JK2001A | 6621JK2001A | 6621JK2001A | SOCKET ASSEMBLY,LAMP |
| 409A | 6912JK2002D | 6912JK2002D | 6912JK2002D | 6912JK2002D | LAMP [INCANDESCENT] |
| S14 | 3J05696W | 3J05696W | 3J05696W | 3J05696W | SCREW,DRAWING |
| S20 | 4001JA3001A | 4001JA3001A | 4001JA3001A | 4001JA3001A | SCREW ASSEMBLY |
| S21 | 4J00415D | 4J00415D | 4J00415D | 4J00415D | SCREW,DRAWING |
| S22 | 4J01425A | 4J01425A | 4J01425A | 4J01425A | SCREW,DRAWING |

CAUTION: Use the part number to order part, not the location number .

REFRIGERATOR PARTS


CAUTION: Use the part number to order part, not the location number .



* : MODEL(S) : 795.73962304, 795.73969304, 795.73964304, 795.73966304, 795.73963304, 795.73262304, 795.73269304, 795.73264304, 795.73266304, 795.73263304
▲ : MODEL(S) : 795.75952402, 795.75959402, 795.75954402, 795.75252402, 795.75259402, 795.75254402

DOOR PARTS

CAUTION: Use the part number to order part, not the location number.



* : MODEL(S): 795.73962304, 795.73969304, 795.73964304, 795.73966304, 795.73963304, 795.73262304, 795.73269304, 795.73264304, 795.73266304, 795.73263304
▲ : MODEL(S): 795.75952402, 795.75959402, 795.75954402, 795.75252402, 795.75259402, 795.75254402



*'You Can Count on me . . .
to Work Safely.'*