

This Owner's Manual is provided and hosted by [Appliance Factory Parts](#).



LG LRFC22750ST Owner's Manual

[Shop genuine replacement parts for LG LRFC22750ST](#)



[Find Your LG Refrigerator Parts - Select From 834 Models](#)


----- Manual continues below -----



REFRIGERATOR

SERVICE MANUAL

CAUTION
BEFORE SERVICING THE UNIT,
READ THE SAFETY PRECAUTIONS IN THIS MANUAL.



MODELS: LRFC22750TT
LRFC22750SW
LRFC22750ST

CONTENTS

| | |
|--|----|
| Contents | 2 |
| Safety Precautions | 2 |
| Specifications | 3 |
| 2. Parts Identification | 4 |
| 3. Disassembly | 5 |
| Door..... | 5 |
| Door Alignment..... | 6 |
| Fan and Fan Motor..... | 7 |
| Defrost Control Assembly..... | 7 |
| Lamp..... | 7 |
| Control Box Refrigerator..... | 7 |
| Multi Duct..... | 7 |
| 4. Adjustment | 8 |
| Compressor..... | 8 |
| PTC-Starter..... | 8 |
| OLP (Overload Protector)..... | 9 |
| To remove the cover PTC..... | 9 |
| 5. Circuit Diagram | 10 |
| 6. Troubleshooting | 11 |
| Compressor & Electric Components..... | 11 |
| PTC & OLP..... | 12 |
| Other Electrical Components..... | 13 |
| Service Diagnosis Chart..... | 14 |
| Refrigeration Cycle..... | 15 |
| 7. Operation Principle & Repair Method Of Ice Maker | 17 |
| 8. Water Filter | 21 |
| Water Filter Cartridge Replacement..... | 21 |
| Water Dispenser..... | 22 |
| 9. Description Of Function & Circuit Of MICOM | 23 |
| 10. Exploded View & Replacement Parts List | 44 |

SAFETY PRECAUTIONS

Please read the following instructions before servicing your refrigerator.

1. Check the refrigerator for current leakage.
2. To prevent electric shock, unplug before servicing.
3. Always check line voltage and amperage.
4. Use standard electrical components.
5. Don't touch metal products in the freezer with wet hands. This may cause frostbite.
6. Prevent water from spilling onto electric elements or the machine parts.
7. Before tilting the refrigerator, remove all materials from on or in the refrigerator.
8. When servicing the evaporator, wear gloves to prevent injuries from the sharp evaporator fins.
9. Service on the refrigerator should be performed by a qualified technician. Sealed system repair must be performed by a CFC certified technician.


1. SPECIFICATIONS

22 cu. Ft. (22.4 cu. Ft.)

| ITEMS | SPECIFICATIONS |
|---------------------|---|
| DOOR DESIGN | Side Rounded |
| DIMENSIONS | W(836)x D(870)x H(1754) mm W(32.91)x D(34.25)x H(69.06) in |
| NET WEIGHT | 127.5 Kg 281.09 pounds |
| COOLING SYSTEM | Fan Cooling |
| TEMPERATURE CONTROL | Micom Control |
| DEFROSTING SYSTEM | Full Automatic Heater Defrost |
| DOOR FINISH | Embossed Metal, VCM, Stainless |
| HANDLE TYPE | Bar |
| INNER CASE | ABS Resin |
| INSULATION | Polyurethane Foam |

| ITEMS | SPECIFICATIONS | |
|-------------------|--------------------|------------|
| VEGETABLE TRAY | Opaque Drawer Type | |
| COMPRESSOR | PTC Starting Type | |
| EVAPORATOR | Fin Tube Type | |
| CONDENSER | Wire Condenser | |
| REFRIGERANT | R-134a (115 g) | |
| LUBRICATING OIL | ISO10 (220 ml) | |
| DEFROSTING DEVICE | SHEATH HEATER | |
| LAMP | REFRIGERATOR | 60 W (2EA) |
| | FREEZER | 60 W (1EA) |

2. PARTS IDENTIFICATION



- A** Digital Sensor Control*
- B** Refrigerator Light
- C** Shelves
- D** Chef Fresh
- E** Can Dispenser
- F** Optibin Crisper
Keeps fruits and vegetable fresh and crisper
- G** Customcube Icemaker
- H** Ice Bin
- I** Full Width Wire Basket
- J** Wire Durabase

- K** Filter (inside)*
- L** Dairy Bin
- M** Egg Box
- N** Design-A-Door Bins
- O** Freezer Light
- P** Wire Basket

*On some models

3. DISASSEMBLY

3-1 DOOR

► Left Door

- Loosen the cover screw (1).
- Disconnect door switch wire (2).
- Loosen hinge bolts (3).
- Lift off the top hinge (4).
- Place the door on a non-scratching surface with the inside up.

► Right Door

- Loosen the cover screw (1).
- Disconnect door switch wire (2).
- Disconnect wire harness (5).
- Loosen hinge bolts (3).
- Loosen ground screw (6).
- Lift off the top hinge (4).
- Place the door on a non-scratching surface with the inside up.




Figure 1

Door Gasket Removal

1. Remove door frame cover

Starting at top of cover and working down, snap cover out and away from door.




Figure 2

2. Remove gasket bracket clips

There are two clips on each door. Start bracket removal near one of the middle clips.

- 1) Pull gasket back to expose gasket bracket clip and door frame.
- 2) Insert a flat tip screwdriver into seam between gasket bracket and door frame and pry back until clips snaps out.
- 3) Continue prying back along seam until all clips snap out.




Figure 3

3. Remove gasket

Pull gasket free from gasket channel on the three remaining sides of door.




Figure 4

Door Gasket Replacement

1. Insert gasket bracket clips

- 1) Insert gasket bracket edge beneath door frame edge.
- 2) Turn upper gasket bracket spring so that both spring ends are in the door channel.
- 3) Push in clip until you hear it snap securely into place.




Figure 5


- 4) Push in remaining two clips until you hear each snap securely into place.

Note: Make sure that no part of gasket bracket edge protrudes from beneath door frame edge.


2. Insert gasket into channel

1) Snap gasket assembly into the door bracket.

<Inserting the Gasket Assembly into the Bracket Door>




2) Press gasket into channels on the three remaining sides of door.



3. Replace door frame cover


Starting at top of cover and working down, snap cover back into door.



3-2 DOOR ALIGNMENT

If the space between your doors is uneven, follow the instructions below to align the doors:

1. With one hand, lift up the door you want to raise at middle hinge.
2. With other hand, use pliers to insert snap ring as shown.
3. Insert additional snap rings until the doors are aligned.
(Three snap rings are provided with unit.)



3-3 FAN AND FAN MOTOR

1. Remove the freezer shelf. (If your refrigerator has an icemaker, remove the icemaker first)
2. Remove the plastic guide for slides on left side by unscrewing phillips head screws.
3. Remove the grille by removing one screw and pulling the grille forward.
4. Remove the Fan Motor assembly by loosening 2 screws and disassembling the shroud.
5. Pull out the fan and separate the Fan Motor and Bracket.




Figure 11

3-4 DEFROST CONTROL ASSEMBLY

Defrost Control assembly consists of Defrost Sensor and FUSE-M.

The Defrost Sensor works to defrost automatically. It is attached to the metal side of the Evaporator and senses its temperature. At 72°C, it turns the Defrost Heater off.

Fuse-M is a safety device for preventing over-heating of the Heater when defrosting.

1. Pull out the grille assembly. (Figure 12)
2. Separate the connector with the Defrost Control assembly and replace the Defrost Control assembly after cutting the Tie Wrap. (Figure 13)




Figure 12




Figure 13

3-5 LAMP




Figure 14

3-5-1 Refrigerator Compartment Lamp

1. Unplug the power cord from the outlet.
2. Remove refrigerator shelves.
3. Release the hooks on both ends of the lamp shield and pull the shield downward to remove it.
4. Turn the lamp counterclockwise.
5. Assembly is the reverse of disassembly. Replacement bulb must be the same specification as the original (Max. 60 W2EA).




Figure 15

3-5-2 Freezer Compartment Lamp

1. Unplug refrigerator or disconnect power.
2. Reach behind light shield to remove bulb.
3. Replace bulb with a 60-watt appliance bulb.
4. Plug in refrigerator or reconnect power.

3-6 CONTROL BOX-REFRIGERATOR

1. First, remove all shelves in the refrigerator, then remove the Refrigerator control Box by loosening 2 screws.




Figure 16

2. Remove the Refrigerator Control Box by pulling it downward.
3. Disconnect the lead wire on the right position and separate the lamp sockets.

3-7 MULTI DUCT

1. Remove the upper and lower Caps by using a flat screwdriver, and remove 2 screws. (Figure 17)
2. Disconnect the lead wire on the bottom position.




Figure 17

4. ADJUSTMENT

4-1 COMPRESSOR

4-1-1 Role

The compressor intakes low temperature and low pressure gas from the evaporator of the refrigerator and compresses this gas to high-temperature and high-pressure gas. It then delivers the gas to the condenser.

4-1-2 Composition

The compressor includes overload protection. The PTC starter and OLP (overload protector) are attached to the outside of the compressor. Since the compressor is manufactured to tolerances of 1 micron and is hermetically sealed in a dust and moisture-free environment, use extreme caution when repairing it.

4-1-3 Note for Usage

- (1) Be careful not to allow over-voltage and over-current.
- (2) If compressor is dropped or handled carelessly, poor operation and noise may result.
- (3) Use proper electric components appropriate to the Particular Compressor in your product.
- (4) Keep Compressor dry.
If the Compressor gets wet (in the rain or a damp environment) and rust forms in the pin of the Hermetic Terminal, poor operation and contact may result.
- (5) When replacing the Compressor, be careful that dust, humidity, and soldering flux don't contaminate the inside of the compressor. Contamination in the cylinder may cause noise, improper operation or even cause it to lock up.

4-2 PTC-STARTER

4-2-1 Composition of PTC-Starter


- (1) PTC (Positive Temperature Coefficient) is a no-contact semiconductor starting device which uses ceramic material consisting of BaTiO₃.
- (2) The higher the temperature is, the higher the resistance value. These features are used as a starting device for the Motor.

4-2-2 Role of PTC-Starter

- (1) The PTC is attached to the Sealed Compressor and is used for starting the Motor.
- (2) The compressor is a single-phase induction motor. During the starting operation, the PTC allows current flow to both the start winding and main winding.

4-2-3 PTC-Applied Circuit Diagram

● Starting Method for the Motor



4-2-4 Motor Restarting and PTC Cooling

- (1) It requires approximately 5 minutes for the pressure to equalize before the compressor can restart.
- (2) The PTC device generates heat during operation. Therefore, it must be allowed to cool before the compressor can restart.

4-2-5 Relation of PTC-Starter and OLP

- (1) If the compressor attempts to restart before the PTC device is cooled, the PTC device will allow current to flow only to the main winding.
- (2) The OLP will open because of the over current condition. This same process will continue (3 to 5 times) when the compressor attempts to restart until the PTC device has cooled. The correct OLP must be properly attached to prevent damage to the compressor.

Parts may appear physically identical but could have different electrical ratings. Replace parts by part number and model number. Using an incorrect part could result in damage to the product, fire, injury, or possibly death.

4-2-6 Note for Using the PTC-Starter

- (1) Be careful not to allow over-voltage and over-current.
- (2) Do not drop or handle carelessly.
- (3) Keep away from any liquid.
If liquid such as oil or water enters the PTC, PTC materials may fail due to breakdown of their insulating capabilities.
- (4) If the exterior of the PTC is damaged, the resistance value may be altered. This can cause damage to the compressor and result in a no-start or hard-to-start condition.
- (5) Always use the PTC designed for the compressor and make sure it is properly attached to the compressor. Parts may appear physically identical but could have different electrical ratings. Replace parts by part number and model number. Using an incorrect part could result in damage to the product, fire, injury, or possibly death.

4-3 OLP (OVERLOAD PROTECTOR)

4-3-1 Definition of OLP

- (1) OLP (OVERLOAD PROTECTOR) is attached to the Compressor and protects the Motor by opening the circuit to the Motor if the temperature rises and activating the bimetal spring in the OLP.
- (2) When high current flows to the Compressor motor, the Bimetal works by heating the heater inside the OLP, and the OLP protects the Motor by cutting off the current flowing to the Compressor Motor.

4-3-2 Role of the OLP

- (1) The OLP is attached to the Sealed Compressor used for the Refrigerator. It prevents the Motor Coil from being started in the Compressor.
- (2) For normal operation of the OLP, do not turn the Adjust Screw of the OLP in any way.






Figure 18

4-4 TO REMOVE THE COVER PTC



- 1) Remove the Cover Back M/C.
- (2) Disconnect two housing upper side of comp connected in.
- (3) Loosen two screws on comp base.




- (4) Use a L-shaped flap tool to pry off the cover.
- (5) Assembly in reverse order of disassembly.

5. CIRCUIT DIAGRAM



LG Electronics CIRCUIT DIAGRAM




3854JK1007B

BK:BLACK BN:BROWN RD:RED BO:BRIGHT ORANGE YL:YELLOW GN:GREEN BL:BLUE
WH:WHITE PK:PINK GY:GREY PR:PURPLE SB:SKY BLUE

6. TROUBLESHOOTING

6-1 COMPRESSOR AND ELECTRIC COMPONENTS



6-2 PTC AND OLP





Figure 19








Figure 20

6-3 OTHER ELECTRICAL COMPONENTS

▼ Not cooling at all




▼ Poor cooling performance



6-4 SERVICE DIAGNOSIS CHART

| COMPLAINT | POINTS TO BE CHECKED | REMEDY |
|--|---|--|
| No Cooling. | <ul style="list-style-type: none"> • Is the power cord unplugged from the outlet? • Check if the power switch is set to OFF. • Check if the fuse of the power switch is shorted. • Measure the voltage of the power outlet. | <ul style="list-style-type: none"> • Plug into the outlet. • Set the switch to ON. • Replace the fuse. • If the voltage is low, correct the wiring. |
| Cools poorly. | <ul style="list-style-type: none"> • Check if the unit is placed too close to the wall. • Check if the unit is placed too close to the stove, gas cooker, or in direct sunlight. • Is the ambient temperature too high or the room door closed? • Check if food put in the refrigerator is hot. • Did you open the door of the unit too often or check if the door is sealed properly? • Check if the Control is set to Warm position. | <ul style="list-style-type: none"> • Place the unit about 4 inches (10 cm) from the wall. • Place the unit away from these heat sources. • Lower the ambient temperature. • Put in foods after they have cooled down. • Don't open the door too often and close it firmly. • Set the control to Recommended position. |
| Food in the Refrigerator is frozen. | <ul style="list-style-type: none"> • Is food placed in the cooling air outlet? • Check if the control is set to colder position. • Is the ambient temperature below 5°C? | <ul style="list-style-type: none"> • Place foods in the high-temperature section. (front part) • Set the control to Recommended position. • Set the control to Warm position. |
| Condensation or ice forms inside the unit. | <ul style="list-style-type: none"> • Is liquid food sealed? • Check if food put in the refrigerator is hot. • Did you open the door of the unit too often or check if the door is sealed properly? | <ul style="list-style-type: none"> • Seal liquid foods with wrap. • Put in foods after they have cooled down. • Don't open the door too often and close it firmly. |
| Condensation forms in the Exterior Case. | <ul style="list-style-type: none"> • Check if the ambient temperature and humidity of the surrounding air are high. • Is there a gap in the door gasket? | <ul style="list-style-type: none"> • Wipe moisture with a dry cloth. It will disappear in low temperature and humidity. • Fill up the gap. |
| There is abnormal noise. | <ul style="list-style-type: none"> • Is the unit positioned in a firm and even place? • Are any unnecessary objects placed in the back side of the unit? • Check if the Drip Tray is not firmly fixed. • Check if the cover of the compressor enclosure in the lower front side is taken out. | <ul style="list-style-type: none"> • Adjust the Leveling Screw, and position the refrigerator in a firm place. • Remove the objects. • Fix the Drip Tray firmly in the original position. • Place the cover in its original position. |
| Door does not close well. | <ul style="list-style-type: none"> • Check if the door gasket is dirty with an item like juice. • Is the refrigerator level? • Is there too much food in the refrigerator? | <ul style="list-style-type: none"> • Clean the door gasket. • Position in a firm place and level the Leveling Screw. • Make sure food stored in shelves does not prevent the door from closing. |
| Ice and foods smell unpleasant. | <ul style="list-style-type: none"> • Check if the inside of the unit is dirty. • Are foods with a strong odor unwrapped? • The unit smells of plastic. | <ul style="list-style-type: none"> • Clean the inside of the unit. • Wrap foods that have a strong odor. • New products smell of plastic, but this will go away after 1-2 weeks. |

● Other possible problems:




6-5 REFRIGERATION CYCLE

▼ Troubleshooting Chart

| CAUSE | | STATE OF THE UNIT | STATE OF THE EVAPORATOR | TEMPERATURE OF THE COMPRESSOR | REMARKS |
|-----------------------|------------------|---|--|---|---|
| LEAKAGE | PARTIAL LEAKAGE | Freezer compartment and Refrigerator don't cool normally. | Low flowing sound of Refrigerant is heard and frost forms in inlet only. | A little higher than ambient temperature. | <ul style="list-style-type: none"> Refrigerant level is low due to a leak. Normal cooling is possible by restoring the normal amount of refrigerant and repairing the leak. |
| | COMPLETE LEAKAGE | Freezer compartment and Refrigerator don't cool normally. | Flowing sound of refrigerant is not heard and frost isn't formed. | Equal to ambient temperature. | <ul style="list-style-type: none"> No discharging of Refrigerant. Normal cooling is possible by restoring the normal amount of refrigerant and repairing the leak. |
| CLOGGED BY DUST | PARTIAL CLOG | Freezer compartment and Refrigerator don't cool normally. | Flowing sound of refrigerant is heard and frost forms in inlet only. | A little higher than ambient temperature. | <ul style="list-style-type: none"> Normal discharging of the refrigerant. The capillary tube is faulty. |
| | WHOLE CLOG | Freezer compartment and Refrigerator don't cool. | Flowing sound of refrigerant is not heard and frost isn't formed. | Equal to ambient temperature. | <ul style="list-style-type: none"> Normal discharging of the Refrigerant. |
| MOISTURE CLOG | | Cooling operation stops periodically. | Flowing sound of refrigerant is not heard and frost melts. | Lower than ambient temperature. | <ul style="list-style-type: none"> Cooling operation restarts when heating the inlet of the capillary tube. |
| DEFECTIVE COMPRESSION | COMP-RESSION | Freezer and Refrigerator don't cool. | Low flowing sound of refrigerant is heard and frost forms in inlet only. | A little higher than ambient temperature. | <ul style="list-style-type: none"> Low pressure at high side of compressor due to low refrigerant level. |
| | NO COMP-RESSION | No compressing operation. | Flowing sound of refrigerant is not heard and there is no frost. | Equal to ambient temperature. | <ul style="list-style-type: none"> No pressure in the high pressure part of the compressor. |

6-5-1 SEALED SYSTEM DIAGNOSIS




(The equalization test is trying to restart a compressor using a start kit after it has been operating.)


7. OPERATION PRINCIPLE AND REPAIR METHOD OF ICEMAKER

7-1 OPERATION PRINCIPLE

7-1-1 Operation Principle of IceMaker



1. Turning the Icemaker stop switch off (O) stops the ice making function.
2. Setting the Icemaker switch to OFF and then turning it back on will reset the icemaker control.



7-2 ICE MAKER FUNCTIONS

7-2-1 Start Position

1. After POWER OFF or Power Outage, check the EJECTOR's position with MICOM initialization to restart.
2. How to check if it is in place:
 - Check **HIGH/LOW** signals from HALL SENSOR in MICOM PIN.
3. Control Method to check if it is in place:
 - (1) EJECTOR is in place,
 - It is an initialized control, so the mode can be changed to ice making control.
 - (2) EJECTOR isn't in place:
 - A. If EJECTOR is back in place within 2 minutes with the motor on, it is being initialized. If not, go to Step B.
 - B. If EJECTOR is back in place within 18 minutes after the heater turns from ON to OFF, it is being initialized. If not, it is not functioning. Repeat Step B with Heater and Motor off.

7-2-2 Ice Making Mode


1. Ice Making refers to the freezing of supplied water in the ice trays. Complete freezing is assured by measuring the temperature of the Tray with Ice-Making SENSOR.
2. Ice Making starts after completion of the water fill operation.
3. The Ice Making function is completed when the sensor reaches -7°C , 60 to 240 minutes after starting.
4. If the temperature sensor is defective, the ice-making function will be completed in 4 hours.

NOTE : After Icemaker Power is ON, the Icemaker heater will be on for test for 9 sec.

7-2-3 Harvest Mode

1. Harvest (Ice removing) refers to the operation of dropping cubes into the ice bin from the tray when ice-making has completed.
2. Harvest mode:
 - (1) The Heater is ON for 30 seconds, then the motor starts.
 - (2) After performing Step 1 (the Heater is turned OFF), the Ejector will be back in place within 18 minutes. (Hall SENSOR sign = 0V). Ice removal is then complete. Then the Ice Maker cycles to the Fill Mode. The water supply fails to start, it is not functioning. Put the Heater and Motor in the off position. Restart every 2 hours. (Refer to fig.1)






NOTE : If the motor malfunctions and starts before the detect lever rises, MICOM regards the Ice-Removing phase as completed. Water then starts flowing. To prevent this, MICOM doesn't switch to water-supply mode, but restarts the ice-removing mode. If this happens 3 times, the motor is malfunctioning and you should stop the loads (Heater, Motor). Then restart the Ice-Removing mode every 2 hours. (See Step 2 above.)



7-2-4 Fill / Park Position

1. Once a normal harvest mode has been completed, the water solenoid will be activated.
2. The amount of water is adjusted by pressing the Fill Key repeatedly. This changes the time allowed for fill as illustrated in the table below.






<Water supply amount TABLE>

| STAGE | TIME TO SUPPLY | INDICATIONS | REMARKS |
|-------|----------------|---|--|
| 1 | 6 sec. |  | The water amount will vary depending on the water control Switch setting, as well as the water pressure of the connected water line. |
| 2 | 6.5 sec. |  | |
| 3 | 7 sec. |  | |
| 4 | 7.5 sec. |  | |
| 5 | 8 sec. |  | |

7-2-5 Function TEST



1. This is a compulsory operation for TEST, SVC, cleaning, etc. It is operated by pressing and holding the Fill Key for 3 seconds.
2. The test works only in the Ice Making Mode. It cannot be entered from the Harvest or Fill mode. (If there is an ERROR, it can only be checked in the TEST mode.)
3. **Caution!** If the test is performed before water in the Maker is frozen, the Ejector will pass through the water. When the Fill mode begins (Stage 4), unless the water supply has been shut off, added water will overflow into the ice bin. If the control doesn't operate normally in the TEST mode, check and repair as needed.
4. After water is supplied, the normal CYCLE is followed: **ice making** → **Harvest** → **Fill** → **Park Position**.
5. Five seconds after Stage 5 is completed, the Ice Maker returns to MICOM control. The time needed to supply water resets to the pre- test setting.

<Diagnosis TABLE>

| STAGE | ITEMS | INDICATOR | REMARKS |
|-------|--|---|--|
| 1 | HEATER |  | Five seconds after heater starts, heater will go off if temperature recorded by sensor is 10°C or lever is in up position. |
| 2 | MOTOR |  | Five seconds after heater starts, you can confirm that motor is moving. |
| 3 | HALL IC I (detection of position) |  | You can confirm Hall Ic detection of position. |
| 4 | VALVE |  | Two seconds after detection of initial position, you can confirm that valve is on. |
| 5 | HALL IC II (detection of full-filled Ice) |  | You can check whether hall is sensing Full ice condition. (If there is a full-filled error, the fifth LED is not on.) |
| 6 | Reset | Return to Status prior to TEST MODE | Five seconds after fifth stage is completed, the icemaker resets to initial status. |

7-3 DEFECT DIAGNOSIS FUNCTION

7-3-1 ERROR CODES shown on Ice Maker water supply control panel

| NO | DIVISION | INDICATOR | CONTENTS | REMARKS |
|----|-------------------------------|---|--|--|
| 1 | Normal | Mark time to supply | None | Display switch operates properly |
| 2 | Ice-Making Sensor malfunction |  | Open or short-circuited wire | Make sure that the wire on each sensor is connected. |
| 3 | Ice Maker Kit malfunction |  | When ejector blades don't reach park position over 18 minutes after Harvest Mode starts. | Check HALL IC/MOTOR/ HEATER/RELAY |


ERROR indicators in table can be checked only in TEST mode.

8 WATER FILTER

8.1 WATER FILTER CARTRIDGE REPLACEMENT

FILTER (on some models)

It is recommended that you replace the filter when the water filter indicator light turns on or your water dispenser or ice maker decreases noticeably.



After changing the water filter cartridge, reset the water filter status display and indicator light by pressing and holding the **BUTTON** for 3 seconds.

How to change the old cartridge.

1. Turn the shutoff valve off (house valve).*



2. Dispense water from the system to empty the tubing (approximately for 50 seconds).*



3. Remove the old cartridge.

Rotate the knob of the cartridge counter clockwise.



When the cartridge is removed, it will click out of place.



NOTE: There will be water in the cartridge. Some spilling may occur through the hole at rear bottom side of cover. You may use a cup or something like that to prevent spill water drop into food.


Pull out the cartridge.



4. Replace with a new cartridge.


Take the new cartridge out of its packaging and remove protective cover from the o-rings.

With cartridge knob in the vertical position, push the new filter cartridge into the cover until it stops.




If you can't turn the filter from side to side, it isn't inserted. Push it in firmly and twist it into place. You will hear it click into place.

Using its handle, twist the cartridge clockwise about 1/4 turn. You will hear when it clicks into place.



5. Turn the shutoff valve on (house valve).*



NOTE: To purchase replacement water filter cartridges, visit your local appliance dealer or part distributor. You can also visit our website : www.lgappliances.com or call 1-877-714-7481.

6. Flush water out from the system until air gets eliminated and water start to dispense (approximately for 60 seconds).*




**Steps 1,2,5 & 6 only for models with water dispenser.*


8.2 WATER DISPENSER(On some models)

WATER DISPENSER

2. Tilt up the front of tray slightly and snap the ribs into the holes to replace the tray.



1. Push up the dispenser switch with a cup until you hear click to get cold water.
Tray can be easily removed by pressing and pulling it.




Important: If no water dispensed when the refrigerator is first installed, there may be air in the water line system. Press the dispenser switch for at least two minutes to remove trapped air from the water line and to fill the water system.

9. DESCRIPTION OF FUNCTION & CIRCUIT OF MICOM

9-1 FUNCTION

9-1-1 Function

1. When the appliance is plugged in, it is set to 37°F for Refrigerator and 0°F for freezer.
You can adjust the Refrigerator and the Freezer control temperature by pressing the ADJUST button.
2. When the power is initially applied or restored after a power failure, it is automatically set to "37" & "0".



Control range : 32°F ~ 47°F
0°C ~ 8°C

Control range : -6°F ~ 8°F
-21°C ~ -13°C

9-1-2 How to Toggle the Display between °F & °C

1. The display temperature mode can be changed from °F to °C or °C to °F by pressing and holding the COLDER FREEZER TEMP and the COLDER REFRIGERATOR TEMP keys at the same time for over one second.
2. The initial setting is °F. Whenever the mode is changed, the LED lights are changed.

9-1-3 Control of freezer fan motor

1. Freezer fan motor has high and standard RPMs.
2. High RPM is used when electricity is first on, for express freezing, and when refrigerator is overloaded.
Standard RPM is used for normal usage.
3. Fan motor stops when refrigerator or freezer door opens.

9-1-4 EXPRESS FREEZING


1. The purpose of this function is to intensify the cooling speed of freezer and to increase the amount of ice.
2. Whenever selection switch is pressed, selection/release, the LED will turn ON or OFF.
3. If there is a power outage and the refrigerator is powered on again, EXPRESS FREEZING will be canceled.
4. To activate this function you need to press the Express Freezing key and the LED will turn ON. This function will remain activated for 24 hrs. The first three hours the compressor and Freezer Fan will be ON. The next 21 hours the freezer will be controlled at the lowest temperature. After 24 hours or if the Express Freezing key is pressed again, the freezer will return to its previous temperature.
5. During the first 3 hours:
 - (1) Compressor and freezer fan(HIGH RPM) run continuously.
 - (2) If a defrost cycle begins during the first 90 minutes of Express Freezing, the Express Freeze cycle will complete its cycle after defrosting has ended. If the defrost cycle begins when Express Freeze has run for more than 90 minutes, Express Freeze will run for two hours after the defrost is completed.
 - (3) If EXPRESS FREEZING is pressed during defrost, EXPRESS FREEZING LED is on but this function will start seven minutes after defrost is completed and it shall operate for three hours.
 - (4) If EXPRESS FREEZING is selected within seven minutes after compressor has stopped, the compressor (compressor delays seven minutes) shall start after the balance of the delay time.
 - (5) The fan motor in the freezer compartment rotates at high speed during EXPRESS FREEZING.
6. For the rest of 21 hours, the freezer will be controlled at the lowest temperature.

9-1-5. REFRIGERATOR LAMP AUTO OFF

1. To protect the risk of lamp heat, when Refrigerator door opens for 7 min., refrigerator lamp is auto off.

9-1-6 Alarm for Open Door

1. This feature sounds a buzzer when the freezer or refrigerator door is not closed within 1 minute after it is opened.
2. One minute after the door is opened, the buzzer sounds three times each for 1/2 seconds. These tones repeat every 30 seconds.
3. The alarm is cancelled when the freezer or the refrigerator is closed while the buzzer sounds.



9-1-7 Buzzer Sound

When the button on the front Display is pushed, a Ding~ Dong~ sound is produced.

9-1-8 Defrosting (removing frost)

1. Defrosting starts each time the COMPRESSOR running time reaches 7 hours.
2. For initial power on or for restoring power, defrosting starts when the compressor running time reaches 4 hours.
3. Defrosting stops if the sensor temperature reaches 8°C or more. If the sensor doesn't reach 8°C in 2 hours, the defrost mode is malfunctioning.
4. Defrosting won't function if its sensor is defective (wires are cut or short circuited)


9-1-9 Electrical Parts Are Turned On Sequentially

Electrical parts such as COMP, defrosting heater, freezer FAN, etc. are turned on in the following order to prevent noise and parts damage. Several parts are started at the same time at initial power on and are turned off together when TEST is completed.

| OPERATING | | ORDERS | | | | |
|--|---|-----------------------|----------------|-----------------------------|-----------------------|---------------------------|
| Initial power on | Temperature of Defrosting Sensor is 45°C or more (when unit is newly purchased or when moved) | POWER ON | in 0.5 sec → | COMP ON | in 0.5 sec → | Freezer FAN ON |
| | Temperature of defrosting sensor is lower than 45°C (when power cuts, SERVICE) | POWER ON | in 0.5 sec → | Defrosting heater ON | in 10 sec → | Defrost heater OFF |
| | | in 0.5 sec → | COMP ON | in 0.5 sec → | Freezer FAN ON | |
| Reset to normal operation from TEST MODE | | Total load OFF | in 7 min → | COMP ON | in 0.5 sec → | Freezer FAN ON |

9-1-10 Defect Diagnosis Function

1. Automatic diagnosis makes servicing the refrigerator easy.
2. When a defect occurs, the buttons will not operate; but the tones, such as ding, will sound.
3. When the defect CODE removes the sign, it returns to normal operation (RESET).
4. The defect CODE shows on the Refrigerator and Freezer Display.



ERROR CODE on display panel

| NO | ITEM | ERROR CODE | | CONTENTS | REMARKS |
|----|---|--------------------------------|----|--|--|
| | | ① | ② | | |
| 1 | Failure of freezer sensor | Er | FS | Cut or short circuit wire | Inspect Connecting wires on each sensor |
| 2 | Failure of Refrigerator sensor | Er | rS | Cut or short circuit wire | |
| 3 | Failure of defrost sensor | Er | dS | Cut or short circuit wire | |
| 4 | Failure of Room Temperature sensor | When display check mode: Er rt | | Cut or short circuit wire | |
| 5 | Failure of defrost mode | Er | dH | When defrost sensor doesn't reach 8°C within 2 hours after starting defrost. | Snapping of defrost heater or Temperature fuse, pull-out of connector (indicated minimum 2 hours after failure occurs) |
| 6 | Failure of BLDC Fan Motor at Freezing Compartment | Er | FF | If there is no fan motor signal for more than 65sec in operation fan motor | Poor motor, hooking to wires of fan, contact of structures to fan, snapping or short circuit of Lead wires |

Note 1) Room Temperature Sensor is not indicated on the failure indicating part but indicated in checking Display. (When pressing for more than the warmer key of Refrigerator Temp. and the warmer key of Freezer Temp for more than 1 second).

* LED check function: If simultaneously pressing the warmer key of Refrigerator Temp and the warmer key of Freezer Temp for a second, all display LED graphics on. If releasing the button, the LED graphics displays the previous status.

9-1-11 TEST Mode

1. The Test mode allows checking the PCB and the function of the product as well as finding out the defective part in case of an error.
2. The test mode is operated by pressing two buttons at Display panel.
3. While in the test mode, the function control button is not recognized, but the recognition tone (beep~) sounds.
4. After exiting the test mode, be sure to reset by unplugging and then plugging in the appliance.
5. If an error, such as a sensor failure, is detected while in the test mode, the test mode is cleared and the error code is displayed.
6. While an error code is displayed, the test mode will not be activated.

| MODE | MANIPULATION | CONTENTS | REMARKS |
|-------|---|---|---|
| TEST1 | Push Express Freezing Key and COLDER KEY of Freezer Temp. at the Same time for 3 seconds. OR Push TEST S/W (on the main Board) Once. | 1) Continuous operation of the COMPRESSOR and the Freezer fan 2) Stepping DAMPER OPEN 3) Defrosting HEATER OFF 4) DISPLAY LED all ON | |
| TEST2 | Push Express Freezing Key and COLDER KEY of Freezer Temp. at the Same time for 3 seconds. In TEST MODE 1 OR Push TEST S/W Once in TEST MODE 1 | 1) Continuous operation of the COMPRESSOR and the Freezer fan 2) Stepping DAMPER CLOSE 3) Defrosting HEATER OFF 4) DISPLAY LED shows no. 2 | |
| TEST3 | Push Express Freezing Key and COLDER KEY of Freezer Temp. at the Same time for 3 seconds. In TEST MODE 2 OR Push TEST S/W Once in TEST MODE 2 | 1) COMPRESSOR and the Freezer fan OFF 2) Stepping DAMPER CLOSE 3) Defrosting HEATER ON 4) DISPLAY LED shows no. 3 | Reset if the Temperature of the Defrosting sensor is 8°C or more. |
| Reset | Push Express Freezing Key and COLDER KEY of Freezer Temp. at the Same time for 3 seconds. In TEST MODE 3 OR Push TEST S/W Once in TEST MODE 3 | Reset to the previously setting Before TEST MODE | The compressor will Start after a 7-minute Delay. |

* Freezer Fan RPM Variable Check:


In case the freezer fan is in operation when the WARMER KEY in Refrigerator and Freezer Temp. Control are pressed for more than one second at the same time freezer fan RPM changes. (for example if high speed, to normal speed or if normal speed, to high speed for 30 seconds)
After 30 seconds, it turns to its original RPM.

* Demonstration (Display) MODE:

1. To enter this mode, raise either the Refrigerator or Freezer temperature to its highest setting. Then, press that Warmer Key and hold for about 5 seconds.
2. The LED panels will display OFF, to indicate that the Compressor, Circulating Fan, Damper, and Defrost Heater are not operating.
3. The Open Door Alarm and the Lamp Auto-Off feature will work normally and can be demonstrated.
4. To reset to normal operation, press and hold either Warmer Key for about 5 seconds.

9-2 PCB FUNCTION

9-2-1 Power Circuit




The secondary part of the TRANSFORMER is composed of the power supply for the display, the BLDC FAN Motor drive (15.5 V), the relay drive (12 Vdc) and the MICOM and IC (5 Vdc).

The voltage for each part is as follows:

| PART | VA 1 | CE 3 | CE 4 | CE 5 |
|---------|---------|--------|----------|------|
| VOLTAGE | 115 Vac | 12 Vdc | 15.5 Vdc | 5 V |


VA1 is a part for preventing over voltage and noise. When 385V or higher power is applied, the inside elements are short-circuited and broken, resulting in blowout of the fuse in order to protect the elements of the secondary part of the TRANSFORMER.

9-2-2 Oscillation Circuit



This circuit generates the base clock for calculating time and the synchro clock for transmitting data from and to the inside logic elements of the IC1 (MICOM). Be sure to use specified replacement parts, since calculating time by the IC1 may be changed. If changed, the OSC1 SPEC will not work.


9-2-3 Reset Circuit



The RESET circuit allows all the functions to start at the initial conditions by initializing various parts, including the RAM inside the MICOM (IC1) when the power is initially supplied or the power supply to the MICOM is restored after a momentary power failure. For the initial 10ms of power supply, LOW voltage is applied to the MICOM RESET terminal. During a normal operation, 5V is applied to the RESET terminal. (If a malfunction occurs in the RESET IC, the MICOM will not operate.)

9-2-4 Load / Buzzer Drive & Open Door Detection Circuit

1. Load Drive Condition Check




| LOAD TYPE | COMP | DEFROSTING HEATER | LAMP | FRENCH DOOR HEATER 1, 2 / DEW HEATER | VALVE |
|----------------------------|-------|-------------------|-------|--------------------------------------|-------|
| Measurement Location (IC6) | NO.13 | NO.14 | NO.16 | NO.12 | NO.15 |
| Condition | ON | 1V or below | | | |
| | OFF | 12V | | | |

2. Motors driving circuit

2.1 Fan motor driving circuit (freezing compartment fan)

1. This circuit makes standby power 0 by cutting off power supplied to ISs inside of the fan motor in the fan motor OFF.
2. This is a circuit to perform a temporary change of speed for the fan motor and applies DC voltage up to 7.5V ~ 16V to motor.
3. This circuit prevents over-driving the fan motor by cutting off power applied to the fan motor in the lock of fan motor by sensing the operation RPM of the fan motor.




| | Ⓐ part | Ⓑ part | Ⓒ part |
|-----------|------------|--------|--------|
| MOTOR OFF | 2V or less | 0V | 5V |
| MOTOR ON | 13V~15V | 0V | 2V~3V |


2.2 Cooling motor driving circuit (machine room)

1. This circuit makes standby power 0 by cutting off power supplied to ISs inside of the fan motor in the fan motor OFF.
2. This circuit prevents over-driving the fan motor by cutting off power applied to the fan motor in the lock of fan motor by sensing the operation RPM of the fan motor.

| | Ⓐ Part | Ⓑ part |
|-----------|------------|--------|
| MOTOR OFF | 2V or less | 0V |
| MOTOR ON | 13V~15V | 0V |




3. Open Door Detection Circuit Check



| Freezer/ Refrigerator Door | Measurement Location (PIN NO.30 & PIN NO.37) |
|-------------------------------|---|
| Closed | 5 V |
| Open | 0 V |

9-2-5 Temperature Sensor Circuit




The upper CIRCUIT reads REFRIGERATOR temperature, FREEZER temperature, and DEFROST-SENSOR temperature for defrosting and the indoor temperature for compensating for the surrounding temperature into MICOM. OPENING or SHORT state of each TEMPERATURE SENSOR are as follows:


| SENSOR | CHECK POINT | NORMAL (-30°C ~ 50°C) | SHORT-CIRCUITED | OPEN |
|-------------------------|-------------------|-----------------------|-----------------|------|
| Freezer Sensor | POINT (A) Voltage | 0.5 V ~ 4.5 V | 0 V | 5 V |
| Refrigerator Sensor | POINT (B) Voltage | | | |
| Defrosting Sensor | POINT (C) Voltage | | | |
| Room Temperature sensor | POINT (D) Voltage | | | |

9-2-6 Refrigeration Compartment Stepping Motor Damper Circuit

* The circuit shown below is the damper circuit to regulate the refrigerator temperature.




9-2-7 Dispenser Input



9-2-8 Temperature Compensation & Overcooling/Undercooling Compensation Circuit

1. Refrigerator Temperature Compensation



| Refrigerator | | Remark |
|------------------|--------------------------|---|
| Resistance (RCR) | Temperature Compensation | |
| 180 KΩ | +2.5°C | Compensation by raising the temperature ↑ |
| 56 KΩ | +2.0°C | |
| 33 KΩ | +1.5°C | |
| 18 KΩ | +1.0°C | |
| 12 KΩ | +0.5°C | |
| 10 KΩ | 0 °C | Standard Temperature |
| 8.2 KΩ | -0.5°C | Compensation by lowering the temperature ↓ |
| 5.6 KΩ | -1.0°C | |
| 3.3 KΩ | -1.5°C | |
| 2 KΩ | -2.0°C | |
| 470 Ω | -2.5°C | |

▶ Table of Temperature Compensation by adjusting the resistance (difference from the current temperature) e.g., If the refrigerator compensation resistance (RCR) is changed from 10K (the current resistance) to 18K (the adjustment resistance), the temperature of the refrigerator rises 33.8°F(+1°C).


2. The temperature compensation for refrigerator compartment is in the following table:

| | Revised resistance / Present resistance | 470Ω | 2kΩ | 3.3kΩ | 5.6kΩ | 8.2kΩ | 10kΩ | 12kΩ | 18kΩ | 33kΩ | 56kΩ | 180kΩ |
|-------|---|--------------------|------------|------------|------------|------------|------------|------------|------------|------------|------------|-----------|
| | | Refrigerator (RCR) | 470Ω | No change | 0.5°C Up | 1°C Up | 1.5°C Up | 2°C Up | 2.5°C Up | 3°C Up | 3.5°C Up | 4°C Up |
| 2kΩ | 0.5°C Down | | No Change | 0.5°C Up | 1°C Up | 1.5°C Up | 2°C Up | 2.5°C Up | 3°C Up | 3.5°C Up | 4°C Up | 4.5°C Up |
| 3.3kΩ | 1°C Down | | 0.5°C Down | No Change | 0.5°C Up | 1°C Up | 1.5°C Up | 2°C Up | 2.5°C Up | 3°C Up | 3.5°C Up | 4°C Up |
| 5.6kΩ | 1.5°C Down | | 1°C Down | 0.5°C Down | No Change | 0.5°C Up | 1°C Up | 1.5°C Up | 2°C Up | 2.5°C Up | 3°C Up | 3.5°C Up |
| 8.2kΩ | 2°C Down | | 1.5°C Down | 1°C Down | 0.5°C Down | No Change | 0.5°C Up | 1°C Up | 1.5°C Up | 2°C Up | 2.5°C Up | 3°C Up |
| 10kΩ | 2.5°C Down | | 2°C Down | 1.5°C Down | 1°C Down | 0.5°C Down | No Change | 0.5°C Up | 1°C Up | 1.5°C Up | 2°C Up | 2.5°C Up |
| 12kΩ | 3°C Down | | 2.5°C Down | 2°C Down | 1.5°C Down | 1°C Down | 0.5°C Down | No Change | 0.5°C Up | 1°C Up | 1.5°C Up | 2°C Up |
| 18kΩ | 3.5°C Down | | 3°C Down | 2.5°C Down | 2°C Down | 1.5°C Down | 1°C Down | 0.5°C Down | No Change | 0.5°C Up | 1°C Up | 1.5°C Up |
| 33kΩ | 4°C Down | | 3.5°C Down | 3°C Down | 2.5°C Down | 2°C Down | 1.5°C Down | 1°C Down | 0.5°C Down | No Change | 0.5°C Up | 1°C Up |
| 56kΩ | 4.5°C Down | | 4°C Down | 3.5°C Down | 3°C Down | 2.5°C Down | 2°C Down | 1.5°C Down | 1°C Down | 0.5°C Down | No Change | 0.5°C Up |
| 180kΩ | 5°C Down | | 4.5°C Down | 4°C Down | 3.5°C Down | 3°C Down | 2.5°C Down | 2°C Down | 1.5°C Down | 1°C Down | 0.5°C Down | No Change |

NOTE: This circuit is designed to input the necessary temperature compensation values into the MICOM. This adjusts the refrigerator temperature, which is different in each model.

9-2-9 Key Button Input & Display Light-On Circuit

The circuit shown above determines whether a function control key on the operation display is pushed. It also turns on the corresponding function indication LED Module SEVEN SEGMENT DISPLAY. The drive type is the scan type.



9-3 RESISTANCE SPECIFICATION OF SENSOR

| TEMPERATURE | RESISTANCE OF FREEZER SENSOR | RESISTANCE OF REFRIGERATOR & DEFROST SENSOR & ROOM SENSOR |
|-------------|------------------------------|---|
| - 20 °C | 22.3 KΩ | 77 KΩ |
| - 15 °C | 16.9 KΩ | 60 KΩ |
| - 10 °C | 13.0 KΩ | 47.3 KΩ |
| - 5 °C | 10.1 KΩ | 38.4 KΩ |
| 0 °C | 7.8 KΩ | 30 KΩ |
| + 5 °C | 6.2 KΩ | 24.1 KΩ |
| + 10 °C | 4.9 KΩ | 19.5 KΩ |
| + 15 °C | 3.9 KΩ | 15.9 KΩ |
| + 20 °C | 3.1 KΩ | 13 KΩ |
| + 25 °C | 2.5 KΩ | 11 KΩ |
| + 30 °C | 2.0 KΩ | 8.9 KΩ |
| + 40 °C | 1.4 KΩ | 6.2 KΩ |
| + 50 °C | 0.8 KΩ | 4.3 KΩ |

- The resistance of the SENSOR has a $\pm 5\%$ common difference.
- Measure the resistance of the SENSOR after leaving it for over 3 minutes in the measuring temperature. This delay is necessary due to sensor response speed.


9-4 TROUBLESHOOTING

| PROBLEM | INDICATED BY | CHECK | CHECKING METHOD | CAUSE | SOLUTION |
|----------------------------------|---|--|---|---|--|
| POWER SOURCE is poor. | 1. The whole DISPLAY LED/SEVEN SEGMENT DISPLAY is off. 2. DISPLAY LED/ SEVEN SEGMENT DISPLAY operates abnormally | 1. FREEZER/ REFRIGERATOR. | Check if FREEZER/ REFRIGERATOR DOOR IS OPEN and check display. | POWER SOURCE is poor. | Check outlet Voltage. |
| | | 2. If LAMP is dim. | Check visually. | Applied voltage error. | Use boosting TRANS. |
| COOLING is poor. | NO COOLING. | 3. The connection of the MAIN PWB CONNECTOR. | Check connection of CONNECTOR. | CONNECTOR connection is poor. | Reconnect CONNECTOR. |
| | | 1. If the COMPRESSOR operate. | USE TEST MODE ¹ (forced COOLING). If less than 7 minutes pass after compressor shuts off, don't press the KEY and wait. | COMPRESSOR locked or blocked. OLP, PTC is poor. COMPRESSOR RELAY is poor. | Replace COMPRESSOR. Replace OLP, PTC. Replace MAIN PWB. |
| FREEZER TEMPERATURE is incorrect | | 2. If refrigerant is leaking. | Measure the amount of frost sticking on EVAPORATOR and the surface temperature of the condenser pipe. | Refrigerant leakage. | Check the connection of the black wire of the MAIN PWB CONNECTOR (CON2). Replace the leaking part and replace any lost refrigerant. |
| | | 1. If FAN MOTOR operates. | USE TEST MODE ¹ (forced COOLING). | FAN MOTOR is poor. | Replace the FAN MOTOR. |
| | | 2. If DEFROSTING is normal. | Check the amount of frost sticking on the EVAPORATOR. | DEFROSTING is poor. | See DEFROSTING is poor. |
| | | 3. If SENSOR is normal. | Check the resistance of the Refrigerator SENSOR. | SENSOR RESISTANCE is poor. | Replace SENSOR. |
| | | 4. Door Line contact. | Check the seal when the door is closed. | Door liner damaged. | Replace door liner. |
| | | | | CONNECTING WIRE is poor. | Refer to 8-2-4. 2 and check |

| PROBLEM | INDICATED BY | CHECK | CHECKING METHOD | CAUSE | SOLUTION |
|---------------------|---|--|--|--|---|
| COOLING is poor. | If REFRIGERATOR TEMPERATURE is too low. | 1. If FREEZER TEMPERATURE is normal. | Check is FREEZER TEMPERATURE is too low. | | Make sure the DOOR is attached. |
| | | 2. If amount of cool air from FAN MOTOR is sufficient. | Make sure that the amount and speed of cool air are sufficient by touching the check supplied on the REFRIGERATOR. | FAN MOTOR is poor. Passage of cool air is blocked. EVA frozen. | Replace FAN MOTOR. Remove impurities. |
| | | 3. Door Line contact. | Check door seal when door is closed. | Door liner damaged. | Replace Door liner. |
| DEFROSTING is poor. | NO DEFROSTING. | 1. If HEATER emits heat. | USE TEST MODE3 (forced DEFROSTING). | HEATER disconnection. | Replace HEATER. |
| | | | | TEMPERATURE FUSE disconnection. | Replace TEMPERATURE FUSE. |
| | | | | Connection is poor. | Check EVAPORATOR connection and wire of MAIN PWB CONNECTOR. |
| | | | | DEFROST-SENSOR is poor. | Replace DEFROST-SENSOR. |
| | | | | HEATER RELAY is poor. | Replace RY2 of MAIN PWB. |
| | | 2. If DRAIN PIPE is blocked. | Check DRAIN PIPE. | DRAIN PIPE is blocked. | Remove ice and impurities. Check HEATER PLATE resistance. |
| | | 3. If ice remains after DEFROSTING. | Make sure that DEFROST SENSOR is connected. Make sure that FREEZER / REFRIGERATOR DOOR is closed. | Connection is poor. DOOR does not close properly. | Reassemble the DEFROST-SENSOR. Reassemble DOOR. Replace GASKET. |

9-5 MAIN PWB ASSEMBLY AND PARTS LIST


9-5-1 Main PWB Assembly



9-5-2 Replacement Parts List

| No | P/N | DESCRIPTION | SPEC | MAKER | REMARK |
|----|--------------|--|--|----------------|------------------------------|
| 1 | 68701R8203A | PWB(PCB) | BEST BRAVO-PJT | DOO SAN | T=1.8 |
| 2 | 61701B2012E | TRANSFORMER(SMPS/COIL) | DL-PJT 2.9MHZ/2W | SAM ILL | TRANS |
| 3 | 61701B2012C | TRANSFORMER(SMPS/COIL) | YH398-074V | YEHN HO | CON2 |
| 4 | 6630A0910G0 | CONNECTOR (CIRC) WAFER | YH398-094V | YEHN HO | CON1 |
| 5 | 6630A0910E0 | CONNECTOR (CIRC) WAFER | YH398-074V | YEHN HO | CON2 |
| 6 | 6630A0910H0 | CONNECTOR (CIRC) WAFER | YH398-054V | YEHN HO | CON3 |
| 7 | 66301B8004E | CONNECTOR (CIRC) WAFER | SMW250 YEHNHO 6P 2.5MM STRAIGHT SN | YEHN HO | CON4 |
| 8 | 66301B8004C | CONNECTOR (CIRC) WAFER | SMW250 YEHNHO 12P 2.5MM STRAIGHT SN | YEHN HO | CON5 |
| 9 | 66301B8004F | CONNECTOR (CIRC) WAFER | SMW250 YEHNHO 4P 2.5MM STRAIGHT SN | YEHN HO | CON6 |
| 10 | 66301B8004D | CONNECTOR (CIRC) WAFER | SMW250 YEHNHO 7P 2.5MM STRAIGHT SN | YEHN HO | CON7 |
| 11 | 01Z2JB2054V | IC DRAWING | TMF87C046N 42P SDIP BK MASK BRAVO33-PJT BEST/BETTER | TOSHIBA | IC1 |
| 12 | 01SK635100A | IC POWER MANAGEMENT | STR-G6351 5PIN BK SMPS 2.4PIN FORM | SANKEN | IC2 |
| 13 | 01PMGNF001A | IC POWER MANAGEMENT | PS2561L 1.1-V NEC 4FDIP BK = TLPT21F | NEC | IC3 |
| 14 | 01KE431000A | IC KEC | K4A31 3 PIN TP - - | KEC | IC4 |
| 15 | 01KE780500Z | IC LINEAR | KIAT805PI SDIP BK 5V 1A REFORM | KEC | IC5 |
| 16 | 01KE650030B | IC KEC | KID65003AP 10P SDIP BK DRIVE IC | KEC | IC6 |
| 17 | 01KE704200A | IC KEC | KIAT042P KFC 3P BK RESET | KEC | IC7 |
| 18 | 01T077400A | IC DRAWING | T17774AP 16 SDIP BK DRIVE IC STEPPING MOTOR | TOSHIBA | IC8 |
| 19 | 6202AL2001B | RELAY | ALZ12B12 4MS 250VAC 16A 12VDC 1A NO VENTING | NIS | RY1 |
| 20 | 69201B2003A | RELAY | CSM 1A OMRON 250VAC 1.6A 12VDC 1A JAPAN | OMRON | RY5,RY6 |
| 21 | 69201B2003F | RELAY | CSMB-1A-E(CHINA) OMRON 250VAC 5A 12VDC 1A NO VENTING | OMRON | RY2-4 |
| 22 | 69201B2009B | RELAY | CS5B 1A OMRON 250VAC 5A 12VDC TC NO VENTING | OMRON | |
| 23 | - | - | - | - | - |
| 24 | 62121B8001B | RESONATOR CERAMIC | CST8040MG03 MURATA 4MHZ TP - | MURATA | OSC1 |
| 25 | 61021B8001B | VANISTOR | NR14D621 ILJIN ULVDE BK 52V | ILJIN | VA1 |
| 26 | 6102W5V007A | VANISTOR | NR14D33TK ILJIN ULCSAVDE BK | ILJIN | VA1 |
| 27 | 0DB350000AA | DIODE RECTIFIERS | D35BA60 BK SHINDENGEN - 600V 4A 80A - 10UA | SHINDENGEN | B01 |
| 28 | 0DD400409AC | DIODE RECTIFIERS | RECT1M4001 TP | DELTA | D7 |
| 29 | 0DR107000AA | DIODE RECTIFIERS | FR107 TP RECTRON D041 1000V 1A 30A 50NSEC 5A | DELTA | D1,D2,D5,D6,D8,D9 |
| 30 | 0DRSA00070A | DIODE RECTIFIERS | RLZ SANKEN BK NON 400V 2A 40A 50NSEC 10UA | SANKEN | D3,D4 |
| 31 | 0CE1058K638 | CAPACITOR FIXED ELECTROLYTIC | 1UF KME RGYX 50V 0.2 FMS TP 5 | SAM WHA | CE10 |
| 32 | 0CE106E638 | CAPACITOR FIXED ELECTROLYTIC | 10UF KMG 50V 20% FMS TP 5 | SAM WHA | CE8,CE9 |
| 33 | 0CE2279F636 | CAPACITOR FIXED ELECTROLYTIC | 220UF KMC TYPE 16V 20% FMS TP 5 | SAM WHA | CE5 |
| 34 | 0CE272B4638 | CAPACITOR FIXED ELECTROLYTIC | 220UF KMF RGV 25V 20% FMS TP 5 | SAM WHA | CE11,CE12 |
| 35 | - | - | - | - | - |
| 36 | 0CE4768K638 | CAPACITOR FIXED ELECTROLYTIC | 47UF KME TYPE 50V 20% FMS TP 5 | SAM WHA | CE2 |
| 37 | 0CE476ZV6F0 | CAPACITOR FIXED ELECTROLYTIC | 47UF HE 450V 20% BULK SNAP IN | SAM WHA | CE1 |
| 38 | 0CE4807H650 | CAPACITOR FIXED ELECTROLYTIC | 680UF R3 250V 20% BULK SNAP IN | SAM WHA | CE3 |
| 39 | 0CE871218 | CAPACITOR FIXED ELECTROLYTIC | 880UF RY 250V 20% BULK | SAM WHA | CE4 |
| 40 | 0CK102DK96A | CAPACITOR FIXED CERAMIC(HIGH DIELECTRIC) | 1NF 2012 50V 80% -20% R1P XTR | MURATA | CC17,CC20 |
| 41 | 0CK104DK949 | CAPACITOR FIXED CERAMIC(High dielectric) | 0.1UF D 50V 80% -20% F1V5V TA52 | SAM WHA | CC3,CC4,CC6,CC7 |
| 42 | 0CK104DK98A | CAPACITOR FIXED CERAMIC(High dielectric) | 0.1UF 2012 50V 80% -20% R1P JE | MURATA | CC5,CC10 |
| 43 | 0CK2210Q2510 | CAPACITOR FIXED CERAMIC(High dielectric) | 220P 2KV K B S | SAM WHA | CC2 |
| 44 | 0CK2230K949 | CAPACITOR FIXED CERAMIC(High dielectric) | 22NF 50V Z F TA52 | SAM WHA | - |
| 45 | 0CK223DK96A | CAPACITOR FIXED CERAMIC(HIGH DIELECTRIC) | 22NF 2012 50V 80% -20% R1P XTR | MURATA | CC8,CC9,CC11-15,CC18 |
| 46 | 0CK4710K519 | CAPACITOR FIXED CERAMIC(High dielectric) | 470PF 50V K B TA52 | SAM WHA | CC1 |
| 47 | 0CQ1041S00 | CAPACITOR FIXED FILM | 0.1UF D 100V 10% PE TP5 | SAM WHA | CM4 |
| 48 | 0CK102DK96A | CAPACITOR FIXED CERAMIC(HIGH DIELECTRIC) | 1NF 2012 50V 80% -20% R1P XTR | MURATA | CC20 |
| 49 | 0CQ473Y430 | CAPACITOR FIXED FILM | 47000PF 5.630V 5% MPPF NI R | SAM WHA | CM3 |
| 50 | 0CQ47418670 | CAPACITOR FIXED FILM | 0.47UF D 275V 20% MPPF NI R | SAM WHA | CM1 |
| 51 | 0LR1001M4F0 | INDUCTOR RADIAL LEAD | 100UH 20% R 6X12.5 BULK | TNC | L3,L4 |
| 52 | 0RD1001G609 | RESISTOR FIXED CARBON FILM | 1K OHM 1/4 W 5% TA52 | SMART | R19 |
| 53 | 0RD1001G609 | RESISTOR FIXED CARBON FILM | 10K OHM 1/4 W 5% TA52 | SMART | R29,R35,R37 |
| 54 | 0RD2001G609 | RESISTOR FIXED CARBON FILM | 2K OHM 1/4 W 5% TA52 | SMART | R17,R20,R21,R22,R26,R27,R36 |
| 55 | 0RD401G609 | RESISTOR FIXED CARBON FILM | 3.9K OHM 1/4 W 5% TA52 | SMART | R34,R41 |
| 56 | 0RD401G609 | RESISTOR FIXED CARBON FILM | 4.7K OHM 1/4 W 5% TA52 | SMART | R18,R33,R40 |
| 57 | 0RD5001G609 | RESISTOR FIXED CARBON FILM | 560K OHM 1/2 W 5% TA52 | SMART | R2 |
| 58 | 0RD2001G609 | RESISTOR FIXED CARBON FILM | 2K OHM 1/4 W 5% TA52 | SMART | R45 |
| 59 | 0RD401G609 | RESISTOR FIXED CARBON FILM | 4.7K OHM 1/4 W 5% TA52 | SMART | R46 |
| 60 | 0RJ2701L622 | RESISTOR METAL GLAZED(CHIP) | 2.7K OHM 1/8 W 5% 2012 R1P | ROHM | R21 |
| 61 | 0RH1001L622 | RESISTOR METAL GLAZED(CHIP) | 10KOHM 1/8 W 5% 2012 R1P | ROHM | R16,R28,R30,R42,R8 |
| 62 | 0RH1004L622 | RESISTOR METAL GLAZED(CHIP) | 1MOHM 1/8 W 5% 2012 R1P | ROHM | R13 |
| 63 | 0RH1001L622 | RESISTOR METAL GLAZED(CHIP) | 1K OHM 1/8 W 5% 2012 5.00% D | ROHM | R7 |
| 64 | 0RH2001L622 | RESISTOR METAL GLAZED(CHIP) | 2K OHM 1/8 W 5% 2012 R1P | ROHM | R23-R25,R36,R39 |
| 65 | 0RH3301L622 | RESISTOR METAL GLAZED(CHIP) | 33K OHM 1/8 W 5% 2012 R1P | ROHM | R31,R43 |
| 66 | 0RH4701L622 | RESISTOR METAL GLAZED(CHIP) | 4.7K OHM 1/8 W 5% 2012 R1P | ROHM | R14,R16,R37 |
| 67 | 0RD1001E672 | RESISTOR METAL GLAZED(CHIP) | 100 OHM 1/8 W 5% 2012 R1P | ROHM | R6 |
| 68 | 0RD1501H609 | RESISTOR FIXED CARBON FILM | 1.5K OHM 1/2 W 5% TA52 | SMART | R32,R44 |
| 69 | 0RJ3000E672 | RESISTOR METAL GLAZED(CHIP) | 0 OHM 1/8 W 5% 2012 R1P | ROHM | R31 |
| 70 | 0RJ2401E472 | RESISTOR METAL GLAZED(CHIP) | 2.4K OHM 1/8 W 1% 2012 R1P | ROHM | RL2 |
| 71 | 0RJ6800E672 | RESISTOR METAL GLAZED(CHIP) | 680 OHM 1/8 W 5% 2012 R1P | ROHM | R6 |
| 72 | 0RD6801G609 | RESISTOR FIXED CARBON FILM | 6.8K OHM 1/4 W 5% TA52 | SMART | R4 |
| 73 | 0RJ401E472 | RESISTOR METAL GLAZED(CHIP) | 4.7K OHM 1/8 W 1% 2012 R1P | ROHM | RL1 |
| 74 | 0RJ1002E472 | RESISTOR FIXED METAL FILM | 10K OHM 1/8 W 1.00% 2012 R1P | ROHM | RT1 |
| 75 | 0RN1622G409 | RESISTOR FIXED METAL FILM | 16.2K OHM 1/4 W 1.00% TA52 | SMART | RF1 |
| 76 | 0RN2612G409 | RESISTOR FIXED METAL FILM | 26.1K OHM 1/4 W 1.00% TA52 | SMART | RF1,RF1 |
| 77 | 0RS0151J609 | RESISTOR FIXED METAL OXIDE FILM | 1.5 OHM 1 W 5.00% TA52 | SMART | ROCOP |
| 78 | 0RS0101J609 | RESISTOR FIXED METAL OXIDE FILM | 1 OHM 1 W 5% TA52 | SMART | ROCOP |
| 79 | 0RS5602K641 | RESISTOR FIXED METAL OXIDE FILM | 56K OHM 2 W 5.00% F90 | SMART | R3 |
| 80 | 0RS3303J609 | RESISTOR FIXED METAL OXIDE FILM | 330K OHM 1 W 5.00% TA52 | SMART | R1 |
| 81 | 0TR319800AA | TRANSISTOR | KTC3198-PY (KTC1815)KEC | KEC | O3,O6 |
| 82 | 0TRKE00008A | TRANSISTOR BIPOLARS | KEC KTB1151 BK TO126 60V 5A | KEC | O2,O4 |
| 83 | 0TRKE80016A | TRANSISTOR BIPOLARS | KEC KRC106S R1P SOT23 50V 100MA | KEC | Q1 |
| 84 | 62001B8004A | FILTER(CIRC)EMC | CV940050 TNC - - | TNC | L1 |
| 85 | 62001B8007X | FILTER(CIRC)EMC | UV11-05370 TNC BK 0.9A 320MH | TNC | L2 |
| 86 | 62101B8001A | FILTER(CIRC)EMC | RF53510A0 SAMWHA TP42 HEAD FILTER | SAM WHA | ER1 |
| 87 | 6800RR1901Z | SWITCH TACT | J1P128048 JEIL 12VDC 50MA - | JEIL | SF1 |
| 88 | 05ZMR00029A | DIODE ZENERS | 1N5222B MOTOROLA TP DC34 0.5W 5.6V 81MA PF | DEL TA | ZD1 |
| 89 | 6854B50001A | JUMP WIRE | 0.6MM 52MM TP TAPING SN | DAE A LEAD | J03,J04,J06-J12,J15(10MM) |
| 90 | 0FZ2JB3001A | FUSE DRAWING | 2A 250V SLOW BLOW LITTELFUSE,TRIAD | SAM JU KYO YUK | J01,J02,J05(12.5MM) FUSE1 |
| 91 | 15BF0302416 | SCREW TAP TITE(S) BINDING HEAD | + D3.0 L8.0 MSWR3FZY | HAENG SUNG | |
| 92 | 49201B3007A | HEAT SINK | 23.3*17*25 DRIVE IC STR R.664.65.73 ZPIN 1 SCREW 3MM - | (IC2) | (IC2) |
| 93 | 49111004 | SOLDER SOLDERING | NA HEEUSUNG METAL BAR SN 63% NA | - | - |
| 94 | 58333105 | FLUX | JS-71 KOCI SANGH KOREA(KSK) SG0 808 +/-0.003 | - | - |
| 95 | 99WF0120000 | SOLDER(ROSN WIRE) R50 | D1.20 | - | - |


9-5-3 PWB Assembly, Display, And Parts List




| QTY | NO | P/NO | DESCRIPTION | SPEC | MAKER | REMARK |
|------|----|---------------------------|------------------------------|--|-----------------|------------------|
| 1 | 1 | 6870B8199A | PWB(PCB) | BVAIO 33 DPLVJ | | |
| 1 | 2 | 6030B8000C | CONNECTOR (CRIC) WAFER | 3MHW25004 | YEON HO | CON01 |
| 1 | 3 | 007.87777 | I.C. DRAWING | IMPACT_00RM 28_SCP28-F-000_BVAIO 33 | YCBWA | IC1 |
| 1 | 4 | 08LM1001A | I.C. BIENWHD LOGIC | M5550FF M5550M 20 5TP CONVERT | MITSUBISHI | IC3 |
| 1 | 5 | 08AN0101E | I.C. EPIC | EPICAN0101EP 140 5TP BR 12K110BND | REC | IC5, IC6 |
| 1 | 6 | 08LM0003A | I.C. STANDARD LOGIC | 80A7005F REC 50040 1P REG-LATED | REC | IC7 |
| 1 | 7 | 08LM0003A | I.C. STANDARD LOGIC | 80A7004F REC 50540 1P REG-ET IC | REC | IC5 |
| 1 | 8 | 08LM0005A | I.C. STANDARD LOGIC | 80C1004S REC 507 23 1P TRANSICD | REC | Q1 |
| 1 | 9 | 6212B83245A | RESISTOR CERAMIC | CR09HW0553-70 MUJWA 4.0M Ω \pm 1 0.5% 1/8 BMD | MURATA | CR01 |
| 1 | 10 | 0CE410W40C | CAPACITOR/FIXED ELECTR | 47UF MV 25V 20% 9TPBMD SMD | SAMSUNG | CE2 |
| 1 | 11 | 0CE107W40C | CAPACITOR/FIXED ELECTR | 100UF MV 16V 20% 9TPBMD SMD | SAMSUNG | CE1 |
| 7 | 12 | 0C1108W40A | CAPACITOR/FIXED CERAMIC | 100NF 2017 50V 80% \pm 20% 9TP H170 | MURATA | CC1,CC7 |
| 2 | 13 | 0C1100W40A | CAPACITOR/FIXED CERAMIC | 100F 2012 50V 80% \pm 20% 9TP X7S | MURATA | CC3,CC4 |
| 1 | 14 | 09A200L422 | RESISTOR METAL GLAZED (CHIP) | 220 OHM 1/8 W 2012 5.00% D | KOHJ | R5 |
| 2 | 15 | 09D100L422 | RESISTOR METAL GLAZED (CHIP) | 1K OHM 1/8 W 5% 2012 9TP | KOHJ | R3, R4 |
| 1 | 16 | 09D200L422 | RESISTOR METAL GLAZED (CHIP) | 2K OHM 1/8 W 5% 2012 9TP | KOHJ | R2 |
| 6 | 17 | 09D400L422 | RESISTOR METAL GLAZED (CHIP) | 4.7K OHM 1/8 W 5% 2012 9TP | KOHJ | R1, R7, R21, R24 |
| 1 | 18 | 09D100W422 | RESISTOR METAL GLAZED (CHIP) | 1M OHM 1/8 W 5% 2012 9TP | KOHJ | R6 |
| 9 | 19 | 09U500W422 | RESISTOR METAL GLAZED (CHIP) | 820 OHM 1/2 W 5% 2012 9TP | KOHJ | R8-R16 |
| 2 | 20 | 09M000L422 | RESISTOR METAL GLAZED (CHIP) | 2K OHM 1/8 W 2012 5.00% D | KOHJ | R17, R19 |
| 2 | 21 | 09M100L422 | RESISTOR METAL GLAZED (CHIP) | 100 OHM 1/2 W 5% 2012 9TP | KOHJ | R15, R20 |
| 1 | 22 | 0C3M001 88A | DIODE 2INERS | 1N4148 1TP (1150) 341 500MAV 5.6V 20MA JF | ROHM | DI01 |
| 5 | 23 | 0C3M000 88A | DIODE 2INERS-BV | 1N5410 30 2044 9TP (1150) 341 75V 450MA 2000MA | ROHM | D108-D112 |
| 1 | 24 | 00041 48099A | DIODE 2INERS-BV | 1N4148 20 2044 | ROHM | |
| 2 | 25 | 6127 80001A | DISPLAY LED ASSEMBLY | 184203-1 184203 GREEN 2 IV 1.7MCD | LEDTECH | SE01, SE02 |
| 4 | 26 | 00UB0098A | LED | 183323-41 8C4 2 IV D3 P GREEN | LEDTECH | L102-L105 |
| 1 | 27 | 00UB0098A | LED | 183323-41 8C4 2 IV D3 P GREEN | LEDTECH | L101, L107 |
| 1 | 28 | 6098 B3000D | Buzzer | B0272203R_00C_2000 SUMMY PRETO 2047 800B 1CH/4M | SUMWAY | B002R |
| 4 | 29 | 6400 B8005A 640090000K | SWITCH PACT | SP1-1105A JPP1230A JEL 12V DC 50MA | KYUNG IN JEL | SW102, SW105 |
| 1 | 30 | 6400 B8004A | SWITCH PACT | SP1-1100S | KYUNG IN | SW106 |
| 2g | 31 | 49111001 | SOLDER SOLDERING | SP1-1109G | KYUNG IN | |
| 3g | 32 | 49111004 | SOLDER SOLDERING | SOLDER (PCOH WIRE) 850 | HUSUNG | |
| 0.5g | 33 | 59333105 | FLUX | H03A | HUSUNG | |
| | | | | SE: 0.825-0.830 KOREA FH-208 | KOKI | |

9-6 PWB DIAGRAM

9-6-1 PWB Main Assembly




TOSHIBA TMP87CH46N(IC1)



10. EXPLODED VIEW & REPLACEMENT PARTS LIST


CASE PARTS

CAUTION: Use the part number to order part, not the position number.




FREEZER PARTS

CAUTION: Use the part number to order part, not the position number.



REFRIGERATOR PARTS


CAUTION: Use the part number to order part, not the position number.



★ : on some models


ICE MAKER PARTS

CAUTION: Use the part number to order part, not the position number.



ICE & WATER PARTS

CAUTION: Use the part number to order part, not the position number.



| LOC | DESCRIPCION | LRFC22750TT | LRFC22750SW | LRFC22750ST |
|------|------------------------|-------------|-------------|-------------|
| 103A | HANDLE,BACK | 3650JJ2003H | 3650JJ2003E | 3650JJ2003L |
| 103B | HANDLE,BACK | 3650JJ2003D | 3650JJ2003A | 3650JJ2003M |
| 103C | COVER ASSEMBLY,LOWER | 3551JJ1015H | 3551JJ1015B | 3551JJ1015F |
| 103E | RAIL,SLIDE | 5218JJ3001A | 5218JJ3001A | 5218JJ3001A |
| 103E | RAIL,SLIDE | 5218JJ3001A | 5218JJ3001A | 5218JJ3001A |
| 103E | RAIL,SLIDE | 5218JJ3001A | 5218JJ3001A | 5218JJ3001A |
| 103E | RAIL,SLIDE | 5218JJ3001A | 5218JJ3001A | 5218JJ3001A |
| 103E | RAIL,SLIDE | 5218JJ3001A | 5218JJ3001A | 5218JJ3001A |
| 103E | RAIL,SLIDE | 5218JJ3001A | 5218JJ3001A | 5218JJ3001A |
| 103E | RAIL,SLIDE | 5218JJ3001A | 5218JJ3001A | 5218JJ3001A |
| 104E | HOLDER ASSEMBLY,GASKET | 4931JJ3002A | 4931JJ3002A | 4931JJ3002A |
| 105A | DRAIN ASSEMBLY,PIPE-Z | 5251JA3003B | 5251JA3003B | 5251JA3003B |
| 105F | SKIRT,LOWER | 5070JJ3002A | 5070JJ3002A | 5070JJ3002A |
| 106A | LEG ASSEMBLY,ADJUST | 4779JA2003A | 4779JA2003A | 4779JA2003A |
| 120B | DUCT ASSEMBLY,MULTI | 5209JJ1002A | 5209JJ1002A | 5209JJ1002A |
| 128A | GUIDE ASSEMBLY,RAIL | 4975JJ2002A | 4975JJ2002A | 4975JJ2002A |
| 128A | GUIDE ASSEMBLY,RAIL | 4975JJ2002A | 4975JJ2002A | 4975JJ2002A |
| 128B | GUIDE ASSEMBLY,RAIL | 4975JJ2002B | 4975JJ2002B | 4975JJ2002B |
| 128C | GUIDE ASSEMBLY,RAIL | 4975JJ2003C | 4975JJ2003C | 4975JJ2003C |
| 128D | GUIDE,RAIL | 4974JJ2035A | 4974JJ2035A | 4974JJ2035A |
| 128E | HOLDER,RAIL | 4930JJ1011C | 4930JJ1011C | 4930JJ1011C |
| 128F | HOLDER,RAIL | 4930JJ1011D | 4930JJ1011D | 4930JJ1011D |
| 128G | LINK | 4520JJ2001A | 4520JJ2001A | 4520JJ2001A |
| 128M | GUIDE,AIR | 4974JJ2011A | 4974JJ2011A | 4974JJ2011A |
| 131A | BANK,ICE | 5074JL1001B | 5074JL1001B | 5074JL1001B |
| 131C | COVER,BANK ICE | 3550JJ2045A | 3550JJ2045A | 3550JJ2045A |
| 135C | COVER,GRILLE FAN | 3550JJ2030A | 3550JJ2030A | 3550JJ2030A |
| 136A | TRAY,DRAWER | 3390JJ1062A | 3390JJ1062A | 3390JJ1062A |
| 136B | TRAY,DRAWER | 3390JJ1059A | 3390JJ1059A | 3390JJ1059A |
| 136C | TRAY ASSEMBLY,DRAWER | 3391JJ1012C | 3391JJ1012C | 3391JJ1012C |
| 136D | DECO,TRAY | 3806JL1020B | 3806JL1020B | 3806JL1020B |
| 136E | DECO,TRAY | 3806JL1024B | 3806JL1024B | 3806JL1024B |
| 136G | TRAY,DRAWER | 3390JJ1036A | 3390JJ1036A | 3390JJ1036A |
| 140A | SHELF ASSEMBLY,R | 5027JJ1014D | 5027JJ1014D | 5027JJ1014D |
| 140B | SHELF ASSEMBLY,R | 5027JJ1005A | 5027JJ1005A | 5027JJ1005A |
| 140F | SHELF ASSEMBLY,NET | 5027JJ2005F | 5027JJ2005F | 5027JJ2005F |
| 141A | SHELF ASSEMBLY,R | 5027JJ1014B | 5027JJ1014B | 5027JJ1014B |
| 141B | SHELF ASSEMBLY,R | 5027JJ1005A | 5027JJ1005A | 5027JJ1005A |
| 141C | SHELF ASSEMBLY,NET | 5027JJ2005C | 5027JJ2005C | 5027JJ2005C |
| 141D | SHELF ASSEMBLY,R | 5027JJ2011B | 5027JJ2011B | 5027JJ2011B |
| 141E | SHELF ASSEMBLY,NET | 5027JJ2005D | 5027JJ2005D | 5027JJ2005D |
| 142A | SHELF ASSEMBLY,R | 5027JJ1013U | 5027JJ1013U | 5027JJ1013U |
| 142B | SHELF ASSEMBLY,R | 5027JJ1006A | 5027JJ1006A | 5027JJ1006A |
| 142D | SHELF,NET | 5026JJ2001L | 5026JJ2001L | 5026JJ2001L |
| 142E | SHELF,NET | 5026JJ2001M | 5026JJ2001M | 5026JJ2001M |
| 145A | HOLDER,SHELF | 4930JJ2003A | 4930JJ2003A | 4930JJ2003A |
| 145B | HOLDER,SHELF | 4930JJ2004A | 4930JJ2004A | 4930JJ2004A |

| LOC | DESCRIPCION | LRFC22750TT | LRFC22750SW | LRFC22750ST |
|------|------------------------------|-------------|-------------|-------------|
| 145C | GUIDE ASSEMBLY,RAIL | 4975JJ1001C | 4975JJ1001C | 4975JJ1001C |
| 146A | CAN,SERVER | 5044JJ1001A | 5044JJ1001A | 5044JJ1001A |
| 146B | CONNECTOR ASSEMBLY (MECH) | 5098JJ2002H | 5098JJ2002H | 5098JJ2002H |
| 146C | CONNECTOR ASSEMBLY (MECH) | 5098JJ2002G | 5098JJ2002G | 5098JJ2002G |
| 147A | BANK,DAIRY | 5074JJ1005A | 5074JJ1005A | 5074JJ1005A |
| 147B | TRAY,EGG | 3390JJ1014A | 3390JJ1014A | 3390JJ1014A |
| 147C | COVER,BANK | 3550JJ1017A | 3550JJ1017A | 3550JJ1017A |
| 147D | TRAY,BUTTER | 3390JJ2003A | 3390JJ2003A | 3390JJ2003A |
| 149C | SHELF ASSEMBLY,R | 5027JJ2010B | 5027JJ2010B | 5027JJ2010B |
| 149E | SHELF ASSEMBLY,R | 5027JJ2009B | 5027JJ2009B | 5027JJ2009B |
| 151A | TRAY ASSEMBLY,VEGETABLE | 3391JJ1019E | 3391JJ1019E | 3391JJ1019E |
| 151C | KNOB,SHUTTER | 4940JJ2003B | 4940JJ2003B | 4940JJ2003B |
| 154A | COVER,T/V | 3550JJ1033A | 3550JJ1033A | 3550JJ1033A |
| 155B | SUPPORTER ASSEMBLY,COVER-T/V | 4981JJ2001A | 4981JJ2001A | 4981JJ2001A |
| 158A | COVER,LAMP | 3550JJ1040A | 3550JJ1040A | 3550JJ1040A |
| 158E | COVER,LAMP | 3550JJ1051A | 3550JJ1051A | 3550JJ1051A |
| 160A | GLASS,SHELF | 4890JL1002K | 4890JL1002K | 4890JL1002K |
| 160B | DECO,TRAY | 3806JL2005D | 3806JL2005D | 3806JL2005D |
| 161A | COVER,TRAY | 3550JJ2026A | 3550JJ2026A | 3550JJ2026A |
| 168A | COVER,MAGIC ROOM | 3550JJ1035A | 3550JJ1035A | 3550JJ1035A |
| 170A | TRAY ASSEMBLY,MEAT | 3391JJ2004K | 3391JJ2004K | 3391JJ2004K |
| 200A | DOOR ASSEMBLY,F | 3581JJ8058P | 3581JJ8058N | 3581JJ8058E |
| 201A | DOOR FOAM ASSEMBLY,F | 5433JJ0022W | 5433JJ0022U | 5433JJ0022M |
| 203A | GASKET ASSEMBLY,DOOR | 4987JJ1004A | 4987JJ1004A | 4987JJ1004E |
| 212A | HANDLE,F | 3650JJ1041A | 3650JJ1041B | 3650JJ1040A |
| 212G | MARK | 3846JD1007B | 3846JD1007B | 3846JD1007B |
| 230A | DOOR ASSEMBLY,R/R | 3581JJ8056J | 3581JJ8056H | 3581JJ8056D |
| 230B | DOOR ASSEMBLY,R/L | 3581JJ8057L | 3581JJ8057K | 3581JJ8055C |
| 231A | DOOR FOAM ASSEMBLY,R | 5433JJ0063G | 5433JJ0063C | 5433JJ0063E |
| 231B | DOOR FOAM ASSEMBLY,R | 5433JJ0061M | 5433JJ0061L | 5433JJ0061C |
| 233A | GASKET ASSEMBLY,DOOR | 4987JJ2003E | 4987JJ2003E | 4987JJ2003F |
| 233B | GASKET ASSEMBLY,DOOR | 4987JJ2003G | 4987JJ2003G | 4987JJ2003H |
| 233C | COVER ASSEMBLY,FRONT | 3551JJ2034B | 3551JJ2034B | 3551JJ2034B |
| 233D | COVER ASSEMBLY,FRONT | 3551JJ2034A | 3551JJ2034A | 3551JJ2034A |
| 241A | COVER,TRAY | 3550JL2006A | 3550JL2006A | 3550JL2006A |
| 241B | BANK,DAIRY | 5074JJ1019A | 5074JJ1019A | 5074JJ1019A |
| 241C | BASKET ASSEMBLY,DOOR | 5005JJ2022A | 5005JJ2022A | 5005JJ2022A |
| 243A | STOPPER,DOOR | 4620JJ3006D | 4620JJ3006A | 4620JJ3006C |
| 243A | STOPPER,DOOR | 4620JJ3006D | 4620JJ3006A | 4620JJ3006C |
| 243B | STOPPER,DOOR | 4620JJ2009A | 4620JJ2009A | 4620JJ2009A |
| 243B | STOPPER,DOOR | 4620JJ2009A | 4620JJ2009A | 4620JJ2009A |
| 244B | HOLDER,HANDLE | 4930JJ2018B | 4930JJ2018A | 4930JJ2018B |
| 244C | HOLDER,HANDLE | 4930JJ2017B | 4930JJ2017A | 4930JJ2017B |
| 244E | HANDLE ASSEMBLY,R | 3650JA1221C | 3651JA2269D | 3650JA2158A |
| 244G | STOPPER,HANDLE | 4620JJ3007B | 4620JJ3007B | 4620JJ3007B |
| 245A | HOLDER,HANDLE | 4930JJ2019B | 4930JJ2019A | 4930JJ2019B |

| LOC | DESCRIPCION | LRFC22750TT | LRFC22750SW | LRFC22750ST |
|------|---------------------------|-------------|-------------|-------------|
| 245B | HOLDER,HANDLE | 4930JJ2020B | 4930JJ2020A | 4930JJ2020B |
| 248A | RAIL ASSEMBLY,SLIDE | 5219JJ1002D | 5219JJ1002D | 5219JJ1002D |
| 248F | SUPPORTER,HOLDER | 4980JJ2005A | 4980JJ2005A | 4980JJ2005A |
| 262D | CLIP | 4004JA3002A | 4004JA3002A | 4004JA3002A |
| 262E | SCREW ASSEMBLY | 4350JA3005B | 4350JA3005B | 4350JA3005B |
| 262H | HINGE ASSEMBLY,C | 4775JJ2019F | 4775JJ2019B | 4775JJ2019D |
| 271A | HINGE ASSEMBLY,U | 4775JJ2018B | 4775JJ2018B | 4775JJ2018B |
| 271C | HINGE ASSEMBLY,U | 4775JJ2018A | 4775JJ2018A | 4775JJ2018A |
| 278C | LEVER,SHUTTER | 4510JJ2002A | 4510JJ2002A | 4510JJ2002A |
| 281A | COVER ASSEMBLY,HINGE | 3551JJ1016S | 3551JJ1016M | 3551JJ1016Q |
| 282B | HINGE ASSEMBLY,C | 4775JJ2019E | 4775JJ2019A | 4775JJ2019C |
| 282E | COVER ASSEMBLY,HINGE | 3551JJ1016X | 3551JJ1016T | 3551JJ1016V |
| 282F | DECO,DUCT | 3806JL2006E | 3806JL2006E | 3806JL2006E |
| 284D | SCREW,DRAWING | 1STZJA3004K | 1STZJA3004K | 1STZJA3004K |
| 285A | GUIDE ASSEMBLY,RAIL | 4975JJ2008B | 4975JJ2008B | 4975JJ2008B |
| 301A | EVAPORATOR ASSEMBLY | 5421JJ1001B | 5421JJ1001B | 5421JJ1001B |
| 304A | COVER ASSEMBLY,BACK-M/C | 3551JJ2008B | 3551JJ2008B | 3551JJ2008B |
| 305B | ROLLER | 4580JJ3001A | 4580JJ3001A | 4580JJ3001A |
| 305B | ROLLER | 4580JJ3001A | 4580JJ3001A | 4580JJ3001A |
| 305C | PIN,DRAWING | 4J04238A | 4J04238A | 4J04238A |
| 305C | PIN,DRAWING | 4J04238A | 4J04238A | 4J04238A |
| 307A | COMPRESSOR,SET ASSEMBLY | 2521C-A5729 | 2521C-A5729 | 2521C-A5729 |
| 308A | P.T.C ASSEMBLY | 6748C-0004D | 6748C-0004D | 6748C-0004D |
| 309A | O.L.P | 6750C-0005P | 6750C-0005P | 6750C-0005P |
| 310A | COVER,P.T.C | 3550JA2042A | 3550JA2042A | 3550JA2042A |
| 312A | RUBBER,SEAT | 5040JA3031A | 5040JA3031A | 5040JA3031A |
| 314A | STOPPER,COMP | 4620JA3009A | 4620JA3009A | 4620JA3009A |
| 315A | COMP BASE ASSEMBLY,STD | 3103JJ1001J | 3103JJ1001J | 3103JJ1001J |
| 317A | DRIER ASSEMBLY | 5851JJ2002B | 5851JJ2002B | 5851JJ2002B |
| 318A | HOLDER,DRIER | 4930JJ3002A | 4930JJ3002A | 4930JJ3002A |
| 319A | TRAY,DRIP | 3390JJ0004A | 3390JJ0004A | 3390JJ0004A |
| 319C | GUIDE,FAN | 4974JJ1009A | 4974JJ1009A | 4974JJ1009A |
| 319E | BRACKET,MOTOR | 4810JJ2005A | 4810JJ2005A | 4810JJ2005A |
| 323B | CONDENSER ASSEMBLY,WIRE | 5403JJ1007A | 5403JJ1007A | 5403JJ1007A |
| 327A | CAP,DRAIN PIPE | 5006JA3034A | 5006JA3034A | 5006JA3034A |
| 328B | RUBBER,DAMPING | 4J04328A | 4J04328A | 4J04328A |
| 328B | RUBBER,DAMPING | 4J04328A | 4J04328A | 4J04328A |
| 329A | FAN ASSEMBLY | 5901JJ1005A | 5901JJ1005A | 5901JJ1005A |
| 329C | FAN ASSEMBLY | 5901JJ1004B | 5901JJ1004B | 5901JJ1004B |
| 332A | GRILLE ASSEMBLY,FAN | 3531JJ1004A | 3531JJ1004A | 3531JJ1004A |
| 401A | CONTROLLER ASSEMBLY(CIRC) | 6615JB2005C | 6615JB2005C | 6615JB2005C |
| 402A | SWITCH,[PUSH] | 6600JB3007B | 6600JB3007A | 6600JB3007E |
| 402A | SWITCH,[PUSH] | 6600JB3007B | 6600JB3007A | 6600JB3007E |
| 404A | MOTOR ASSEMBLY,REF FAN | 4681JK1004A | 4681JK1004A | 4681JK1004A |
| 405A | BRACKET ASSEMBLY,MOTOR | 4811JJ2002A | 4811JJ2002A | 4811JJ2002A |
| 405B | RUBBER,MOTOR-N | 5040JJ2001A | 5040JJ2001A | 5040JJ2001A |
| 405C | RUBBER,MOTOR-F | 5040JA2009B | 5040JA2009B | 5040JA2009B |

| LOC | DESCRIPCION | LRFC22750TT | LRFC22750SW | LRFC22750ST |
|------|---------------------------|-------------|-------------|-------------|
| 405F | RUBBER,MOTOR-F | 5040JA2004B | 5040JA2004B | 5040JA2004B |
| 405G | BRACKET ASSEMBLY,MOTOR | 4811JJ2002H | 4811JJ2002H | 4811JJ2002H |
| 406B | SWITCH,[PUSH] | 6600JB1004A | 6600JB1004A | 6600JB1004A |
| 409B | LAMP,[INCANDESCENT] | 6912JK2002C | 6912JK2002C | 6912JK2002C |
| 409D | REFLECTOR,LAMP | 3034JJ1002B | 3034JJ1002B | 3034JJ1002B |
| 410A | SOCKET ASSEMBLY,LAMP | 6621JK2002D | 6621JK2002D | 6621JK2002D |
| 410G | CAPACITOR,DRAWING | 0CZZJB2012G | 0CZZJB2012G | 0CZZJB2012G |
| 411A | POWER CORD ASSEMBLY | 6411JK1006H | 6411JK1006H | 6411JK1006H |
| 418A | HEATER,SHEATH | 5300JB1100J | 5300JB1100J | 5300JB1100J |
| 420A | MOTOR ASSEMBLY,REF FAN | 4681JK1004C | 4681JK1004C | 4681JK1004C |
| 501A | PWB(PCB) ASSEMBLY,MAIN | 6871JB1375A | 6871JB1375A | 6871JB1375A |
| 501F | COVER,PWB | 3550JJ1042B | 3550JJ1042B | 3550JJ1042B |
| 503C | PWB(PCB) ASSEMBLY,DISPLAY | 6871JB1374A | 6871JB1374A | 6871JB1374A |
| 503D | CASE,DISPLAY | 3110JJ1005A | 3110JJ1005A | 3110JJ1005A |
| 503E | COVER,DISPLAY | 3550JJ2032A | 3550JJ2032A | 3550JJ2032A |
| 503G | DECO,CONTROL | 3806JL1035A | 3806JL1035A | 3806JL1035A |
| 600A | ICE MAKER ASSEMBLY,KIT | 5989JA0002A | 5989JA0002A | 5989JA0002A |
| 602A | HOLDER,BRACKET | 4930JA3037A | 4930JA3037A | 4930JA3037A |
| 610A | COVER,SENSOR | 3550JJ2020A | 3550JJ2020A | 3550JJ2020A |
| 616E | TUBE,PE | 5210JA3005N | 5210JA3005N | 5210JA3005N |
| 618A | TUBE,INJECT | 5210JJ3005B | 5210JJ3005B | 5210JJ3005B |
| 619A | VALVE,WATER | 5220JA2009D | 5220JA2009D | 5220JA2009D |
| 619B | COVER,VALVE | 3550JJ2024A | 3550JJ2024A | 3550JJ2024A |
| 619C | VALVE ASSEMBLY,WATER | 5221JA2008G | 5221JA2008G | 5221JA2008G |
| 621A | CONNECTOR (MECH),DOOR | 4932JJ2001B | 4932JJ2001B | 4932JJ2001B |
| 622A | TUBE,INLET | 5210JJ3002A | 5210JJ3002A | 5210JJ3002A |
| 623C | BAND (MECH) | 4770JA3001A | 4770JA3001A | 4770JA3001A |
| 700B | HANDLE ASSEMBLY,F | 3651JJ2010N | 3651JJ2010P | 3651JA2268H |
| 700C | HANDLE ASSEMBLY,R | 3651JA2269C | 3651JA2269D | 3651JA2269G |
| 903A | COVER,LOWER | 3550JJ0006D | 3550JJ0006A | 3550JJ0006C |
| 903B | HOLDER,COVER LOWER | 4930JJ2021A | 4930JJ2021A | 4930JJ2021A |
| 903D | SENSOR | 6500JK1003A | 6500JK1003A | 6500JK1003A |
| 903E | SENSOR | 6500JK1004A | 6500JK1004A | 6500JK1004A |
| S01 | SCREW,DRAWING | 1SZZJJ3010A | 1SZZJJ3010A | 1SZZJJ3010A |
| S22 | SCREW,DRAWING | 3J05696C | 3J05696C | 3J05696C |
| S24 | SCREW,DRAWING | 1SZZJA3011B | 1SZZJA3011B | 1SZZJA3011B |
| S28 | SCREW,DRAWING | 3J05696W | 3J05696W | 3J05696W |



P/No. 3828JL8076A

SEPTEMBER 19, 2005