Appliance Factory Parts Experts in BBQ, Humidifier, & Appliance Parts

Kenmore 77549 Owner's Manual

Shop genuine replacement parts for Kenmore 77549



Find Your Kenmore Refrigerator Parts - Select From 665 Models

----- Manual continues below ------



REFRIGERATOR SERVICE MANUAL

CAUTION

BEFORE SERVICING THE UNIT, READ THE SAFETY PRECAUTIONS IN THIS MANUAL.



Model #s:

| 795.77192600 |
|--------------|
| 795.77199600 |
| 795.77194600 |
| 795.77193600 |
| 795.77196600 |
| 795.77542600 |
| 795.77549600 |
| 795.77544600 |
| 795.77543600 |
| 795.77546600 |
| 795.77552600 |
| 795.77559600 |
| 795.77554600 |
| 795.77553600 |
| 795.77556600 |

CONTENTS

| SAFETY PRECAUTIONS | |
|--|-------|
| 1. SPECIFICATIONS | |
| 2. PARTS IDENTIFICATION | |
| 3. DISASSEMBLY | 5-10 |
| DOOR | |
| TO REMOVE THE DISPENSER | 7 |
| FAN AND FAN MOTOR | |
| DEFROST CONTROL ASSEMBLY | |
| LAMP | |
| CONTROL BOX-REFRIGERATOR | |
| MULTI DUCT | |
| HOW TO REMOVE AND REINSTALL THE PULLOUT DRAWER | |
| 4. ADJUSTMENT | 11-12 |
| COMPRESSOR | 11 |
| PTC-STARTER | 11 |
| OLP (OVERLOAD PROTECTOR) | 12 |
| TO REMOVE THE COVER PTC | 12 |
| 5. CIRCUIT DIAGRAM | |
| 6. TROUBLESHOOTING | 14-19 |
| COMPRESSOR AND ELECTRIC COMPONENTS | 14 |
| PTC AND OLP | 15 |
| OTHER ELECTRICAL COMPONENTS | |
| SERVICE DIAGNOSIS CHART | 17 |
| REFRIGERATION CYCLE | 18-19 |
| 7. OPERATION PRINCIPLE & REPAIR METHOD OF ICEMAKER | 20-23 |
| 8. DESCRIPTION OF FUNCTION & CIRCUIT OF MICOM | 24-35 |

SAFETY PRECAUTIONS

Please read the following instructions before servicing your refrigerator.

- 1. Unplug the power before handling any elctrical componets.
- 2. Check the rated current, voltage, and capacity.
- 3. Take caution not to get water near any electrical components.
- 4. Use exact replacement parts.
- 5. Remove any objects from the top prior to tilting the product.

1-1 DISCONNECT POWER CORD BEFORE SERVICING **IMPORTANT – RECONNECT ALL GROUNDING DEVICES**

All parts of this appliance capable of conducting electrical current are grounded. If grounding wires, screws, straps, clips, nuts or washers used to complete a path to ground are removed for service, they must be returned to their original position and properly fastened.

1-2 IMPORTANT NOTICE

This information is intended for use by individuals possessing adequate backgrounds of electrical, electronic and mechanical experience. Any attempt to repair a major appliance may result in personal injury and property damage. The manufacturer or seller cannot be responsible for the interpretation of this information, nor can it assume any liability in connection with its use.

1-3 ELECTRICAL SPECIFICATIONS

| Temperature Control (Freezer Compart | tment)6°F to +8°F |
|--------------------------------------|----------------------|
| Defrost ControlTotal Comp F | Running Time : 7 hrs |
| Defrost Thermostat | 46°F |
| Electrical Rating : 115VAC, 60Hz | 1-5 A |
| Maximum Current Leakage | 0.5 mA |
| Maximum Ground Path Resistance | 0.14 Ohms |
| Energy Consumption21 cu.ft. 465 k | Wh/yr (Energy Star) |
| 25 cu.ft. 499 k | Wh/yr (Energy Star) |

1-4 NO LOAD PERFORMANCE CONTROL POSITION: MID/MID

| And Ambient of: | 70°F | 90°F |
|----------------------|--------------|--------------|
| Fresh Food, °F | 33°F to 41°F | 33°F to 41°F |
| Frozen Food, °F | 4°F to +4°F | 4°F to +4°F |
| Percent Running Time | 35%-45% | 50°F-70°F |

1-5 REFRIGERATION SYSTEM

| Minimum Compressor Capacity Vacuum | 20 MIN. |
|------------------------------------|---------|
| Minimum Equalized Pressure | |
| @ 70°F | 49 PSIG |
| @ 90°F | 56 PSIG |
| Refrigerant B134a | 4 06 07 |

| rionigoranti | . 1.00 | 02 |
|--------------|-----------|------|
| Compressor | 0 BTI | J/hi |

1-6 INSTALLATION

| Clearance must be provided at top, sides an | nd rear of the |
|---|----------------|
| refrigerator for air circulation. | |
| AT TOP | 1 in |
| AT SIDES | 1 in |
| AT REAR | |

1-7 REPLACEMENT PARTS

| Relay | 6748C-0004D |
|----------------------|--------------|
| Overload | 6750C-0005P |
| Defrost Thermostat | 6615JB2005H |
| Defrost Heater | 5300JK1005D |
| Evaporator Fan Motor | 4681JK1004A |
| Capacitor | 0CZZJB2012G |
| Compressor (Hi-Side) | 2521C-A5719 |
| Evaporator (Lo-Side) | 5421JJ0006A |
| | *5421JJ0007A |
| Condenser | 5403JJ1004B |
| Dryer | 5851JA2008A |
| Condenser Fan Motor | 4681JB1029D |
| Temperature Control | 6871JB1439A |
| Main Control | 6871JB1423B |
| | |

1-8 AIR FLOW / CIRCULATION D'AIR





1-9 DIMENSIONS





| Description | | 795.771** | 795.775** |
|--------------------------------------|---|------------|-------------|
| Depth w/ Handles | А | 30 in. | 34 1/4 in. |
| Depth w/o Handles | В | 27 1/2 in. | 31 3/4 in. |
| Depth w/o Door | С | 23 5/8 in. | 27 7/8 in. |
| Depth (Total with Door Open) | D | 42 1/4 in. | 46 1 /2 in. |
| Height to Top of Case | Е | 68 3/8 in. | 68 3/8 in. |
| Height to Top of Door Hinge | F | 69 3/4 in. | 69 3/4 in. |
| Width | G | 35 3/4 in. | 35 3/4 in. |
| Width (door open 90 deg. w/o handle) | Н | 39 1/4 in. | 39/1/4 in. |
| Width (door open 90 deg. w/ handle) | | 44 1/4 in. | 44 1/4 in. |

2. PARTS IDENTIFICATION



3-1 REMOVING AND REPLACING REFRIGERATOR DOORS

Removing Refrigerator Door

- **A** CAUTION: Before you begin, unplug the refrigerator. Remove food and bins from doors.
- Left Door
- 1. Disconnect water supply tube by pushing back on the disconnect ring (4).
- 2. Open door. Loosen top hinge cover screw (1).
- Use flat tip screwdriver to pry back hooks on front underside of cover (3). Lift up cover.
- 3. Disconnect door switch wire harness (2). Remove cover.
- 4. Attach the tube on the door with door.
- 5. Pull out the tube.
- 6. Disconnect the three wire harnesses (5). Remove the grounding screw (6).
- 7. Rotate hinge lever (7) counterclockwise and remove. Lift top hinge (8) free of hinge lever latch (9).
- **A** CAUTION: When lifting hinge free of latch, be careful that door does not fall forward.
- 8. Lift door up from middle hinge pin (10) and remove door.
- 9. Place door, inside facing up, down onto a non-scratching surface.

Right Door

- 1. Open door. Loosen top hinge cover screw (1). Lift up cover (3).
- 2. Disconnect door switch wire harness (2). Remove cover.
- 3. Disconnect wire harness (5). Remove the grounding screw (6).
- 4. Rotate hinge lever (7) clockwise and remove. Lift top hinge (8) free of hinge lever latch (9).
- A CAUTION: When lifting hinge free of latch, be careful that door does not fall forward.
- 5. Lift door up from middle hinge pin (10) and remove door.
- 6. Place door, inside facing up, down onto a non-scratching surface.



3-2 DOOR

- Door Gasket Removal
- 1. Remove door frame cover
- Starting at top of cover and working down, snap cover out and away from door.



2. Remove gasket bracket clips

There are two clips on each door. Start bracket removal near one of the middle clips.

- 1) Pull gasket back to expose gasket bracket clip and door frame.
- Insert a flat tip screwdriver into seam between gasket bracket and door frame and pry back until clips snaps out.
- Continue prying back along seam until all clips snap out.



3. Remove gasket

Pull gasket free from gasket channel on the three remaining sides of door.



• Door Gasket Replacement 1. Insert gasket bracket clips

- 1) Insert gasket bracket edge beneath door frame edge.
- 2) Turn upper gasket bracket spring so that the spring ends are in the door channel.
- 3) Push in clip until you hear it snap securely into place.



- 4) Push in remaining two clips until you hear each snap securely into place.
- **Note:** Make sure that no part of gasket bracket edge protrudes from beneath door frame edge.

2. Insert gasket into channel

1) Snap gasket assembly into the door bracket. <Inserting the Gasket Assembly into the Bracket Door>



2) Press gasket into channels on the three remaining sides of door.



3. Replace door frame cover

Starting at top of cover and working down, snap cover back into door.



3-3 TO REMOVE THE DISPENSER

1. Use fiat tip screwdriver to pry back hooks on botton underside of cover dispenser.



2. Pry off cover dispenser.



Disconnect wire harness.

3. Replace cover dispenser in opposite manner and order of removal.

3-4 DOOR ALIGNMENT

If the space between your doors is uneven, follow the instructions below to align the doors:

- 1. With one hand, lift up the door you want to raise at middle hinge.
- 2. With other hand, use pliers to insert snap ring as shown.
- 3. Insert additional snap rings until the doors are aligned. (Three snap rings are provided with unit.)



3-5 FAN AND FAN MOTOR

- 1. Remove the freezer shelf. (If your refrigerator has an icemaker, remove the icemaker first)
- 2. Remove the plastic guide for slides on left side by unscrewing phillips head screws.
- 3. Remove the grille by pulling it out and by loosening a screw.
- 4. Remove the Fan Motor assembly by loosening 2 screws and disassemble the shroud.
- 5. Pull out the fan and separate the Fan Motor and Bracket.



3-6 DEFROST CONTROL ASSEMBLY

Defrost Control assembly consists of Defrost Sensor and FUSE–M.

The Defrost Sensor works to defrost automatically. It is attached to the metal side of the Evaporator and senses its temperature. At $161.6^{\circ}F(72^{\circ}C)$, it turns the Defrost Heater off. Fuse-M is a safety device for preventing over-heating of the Heater when defrosting.

- 1. Pull out the grille assembly. (Figure 12)
- 2. Separate the connector with the Defrost Control assembly and replace the Defrost Control assembly after cutting the Tie Wrap. (Figure 13)



3-7 LAMP

3-7-1 Refrigerator Compartment Lamp

- 1. Unplug Refrigerator, or disconnect power at the circuit breaker.
- 2. If necessary, remove top shelf or shelves.
- 3. Using a flat instrument, gently pry the cover loose in the front as shown. Rotate downward to remove rear tabs.

- 4. Make sure the bulbs are cool to the touch. Turn bulbs counterclockwise to remove.
- 5. Assemble in reverse order by snapping the Lamp Cover in, engaging the rear tabs followed by the front tabs. (Max. 60 W-2EA)



3-7-2 Freezer Compartment Lamp

- 1. Unplug refrigerator power cord form outlet.
- 2. Using a flat instrument, gently pry the lamp cover loose in the front as shown. Rotate downward to remove the rear tabs.
- 3. Make sure the bulb is cool to the touch. Turn the bulb counterclockwise to remove.
- 4. Replace with a new 60-watt appliance bulb.
- 5. Insert tabs on back of cover into slots in freezer ceiling. Push cover up to snap front into place.



3-8 CONTROL BOX-REFRIGERATOR

1. First, remove all shelves in the refrigerator, than remove the Refrigerator control Box by loosening 2 screws.



- 2. Remove the Refrigerator Control Box by pulling it downward.
- 3. Disconnect the lead wire on the right position and separate the lamp sockets.

3-9 MULTI DUCT

- 1. Remove an upper and lower Cap by using a flat screwdriver, and loosen 2 screws. (Figure 17)
- 2. Disconnect the lead wire on the bottom position.



3-10 HOW TO REMOVE AND REINSTALL THE PULLOUT DRAWER

3-10-1 FOLLOW STEPS TO REMOVE

Step 1) Open the freezer door.



Step 3) Remove the two screws from the guide rails (one from each side).

Step 2) Remove the lower basket.



Step 4) Lift the freezer door up to unhook it from the rail support and remove. Pull both rails to full extension.





Step 5) First: Remove the gear from the left side first by releasing the tab behind the gear, place a screwdriver between the gear and the tab and pull up on the gear.

Second: Remove the center rail.

Third: Remove the gear from the right side by following the same steps for the left side.



NOTE: THIS TAB MUST BE PUSHED IN TO RELEASE THE GEAR.

3-10-2 FOLLOW STEPS TO REINSTALL

Step 1) Reinstall the right side gear into the clip.



Step 2) Insert the rail into the right side gear. Gears do **not** need to be perpendicular to each other.



Step 4) The rail system will align itself by pushing the rails all the way into the freezer section. Pull the rails back out to full extension.



Step 6) Reinstall the two screws into the guide rails (one from each side).





Step 3) Insert the rail into the left side gear, and insert the gear into the clip.



Step 5) Reinstall the freezer door by inserting the rail tabs into the guide rail.



Step 7) Reinstall the lower basket, and close the freezer door.



3-10-3 PULL OUT DRAWER

To separate the drawer, push the front left and right hooks in ① direction to pull up and remove. Then gently lift the gear part of rear left and right side of the drawer and pull it out in ③ direction.



To install, reposition the gear part of rear left and right side of the drawer after pulling out both rails as much as possible, and gently push down both left and right side while checking the hook on the front part.



4-1 COMPRESSOR

4-1-1 Role

The compressor intakes low temperature and low pressure gas from the evaporator of the refrigerator and compresses this gas to high-temperature and high-pressure gas. It then delivers the gas to the condenser.

4-1-2 Composition

The compressor includes overload protection. The PTC starter and OLP (overload protector) are attached to the outside of the compressor. Since the compressor is manufactured to tolerances of 1 micron and is hermetically sealed in a dust and moisture-free environment, use extreme caution when performing repairs.

4-1-3 Note for Usage

- (1) Be careful not to allow over-voltage and over-current.
- (2) If compressor is dropped or handled carelessly, poor operation and noise may result.
- (3) Use proper electric components appropriate to the Particular Compressor in your product.
- (4) Keep Compressor dry.
 If the Compressor gets wet (in the rain or a damp environment) and rust forms in the pin of the Hermetic Terminal, poor operation and contact may result.
- (5) When replacing the Compressor, be careful that dust, humidity, and soldering flux don't contaminate the inside of the compressor. Dust, humidity, and solder flux contaminate the cylinder and may cause noise, improper operation or even cause it to lock up.

4-2 PTC-STARTER

4-2-1 Composition of PTC-Starter

- PTC (Positive Temperature Coefficient) is a no-contact semiconductor starting device which uses ceramic material consisting of BaTiO3.
- (2) The higher the temperature is, the higher the resistance value. These features are used as a starting device for the Motor.

4-2-2 Role of PTC-Starter

- (1) The PTC is attached to the Sealed Compressor and is used for starting the Compressor Motor.
- (2) The compressor is a single-phase induction motor. The starting operation, the PTC allows current flow to both the start winding and main winding.

4-2-3 PTC-Applied Circuit Diagram

Starting Method for the Motor



4-2-4 Motor Restarting and PTC Cooling

- (1) It requires approximately 5 minutes for the pressure to equalize before the compressor can restart.
- (2) The PTC device generates heat during operation. Therefore, it must be allowed to cool before the compressor can restart.

4-2-5 Relation of PTC-Starter and OLP

- If the compressor attempts to restart before the PTC device is cooled, the PTC device will allow current to flow only to the main winding.
- (2) The OLP will open because of the over current condition. This same process will continue (3 to 5 times) when the compressor attempts to restart until the PTC device has cooled. The correct OLP must be properly attached to prevent damage to the compressor.

Parts may appear physically identical but could have different electrical ratings. Replace parts by part number and model number. Use only approved substitute parts.

4-2-6 Note for Using the PTC-Starter

- (1) Be careful not to allow over-voltage and over-current.
- (2) Do not drop or handle carelessly.
- (3) Keep away from any liquid. If liquid such as oil or water enters the PTC, PTC materials may fail due to breakdown of their insulating capabilities.
- (4) If the exterior of the PTC is damaged, the resistance value may be altered. This can cause damage to the compressor and result in a no-start or hard-to-start condition.
- (5) Always use the PTC designed for the compressor and make sure it is properly attached to the compressor. Parts may appear physically identical but could have different electrical ratings. Replace parts by part number and model number. Use only approved substitute parts.

4-3 OLP (OVERLOAD PROTECTOR)

4-3-1 Definition of OLP

- (1) OLP (OVERLOAD PROTECTOR) is attached to the Compressor and protects the Motor by opening the circuit to the Motor if the temperature rises and activating the bimetal spring in the OLP.
- (2) When high current flows to the Compressor motor, the Bimetal works by heating the heater inside the OLP, and the OLP protects the Motor by cutting off the current flowing to the Compressor Motor.

4-3-2 Role of the OLP

- (1) The OLP is attached to the Sealed Compressor used for the Refrigerator. It prevents the Motor Coil from being started in the Compressor.
- (2) For normal operation of the OLP, do not turn the Adjust Screw of the OLP in any way.



4-4 TO REMOVE THE COVER PTC



- (1) Remove the Cover Back M/C.
- (2) Disconnect two housing upper side of comp connected in.
- (3) Loosen two screws on comp base.



- (4) Use a L-shaped flap tool to pry off the cover.
- (5) Assembly in reverse order of disassembly.

5. CIRCUIT DIAGRAM



6. TROUBLESHOOTING

6-1 COMPRESSOR AND ELECTRIC COMPONENTS





6-3 OTHER ELECTRICAL COMPONENTS

▼ Not cooling at all



6-4 SERVICE DIAGNOSIS CHART

| COMPLAINT | POINTS TO BE CHECKED | REMEDY |
|---|--|--|
| No Cooling. | Is the power cord unplugged from the outlet? Check if the power switch is set to OFF. Check if the fuse of the power switch is shorted. Measure the voltage of the power outlet. | Plug into the outlet. Set the switch to ON. Replace the fuse. If the voltage is low, correct the wiring. |
| Cools poorly. | Check if the unit is placed too close to the wall. Check if the unit is placed too close to the stove, gas cooker, or in direct sunlight. Is the ambient temperature too high or the room door closed? Check if food put in the refrigerator is hot. Did you open the door of the unit too often or check if the door is sealed properly? Check if the Control is set to Warm position. | Place the unit about 4 inches (10 cm) from the wall. Place the unit away from these heat sources. Lower the ambient temperature. Put in foods after they have cooled down. Don't open the door too often and close it firmly. Set the control to Recommended position. |
| Foods in the Refrigerator are frozen. | Is food placed in the cooling air outlet? Check if the control is set to colder position. Is the ambient temperature below 41°F(5°C)? | Place foods in the high-temperature section. (front part) Set the control to Recommended position. Set the control to Warm position. |
| Condensartion or ice forms inside the unit. | Is liquid food sealed? Check if food put in the refrigerator is hot. Did you open the door of the unit too often or check if the door is sealed properly? | Seal liquid foods with wrap. Put in foods after they have cooled down. Don't open the door too often and close it firmly. |
| Condensartion forms in the Exterior Case. | Check if the ambient temperature and humidity of the surrounding air are high. Is there a gap in the door gasket? | Wipe moisture with a dry cloth. It will disappear in low temperature and humidity. Fill up the gap. |
| There is abnormal noise. | Is the unit positioned in a firm and even place? Are any unnecessary objects placed in the back side of the unit? Check if the Drip Tray is not firmly fixed. Check if the cover of the compressor enclosure in the lower front side is taken out. | Adjust the Leveling Screw, and position the refrigerator in a firm place. Remove the objects. Fix the Drip Tray firmly in the original position. Place the cover in its original position. |
| Door does not close well. | Check if the door gasket is dirty with an item like juice. Is the refrigerator level? Is there too much food in the refrigerator? | Clean the door gasket. Position in the firm place and level the Leveling Screw. Make sure food stored in shelves does not prevent the door from closing. |
| Ice and foods smell unpleasant. | Check if the inside of the unit is dirty. Are foods with a strong odor unwrapped? The unit smells of plastic. | Clean the inside of the unit. Wrap foods that have a strong odor. New products smell of plastic, but this will go away after 1-2 weeks. |

• Other possible problems:



6-5 REFRIGERATION CYCLE

▼ Troubleshooting Chart

| | CAUSE | STATE OF THE UNIT | STATE OF THE EVAPORATOR | TEMPERATURE OF THE COMPRESSOR | REMARKS |
|---------|---------------------|--|--|---|---|
| LEAK | PARTIAL LEAKAGE | Freezer compartment and Refrigerator don't cool normally. | Low flowing sound of Refrigerant is heard and frost forms in inlet only. | A little higher than ambient temperature. | Refrigerant level is low due to a leak. Normal cooling is possible by restoring the normal amount of refrigerant and repairing the leak. |
| AGE | COMPLETE LEAKAGE | Freezer compartment and Refrigerator don't cool normally. | Flowing sound of refrigerant is not heard and frost isn't formed. | Equal to ambient temperature. | No discharging of Refrigerant. Normal cooling is possible by restoring the normal amount of refrigerant and repairing the leak. |
| CLOGGED | PARTIAL CLOG | Freezer compartment and Refrigerator don't cool normally. | Flowing sound of refrigerant is heard and frost forms in inlet only. | A little higher than ambient temperature. | Normal discharging of the refrigerant.The capillary tube is faulty. |
| BY DUST | WHOLE CLOG | Freezer compartment and Refrigerator don't cool. | Flowing sound of refrigerant is not heard and frost isn't formed. | Equal to ambient temperature. | Normal discharging of the Refrigerant. |
| 1 | MOISTURE CLOG | Cooling operation stops periodically. | Flowing sound of refrigerant is not heard and frost melts. | Lower than ambient temperature. | Cooling operation restarts when heating the inlet of the capillary tube. |
| COMPF | COMP- RESSION | Freezer and Refrigerator don't cool. | Low flowing sound of refrigerant is heard and frost forms in inlet only. | A little higher ambient temperature. | Low pressure at high side of compressor due to low refrigerant level. |
| CTIVE | NO COMP- RESSION | No compressing operation. | Flowing sound of refrigerant is not heard and there is no frost. | Equal to ambient temperature. | No pressure in the high pressure part of the compressor. |

6-5-1 SEALED SYSTEM DIAGNOSIS



(The equalization test is trying to restart a compressor using a start kit after it has been operating.)

7. OPERATION PRINCIPLE AND REPAIR METHOD OF ICEMAKER

7-1 OPERATION PRINCIPLE

7-1-1 Operation Principle of IceMaker



- 1. Turning the Icemaker stop switch off (O) stops the icemaking function.
- 2. Setting the Icemaker switch to OFF and then turning it back on will reset the icemaker control.



7-2 ICE MAKER FUNCTIONS

7-2-1 Start Position

- 1. After POWER OFF or power outage, check the EJECTOR's position with MICOM initialization to restart.
- 2. How to check if it is in place:
 - Check HIGH/LOW signals from HALL SENSOR in MICOM PIN.
- 3. Control method to check if it is in place:
 - (1) EJECTOR is in place,
 - It is an initialized control, so the mode can be changed to ice making control.
 - (2) EJECTOR isn't in place:
 - A. If EJECTOR is back in place within 2 minutes with the motor on, it is being initialized. If not, go to step B.
 - B. If EJECTOR is back in place within 18 minutes after the heater turns from ON to OFF, it is being initialized. If not, it is not functioning. Repeat step B with heater and motor off.

7-2-2 Ice Making Mode

- 1. Icemaking refers to the freezing of supplied water in the ice trays. Complete freezing is assured by measuring the temperature of the Tray with icemaking SENSOR.
- 2. Icemaking starts after completion of the water fill operation.
- 3. The icemaking function is completed when the sensor reaches -7°C, 60 to 240 minutes after starting.
- 4. If the temperature sensor is defective, the icemaking function will be completed in 4 hours.

NOTE : After icemaker power is ON, the icemaker heater will be on for test for 9 sec.

7-2-3 Harvest Mode

- 1. Harvest (Ice removing) refers to the operation of dropping ices into the ice bin from the tray when icemaking has completed.
- 2. Harvest mode:
 - (1) The Heater is ON for 30 seconds, then the motor starts.
 - (2) Harvest mode is completed if it reaches start position again while Heater & Motor are on at the same time. A. ice bin is full : The EJECTOR stops (heater off).
 - B. ice bin is not full : The EJECTOR rotates twice to open for ice.
 - **NOTE :** If the EJECTOR does not rotate once within 5 minutes in status (2), separate heater control mode starts operating to prevent the EJECTOR from being constrained. (It is recommended that the user open for ice to return to normal mode.)

7-2-4 Fill/Park Position

- 1. Once a normal harvest mode has been completed, the water solenoid will be activated.
- 2. The amount of water is adjusted by pressing the fill key repeatedly. This changes the time allowed for fill as illustrated in the table below.

Water supply amount table

| STAGE | TIME TO SUPPLY | INDICATIONS | REMARKS |
|-------|----------------|-------------|---|
| 1 | 6 sec. | | |
| 2 | 7 sec. | | on the water control switch setting, as well as the water pressure of the connected water line. |
| 3 | 8 sec. | | |

NOTE : Below is an example used by another vendor as an explanation of what is taking place.



7-2-5 Function TEST

- 1. This is a compulsory operation for test, service, cleaning, etc. It is operated by pressing and holding the fill key for 3 seconds.
- 2. The test works only in the icemaking mode. It cannot be entered from the harvest or fill mode. (If there is an ERROR, it can only be checked in the test mode.)
- 3. **Caution!** If the test is performed before water in the icemaker is frozen, the ejector will pass through the water. When the fill mode begins (stage 4), unless the water supply has been shut off, added water will overflow into the ice bin. If the control doesn't operate normally in the test mode, check and repair as needed.
- 4. After water is supplied, the normal cycle is followed: icemaking \rightarrow harvest \rightarrow fill \rightarrow park position.
- 5. Five seconds after stage 5 is completed, the icemaker returns to MICOM control. The time needed to supply water resets to the pre-test setting.

| STAGE | ITEMS | INDICATOR | REMARKS |
|-------|--|--------------------------------------|--|
| 1 | HEATER | | Five seconds after heater starts, heater will go off if temperature recorded by sensor is 50°F(10°C) or lever is in up position. |
| 2 | MOTOR | | Five seconds after heater starts, you can confirm that motor is moving. |
| 3 | HALL IC I (detection of position) | | You can confirm hall ic detection of position. |
| 4 | VALVE | | Two seconds after detection of initial position, you can confirm that valve is on. |
| 5 | HALL IC II (detection of full-filled Ice) | | You can check whether the Hall IC is sensing a full ice condition.(If there is a full-filled error, the fifth stage would not be progressed) |
| 6 | Reset | Mark previous status on TEST mode | Five seconds after fifth stage is completed, the icemaker resets to initial status. |

< 5 stage of diagnosis >

7-3 DEFECT DIAGNOSIS FUNCTION

7-3-1 ERROR CODE on water supply control panel at Ice Maker

| No | ITEM | ERROR CODE | CONTENTS | REMARKS |
|----|-------------------------------------|------------------------|------------------------------|--|
| 1 | Normal | Mark time to supply | None | Display switch operates properly |
| 2 | Ice-Making Sensor malfunction | | Open or short-circuited wire | Make sure that the wire on each sensor is connected. |

* ERROR indicators in table can be checked only on TEST mode.

8. DESCRIPTION OF FUNCTION & CIRCUIT OF MICOM

8-1 FUNCTION

8-1-1 Function

- 1. When the appliance is plugged in, it is set to "37" for Refrigerator and "0" for freezer.
- You can adjust the Refrigerator and the Freezer control temperature by pressing the ADJUST button.
- 2. When the power is initially applied or restored after a power failure, it is automatically set to "37" & "0".



8-1-2 How to Change the Temperature Mode to °F / °C

- 1. The setting temperature mode can be changed to °F / °C by pressing and holding Freezer Temp. key of Freezer and Refrigerator Temp. key of Refrigerator over 5 seconds. at the same time.
- 2. The initial setting is °F. Whenever the mode is changed, the LED lights are changed.

8-1-3 Lock function (dispenser and display button lock)

- 1. In power application of refrigerator, the "LOCK" icon is turned off at the upper side of lock graphic of display with the lock release status.
- 2. If desiring to lock the display the dispenser and control panel push on the LOCK button more than 3 seconds. LOCK text is turned on at the upper side of lock graphic of display with lock status.
- 3. The buzzer sound and control panel and dispenser function is not performed even if pressing display button other than lock key in the lock status.
- 4. If desiring to release the lock status and pressing the lock button more than 3 seconds. "LOCK" icon is turned off at the upper side of lock graphic of display with the lock release status.

8-1-4 Filter condition display function

- 1. There is a replacement indicator icon for the water filter cartridge on the dispenser.
- 2. Water filter needs replacement once six months or about 28,000 seconds of using water filter.
- 3. Water filter icon turns on to tell you need to replace the filter soon.
- After replace the filter, press and hold the lock button more than 3 seconds. Then water filter light turns off with reset status.

8-1-5 Ultra Ice selection

Please select this function for prompt freezer.

- Function is repeated following below whenever pressing Ultra Ice button.
- Ultra Ice function automatically turns off if a fixed time passes.









8-1-6 CONTROL OF FREEZER FAN MOTOR

- 1. Freezer fan motor has high and standard speeds.
- 2. High speed is used at power-up, for Ultra Ice, and when refrigerator is overloaded. Standard speeds is used for general purposes.
- 3. To improve cooling speed, the RPM of the freezer fan motor change from normal speed to high.
- 4. High speed (2700RPM) : Initial power on or load corresponding operation, Ultra Ice. Normal speed (2400RPM) : General working conditions.
- 5. Fan motor stops when refrigerator or freezer door opens.

8-1-7 Ultra Ice

- 1. The purpose of this function is to intensify the cooling speed of freezer and to increase the amount of ice.
- 2. When Ultra Ice is selected, LED will remain ON for Ultra Ice Cycle.
- 3. If power is lost to the refrigerator, Ultra Ice function will be canceled.
- 4. To activate this function, to press the Ultra Ice key and the LED will turn ON. This function will remain activated for 24 hrs. The first three hours the compressor and Freezer Fan will be ON. The next 21 hours the freezer will be controlled at the lowest temperature. After 24 hours or if the Ultra Ice key is pressed again, the freezer will return to its previous temperature.
- 5. For the first three hours notice the following cases:
 - (1) Compressor and freezer fan (HIGH RPM) continuously operate for three hours.
 - (2) If defrost starts during Ultra Ice, Ultra Ice operates for the rest of time after defrost is completed, when Ultra Ice operation time is less than 90 minutes.
 - If Ultra Ice operates for more than 90 minutes, the Ultra Ice will operate for two hours after defrost is completed.
 - (3) If Ultra Ice is pressed during defrost, Ultra Ice LED is on but this function will start seven minutes after defrost is completed and it shall operate for three hours.
 - (4) If Ultra Ice is selected within seven minutes after compressor has stopped, the compressor (compressor delays seven minutes) shall start after the balance of the delay time.
 - (5) The fan motor in the freezer compartment runs at high speed during Ultra Ice .
- 6. For the rest of the 21 hours, the freezer will be controlled at the lowest temperature.

8-1-8 REFRIGERATOR LAMP AUTO OFF

1. To avoid heat damage caused by the lamp, it is turned off automatically when the refrigerator door is open for more than 7 minutes.

8-1-9 Alarm for Open Door

- 1. This feature sounds a buzzer when the freezer or refrigerator door is not closed within 1 minute after it is opened.
- One minute after the door is opened, the buzzer sounds three times each for 1/2 seconds. These tones repeat every 30 seconds.
- 3. The alarm is cancelled when the freezer or the refrigerator is closed while the buzzer sounds.



8-1-10 Buzzer Sound

When the button on the front Display is pushed, a Ding~ Dong~ sound is produced.

8-1-11 Defrost cycle

- 1. A defrost cycle will be initiated after 4 hours of accumulated compressor run time after the initial power up or a power failure.
- 2. After the initial defrost, the defrost cycle is initiated after 7 hours of accumulated compressor run time.
- 3. The defrost cycle will be terminated once the defrost sensor reaches 50°F(10°C).

8-1-12 Filter Replacement Indication

- 1. In 6 months after the UNIT (refrigerator) is power on, or after 28,000 seconds of dispenser use, the water filter icon is ON.
- 2. When the water filter indicator LED is illuminated, you should change the water filter. After this, you must press the water filter button for three seconds and you will hear a ding-dong sound.
 - The icon will be OFF. This operation will indicate that the UNIT is reset to its initial conditions, so this process is restarted.

8-1-13 DISPENSER LIGHT

Please select this function for DISPENSER LIGHT MODE.

- 1. Normal status (LIGHT icon is OFF) : When dispenser is operated, DISPENSER LIGHT is ON.
- 2. ON status (LIGHT icon is ON) : DISPENSER LIGHT is on continuously.

8-1-13 Automatic Diagnosis Function

- 1. Automatic diagnosis makes servicing the refrigerator easy.
- 2. When an error occurs, the buttons will not operate; but the tones. such as ding. will sound.
- 3. When the error CODE removes the sign, it returns to normal operation (RESET).
- 4. The error CODE shows on the Refrigerator and Freezer Display.



ERROR CODE on display panel

| | | ERROR CODE | | | | |
|----|--|------------|----|--|--|--|
| NO | ITEM | 1 | 2 | CONTENTS | REMARKS | |
| 1 | Failure of freezer sensor | Er | FS | Cut or short circuit wire | | |
| 2 | Failure of Refrigerator sensor | Er | rS | Cut or short circuit wire | Inspect Connecting wires | |
| 3 | Failure of defrost sensor | Er | dS | Cut or short circuit wire | | |
| 4 | Failure of Room Temperature sensor | * NOTE 1 | | Cut or short circuit wire | | |
| 5 | Failure of defrost mode | Er | dH | When defrost sensor doesn't reach 46°F(8°C) within 1 hour after starting defrost | Snapping of defrost heater or Temperature fuse, pull-out of connector (indicated minimum 1 hour after failure occurs) | |
| 6 | Failure of BLDC Fan Motor at Freezing Compartment | Er | FF | If there is no fan motor signal for more than 115sec in operation fan motor | Poor motor, hooking to wires of fan, contact of structures to fan, snapping or short circuit of Lead wires | |
| 7 | Failure of BLDC Fan Motor a Mechanical Room | Er | CF | If there is no fan motor signal for more than 115sec in operation fan motor | Poor motor, hooking to wires of fan, contact of structures to fan, snapping or short circuit of Lead wires | |

LED check function: If simultaneously pressing Ultra Ice button and freezing temperature adjustment button for a second, display LED graphics on. If releasing the button, the LED graphic displays the previous status.

8-1-14 TEST Mode

- 1. The Test mode allows checking the PCB and the function of the components as well as finding out the defective part in case of an error.
- 2. The test mode is operated by pressing two buttons at Display panel.
- 3. While in the test mode, the function control button is not recognized, but the recognition tone (beep~) sounds.
- 4. After exiting the test mode, be sure to reset by unplugging and then plugging in the appliance.
- 5. If an error, such as a sensor problem, is detected while in the test mode, the test mode is cleared and the error code is displayed.
- 6. While an error code is displayed, the test mode will not be activated.

| MODE | MANIPULATION | CONTENTS | REMARKS |
|-------|---|---|--|
| TEST1 | Push FREEZER KEY and LOCK KEY at the same time over 5 seconds OR Push TEST Switch (in the main Board) once. (See page 37) | Continuous operation of the COMPRESSOR and the Freezer fan Stepping DAMPER OPEN Defrosting HEATER OFF DISPLAY LED all ON | |
| TEST2 | Push FREEZER KEY and LOCK KEY at the same time over 5 seconds in TEST MODE 1 OR Push TEST Switch once in TEST MODE 1 (See page 37) | Continuous operation of the COMPRESSOR and the Freezer fan Stepping DAMPER CLOSE Defrosting HEATER OFF DISPLAY LED shows no. 2 | |
| TEST3 | Push FREEZER KEY and LOCK KEY at the same time over 5 seconds in TEST MODE 2 OR Push TEST Switch once in TEST MODE 2 (See page 37) | COMPRESSOR and the Freezer fan OFF Stepping DAMPER CLOSE Defrosting HEATER ON DISPLAY LED shows no. 3 | Reset if the Temperature of the Defrosting Sensor is 46°F(8°C)or more. |
| RESET | Push FREEZER KEY and LOCK KEY at the same time over 5 seconds in TEST MODE 3 OR Push TEST Switch once in TEST MODE 3 (See page 37) | Reset to the previously setting Before TEST MODE. | The compressor will Start after a 7-minute Delay. |

* Freezer Fan RPM Variable Check:

In case the freezer fan is in operation when the Ultra Ice button and freezing temp. button. Control are pressed for more than one second at the same time freezer fan RPM changes. (for example if high speed, to normal speed or if normal speed, to high speed for 30 seconds)

After 30 seconds, it turns to its original RPM.

* Demonstration MODE:

- 1. When the Ultra Ice button and the Refrigerator Temperature Control button are pushed at the same time and hold for 5 seconds or longer, it converts to Demonstration Mode.
- 2. The Display shows the Demo graphic.
- 3. In this status, all Loads are off (Compressor / Fan / Damper / Heater)

(Even is Demonstration Mode, the refrigerator Lamp automatic off function warks normally and can be demonstrated)4. Exit Demonstration mode and reset Display by pressing the Ultra Ice button and the Refrigerator Temperature Control button for 5 seconds or longer.

8-2 PCB FUNCTION

8-2-1 Power Circuit

1. Power is supplied to the control board at pin7 and 9 of connector #1.



8-2-2 Load / Buzzer Drive & Open Door Detection Circuit

1. Load Drive Condition Check



To measure outputs of the control board, check voltages between the pins for the following components:

| Circuit | Pin Number | Pin Number | Output Voltage |
|-----------------------|--------------|------------|----------------|
| Compressor | Con1 pin1 | Con1 pin1 | 115 VAC |
| Defrost heater | Con2 pin1 | Con1 pin1 | 115 VAC |
| F,R-lamp | Con2 pin,3.5 | Con1 pin1 | 115 VAC |
| Water valve Con2 pin7 | | Con1 pin1 | 115 VAC |
| Dew heater | Con3 pin3 | Con1 pin1 | 115 VAC |
| Water valve Con3 pin1 | | Con1 pin1 | 115 VAC |

NOTE: When the door of the freezer/refrigerator is left open for 7 minutes or longer, the lamp of the freezer'refrigerator turns.

2. Fan motor driving circuit (freezing compartment fan, mechanical room)

| | F-FAN | C-FAN |
|------------|------------------|------------------|
| Pin Number | Pin1 & 2 of con4 | Pin4 & 5 of con4 |
| MOTOR OFF | 2V or less | 2V or less |
| MOTOR ON | 2V or less | 2V or less |

3. Open Door Detection Circuit Check



8-2-3 Temperature Sensor Circuit





| TEMPERATURE | RESISTANCE OF FREEZER SENSOR | RESISTANCE OF REFRIGERATOR & DEFROST SENSOR & ROOM SENSOR |
|------------------|---------------------------------|--|
| - 20 °C (-4 °F) | 22.3 ΚΩ | 77 ΚΩ |
| - 15 °C (5 °F) | 16.9 ΚΩ | 60 ΚΩ |
| - 10 °C (14 °F) | 13.0 ΚΩ | 47.3 ΚΩ |
| - 5 °C (23 °F) | 10.1 ΚΩ | 38.4 ΚΩ |
| 0 °C (32 °F) | 7.8 ΚΩ | 30 ΚΩ |
| + 5 °C (41 °F) | 6.2 ΚΩ | 24.1 ΚΩ |
| + 10 °C (50 °F) | 4.9 ΚΩ | 19.5 ΚΩ |
| + 15 °C (59 °F) | 3.9 ΚΩ | 15.9 ΚΩ |
| + 20 °C (68 °F) | 3.1 KΩ | 13 ΚΩ |
| + 25 °C (77 °F) | 2.5 ΚΩ | 11 ΚΩ |
| + 30 °C (86 °F) | 2.0 ΚΩ | 8.9 ΚΩ |
| + 40 °C (104 °F) | 1.4 ΚΩ | 6.2 ΚΩ |
| + 50 °C (122 °F) | 0.8 ΚΩ | 4.3 ΚΩ |

 \bullet The resistance of the SENSOR has a $\pm 5\%$ common difference.

• Measure the resistance of the SENSOR after leaving it for over 3 minutes in the measuring temperature. This delay is necessary due to sensor response speed.

8-2-4 Refrigeration Compartment Stepping Motor Damper Circuit

A reversible DC motor is used to open and close the damper.

To open the damper, push test button once.

To close the damper, push test button twice.



8-3 TROUBLESHOOTING

| PROBLEM | INDICATED BY | CHECK | CHECKING METHOD | CAUSE | SOLUTION |
|-----------------------------|---|--------------------------------------|---|---|--|
| POWER SOURCE is poor. | 1. The whole DISPLAY LED/SEVEN SEGMENT DISPLAY is off | 1. FREEZER/ REFRIGERATOR. | Check if FREEZER/REFRIGERA TOR DOOR IS OPEN and check display. | POWER SOURCE is poor. | Use boosting TRANS. |
| | 2. DISPLAY LED/ | 2. If LAMP is dim. | Check visually. | Applied voltage error. | Reconnect CONNECTOR. |
| | SEGMENT DISPLAY | 3. The connection of the MAIN PWB | Check connection of CONNECTOR. | CONNECTOR connection is poor. | Replace TRANS. |
| | abnormally | | | TRANS FUSE is open. | Replace COMPRESSOR. |
| COOLING is poor. | NO COOLING. | 1. If the COMPRESSOR operate. | USE TEST MODE1 (forced COOLING). | COMPRESSOR locked or blocked. | Replace OLP, PTC. |
| | | | pass after compressor shuts off, don't press the KEY and wait. | OLP, PTC is poor. COMPRESSOR RELAY is poor. | Replace MAIN PWB. |
| | | | | THE CONNECTING WIRE is poor. | Check the connection of the black wire of the MAIN PWB CONNECTOR (CON2). |
| | | 2. If refrigerant is leaking. | Measure the amount of frost sticking on EVAPORATOR and the surface temperature of the condenser pipe. | Refrigerant leakage. | Replace the leaking part and replace any lost refrigerant. |
| | FREEZER TEMPERATURE is incorrect | 1. If FAN MOTOR operates. | USE TEST MODE1 (forced COOLING). | FAN MOTOR is poor. | Replace the FAN MOTOR. |
| | | | | CONNECTING WIRE is poor. | Certify the MOTOR and the connection of the black wire of the MAIN PWB CONNECTOR (CON2). |
| | | 2. If DEFROSTING is normal. | Check the amount of frost sticking on the EVAPORATOR . | DEFROSTING is poor. | See DEFROSTING is poor. |
| | | 3. If SENSOR is normal. | of the Refrigerator SENSOR. | SENSOR RESISTANCE is poor. | Replace SENSOR. |
| | | 4. Door Line contact. | Check the seal when the door is closed. | Door liner damaged. | Replace door liner. |

| PROBLEM | INDICATED BY | СНЕСК | CHECKING METHOD | CAUSE | SOLUTION |
|------------------------|-----------------------------------|--|---|---------------------------------|--|
| COOLING is poor. | If REFRIGERATOR TEMPERATURE | 1. If FREEZER TEMPERATURE is normal. | Check is FREEZER TEMPERATURE is too low. | | Make sure the DOOR isattached. |
| | 13 100 IOW. | 2. If amount of cool air | Make sure that the | FAN MOTOR is poor. | Replace FAN MOTOR. |
| | | sufficient. | air are sufficient by touching the check | Passage of cool air is blocked. | Remove impurities. |
| | | | REFRIGERATOR. | EVA frozen. | See DEFROSTING is poor. |
| | | 3. Door Line contact. | Check door seal when door is closed. | Door liner damaged. | Replace Door liner. |
| DEFROSTIN G is poor | NO DEEBOSTING | 1. If HEATER emits heat. | USE TEST MODE3 | HEATER disconnection. | Replace HEATER. |
| | DEFROSTING | | | TEMPERATURE FUSE disconnection. | Replace TEMPERATURE FUSE. |
| | | | | Connection is poor. | Check EVAPORATOR connection and wire of MAIN PWB CONNECTOR. |
| | | | | DEFROST-SENSOR is poor. | Replace DEFROST- SENSOR. |
| | | | | HEATER RELAY is poor. | Replace RY3 of MAIN PWB. |
| | | 2. If DRAIN PIPE is blocked. | Check DRAIN PIPE. | DRAIN PIPE is blocked. | Remove ice and impurities. |
| | | | | | Check HEATER PLATE resistance. |
| | | 3. If ice remains after DEFROSTING. | Make sure that DEFROST SENSOR is connected. | Connection is poor. | Reassemble the DEFROST-SENSOR. |
| | | | Make sure that | DOOR does not close | Reassemble DOOR. |
| | | | /REFRIGERATOR DOOR is closed. | рюрену. | Replace GASKET. |

8-4 MAIN PWB ASSEMBLY AND PARTS LIST

8-4-1 Main PWB Assembly



| REPAIR | | Your Home |
|-------------------------------------|---|--|
| LIST | | For repair – in your nome – of all major brand appliances, lawn and garden equipment, or heating and cooling systems, no matter who made it, no matter who sold it! |
| MODELS No. | The model number of your refrigerator is found on the serial | For the replacement parts, accessories and owner's manuals that you need to do-it-yourself. |
| 795.77542600 795.77549600 | plate inside. | For Sears professional installation of home appliances and items like garage door openers and water heaters. |
| 795.77544600 | All repair parts listed are available | 1-800-4-MY-HOME [®] (1-800-469-4663) |
| 795.77546600 795.77546600 | order when you visit your nearest | Call anytime, day or night (U.S.A. and Canada) www.sears.com www.sears.ca |
| 795.77552600 | Sears Service Center, or the Service Department at most Sears | Our Home |
| 795.77554600 795.77553600 | stores. To order parts by phone, call the toll free parts number | For repair of carry-in items like vacuums, lawn equipment, and electronics, call or go on-line for the location of your nearest |
| 795.77556600 | | Sears Paris & Repair Center. 1-800-488-1222 |
| | When requesting service or ordering parts, always provide the | Call anytime, day or night (U.S.A. only) |
| | following information: | www.sears.com |
| | Product Type Part Number | or maintenance agreement (Canada) on a product serviced by Sears |
| To call Toll Free For Parts: | Model Number Part Description | 1-800-827-6655 (U.S.A.) 1-800-361-6665 (Canada) Para pedir servicio de reparación Au Canada pour service en francais |
| 1-800-366-PART (1-800-366-7278) | | a domicilio, y para ordenar piezas: 1-800-LE-FOYER SM (1-888-533-6937) (1-888-533-6937) |
| For Service: | | (1-585-764-0427) www.stais.La |
| 1-800-4-MY-HOME (1-800-469-4663) | JUNE. 04. 2008 | JEalls |
| Sears, Roebuck | and Co., Hoffman Estates, IL 60179 U.S.A. | © Registered Trademark /nu Trademark /nu Service Mark of Sears, Roebuck and Co. © Marca Registrada /nu Marca de Fábrica /nu Marca de Servicio de Sears, Roebuck and Co. |
| | | Marque de commerce /wu marque deposee de Sears, Hoeduck and Lo. Sears, noeuvuck and Sears, noeuvuck and Sears, noeuvuck and Sears, Hoeduck and Lo. |
| | | |

| | LOC No. |
|----------------|---------------------|
| | 600A |
| | 602A |
| | 603A |
| | 603B |
| | 616C |
| | 9 616D |
| | 616E |
| | 616F |
| | ه 616H |
| | 617A |
| | 619A |
| G16H G | 623A |
| 603A) - 3 | St 623B |
| (616F) c====== | > [™] 625A |
| | √ 33 627A |
| | 627B |
| | [®] S13 |
| | S30 |
| | S31 |
| | S32 |
| | |
| L / | |

| OC No. | 775** | Description |
|--------|--------------|-------------------------|
| 00A | 5989JA0002Q | ICE MAKER ASSEMBLY, KIT |
| 02A | 4930JA3090A | HOLDER, BRACKET |
| 03A | 4930JA3093B | HOLDER, BRACKET |
| 03B | 4930JA3091A | HOLDER, BRACKET |
| 16C | 5210JA3004U | TUBE,PE |
| 16D | 5210JA3005Q | TUBE,PE |
| 16E | 5211JA3003E | TUBE ASSEMBLY, INJECT |
| 16F | 5210JA3004R | TUBE,PE |
| 16H | 4932JA3002C | CONNECTOR (MECH), TUBE |
| 17A | 4970JA3004J | SPRING,W |
| 19A | 5221JB2006K | VALVE ASSEMBLY,WATER |
| 23A | 4770JA3001A | BAND (MECH) |
| 23B | 5006JJ2009A | CAP,COVER |
| 25A | 3550JA2184A | COVER,TUBE |
| 27A | 4930JJ 3018A | HOLDER, PIPE |
| 27B | 4930JA3054A | HOLDER, PIPE |
| 13 | 1SZZJJ3005E | SCREW, DRAWING |
| 30 | 1SZZJJ3009A | SCREW, DRAWING |
| 31 | 4J00415D | SCREW, DRAWING |
| 32 | 4000W4A003A | SCREW, DRAWING |
| | | |

nber.



CASE PARTS

| LOC No. | 775*3 | 775*6 | 775*2 | 775*9 | 775*4 | Description |
|--------------|--|--|----------------------------------|-----------------------------|------------------------------|---------------------------------------|
| 103A | 3650JA2061X | 3650JA2061X | 3650JA2061B | 3650JA2113P | 3650JA2061 | VHANDLE.BACK |
| 103B | 3650JA2061W | 3650JA2061W | 3650JA2061A | 3650JA2113N | 3650JA2061U | HANDLE,BACK |
| 103C | 3550JJ0008D | 3550JJ0008D | 3550JJ0008A | 3550JJ0008C | 3550JJ0008B | COVER,LOWER |
| 105A | 5251JA3003B | 5251JA3003B | 5251JA3003B | 5251JA3003B | 5251JA3003B | DRAINASSEMBLY, PIPE-Z |
| 106A | 4779JJ2001A | 4779JJ2001A | 4779JJ2001A | 4779JJ2001A | 4779JJ2001 | ALEGASSEMBLY, ADJUST |
| 120B | 5208JJ1055A | 5208JJ1055A | 5208JJ1055A | 5208JJ1055A | 5208JJ1055A | |
| 1350 | 3330JAZZ03A | 300UJA2203A | 3330JA2203A | 3330UJA2203A | 3330JA2203A | |
| 145A | 4930.1A2080C | 4930.1A2080C | 4930.JA2080C | 4930.JA2080C | 4930.JA2080C | HOI DEB SHELE |
| 145B | 4930JA2081C | 4930JA2081C | 4930JA2081C | 4930JA2081C | 4930JA2081C | HOLDER,SHELF |
| | | | | | | |
| 158A | 3550JJ1070B | 3550JJ1070B | 3550JJ1070B | 3550JJ1070B | 3550JJ1070B | |
| 2074 | 3550 L 110970 | 3550 L 110970 | 3000JA 1300D | 3000JA 1300D | 3550 J 11007C | |
| 207B | 3550JJ1097B | 3550JJ1097B | 3550JJ1097B | 3550JJ1097E | 3550JJ1097D | COVER HINGE |
| 249C | 4930JA1066B | 4930JA1066B | 4930JA1066B | 4930JA1066B | 4930JA1066B | HOLDER, RAIL |
| 249D | 4930JA1066A | 4930JA1066A | 4930JA1066A | 4930JA1066A | 4930JA1066A | HOLDER,RAIL |
| 262B | 4775JJ2017P | 4775JJ2017P | 4775JJ2017B | 4775JJ2017F | 4775JJ2017K | HINGEASSEMBLY,C |
| 262H | 4775JJ2017R | 4775JJ2017R | 4775JJ2017D | 4775JJ2017H | 4775JJ2017M | HINGEASSEMBLY,C |
| 271A 271P | 4775JJ2014B | 4775JJ2014B | 4775JJ2014B | 4775JJ2014B | 4775JJ2014B | |
| 2710 | 45100A3004A | 45100A5004A | 40100A004A | 40100430044 | 4510JA3004A | |
| 271C | 4775JJ2014A | 4775JJ2014A | 4775JJ2014A | 4775JJ2014A | 4775JJ2014A | HINGEASSEMBLY,U |
| 282F | 3806JL1037A | 3806JL1037A | 3806JL1037A | 3806JL1037A | 3806JL1037A | DECO,DUCT |
| 283B 300A | 4774JJ3002A | 4774JJ3002A | 4774JJ3002A | 4774JJ3002A | 4774JJ3002A | |
| 3004 | 5421,11003B | 5421,11003R | 5421,11003B | 5421, J1003B | 5421,JJ1003B | |
| 301A | (*)5421JJ1003A | (*)5421JJ1003A | (*)5421JJ1003A | (*)5421JJ1003A | (*)5421JJ1003A | AEVAPORATORASSEMBLY |
| 303B | 6748C-0004D | 6748C-0004D | 6748C-0004D | 6748C-0004D | 6748C-0004D | P.T.CASSEMBLY |
| 303C | 6750C-0005P | 6750C-0005P | 6750C-0005P | 6750C-0005P | 6750C-0005P | O.L.P |
| 304A | 3550JA2042B | 3550JA2042B | 3550JA2042B | 3550JA2042B | 3550JA2042B | COVER, P.T.C |
| 309B | 5040JJ2001A | 5040JJ2001A | 5040JJ2001A | 5040JJ2001A | 5040JJ2001A | RUBBER,MOTOR-N |
| 310B | 5200JA1029A | 5200JA1029A | 5200JA1029A | 5200JA1029A | 5200JA1029A | PIPE, JOINT |
| 312A | 5040JA3071A | 5040JA3071A | 5040JA3071A | 5040JA3071A | 5040JA3071A | RUBBER,SEAT |
| 313A | 3551JJ2018A | 3551JJ2018A | 3551JJ2018A | 3551JJ2018A | 3551JJ2018A | COVERASSEMBLY, BACK-M/C |
| 314A | 4620JA3015A | 4620JA3015A | 4620JA3015A | 4620JA3015A | 4620JA3015A | STOPPER,COMP |
| 315A | 3103JJ1001H | 3103JJ1001H | 3103JJ1001H | 3103JJ1001H | 3103JJ1001H | COMPBASEASSEMBLY,STD |
| 3150 | 4080JA3033A | 4080JA3033A | 4580JA3033A | 4580JA3033A | 4580JA3033A | |
| 316A | 5072JA3003F | 5072JA3003F | 5072JA3003F | 5072JA3003F | 5072JA3003F | RESTRAINER |
| 316B | 5072JA3003B | 5072JA3003B | 5072JA3003B | 5072JA3003B | 5072JA3003B | RESTRAINER |
| 317A | 5851JA2008A | 5851JA2008A | 5851JA2008A | 5851JA2008A | 5851JA2008A | DRIERASSEMBLY |
| 2194 | 1020 1020240 | 1020 1020240 | 1020 1020210 | 1020 1020210 | 1020 1020240 | |
| 310A 310A | 4930JA3034A 3300 IA0040A | 4930JA3034A 3300 IA0040A | 4930JA3034A 3300 IA0040A | 4930JA3034A 3300 IA0040A | 4930JA3034A 3300 IA00/0A | |
| 319C | 4974JJ1036A | 4974JJ1036A | 4974JJ1036A | 4974JJ1036A | 4974JJ1036A | GUIDE.FAN |
| 323B | 5403JJ1004B | 5403JJ1004B | 5403JJ1004B | 5403JJ1004B | 5403JJ1004B | CONDENSERASSEMBLY, WIRE |
| 327A | 5040JA3056A | 5040JA3056A | 5040JA3056A | 5040JA3056A | 5040JA3056A | RUBBER, DAMPING |
| 329A | 5901JA1021A | 5901JA1021A | 5901JA1021A | 5901JA1021A | 5901JA1021A | FANASSEMBLY |
| 3290 | 5901JA1013A | 5901JA1013A | 5901JA1013A | 5901JA1013A | 5901JA1013A | |
| 332A 4004 | 3530JJ0007A 6615 IB2005H | 3530JJ0007A | 3530JJ0007A 6615 IB2005H | 3530JJ0007A | 3030JJ0007A 6615 IB2005H | CONTROLLERASSEMBLY |
| 402A | 6600JB3007B | 6600JB3007B | 6600JB3007A | 6600JB3007E | 6600JB3007A | SWITCH,[PUSH] |
| | | 1001 11/10010 | | | | |
| 404A | 4681JK1004D | 4681JK1004D | 4681JK1004D | 4681JK1004D | 4681JK1004D | MUTURASSEMBLY, REFFAN |
| 405A 405B | 40100000000000000000000000000000000000 | 40100000000000000000000000000000000000 | 4010JJUUU3A | 4010JJUUU3A 48101J2005A | 4010JJUUU3AB 48101J2005AB | RACKET MOTOR |
| 405D 405C | 5040.1A2009R | 5040 JA2009R | 5040 142009R | 5040.142009R | 5040.142009R | BUBBER MOTOR-F |
| 405F | 5040JA2004B | 5040JA2004B | 5040JA2004B | 5040JA2004B | 5040JA2004B | RUBBER, MOTOR-F |
| 406A | 4930JJ3020A | 4930JJ3020A | 4930JJ3020A | 4930JJ3020A | 4930JJ3020A | HOLDER, BRACKET |
| 406B | 6600JB1004A | 6600JB1004A | 6600JB1004A | 6600JB1004A | 6600JB1004A | SWITCH,[PUSH] |
| 406D | 4931JA3006A | 4931JA3006A | 4931JA3006A | 4931JA3006A | 4931JA3006A | HOLDER ASSEMBLY, DOOR |
| 408A | 5300JK1005D | 5300JK1005D | 5300JK1005D | 5300JK1005D | 5300JK1005D | HEATER, SHEATH |
| 409B | (*)6912JB2004K (*)6912JK2002C | (*)6912JB2004K | (*)6912JB2004K (*)6912JK2002C | (*)6912JB2004K | (*)6912JK2004K | CLAMP,[INCANDESCENT] |
| 1005 | | | | | 000414/0001 | |
| 409D 4104 | 3034JA1009A | 3034JA1009A | 3034JA1009A | 3034JA1009A | 3034JA1009A | REFLECTOR,LAMP |
| 410A | 0CZ7JR2003D | 0C77,JR2003B | 0C77,JR2003B | 0C77,JR2014D | 0C77,JR2003D | |
| 410G | (*)0CZZJB2012 | (*)0CZZJB2012 | (*)0CZZJB2012 | (*)0CZZJB2012 | (*)0CZZJB2012 | CAPACITOR, DRAWING |
| 411A | 6411JK1006A | 6411JK1006A | 6411JK1006A | 6411JK1006A | 6411JK1006A | POWERCORDASSEMBLY |
| 420A | 4681JB1029D | 4681JB1029D | 4681JB1029D | 4681JB1029D | 4681JB1029D | MOTORASSEMBLY, REFFAN |
| 500A | 6871JB1423N | 6871JB1423N | 6871JB1423N | 6871JB1423N | 6871JB1423N | PWB(PCB)ASSEMBLY,MAIN |
| 501F | 3551JA2144D | 3551JA2144D | 3551JA2144D | 3551JA2144D | 3551JA2144D | |
| 503D 607A | 4931JA3005B | 4931JA3005B | 4931JA3005B | 4931JA3005B | 4931JA3005B | UAGE,LAIVIP HOLDERASSEMBLY,BRACKET |
| 6104 | | | | | | |
| 610B | 3550JA224/A | 3550JA224/A | 3350JA224/A | 3350JA224/A | 3550JA224/A | UVER, SENSUK SENSOB |
| 610C | 6500JB2002B | 6500JB2002B | 6500JB2002B | 6500JB2002B | 6500JB2002B | SENSOR |
| 610D | 6500JB2001B | 6500JB2001B | 6500JB2001B | 6500JB2001B | 6500JB2001B | SENSOR |
| 624A | 5231JA2006A | 5231JA2006A | 5231JA2006A | 5231JA2006A | 5231JA2006A | FILTERASSEMBLY,WATER |
| 624C | 3550JD1128B | 3550JD1128B | 3550JD1128B | 3550JD1128B | 3550JD1128B | COVER, FILTER |
| 624D | 3550JA2279A | 3550JA2279A | 3550JA2279A | 3550JA2279A | 3550JA2279A | |
| 020A | 5230JA2003A | 5230JA2003A | 5230JA2003A | 5230JA2003A | 5230JA2003A | FILIEK(MECH), MEAD |
| CAUTI | ON: Use the pa | rt number to or | der part, not th | e position num | ber. | |

- 3 -

CASE PARTS

| LOC No. | 77193(ST) | 77196(TI) | 77192(SW) | 77199(WB) | 77194(BI) | Description | |
|---------|-------------|-------------|-------------|-------------|-------------|----------------|--|
| B01 | 4000W4A003A | 4000W4A003A | 4000W4A003A | 4000W4A003A | 4000W4A003A | SCREW, DRAWING | |
| B02 | 1STZJA3004G | 1STZJA3004G | 1STZJA3004D | 1STZJA3004Q | 1STZJA3004J | SCREW, DRAWING | |
| B03 | 1STZJA3004F | 1STZJA3004F | 1STZJA3004F | 1STZJA3004F | 1STZJA3004F | SCREW, DRAWING | |
| B04 | 1BZZJA2002A | 1BZZJA2002A | 1BZZJA2002A | 1BZZJA2002A | 1BZZJA2002A | SCREW, DRAWING | |
| S01 | 4J00415D | 4J00415D | 4J00415D | 4J00415D4 | J00415D | SCREW, DRAWING | |
| S02 | 4J00415D | 4J00415D | 4J00415D | 4J00415D | 4J00415D | SCREW, DRAWING | |
| S03 | 4J01424B | 4J01424B | 4J01424B | 4J01424B | 4J01424B | SCREW, DRAWING | |
| S08 | 1SZZJJ3005E | 1SZZJJ3005E | 1SZZJJ3005E | 1SZZJJ3005E | 1SZZJJ3005E | SCREW, DRAWING | |
| S09 | 4J00415D | 4J00415D | 4J00415D | 4J00415D | 4J00415D | SCREW, DRAWING | |
| S10 | 1SBZJA3004L | 1SBZJA3004L | 1SBZJA3004L | 1SBZJA3004L | 1SBZJA3004L | SCREW, DRAWING | |
| S11 | 3J05696W | 3J05696W | 3J05696W | 3J05696W | 3J05696W | SCREW, DRAWING | |
| S13 | 1SZZJJ3005E | 1SZZJJ3005E | 1SZZJJ3005E | 1SZZJJ3005E | 1SZZJJ3005E | SCREW, DRAWING | |
| S14 | 1SZZJJ3010C | 1SZZJJ3010C | 1SZZJJ3010B | 1SZZJJ3010D | 1SZZJJ3010E | SCREW, DRAWING | |
| S15 | 4000W4A003A | 4000W4A003A | 4000W4A003A | 4000W4A003A | 4000W4A003A | SCREW, DRAWING | |
| S16 | 3J05696W | 3J05696W | 3J05696W | 3J05696W | 3J05696W | SCREW, DRAWING | |
| S17 | 1SZZJA3005H | 1SZZJA3005H | 1SZZJA3005H | 1SZZJA3005H | 1SZZJA3005H | SCREW DRAWING | |
| S18 | 4J00415D | 4J00415D | 4J00415D | 4J00415D | 4J00415D | SCREW DRAWING | |
| S19 | 4J00415D | 4J00415D | 4J00415D | 4J00415D | 4J00415D | SCREW DRAWING | |
| S20 | 1SZZJA3016A | 1SZZJA3016A | 1SZZJA3016A | 1SZZJA3016A | 1SZZJA3016A | SCREW, DRAWING | |

FREEZER PARTS

CAUTION: Use the part number to order part, not the position number.



| 775** | Description | |
|---------------|---|---|
| 5074JA2007A | BANK, ICE | |
| 3390JJ 1 072A | TRAY, DRAWER | |
| 3391JA114G | TRAY ASSEMBLY, DRAWER | |
| 4975JA1040B | GUIDE ASSEMBLY, RAIL | |
| 4975JA1040A | GUIDE ASSEMBLY, RAIL | |
| 4974JJ1031A | GUIDE, DRAWER | |
| 4270JA3009H | BAR | |
| 4470JA2008A | GEAR, ICE | |
| 5006JA2069A | CAP, COVER | |
| | 775** 5074JA2007A 3390JJ 1 072A 3391JA114G 4975JA1040B 4975JA1040A 4974JJ1031A 4270JA3009H 4470JA2008A 5006JA2069A | 775** Description 5074JA2007A BANK, ICE 3390JJ 1 072A TRAY,DRAWER 3391JA114G TRAY ASSEMBLY,DRAWER 4975JA1040B GUIDE ASSEMBLY,RAIL 4975JA1040A GUIDE ASSEMBLY,RAIL 4974JJ1031A GUIDE,DRAWER 4270JA3009H BAR 4470JA2008A GEAR, ICE 5006JA2069A CAP, COVER |

REFRIGERATOR PARTS



REFRIGERATOR PARTS

| LOC No. | 7754* | 7755* | Description | |
|---------|---------------|---------------|-------------------------|--|
| 141A | 5027JJ2014D | 5027JJ2014D | SHELFASSEMBLY,R | |
| 141B | 5026JJ1050B | 5026JJ1050B | SHELF,R | |
| 141C | 5027JJ2012F | 5027JJ2012F | SHELFASSEMBLY,NET | |
| 141D | 4890JL1012A | 4890JL1012A | GLASS,COVER-T/V | |
| 145D | 3391JJ1030A | 3391JJ1030A | TRAYASSEMBLY, FRESHROOM | |
| 145E | 3550JL1010B | 3550JL1010B | COVER, TRAY | |
| 146A | | J469-00030A | BOTTLE.RACK | |
| 146B | 4520JJ1003A | 4520JJ1003A | LINK | |
| 147A | 5074JJ1016A | 5074JJ1016A | BANK.DAIRY | |
| 147B | 3390JJ1082A | 3390JJ1082A | TRAY.EGG | |
| 147C | 3550JJ1084A | 3550JJ1084A | COVER.BANK | |
| 151A | 3391JJ2014B | 3391JJ2014B | TRAYASSEMBLY.VEGETABLE | |
| 151C | 4940JA2026C | 4940JA2026C | KNOB.SHUTTER | |
| 154A | 3550 JI 1016A | 3550 JI 1016A | COVEB T/V | |
| 155.1 | 4940.J.I2009B | 4940.1.12009B | KNOB SHUTTER | |
| 160C | 3551.JJ2021A | 3551.U2021A | COVERASSEMBLY TRAY | |
| 162A | 4975.J.I2016A | 4975.J.I2016A | GUIDEASSEMBLY BAIL | |
| 162B | 4975.J.I2016B | 4975.J.I2016B | GUIDEASSEMBLY BAIL | |
| 167B | 3550.JJ1069A | 3550.JJ1069A | COVER MAGICBOOM | |
| 248H | 4980.1.12014A | 4980.1.12014A | SUPPORTER HOLDER | |
| S13 | 1SZZJJ3005E | 1SZZJJ3005E | SCREW, DRAWING | |

DOOR PARTS

| LOC No. | 775*3 | 775*6 | 775*2 | 775*9 | 775*4 | Description |
|---------|-------------|-------------|-------------|-------------|--------------|-------------------------|
| 200A | 3581JA8820F | 3581JA8820J | 3581JA8820E | 3581JA8820G | 3581JA8820H | DOORASSEMBLY,F |
| 201A | 5433JA8558A | 5433JA8007X | 5433JJ8007R | 5433JA8007U | 5433JA8558C | DOORFOAMASSEMBLY,F |
| 203A | 4987JA2008E | 4987JA2008E | 4987JA2008E | 4987JA2008J | 4987JA2008E | GASKETASSEMBLY,DOOR |
| 205A | 5004JJ1061B | 5004JJ1061B | 5004JJ1061B | 5004JJ1061B | 5004JJ1061B | BASKET,DOOR |
| 205B | 5004JA2017A | 5004JA2017A | 5004JA2017A | 5004JA2017A | 5004JA2017A | BASKET,TILT |
| 205C | 5004JA2017B | 5004JA2017B | 5004JA2017B | 5004JA2017B | 5004JA2017B | BASKET,TILT |
| 212D | 3650JA1234B | 3650JA1234B | 3650JA1234C | 3650JA1234E | 3650JA1234D | HANDLE,F |
| 12G | 3846JD1019A | 3846JD1019A | 3846JD1019A | 3846JD1019A | 3846JD1019A | MARK |
| 230A | 3581JA8807G | 3581JA8807L | 3581JA8807F | 3581JA8807J | 3581JA8807K | DOORASSEMBLY,R/R |
| 230B | 3581JA8808F | 3581JA8808K | 3581JA8808E | 3581JA8808H | 3581JA8808J | DOORASSEMBLY,R/L |
| 31A | 5433JJ0064P | 5433JJ0064L | 5433JJ0064E | 5433JJ0064H | 5433JJ0064R | DOORFOAMASSEMBLY,R |
| 31B | 5433JA8559Q | 5433JA8559L | 5433JA8559C | 5433JA8559A | 5433JA8559S | DOORFOAMASSEMBLY,R |
| 33A | 4987JJ2002A | 4987JJ2002A | 4987JJ2002A | 4987JJ2002C | 4987JJ2002A | GASKETASSEMBLY,DOOR |
| 33B | 4987JJ2002B | 4987JJ2002B | 4987JJ2002B | 4987JJ2002D | 4987JJ2002B | GASKETASSEMBLY,DOOR |
| 33C | 3551JJ2030B | 3551JJ2030B | 3551JJ2030B | 3551JJ2030B | 3551JJ2030B | COVERASSEMBLY, FRONT |
| 33D | 3551JJ2030A | 3551JJ2030A | 3551JJ2030A | 3551JJ2030A | 3551JJ2030A | COVERASSEMBLY, FRONT |
| 37A | 4974JA2055A | 4974JA2055A | 4974JA2055A | 4974JA2055A | 4974JA2055A | GUIDE,BOTTLE |
| 41A | 5004JL1006B | 5004JL1006B | 5004JL1006B | 5004JL1006B | 5004JL1006B | BASKET, WINDOW |
| 41B | 5004JJ1057A | 5004JJ1057A | 5004JJ1057A | 5004JJ1057A | 5004JJ1057A | BASKET,DOOR |
| 41C | 5005JJ2014A | 5005JJ2014A | 5005JJ2014A | 5005JJ2014A | 5005JJ2014A | BASKETASSEMBLY,DOOR |
| 43A | 4620JJ3006D | 4620JJ3006D | 4620JJ3006A | 4620JJ3006C | 4620JJ3006B | STOPPER,DOOR |
| 43B | 4620JJ2009A | 4620JJ2009A | 4620JJ2009A | 4620JJ2009A | 4620JJ2009A | STOPPER.DOOR |
| 44A | 3650JA1235B | 3650JA1235B | 3650JA1235C | 3650JA1235E | 3650JA1235D | HANDLE.R |
| 49A | 5098JJ2002T | 5098JJ2002T | 5098JJ2002T | 5098JJ2002T | 5098JJ2002T | CONNECTORASSEMBLY(MECH) |
| 49B | 5098JJ2002S | 5098JJ2002S | 5098JJ2002S | 5098JJ2002S | 5098JJ2002S | CONNECTORASSEMBLY |
| 49E | 5218JA1010E | 5218JA1010E | 5218JA1010E | 5218JA1010E | 5218JA1010E | BAIL.SLIDE |
| 49F | 5218JA1010F | 5218JA1010F | 5218JA1010F | 5218JA1010F | 5218JA1010F | BAIL.SLIDE |
| 49G | 5098JA2001H | 5098JA2001H | 5098JA2001H | 5098JA2001H | 5098JA2001H | CONNECTORASSEMBLY(MECH) |
| 49H | 5098JA2001G | 5098JA2001G | 5098JA2001G | 5098JA2001G | 5098 JA2001G | CONNECTOBASSEMBLY(MECH) |
| 62C | 4350JA3005B | 4350JA3005B | 4350JA3005B | 4350JA3005B | 4350JA3005B | RING |
| 81C | 4811JJ2015A | 4811JJ2015A | 4811JJ2015A | 4811JJ2015A | 4811JJ2015AB | RACKETASSEMBLY,DOOR |
| 81D | 3550JA2267B | 3550JA2267B | 3550JA2267B | 3550JA2267B | 3550JA2267B | COVER.HINGE |
| 81E | 3550JA2267A | 3550JA2267A | 3550JA2267A | 3550JA2267A | 3550JA2267A | COVER.HINGE |
| B1F | 3550JA2264A | 3550JA2264A | 3550JA2264A | 3550JA2264A | 3550JA2264A | COVER.HINGE |
| 12B | 3550JL1014A | 3550JL1014A | 3550JL1014A | 3550JL1014A | 3550JL1014A | COVER, FRONT |
| 12C | 5006JA3016C | 5006JA3016C | 5006JA3016C | 5006JA3016C | 5006JA3016C | CAP.DUCT |
| 15Ă | 4838JA2002B | 4838JA2002B | 4838JA2002B | 4838JA2002B | 4838JA2002B | TANK.WATER |
| 05 | 4620JJ2010C | 4620JJ2010C | 4620JJ2010C | 4620JJ2010C | 4620JJ2010C | STOPPER.HANDLE |
| 06 | 4620JJ2010C | 4620JJ2010C | 4620JJ2010C | 4620JJ2010C | 4620JJ2010C | STOPPER HANDI F |
| 807 | 1STZJA3001B | 1STZJA3001B | 1STZJA3001B | 1STZJA3001B | 1STZJA3001B | SCREW, DRAWING |
| 25 | 1SZZJA3011D | 1SZZJA3011D | 1SZZJA3011D | 1SZZJA3011D | 1SZZJA3011D | SCREW, DRAWING |
| 626 | J471-00001J | J471-00001J | J471-00001J | J471-00001J | J471-00001J | SCREW, DRAWING |
| 34 | 1SZZJJ3011C | 1SZZJJ3011C | 1SZZJJ3011C | 1SZZJJ3011C | 1SZZJJ3011C | SCREW DRAWING |

DOOR PARTS



DISPENSER PARTS



| LOC No. | 775*3 | 775*6 | 775*2 | 775*9 | 775*4 | Description |
|---------|-------------|-------------|-------------|-------------|-------------|--------------------------|
| 279A | 6871JB1439A | 6871JB1439A | 6871JB1439A | 6871JB1439A | 6871JB1439A | PWB(PCB)ASSEMBLY,DISPLAY |
| 279B | 3550JA1492B | 3550JA1492B | 3550JA1492A | 3550JA1492C | 3550JA1492D | COVER, DISPENSER |
| 279C | 3806JJ2053E | 3806JJ2053E | 3806JJ2053A | 3806JJ2053H | 3806JJ2053D | DECO,DRAIN |
| 290A | 3550JA2280A | 3550JA2280A | 3550JA2280A | 3550JA2280A | 3550JA2280A | COVER,PWB |
| 291A | 4890JD1110B | 4890JD1110B | 4890JD1110B | 4890JD1110B | 4890JD1110B | COVER, DISPLAY |
| 292A | 6871JB2074B | 6871JB2074B | 6871JB2074B | 6871JB2074B | 6871JB2074B | PWB(PCB)ASSEMBLY,DISPLAY |
| 293A | 5021JA3020B | 5021JA3020B | 5021JA3020A | 5021JA3020C | 5021JA3020D | BUTTONASSEMBLY |
| 294A | 4510JA2028A | 4510JA2028A | 4510JA2028A | 4510JA2028A | 4510JA2028A | LEVER, DISPENSER |
| 295A | 6877JB2181A | 6877JB2181A | 6877JB2181A | 6877JB2181A | 6877JB2181A | HARNESS, JOINT |
| 403A | 6600JB3001C | 6600JB3001C | 6600JB3001C | 6600JB3001C | 6600JB3001C | SWITCH, MICRO |
| 616A | 5210JA2012F | 5210JA2012F | 5210JA2012A | 5210JA2012E | 5210JA2012G | TUBE, INJECT |
| S27 | 4J00415D | 4J00415D | 4J00415D | 4J00415D | 4J00415D | SCREW, DRAWING |

