

Compact Propane Lantern

Instructions for use

U.S. Patent D448,518 © 2003 The Coleman Company, Inc. www.coleman.com

IMPORTANT

Read this manual carefully before assembling, using or servicing these lanterns. Keep this manual for future reference. If you have questions about assembly, operation, servicing or repair of these lanterns, please call Coleman at 1-800-835-3278 or TDD: 316-832-8707. In Canada call 1-800-387-6161.





ANSI Z21.73a - CSA 11.1a (2001) Camp Light

Contents

General Safety Information To Set Up To Light To Turn Off To Store Things You Should Know Parts List Warranty

General Safety Information

FOR YOUR SAFETY

If you smell gas:

- 1. Do not attempt to light appliance.
- 2. Extinguish any open flame.
- 3. Disconnect from fuel supply.

FOR YOUR SAFETY

Do not store or use gasoline or other liquids with flammable vapors in the vicinity of this or any other appliance.

A DANGER



• CARBON MONOXIDE HAZARD

- This appliance can produce carbon monoxide which has no odor.
- Using it in an enclosed space can kill you.
- Never use this appliance in an enclosed space such as a camper, tent, car or home.

This manual contains important information about the assembly, operation and maintenance of these propane lanterns. General safety information is presented in these first few pages and is also located throughout the manual. Particular attention should be paid to information accompanied by the safety alert symbol "A DANGER", "A WARNING", "A CAUTION".

Keep this manual for future reference and to educate new users of this product. This manual should be read in conjunction with the labeling on the product.

Safety precautions are essential when any mechanical or propane fueled equipment is involved. These precautions are necessary when using, storing, and servicing. Using this equipment with the respect and caution demanded will reduce the possibilities of personal injury or property damage.

The following symbols are used extensively throughout this manual. Always heed these precautions, as they are essential when using any mechanical or propane-fueled equipment.

General Safety Information continued

A DANGER

DANGER indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury.

AWARNING

WARNING indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.

ACAUTION

CAUTION indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate personal injury, or property damage.

A DANGER

Failure to comply with the precautions and instructions provided with these lanterns can result in death, serious bodily injury and property loss or damage from hazards of fire, explosion, burn, asphyxiation, and/or carbon monoxide poisoning.

Only persons who can understand and follow the instructions should use or service these lanterns.

If you need assistance or information such as an instruction manual or labels, contact the Coleman Co., Inc.

A DANGER



 Never store propane near high heat, open flames, pilot lights, direct sunlight, other ignition sources or where temperatures exceed 120 degrees F (49°C).

• Propane is heavier than air and can accumulate in low places. If you smell gas, leave the area immediately.

 Never install or remove propane tank while lantern is lighted, near flame, pilot lights, other ignition sources or while lantern is hot to touch.

• During operation, this product can be a source of ignition. Never use the lantern in spaces that contain or may contain volatile or airborne combustibles, or products such as gasoline, solvents, paint thinner, dust particles or unknown chemicals. Minimum clearances from combustible materials: 12 inches from the sides and 48 inches from the top.

• Provide adequate clearances around air openings into the combustion chamber.

A WARNING

Not for home or recreational vehicle use.

We cannot foresee every use which may be made of our products. **Check with your local fire safety authority if you have questions about use.** Other standards govern the use of fuel gases and heat producing products for specific uses. Your local authorities can advise you about these.

• Never refill disposable cylinders.

• Use the preset regulator that came with the lantern. Do not attempt to adjust.

• If using refillable propane cylinder, the LP-gas cylinder(s) must be constructed and marked in accordance with the specifications for LP-gas cylinders of the U.S. Department of Transportation or *Transport Canada, CAN/CSA B339.* Use only Coleman[®] accessories or parts. During lantern set-up, check all hoses and fittings for leaks using soapy water. Never use a flame. Always keep refillable cylinders outdoors, never inside house, camper or tent.

A DANGER



• CARBON MONOXIDE HAZARD

• This lantern is a combustion appliance. All combustion appliances produce carbon monoxide (CO) during the combustion process. This product is designed to produce extremely minute, non-hazardous amounts of CO if used and maintained in accordance with all warnings and instructions. Do not block air flow into or out of the lantern.

• Carbon Monoxide (CO) poisoning produces flu-like symptoms, watery eyes, headaches, dizziness, fatigue and possibly death. You can't see it and you can't smell it. It's an invisible killer. If these symptoms are present during operation of this product **get fresh air immediately**!

• For outdoor use only.

• Never use inside house, camper, tent, vehicle or other unventilated or enclosed areas. This lantern consumes air (oxygen). Do not use in unventilated or enclosed areas to avoid endangering your life.

AWARNING

• This product is fueled by propane gas. Propane gas is invisible, odorless, and flammable. An odorant is normally added to help detect leaks and can be described as a "rotten egg" smell. The odorant can fade over time so leaking gas is not always detectable by smell alone.

• Propane gas is heavier than air and leaking propane will sink to the lowest level possible. It can ignite by ignition sources including matches, lighters, sparks or open flames of any kind many feet away from the original leak. Use only propane gas setup for vapor withdrawal.

• Propane gas should be stored or used in compliance with local ordinances and codes or with ANSI/NFPA 58. Turn off propane when not in use.

CALIFORNIA PROPOSITION 65:

WARNING: This fuel, and byproducts of combustion of this fuel, contain chemicals known to the state of California to cause cancer, birth defects, or other reproductive harm.





• BURN HAZARD

- Never leave lantern unattended when hot or in use.
- Keep out of reach of children.

A CAUTION

• SERVICE SAFETY

• Keep all connections and fittings clean. Inspect propane cylinder and lantern propane connections for damage before attaching.

• During setup, CHECK FOR LEAKS in one or more ways: Apply soapy water to connections. Look for bubbles. Listen for hiss of escaping gas. Feel for extreme cold. Smell for rotten egg odor. Never use a flame. Do not use if leaking.

• Use as a lighting appliance only. Never alter in any way or use with any device or part not expressly approved by Coleman.

- Never use as a space heater.
- Always use in upright position. Protect cylinder from excess heat.

To Set Up

A DANGER



• CARBON MONOXIDE HAZARD

• For outdoor use only.

• Never use inside house, camper, tent, vehicle or other unventilated or enclosed areas. This lantern consumes air (oxygen). Do not use in unventilated or enclosed areas to avoid endangering your life.

Take lantern outdoors away from ignition sources.
 Lift COVER.



Remove GLOBE.



■ Install MANTLE. Make sure small hole is at top and larger hole is at bottom. Colored part is up.




■ Make sure MANTLE is properly positioned with top and bottom in grooves of burner.



To Set Up continued

■ Ignite MANTLE.



After mantle has burned, install GLOBE and seat GLOBE in position.






Close COVER.





Attach CHAIN as shown.





A CAUTION

SERVICE SAFETY

 Keep all connections and fittings clean. Inspect propane cylinder and lantern propane connections for damage before attaching.

• During setup, check all connections and fittings for leaks using soapy water. Bubbles indicate a leak. Never use a flame.

WARNING

· Replace any mantle with a hole in it. A hole can cause lantern to overheat and create a hazard.

■ Note: Use Coleman 16.4 oz. disposable propane cylinders. The LP-gas cvlinder(s) used with lanterns must be constructed and marked in accordance with the specifications for LP-gas cylinders of the U.S. Department of Transportation or Transport Canada, CAN/CSA B339.

Use outdoors only. Remove cap from propane cylinder. Save cap for use in storing.



Turn fuel valve OFF.





A DANGER



EXPLOSION - FIRE HAZARD

• Propane is heavier than air and can accumulate in low places. If you smell gas, leave the area immediately.

· Always attach or detach propane source outdoors; never while lantern is lighted, near flame, pilot lights, other ignition sources or while lantern is hot to touch. Always light & use lantern outdoors.

• This lantern must not be exposed to flammable vapors or liquids during lighting.

 This lantern is red hot during use and can ignite flammables too close to the mantles. Keep flammables at least 12 inches from the sides and 48 inches from the top of the lantern. Keep gasoline and other flammable liquids and vapors well away from lantern.

To Light continued

■ Screw propane cylinder into lantern. Take care not to cross thread. Hand tighten only.



Place lantern upright. Burn in upright position only.





Hold lighted match near top of

Brightness may be adjusted with fuel valve.



AWARNING



- Never leave lantern unattended when hot or in use.
- Keep out of reach of children.

To Turn Off

Turn fuel valve off.



To Store

- Make sure lantern is cool.
- Move lantern away from flame (including pilot lights) and other ignition sources.
- Remove propane cylinder from lantern.
- Replace protective cap on propane.





A DANGER



• EXPLOSION - FIRE HAZARD

Never store propane near high heat, open flames, pilot lights, direct sunlight, other ignition sources or where temperatures exceed 120 degrees F (49°C).
Refillable propane tanks must always be stored outdoors in a well ventilated space. Never store propane tank in an enclosed area (house, garage, etc.). If lantern is to be stored indoors, disconnect the propane tank for outdoor storage.

Things You Should Know

1. It is unsafe and illegal in some places to store or use liquid propane cylinders of greater than 1.14 kg (2.5 lbs.) water capacity (approximately 465g [1 lb.] propane) in occupied enclosures.

2. Always have a spare set of Coleman $^{\circ}$ Mantles. Once burned, a mantle is fragile and can be damaged if touched or dropped.

The usual storage areas for camping and picnic equipment are the basement, attic, or garage. To avoid the accumulation of dust, cobwebs, etc., that is common in these storage areas, place your lantern in a plastic bag and seal it with a rubber band.
 During operation, carry the lantern using the chain.

5. If your lantern burns with a yellow smokey flame, check the burner and air tube for spider webs.

6. For repair service call one of the numbers listed on the front cover for location of your nearest Coleman Service Center. If lantern must be mailed to Service Center, attach to the product a tag that includes your name, address, daytime telephone number and a description of problem. Remove globe and ventilator to prevent breakage. Do NOT send propane cylinder. Carefully package the product and send either by UPS or Parcel Post **insured** with shipping and **insurance** prepaid to:

For products purchased in the United States:

The Coleman Company, Inc. 3600 North Hydraulic Wichita, KS 67219

For products purchased in Canada:

Sunbeam Corporation (Canada) Limited 5975 Falbourne Street Mississauga, Ontario Canada L5R 3V8

7. If not completely satisfied with the performance of this product, please call one of the numbers listed on the cover of this manual.

Parts List

No.

2

3

4

5

6

Part No.	Description
R132-043C	Globe
5132-1381	Chain
5132-6151	Lantern Top Assembly
5132-6711	Collar Assembly (left/right) & screw
5132-5251	Regulator Valve Assy.
9950-1491	Control Knob & screw
#51	
	3
	4
	(6)

Limited Lifetime Warranty

The Coleman Company, Inc. ("Coleman") warrants that for the period that you own this product, it will be free from defects in material and workmanship. Coleman, at its option, will repair or replace this product or any component of the product found to be defective during the warranty period. Replacement will be made with a new or remanufactured product or component. If the product is no longer available, replacement may be made with a similar product of equal or greater value. This is your exclusive warranty.

This warranty is valid for the original retail purchaser from the date of initial retail purchase and is not transferable. Keep the original sales receipt. Proof of purchase is required to obtain warranty performance. Coleman dealers, service centers, or retail stores selling Coleman products do not have the right to alter, modify or in any way change the terms and conditions of this warranty.

This warranty does not cover normal wear of parts or damage resulting from any of the following: negligent use or misuse of the product, use on improper voltage or current, use contrary to the operating instructions, disassembly, repair or alteration by anyone other than Coleman or an authorized service center. Further, the warranty does not cover Acts of God, such as fire, flood, hurricanes and tornadoes.

Coleman shall not be liable for any incidental or consequential damages caused by the breach of any express or implied warranty or conditions. Except to the extent prohibited by applicable law, any implied warranty of merchantability or fitness for a particular purpose is limited in duration to the duration of the above warranty or conditions. Some states, provinces or jurisdictions do not allow the exclusion or limitation of incidental or consequential damages or limitations on how long an implied warranty gives you specific legal rights, and you may also have other rights that vary from state to state or province to province.

How to Obtain Warranty Service

Take the product to an authorized Coleman service center. You can find the nearest authorized Coleman service center by calling 1-800-835-3278 or TDD 316-832-8707 in the United States or 1 800 387-6161 in Canada. If a service center is not conveniently located, attach to the product a tag that includes your name, address, daytime telephone number and description of the problem. Include a copy of the original sales receipt. Carefully package the product and send either by UPS or Parcel Post **insured** with shipping and **insurance** prepaid to:

For products purchased in the United States:

The Coleman Company, Inc. 3600 North Hydraulic Wichita, KS 67219

For products purchased in Canada:

Sunbeam Corporation (Canada) Limited 5975 Falbourne Street Mississauga, Ontario Canada L5R 3V8

Do not mail products with fuel in tanks, or with disposable propane cylinders. Remove glass globes from lanterns and wrap separately. DO NOT RETURN THIS PRODUCT TO THE PLACE OF PURCHASE. If you have any questions regarding this warranty please call 1-800-835-3278 or TDD 316-832-8707 in the United States or 1 800 387-6161 in Canada.



The Coleman Co., Inc. • 3600 N. Hydraulic • Wichita, KS 67219 U.S.A. 1-800-835-3278 • TDD: 316-832-8707

Sunbeam Corporation (Canada) Limited • 5975 Falbourne Street Mississauga, Ontario, Canada L5R 3V8 • 1 800 387-6161

©2003 The Coleman Company, Inc. All rights reserved. Coleman® is a registered trademark of The Coleman Company, Inc.

©2003 The Coleman Company, Inc. Tous droits réservés. Coleman® est une marque déposée de The Coleman Company, Inc.

©2003 The Coleman Company, Inc. Derechos Reservados Coleman® es una marca registrada de la Compañia Coleman, Inc.