

This Owner's Manual is provided and hosted by [Appliance Factory Parts](#).




# HAMILTON BEACH 52655 Owner's Manual

[Shop genuine replacement parts for HAMILTON  
BEACH 52655](#)



[Find Your HAMILTON BEACH Small Appliance Parts - Select From 252 Models](#)

----- Manual continues below -----



**READ BEFORE USE**  
**LIRE AVANT D'UTILISER**  
**LEA ANTES DE USAR**

Visit **hamiltonbeach.com** for  
delicious recipes and to register  
your product online!



Consulter **hamiltonbeach.ca** pour les  
recettes délicieuses et pour enregistrer  
votre produit!

Visite **hamiltonbeach.com.mx** para  
recetas deliciosas y para registro de  
su producto en línea.

**Questions?**  
Please call us – our friendly  
associates are ready to help.

**USA: 1.800.851.8900**

**CAN: 1.800.267.2826**

**MEX: 01 800 71 16 100**

*Le invitamos a leer cuidadosamente  
este instructivo antes de usar su  
aparato.*



**Hamilton**

**E**

**E**


**M**


**L**

English

Français

Español






## IMPORTANT SAFEGUARDS

When using electrical appliances, basic safety precautions should always be followed, including the following:

1. Read all instructions.
2. To protect against risk of electrical shock, do not put cord, plug, or base in water or other liquid.
3. Close supervision is necessary when any appliance is used by or near children.
4. Unplug cord from outlet when not in use, before putting on or taking off parts, and before cleaning.
5. Avoid contacting moving parts.
6. Do not operate any appliance with a damaged cord or plug, or after appliance malfunctions, or is dropped or damaged in any manner. Call our toll-free customer service number for information on examination, repair or electrical or mechanical adjustment.
7. The use of attachments, including canning jars, not recommended or sold by the appliance manufacturer may cause a risk of injury to persons.
8. Do not use outdoors.
9. Do not let cord hang over edge of table or counter, or touch hot surfaces, including the stove.
10. Keep hands and utensils out of jar while blending to reduce the risk of severe injury to persons or damage to the blender. A rubber spatula may be used but must be used only when blender is not running.
11. Blades are sharp; handle carefully—especially when disassembling or cleaning inside blender jar.
12. Do not use a broken, chipped, or cracked blade.
13. Do not use broken, cracked, or loose cutting blades.
14. To reduce the risk of injury, never place cutting blades on base without jar properly attached.
15. Always operate blender with lid in place.
16. When blending hot liquids, remove center-piece from lid. Hot liquids may push lid off jar during blending. To prevent possible burns: do not fill blender jar beyond 750 ml level. With the protection of an oven mitt or towel, place one hand on top of lid. Keep eyes and face away from lid. Start blending at lowest speed.
17. Do not leave blender unattended while it is operating.
18. To disconnect cord, turn the control to OFF (0) and unplug from wall outlet.
19. Do not use appliance for other than intended purposes.

## SAVE THESE INSTRUCTIONS!



## OTHER CONSUMER SAFETY INFORMATION

**This appliance is intended for household use only. Use for food or liquids only.**

**WARNING!** Shock Hazard: This appliance has a polarized plug (one wide blade) that reduces the risk of electric shock. The plug fits only one way into a polarized outlet. Do not defeat the safety purpose of the plug by modifying the plug in any way or using an adaptor. If the plug does not fit, reverse the plug. If it still does not fit, have an electrician replace the outlet.

The length of the cord used on this appliance will help to reduce the hazards of becoming tangled in, or tripped over, a longer cord. If a longer cord is necessary, an approved extension cord may be used. The electrical rating of the extension cord must be equal to or greater than the rating of the appliance. Care must be taken to arrange the extension cord so it does not drape over the countertop or tabletop where it could be reached by children or accidentally tripped over.

Do not place blender jar in the freezer filled with liquid. The contents may freeze and may result in damage to the cutting blades, jar, blender and possibly result in injury. If cutting blades lock and do not move, it will draw excessive power. Do not use. Call the toll-free customer service number for more information.

### Wattage/Peak Power Information

The wattage/ampere rating of the blender is determined by an Underwriter's Laboratory test. These tests are based on available cutting blades and jar combinations that may not be provided with your unit. This is a measure of input wattage/amperes after 30 seconds of operation.

Peak power is the measure of the motor wattage during the first seconds of operation. This is when a blender requires the most power to crush ice, frozen fruit, etc. This is a better measure of what a blender motor can consume when power is needed most. The blender as provided may draw significantly less power.


### Optional Accessory

Hamilton Beach Stay or Go™ Personal Blending Jar may be purchased separately and used with this appliance.


**NOTE:** This accessory is intended for use with certain Hamilton Beach blender types. Blender type may vary from the bottom of your blender.

TYPE OF BLENDING JAR PROVIDED WITH YOUR BLENDER	BLENDERS THAT COME WITH STAY OR GO BLENDING JAR
Plastic Jar	B40, B48
Glass Jar	B29, B36, B39, B42
Either Plastic or Glass	B12, B20, B23, B30


# Choose Your Blender



**Types: B46 with glass jar,  
B20, B23, B30,**



**Type: B46 with plastic jar**




**Type: B33 with plastic jar**



**Types: B33  
B29**







**Blender type can be found on the bottom of the blender carton or on the bottom of the blender base.**




# Using Your Blender

**Before First Use:** Wash all parts in hot, soapy water. Dry thoroughly.


**Types: B46 with glass jar, B20, B23, B30,**












# Using Your Blender

**Before First Use:** Wash all parts in hot, soapy water. Dry thoroughly.




## Type: B46 with plastic jar








# Using Your Blender

**Before First Use:** Wash all parts in hot, soapy water. Dry thoroughly.




## Type: B33 with plastic jar








# Using Your Blender

**Before First Use:** Wash all parts in hot, soapy water. Dry thoroughly.



**Types: B33 with glass jar, B12, B29, B45, B49**







# Cleaning Your Blender


**⚠ WARNING**

**Electrical Shock Hazard.**



Disconnect power before cleaning.  
Do not immerse cord, plug or base in a




Carefully wash blades in hot, soapy water. Rinse and dry thoroughly. Do not soak.



Wipe blender base, control panel, and cord with a damp cloth or sponge. To remove stubborn spots, use a mild, non-abrasive cleanser.





# Troubleshooting

PROBLEM	PROBABLE CAUSE/SOLUTION
Blender leaks.	<ul style="list-style-type: none"> <li>• Tighten collar on jar.</li> <li>• Make sure lid with filler cap is pushed down tightly on jar.</li> <li>• For units with separate gasket, make sure gasket is in place on cutter assembly.</li> </ul>
Does not blend well.	<ul style="list-style-type: none"> <li>• Make sure enough liquid has been added. A minimum of 8 ounces (250 ml) is recommended.</li> <li>• Do not try to mash potatoes, mix stiff dough, whip egg whites, grind raw meat, or extract juices from fruits and vegetables. The blender is not made to perform these tasks.</li> <li>• If mixture is too thick, continue to add liquid until mixture is blended to desired consistency.</li> </ul>
Cannot remove base.	<ul style="list-style-type: none"> <li>• Loosen collar by holding jar and turning collar counterclockwise.</li> </ul>

## Blending Tips

### Crushing Ice

For best performance, when a recipe calls for liquid, place the liquid in blender jar followed by the ice cubes. Ensure ice cubes are separated. When only crushed ice is desired, add 1 cup (250 ml) of ice cubes to jar. Place lid on blender jar then Pulse on any of the 5 pulse speeds. Allow blades to come to a complete stop between pulses. Continue until ice is crushed to desired consistency. For best results always crush ice immediately after removing from freezer.

### General

To add foods when blender is operating, remove filler cap from container lid and add ingredients through the opening. Do not store food or liquids in the blender jar.

10

## Optional Accessories

Hamilton Beach Stay or Go™ Personal Blender (AC16) may be purchased separately for this appliance.


### To Order Call:


**1.800.851.8900 (U.S.)**

**1.800.267.2826 (Canada)**

**01.800.71.16.100 (Mexico)**





**or visit [hamiltonbeach.com](http://hamiltonbeach.com)**






# Single Serving Smoothie Recipe

**NOTE:** Recipe can be doubled.





# Warranty

## LIMITED WARRANTY

**This warranty applies to products purchased in the U.S. or Canada.**

This product is warranted to be free from defects in material and workmanship for a period of three (3) years from the date of purchase, except as noted below. During this period, we will repair or replace this product at our option. THE FOREGOING WARRANTY IS IN LIEU OF ANY OTHER WARRANTY OR CONDITION, WHETHER EXPRESS OR IMPLIED, WRITTEN OR ORAL INCLUDING ANY STATUTORY WARRANTY OR CONDITION OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. LIABILITY IS EXPRESSLY LIMITED TO AN AMOUNT EQUAL TO THE PURCHASE PRICE PAID, AND ALL CLAIMS FOR SPECIAL AND CONSEQUENTIAL DAMAGES ARE HEREBY EXCLUDED. There is no warranty with respect to the following, which may include this product, including without limitation: glass parts, glass containers, cutter/strainers, blades, seals, gaskets, clutches, motor agitators, etc. This warranty extends only to the original consumer purchaser and does not cover a defect resulting from abuse or neglect including failure to clean product regularly in accordance with manufacturer's instructions, use for commercial purposes, or use not in conformity with the printed directions. This warranty gives you specific legal rights, and you may also have other legal rights from state to state, or province to province. Some states or provinces do not allow limitations on implied warranties or special consequential damages, so the foregoing limitations may not apply to you.

If you have a claim under this warranty, DO NOT RETURN THE APPLIANCE TO THE STORE! Please call our CUSTOMER SERVICE (For faster service please have model, series, and type numbers ready for operator to assist you.)

### CUSTOMER SERVICE NUMBERS

In the U.S. 1-800-851-8900

In Canada 1-800-267-2826

In Mexico 01-800-71-16-100

[hamiltonbeach.com](http://hamiltonbeach.com)

**KEEP THESE NUMBERS FOR FUTURE REFERENCE!**

