



LG

website: <http://www.LGEservice.com>
E-mail: <http://www.LGEservice.com/techsup.html>

MICROWAVE OVEN SERVICE MANUAL

MODEL: MV-154SJ

MV-1511M = mv153XD = ABIEGSC

CAUTION

BEFORE SERVICING THE UNIT, READ THE
SAFETY PRECAUTIONS IN THIS MANUAL.

CAUTION

SAFETY PRECAUTIONS

PRECAUTIONS TO BE OBSERVED BEFORE AND DURING SERVICING TO AVOID POSSIBLE EXPOSURE TO EXCESSIVE MICROWAVE ENERGY

- a. Do not operate or allow the oven to be operated with the door open.
 - b. Make the following safety checks on all ovens to be serviced before activating the magnetron or other microwave source, and make repairs as necessary; (1) Interlock operation, (2) proper door closing, (3) seal and sealing surfaces (arching, wear, and other damage), (4) damage to or loosening of hinges and latches, (5) evidence of dropping or abuse.
 - c. Before turning on microwave power for any service test or inspection within the microwave generating compartments, check the magnetron, wave guide or transmission line, and cavity for proper alignment, integrity, and connections.
 - d. Any defective or misadjusted components in the interlock, monitor, door seal, and microwave generation and transmission systems shall be repaired, replaced, or adjusted by procedures described in this manual before the oven is released to the owner.
 - e. A Microwave leakage check to verify compliance with the CSA Standard should be performed on each oven prior to release to the owner.
- Proper operation of the microwave ovens requires that the magnetron be assembled to the wave guide and cavity. Never operate the magnetron unless it is properly installed.
 - Be sure that the magnetron gasket is properly installed around the dome of the tube whenever installing the magnetron.
 - Routine service safety procedures should be exercised at all times.
 - Untrained personnel should not attempt service without a thorough review of the test procedures and safety information contained in this manual.

CAUTION

SAFETY PRECAUTIONS

PRECAUTIONS TO BE OBSERVED BEFORE AND DURING SERVICING TO AVOID POSSIBLE EXPOSURE TO EXCESSIVE MICROWAVE ENERGY

- a. Do not operate or allow the oven to be operated with the door open.
- b. Make the following safety checks on all ovens to be serviced before activating the magnetron or other microwave source, and make repairs as necessary; (1) Interlock operation, (2) proper door closing, (3) seal and sealing surfaces (arching, wear, and other damage), (4) damage to or loosening of hinges and latches, (5) evidence of dropping or abuse.
- c. Before turning on microwave power for any service test or inspection within the microwave generating compartments, check the magnetron, wave guide or transmission line, and cavity for proper alignment, integrity, and connections.
- d. Any defective or misadjusted components in the interlock, monitor, door seal, and microwave generation and transmission systems shall be repaired, replaced, or adjusted by procedures described in this manual before the oven is released to the owner.
- e. A Microwave leakage check to verify compliance with the CSA Standard should be performed on each oven prior to release to the owner.
 - Proper operation of the microwave ovens requires that the magnetron be assembled to the wave guide and cavity. Never operate the magnetron unless it is properly installed.
 - Be sure that the magnetron gasket is properly installed around the dome of the tube whenever installing the magnetron.
 - Routine service safety procedures should be exercised at all times.
 - Untrained personnel should not attempt service without a thorough review of the test procedures and safety information contained in this manual.

FOREWORD

Read this Manual carefully. Failure to adhere to or observe the information in this Manual may result in exposing yourself to the Microwave Energy normally contained within the oven cavity.

TABLE OF CONTENTS

| | (Page) |
|---|-------------------|
| SAFETY PRECAUTIONS | Inside front page |
| SPECIFICATIONS | 1-1 |
| CAUTIONS | 2-1 |
| INSTALLATIONS | 3-1 |
| OPERATING INSTRUCTIONS | 4-1 |
| CONTROL PANEL | 4-1 |
| CONTROL PANEL INSTRUCTIONS | 4-2 |
| OVERALL CIRCUIT DIAGRAM | 5-1 |
| SCHEMATIC DIAGRAM | 5-1 |
| MATRIX CIRCUIT FOR TOUCH KEY BOARD | 5-2 |
| GENERAL INFORMATION FOR SERVICE | 6-1 |
| GENERAL PRECAUTIONS IN USE | 6-1 |
| TRIAL OPERATION | 6-1 |
| FEATURES AND SPECIFICATIONS FEATURES | 6-1 |
| SERVICE INFORMATION | 7-1 |
| PRECAUTIONS AND REPAIR SERVICE TIPS | 7-1 |
| MICROWAVE LEAKAGE TEST | 7-2 |
| POWER OUTPUT MEASUREMENT | 7-3 |
| DISASSEMBLY INSTRUCTIONS | 7-4 |
| INTERLOCK SYSTEM | 7-12 |
| INTERLOCK CONTINUITY TEST | 7-14 |
| TEST AND CHECKOUT PROCEDURES AND TROUBLE SHOOTING | 7-15 |
| A. TEST PROCEDURES | 7-15 |
| B. CHECKOUT PROCEDURES | 7-18 |
| C. TROUBLE SHOOTING | 7-21 |
| EXPLODED VIEW | 8-1 |
| REPLACEMENT PARTS LIST | 8-8 |
| SCHEMATIC DIAGRAM OF PCB | 8-12 |
| PRINTED CIRCUIT BOARD | 8-13 |
| PCB PARTS LIST | 8-14 |


SPECIFICATIONS

| | |
|---|--|
| Rated Power Consumption | 1,400W maximum (Microwave oven only) 1,500W maximum (Microwave oven+Cook top lamps+Ventilation fan) |
| Microwave Output | 1000W (IEC 705 TEST PROCEDURE) Adjustable 100W through 1000W, 10 steps |
| Frequency | 2,450 MHz ± 50 MHz |
| Power Supply | 120 VAC, 60 Hz |
| Rated Current | 13 Amp. (Microwave oven only) 14 Amp. (Microwave oven+Cook top lamps+Ventilation fan) |
| Magnetron Cooling | Forced Air Cooling |
| Rectification | Rectification Voltage Double Half-Wave |
| Door Sealing | Choke System |
| Safety Devices | Magnetron Thermostat: Open at 150°C±7°C (302°F±44°F), short at 60°C±15°C (140°F±59°F) Oven Cavity Thermostat: Open at 110°C±5°C (230°F±41°F), short at 0°C (32°F) Fuse(20A) Primary Interlock Switch Secondary Interlock Switch Interlock Monitor 2M246-310GF or 2M248E Capacitor: 1.0µF, 2.1 KV AC Diode; 350mA, 9.0 KV 125 V, 30 W 125 V, 30 W or 40 W Digital, up to 99 min. 99 sec. (in each cooking stage) Tempered Safety Glass ²⁹ ₁₅ / ₁₆ "(W)x ¹⁶ / ₁₆ "(D)x ¹⁵ / ₈ "(H) ¹⁹ / ₈ "(W)x ¹⁴ ₅ / ₃₂ "(D)x ⁸ ₁₅ / ₁₆ "(H) 1.5 Cu.ft. Owner's Manual & Cooking Guide, Installation Manual, Exhaust Adapter, Exhaust Damper, Mounting Kit and Two Filters, Rotating Ring Assembly. |
| Magnetron | 2M246-310GF or 2M248E |
| High Voltage Capacitor | Capacitor: 1.0µF, 2.1 KV AC |
| High Voltage Diode | Diode; 350mA, 9.0 KV |
| Cook top Lamp | 125 V, 30 W |
| Cavity Lamp | 125 V, 30 W or 40 W |
| Timer | Digital, up to 99 min. 99 sec. (in each cooking stage) |
| Tray | Tempered Safety Glass |
| Overall Dimensions | ²⁹ ₁₅ / ₁₆ "(W)x ¹⁶ / ₁₆ "(D)x ¹⁵ / ₈ "(H) |
| Oven Cavity Size | ¹⁹ / ₈ "(W)x ¹⁴ ₅ / ₃₂ "(D)x ⁸ ₁₅ / ₁₆ "(H) |
| Effective Capacity of Oven Cavity | 1.5 Cu.ft. |
| Accessories | Owner's Manual & Cooking Guide, Installation Manual, Exhaust Adapter, Exhaust Damper, Mounting Kit and Two Filters, Rotating Ring Assembly. |

CAUTIONS

Unlike other appliances, the microwave oven is high-voltage and high-current equipment. Though it is free from danger in ordinary use, extreme care should be taken during repair.

- DO NOT operate on a 2-wire extension cord during repair and use.
- NEVER TOUCH any oven components or wiring during operation.
- BEFORE TOUCHING any parts of the oven, always remove the power plug from the outlet.
- For about 30 seconds after the oven stops, an electric charge remains in the high voltage capacitor. When replacing or checking, you must discharge the high voltage capacitor by shorting across the two terminals with an insulated screwdriver.




- Remove your watches whenever working close to or replacing the Magnetron.
- DO NOT touch any parts of the control panel circuit. A resulting static electric discharge may damage this P.C.B.
- NEVER operate the oven with no load.
- NEVER injure the door seal and front plate of the oven cavity.
- NEVER put iron tools on the magnetron.
- NEVER put anything into the latch hole and the interlock switches area.

MICROWAVE RADIATION

Personnel should not be exposed to the microwave energy which may radiate from the magnetron or other microwave generating device if it is improperly used or connection. All input and output microwave connections, waveguide, flange, and gasket must be secure never operate the device without a microwave energy absorbing load attached. Never look into an open waveguide or antenna while the device is energized.

- Proper operation of the microwave oven requires that the magnetron be assembled to the waveguide and cavity. Never operate the magnetron unless it is properly installed.
- Be sure that the magnetron gasket is properly installed around the dome of the tube whenever installing the magnetron.



**THE OVEN IS TO BE SERVICED ONLY
BY PROPERLY QUALIFIED SERVICE
PERSONNEL.**

INSTALLATIONS

BEFORE YOU BEGIN, READ THE FOLLOWING INSTRUCTIONS COMPLETELY AND CAREFULLY.

PRECAUTIONS ON INSTALLATION

- A. Plug the power supply cord into a 120V AC, 60Hz, single-phase power source with a capacity of 15A or 20A.
- B. Avoid placing the unit in a location where there is direct heat or splashing water.
- C. Install the unit on the mounting plate firmly.
- D. Place the unit as far away as possible from TV, radio, etc. to prevent interference.

GROUNDING INSTRUCTIONS

For personal safety, this appliance must be fully grounded at all times.

In the event of an electrical short circuit, grounding reduces the risk of electrical shock.

The plug must be plugged into an outlet that is properly installed and grounded.

CAUTION

This unit is equipped with a 3-prong plug for your safety. If the wall outlet is a grounded 3-hole type, the unit will be grounded automatically.

Plug with Ground Prong



Properly Polarized and Grounded Outlet


WARNING

Improper use of the grounding plug can result in a risk of electric shock.

Do not, under any circumstances, cut or remove the third ground prong from the power cord plug.

OPERATING INSTRUCTIONS

CONTROL PANEL



CONTROL PANEL INSTRUCTIONS

The entire operation is done by simple touch control pads.

(1) Display Window

Numbers and letters are shown in the display window (Vacuum Fluorescent Tube). Each Indicator Light shows which function is set and involved in the course of cooking by turning itself on. Indicator Lights automatically go out upon completion of cooking.

(2) POWER LEVEL Key

Used to select cooking power level.

(3) EZ ON Key

Used to cook for one minute at 100% power level. It can be used to extend cooking time in multiples of one minute up to 99 minutes.

(4) CLOCK(TIME OF DAY) Key

Used in setting Time of Day.

(5) STOP/CLEAR Key

Used to stop the oven or clear all entries except Time of Day.

(6) START Key

Touch the START key after setting the desired cooking times etc. Also touch the START key to resume cooking after the cooking is temporarily stopped by opening the door. The key will not function unless the door is closed.

(7) AUTO DEFROST Key
Used to defrost for frozen foods by weight.

(8) AUTO COOK & REHEAT Key

Used to cook the preprogrammed food automatically.

(9) KITCHEN TIMER Key

Used to set the timer.

(10) CUSTOM SET Key

Touch this pad to change the oven's default setting for sound, clock, display speed, defrost weight, and demo mode operations.

(11) VENT HI-LOW-OFF Key

Touch FAN once for HIGH fan speed, twice for low fan speed, or three times to turn the fan off.

(12) LIGHT HI-LOW-OFF Key




Touch LIGHT once for bright light, twice for the night light, or three times to turn the light off.

OVERALL CIRCUIT DIAGRAM

SCHEMATIC DIAGRAM

*Note

1. DOOR OPENED & COOK OFF MODE.
2. BLUE MARK ON LAMP SOCKET MUST BE CONNECTED TO LIVE PART(BLACK WIRE).
3. ONLY CERTAIN MODELS USE THE ABSOLUTE HUMIDITY SENSOR.



| SYMBOL | COLOR |
|--------|-------|
| WH | WHITE |
| BK | BLACK |
| RD | RED |
| YL | PINK |
| PK | BLUE |
| BL | BROWN |
| BR | GREEN |
| GY | GREY |

MATRIX CIRCUIT FOR TOUCH KEY BOARD

| | 1 | 2 | 3 | 4 | 5 | 6 | 7 |
|----|--------------------|----------------|--------|---------|------------------|-----|-----|
| 8 | FAN HI/LO/OFF | HELP | COOK | POPCORN | TIME COOK | 5 | 0 |
| 9 | LIGHT HI/LO/OFF | CUSTOM SET | REHEAT | POTATO | AUTO DEFROST | 6 | 1 |
| 10 | N.C | CLOCK | EZON | N.C | KITCHEN TIMER | 7 | 2 |
| 11 | N.C | N.C | N.C | N.C | POWER | 8 | 3 |
| 12 | N.C | STOP/ CLEAR | START | N.C | HOLD WARM | 9 | 4 |
| 13 | N.C | N.C | N.C | N.C | N.C | N.C | N.C |

GENERAL INFORMATION FOR SERVICE

GENERAL PRECAUTIONS IN USE

- A. **Never operate the unit when it is empty.**
Operating the oven with no load may shorten the life of the magnetron. Whenever cooking dry foods (dried fish, bread, etc.) or a small amount of food, be sure to put a glass of water into the cooking compartment. The glass turntable may become hot after operating, be careful when touching it.
- B. Aluminum foil should be avoided because it will disrupt cooking and may cause arcing. However, small pieces may be used to cover some parts of food to slow the cooking. Any aluminum foil used should never be closer than 2.5 cm to any side wall of the oven.

- (1) Primary interlock switch
- (2) Secondary interlock switch
- (3) Interlock monitor switch
- (4) Choke system
- (5) Magnetron thermostat
- (6) Oven cavity thermostat

(Note: This thermostat located on the oven cavity will open and stop the unit from operation only if a high temperature is reached, such as, a fire created by overcooking food.)

- B. Any one of 10 power output levels ranging 100W to 1000W can be selected by the touch control and electronic computer system.

TRIAL OPERATION

After installation, the following sequences and results should be checked carefully.

- A. Put a container filled with water (about 1 liter) into the oven, and close the door tightly.
- B. Set cooking time for 10 minutes by touching "1" and then "0" three times. "1, 0, 0, 0" appears in the display window.
- C. Touch the START key.
Make sure the cavity light comes on. The unit will begin cooking and the display window will show the time counting down by seconds.
- D. After about 5 minutes, make sure the primary interlock switch, the secondary interlock switch and the interlock monitor switch operate properly by opening and closing the door several times. Touch the START key each time the door is closed.
- E. Continue operating the unit. Two short and a long beep sound signal is heard when the time is up. The unit will shut off automatically.
- F. Confirm the water is hot.
- G. Finally, measure the output power according to "POWER OUTPUT MEASUREMENT" on page 7-3.


FEATURES AND SPECIFICATIONS

FEATURES


- A. The safety systems incorporated in this model are:

EXPLODED VIEW


DOOR PARTS




CONTROLLER PARTS




OVEN CAVITY PARTS




LATCH BOARD PARTS




INTERIOR PARTS (I)




INTERIOR PARTS (II)





INSTALLATION PARTS



SCHEMATIC DIAGRAM OF P.C.B



PRINTED CIRCUIT BOARD



DESIGNED BY J.H.JE
1998.12.26.

| Model No. | Loc No. | C/Part No | Description | Spec | Alternate |
|-----------|---------|-------------|--------------------------|-----------------------|-----------|
| MV-1511M | *01 | 3828W5A1558 | MANUAL,[OWNERS]MWO | MV-153XD LGECI EN | |
| MV-1511M | *02 | 3828W5S1502 | MANUAL,[SERVICE] | MV-153XD LGECI EN | |
| MV-1511M | *03 | 3878W5B0004 | COOK BOOK | A4 MV-1340 LGECI EN | |
| MV-1511M | *10 | 3890W3Y096B | BOX,[YELLOW] | MV-153XD MV-1511M | |
| MV-1511M | 13213A | 3213W1A035H | DOOR FRAME ASSY | MV-1560_BLACK(P.C) | |
| MV-1511M | 13536A | 3536WRA001R | SEAL TAPE | - 443* 186MM R2 MV- | |
| MV-1511M | 13552A | 3552W1A032B | CHOKE COVER | MV-1520,BK | |
| MV-1511M | 13581A | 3581W1A160Q | DOOR ASSY | MV-153XD LGECI BL/ | |
| MV-1511M | 13650A | 3650W1A026B | HANDLE | MV-1520,BK | |
| MV-1511M | 13720D | 3720W0D107B | PANEL,[DOOR] | MV-1520,LGEUS,BK | |
| MV-1511M | 14026A | 4026W2A015A | LATCH | POM,BLACK,MB-359C | |
| MV-1511M | 14890C | 4890W1D042V | GLASS | 523.1* 278.2MM T3.2 I | |
| MV-1511M | 14970A | 4970WRA001E | SPRING | 1.4CU.FT PULL-OUT | |
| MV-1511M | 23572A | 3572W1A141B | CONTROL PANEL | MV-1520,LGEUS,BK | |
| MV-1511M | 24781M | 4781W1M250K | CONTROLLER ASSY,[MICOM] | MV-153XD LGECI BL/ | |
| MV-1511M | 24810P | 4810W1G061A | BRACKET,[CONTROL PANEL] | MV-1520 | |
| MV-1511M | 26638A | 6638W2A360B | KEY MEMBRANE | MV-153XD LGECI BL/ | |
| MV-1511M | 268711 | 6871W2S090N | PWB(PCB) ASSY,[MAIN | P2-8090 MV-153XD T/ | |
| MV-1511M | 33052M | 3052W3M016A | CANOPY,[MICA] | MICA T0.5 92MM 110I | |
| MV-1511M | 33112U | 3112W1U016F | OUT CASE,[U-BENDING] | VCM BLACK 1.5CU.F | |
| MV-1511M | 33390G | 1B71961E | TRAY,[GLASS] | DIA. 324MM 1150G 6. | |
| MV-1511M | 33530A | 3530W0A003B | GRILLE,[VENT GRILL] | MV-1520,BK | |
| MV-1511M | 33531A | 3531W1A005B | GRILLE ASSY | MV-1560T,LGEUS,BK | |
| MV-1511M | 33550P | 3550W3A084A | COVER,[POWER CORD COVER | SECC MATERIAL MV- | |
| MV-1511M | 340511 | 4051W3A001A | RIVET ASSY | MV-1320,PP | |
| MV-1511M | 34370T | 3B72373D | SHAFT,[TURN TABLE SHAFT] | TEFLON WHITE T7.5 | |
| MV-1511M | 34810Q | 4810W3G062A | BRACKET,[MOUNT] | MV-1120 | |
| MV-1511M | 34810R | 4810W3G100A | BRACKET,[COOKTOP] | MV-1320,C/TOP LAMP | |
| MV-1511M | 34890C | 4890W4A001B | GLASS | MV-1320M | |
| MV-1511M | 34960A | 4960W2G022B | MOUNT | MV-1560T | |
| MV-1511M | 35230A | 2B72705B | FILTER(MECH),[GREASE] | 7.638*5.1*0.085 | |
| MV-1511M | 35889A | 5889W2A012A | ROTATING RING ASSY | D 254 H14 PPS(R-7) E | |
| MV-1511M | 36549S | 2B72754K | MOTOR(CIRC),SYNCHRONOUS | 120V 60HZ SHINIL FR | |
| MV-1511M | 36549V | 6549W1V001J | MOTOR(CIRC),VENTILATION | MV-1350,120V/60HZ,C | |
| MV-1511M | 368771 | 6877W3S001A | CONNECTOR ASSEMBLY | LGEWC MV-1320 L/W | |
| MV-1511M | 36912C | 6912W3Q001A | LAMP[OVEN/BASELESS] | 12530W-25 DUKWOO | |
| MV-1511M | 43500A | 3500W1A005A | BOARD,[LATCH BOARD] | POM FULL OUT LGEC | |
| MV-1511M | 43501A | 3501W1A016F | BOARD ASSY,LATCH | MR-M274 | |
| MV-1511M | 44510A | 4510W4A005A | LEVER | MV-1120 | |
| MV-1511M | 466001 | 3B73362F | SWITCH,MICRO | SZM-V16-FA-63 LG UI | |
| MV-1511M | 466003 | 3B73361E | SWITCH,MICRO | SZM-V16-FA-62 LG UI | |
| MV-1511M | 50CZZH | 0CZZW1H002H | CAPACITOR,DRAWING[HIGH V | 2100VAC 1.00UF VDE | |
| MV-1511M | 50FZZA | 3B74133K | FUSE,DRAWING | 20A 250V CERAMIC 6 | |
| MV-1511M | 50FZZA | 3B74133K | FUSE,DRAWING | 20A 250V CERAMIC 6 | |
| MV-1511M | 53300B | 3300W1G081A | PLATE,[BOTTOM PLATE] | MV-1520 | |
| MV-1511M | 53550L | 3550W3A082A | COVER,[LAMP COVER] | SECC MATERIAL MV- | |
| MV-1511M | 54810C | 4810W3C002A | BRACKET,[CAPACITOR] | T0.5 SECC MV-1320 L | |

| | | | | |
|----------|--------|-------------|---|-----------------------|
| MV-1511M | 55231C | 2B72706C | FILTER(MECH),[CHARCOAL] | 10.0*4.843*0.345 |
| MV-1511M | 55238A | 4974W1G038A | GUIDE,[AIR GUIDE] | MV-1520,AIR |
| MV-1511M | 55262A | 5262W0A008A | DUCT | MV-1520 |
| MV-1511M | 55900A | 2B72125A | FAN | DIA.110 CCW 4 WING |
| MV-1511M | 56170D | 6170W1D003C | TRANSFORMER,HIGH VOLTAGE | 120V 60HZ 1000W 21 |
| MV-1511M | 56201A | 2B72130F | FILTER ASSY,NOISE | 250V 66* 52MM D 6.3 |
| MV-1511M | 56201A | 2B72130F | FILTER ASSY,NOISE | 250V 66* 52MM D 6.3 |
| MV-1511M | 56201B | 6201W2A019A | FILTER ASSY,CHOKE | MS-100/120/150,CAN/ |
| MV-1511M | 56324A | 6324W1A001D | MAGNETRON | 1000W 2M246-310GF |
| MV-1511M | 56411A | 6411W2A002N | POWER CORD ASSY | A-2 SJT 14AWG 3 D/C |
| MV-1511M | 56549F | 6549W2F016D | MOTOR(CIRC),FAN | 120V 60HZ 8.0MM 23 |
| MV-1511M | 56804A | 6804W3A001A | SOCKET(CIRC),LAMP | 250V2A E-17 #187 BJI |
| MV-1511M | 56804A | 6804W3A001A | SOCKET(CIRC),LAMP | 250V2A E-17 #187 BJI |
| MV-1511M | 56851D | 6021W3B001M | CABLE ASSEMBLY | HVR-1X-06B 0MM NO |
| MV-1511M | 568771 | 6877W1A148C | CONNECTOR ASSEMBLY | LGECW MV-153XD LC |
| MV-1511M | 568772 | 6877W2S002C | CONNECTOR ASSEMBLY | LGECW MV-1320 L/W |
| MV-1511M | 56912B | 3B70067A | LAMP[OVEN/BASELESS] | 12530W-25 DUKWOO |
| MV-1511M | 56930G | 3B70068V | THERMOSTAT | 40 /56 PW-2R VERTIC |
| MV-1511M | 56930V | 6930WRT003C | THERMOSTAT | 110 /0 PW-2N VERTIC |
| MV-1511M | 63300M | 3300W0G039A | PLATE,[MOUNTING PLATE] | MV-1120 |
| MV-1511M | 63302A | 3302W0A013A | BASE PLATE | MV-1520 |
| MV-1511M | 63303A | 3303W1A041C | BASE PLATE ASSY | MV-1580,AMANA,WH |
| MV-1511M | 63861A | 2B72771A | KIT ASSY | MV-1560M WHEGSE |
| MV-1511M | 64360A | 4360W4A001A | ROD | MV-1120 |
| MV-1511M | 65862B | 3B72144A | EXHAUST,[ADAPTER] | ER-830 CUSHION |
| MV-1511M | 65862D | 3B71432A | EXHAUST,[DAMPER] | ER-810MV T0.5 1 |
| MV-1511M | 95001A | 5001W2A006S | ACCESSORY ASSY | MV-153XD LGECI OW |
| MV-1511M | AR1 | 0RZ1503G610 | RESISTOR,DRAWING | 150K OHM 1 / 4 W 32 |
| MV-1511M | BZ1 | 6908W3YA01A | BUZZER,PIEZO CERAMIC | GPB-B-26B2.1ES(EXT) |
| MV-1511M | C01 | 0CK1040K518 | CAPACITOR,FIXED CERAMIC(H 0.1UF D 50V 10% B(Y | |
| MV-1511M | C02 | 0CE2272H638 | CAPACITOR,FIXED ELECTROLY 220UF SME,SQ 25V 2 | |
| MV-1511M | C02 | 0CE2272H638 | CAPACITOR,FIXED ELECTROLY 220UF SME,SQ 25V 2 | |
| MV-1511M | C03 | 0CE2272H638 | CAPACITOR,FIXED ELECTROLY 220UF SME,SQ 25V 2 | |
| MV-1511M | C03 | 0CE2272H638 | CAPACITOR,FIXED ELECTROLY 220UF SME,SQ 25V 2 | |
| MV-1511M | C04 | 0CE4761K638 | CAPACITOR,FIXED ELECTROLY 47UF SM,SA 50V 20% | |
| MV-1511M | C04 | 0CE4761K638 | CAPACITOR,FIXED ELECTROLY 47UF SM,SA 50V 20% | |
| MV-1511M | C05 | 0CK2230H518 | CAPACITOR,FIXED CERAMIC(H 0.022UF D 25V 10% B | |
| MV-1511M | C06 | 0CK1040K518 | CAPACITOR,FIXED CERAMIC(H 0.1UF D 50V 10% B(Y | |
| MV-1511M | C10 | 0CE4761K638 | CAPACITOR,FIXED ELECTROLY 47UF SM,SA 50V 20% | |
| MV-1511M | C10 | 0CE4761K638 | CAPACITOR,FIXED ELECTROLY 47UF SM,SA 50V 20% | |
| MV-1511M | C20 | 0CK2230H518 | CAPACITOR,FIXED CERAMIC(H 0.022UF D 25V 10% B | |
| MV-1511M | C21 | 0CK2230H518 | CAPACITOR,FIXED CERAMIC(H 0.022UF D 25V 10% B | |
| MV-1511M | C25 | 0CK2230H518 | CAPACITOR,FIXED CERAMIC(H 0.022UF D 25V 10% B | |
| MV-1511M | CN1 | 6630W5V012A | CONNECTOR (CIRC),WAFER | YW396-15AV(2,4,...,14 |
| MV-1511M | CN2 | CQ52212A | CONNECTOR (CIRC),WAFER | YW396-03,#2 VOID |
| MV-1511M | CN3 | 6630W5YA19E | CONNECTOR (CIRC),WAFER | FCZ254-13D |
| MV-1511M | CR1 | 6212W5M002A | RESONATOR,CERAMIC | CSTS0400MG06-T2 N |
| MV-1511M | CU1 | 4850W4C001A | CUSHION | 3.5MM |
| MV-1511M | D01 | ODD400209AA | DIODE,RECTIFIERS | 1N4002 TP KEC ---- |

| | | | | |
|----------|------|-------------|--|---------------------|
| MV-1511M | D02 | ODD400209AA | DIODE,RECTIFIERS | 1N4002 TP KEC ---- |
| MV-1511M | D03 | ODD400209AA | DIODE,RECTIFIERS | 1N4002 TP KEC ---- |
| MV-1511M | D04 | ODD400209AA | DIODE,RECTIFIERS | 1N4002 TP KEC ---- |
| MV-1511M | D20 | ODD414809AA | DIODE,SWITCHING | 1N4148 TP GRANDE . |
| MV-1511M | D25 | ODD414809AA | DIODE,SWITCHING | 1N4148 TP GRANDE . |
| MV-1511M | D26 | ODD414809AA | DIODE,SWITCHING | 1N4148 TP GRANDE . |
| MV-1511M | D30 | ODD400409AA | DIODE,RECTIFIERS | 1N4004 TP PYUNGCH |
| MV-1511M | D32 | ODD414809AA | DIODE,SWITCHING | 1N4148 TP GRANDE . |
| MV-1511M | D80 | ODD414809AA | DIODE,SWITCHING | 1N4148 TP GRANDE . |
| MV-1511M | D81 | ODD414809AA | DIODE,SWITCHING | 1N4148 TP GRANDE . |
| MV-1511M | D82 | ODD414809AA | DIODE,SWITCHING | 1N4148 TP GRANDE . |
| MV-1511M | D83 | ODD414809AA | DIODE,SWITCHING | 1N4148 TP GRANDE . |
| MV-1511M | D84 | ODD414809AA | DIODE,SWITCHING | 1N4148 TP GRANDE . |
| MV-1511M | D85 | ODD414809AA | DIODE,SWITCHING | 1N4148 TP GRANDE . |
| MV-1511M | D86 | ODD414809AA | DIODE,SWITCHING | 1N4148 TP GRANDE . |
| MV-1511M | DP1 | 6302W5A002A | DIGITRON | SVM-07SS15, 7-MT-2' |
| MV-1511M | PT1 | 6010W2P043A | TRANSFORMER,POWER | 120V/60HZ,144MA/12' |
| MV-1511M | Q01 | OTR101509AB | TRANSISTOR,BIPOLARS | KTA1015-O TP KEC - |
| MV-1511M | Q02 | OTR101509AB | TRANSISTOR,BIPOLARS | KTA1015-O TP KEC - |
| MV-1511M | Q20 | OTR106009AF | TRANSISTOR,BIPOLARS | KRC 106M TP KEC -- |
| MV-1511M | Q30 | OTR181509AB | TRANSISTOR,BIPOLARS | KTC1815-Y TP KEC - |
| MV-1511M | Q31 | OTR107009AE | TRANSISTOR,BIPOLARS | KRA107M TO-92M KE |
| MV-1511M | Q50 | OTR107009AD | TRANSISTOR,BIPOLARS | KRC 107M TP KEC -- |
| MV-1511M | R01 | ORD2001F608 | RESISTOR,FIXED CARBON FILM 2K OHM 1/6 W 5.00% | |
| MV-1511M | R01 | ORD2001F608 | RESISTOR,FIXED CARBON FILM 2K OHM 1/6 W 5.00% | |
| MV-1511M | R02 | ORD1001F608 | RESISTOR,FIXED CARBON FILM 1K OHM 1/6 W 5.00% | |
| MV-1511M | R02 | ORD1001F608 | RESISTOR,FIXED CARBON FILM 1K OHM 1/6 W 5.00% | |
| MV-1511M | R03 | ORD1002F608 | RESISTOR,FIXED CARBON FILM 10K OHM 1/6 W 5.00% | |
| MV-1511M | R03 | ORD1002F608 | RESISTOR,FIXED CARBON FILM 10K OHM 1/6 W 5.00% | |
| MV-1511M | R04 | ORD1001F608 | RESISTOR,FIXED CARBON FILM 1K OHM 1/6 W 5.00% | |
| MV-1511M | R04 | ORD1001F608 | RESISTOR,FIXED CARBON FILM 1K OHM 1/6 W 5.00% | |
| MV-1511M | R05 | ORD1000G608 | RESISTOR,FIXED CARBON FILM 100 OHM 1/4 W 5.00% | |
| MV-1511M | R05 | ORD1000G608 | RESISTOR,FIXED CARBON FILM 100 OHM 1/4 W 5.00% | |
| MV-1511M | R06 | ORD0202F608 | RESISTOR,FIXED CARBON FILM 20 OHM 1/6 W 5.00% | |
| MV-1511M | R07 | ORD0202F608 | RESISTOR,FIXED CARBON FILM 20 OHM 1/6 W 5.00% | |
| MV-1511M | R08 | ORD1003F608 | RESISTOR,FIXED CARBON FILM 100K OHM 1/6 W 5.00 | |
| MV-1511M | R08 | ORD1003F608 | RESISTOR,FIXED CARBON FILM 100K OHM 1/6 W 5.00 | |
| MV-1511M | R101 | ORD4702F608 | RESISTOR,FIXED CARBON FILM 47K OHM 1/6 W 5.00% | |
| MV-1511M | R101 | ORD4702F608 | RESISTOR,FIXED CARBON FILM 47K OHM 1/6 W 5.00% | |
| MV-1511M | R103 | ORD4702F608 | RESISTOR,FIXED CARBON FILM 47K OHM 1/6 W 5.00% | |
| MV-1511M | R103 | ORD4702F608 | RESISTOR,FIXED CARBON FILM 47K OHM 1/6 W 5.00% | |
| MV-1511M | R105 | ORD4702F608 | RESISTOR,FIXED CARBON FILM 47K OHM 1/6 W 5.00% | |
| MV-1511M | R105 | ORD4702F608 | RESISTOR,FIXED CARBON FILM 47K OHM 1/6 W 5.00% | |
| MV-1511M | R106 | ORD3302F608 | RESISTOR,FIXED CARBON FILM 33K OHM 1/6 W 5.00% | |
| MV-1511M | R106 | ORD3302F608 | RESISTOR,FIXED CARBON FILM 33K OHM 1/6 W 5.00% | |
| MV-1511M | R107 | ORD1202G608 | RESISTOR,FIXED CARBON FILM 12K OHM 1/4 W 5.00% | |
| MV-1511M | R107 | ORD1202G608 | RESISTOR,FIXED CARBON FILM 12K OHM 1/4 W 5.00% | |
| MV-1511M | R20 | ORD1001F608 | RESISTOR,FIXED CARBON FILM 1K OHM 1/6 W 5.00% | |
| MV-1511M | R20 | ORD1001F608 | RESISTOR,FIXED CARBON FILM 1K OHM 1/6 W 5.00% | |

| | | | | |
|----------|--------|-------------|----------------------------|----------------------|
| MV-1511M | RY1 | 6920W2D010A | RELAY | OJ-SS-112LM |
| MV-1511M | RY11 | 6920W5A005A | RELAY | VE-12HE-K TAKAMIS/ |
| MV-1511M | RY12 | 6920W2D010A | RELAY | OJ-SS-112LM |
| MV-1511M | RY12 | 6920W2D010A | RELAY | OJ-SS-112LM |
| MV-1511M | RY14 | 6920W2D010A | RELAY | OJ-SS-112LM |
| MV-1511M | RY14 | 6920W2D010A | RELAY | OJ-SS-112LM |
| MV-1511M | RY15 | 6920W2D010A | RELAY | OJ-SS-112LM |
| MV-1511M | RY15 | 6920W2D010A | RELAY | OJ-SS-112LM |
| MV-1511M | RY2 | 6920W2YD04A | RELAY | OZF-S-112LM1P,DC1: |
| MV-1511M | RY2 | 6920W2YD04A | RELAY | OZF-S-112LM1P,DC1: |
| MV-1511M | U01 | 0IZZW5A078A | IC | GMS87C2020 64PIN E |
| MV-1511M | U03 | 0ITO200400A | IC,TOSHIBA | ULN2004A 16DIP BK I |
| MV-1511M | VR1 | CQ33026A | VARISTOR | INR14D271 |
| MV-1511M | WBZZ01 | 4B72059B | BOLT[TOGGLE] | 1/4/20 |
| MV-1511M | WBZZ02 | 4B72059C | BOLT[TOGGLE] | 1 |
| MV-1511M | WSZ002 | 1SBF0402418 | SCREW TAP TITE(S),BINDING | ‐ #NAME? |
| MV-1511M | WSZ002 | 1SBF0402418 | SCREW TAP TITE(S),BINDING | ‐ #NAME? |
| MV-1511M | WSZ002 | 1SBF0402418 | SCREW TAP TITE(S),BINDING | ‐ #NAME? |
| MV-1511M | WSZ002 | 1SBF0402418 | SCREW TAP TITE(S),BINDING | ‐ #NAME? |
| MV-1511M | WSZ002 | 1SBF0402418 | SCREW TAP TITE(S),BINDING | ‐ #NAME? |
| MV-1511M | WSZ002 | 1SBF0402418 | SCREW TAP TITE(S),BINDING | ‐ #NAME? |
| MV-1511M | WSZ005 | 1SPF0302018 | SCREW TAP TITE(S),PAN HEAD | #NAME? |
| MV-1511M | WSZ084 | 4B70188B | SCREW,DRAWING | #NAME? |
| MV-1511M | WSZ098 | 4B70637B | SCREW,DRAWING | TEST |
| MV-1511M | WSZ133 | 4B73234A | SCREW,DRAWING | TEST |
| MV-1511M | WSZ136 | 4B73243A | SCREW,DRAWING | ER-840TV |
| MV-1511M | WSZ137 | 4B73763A | SCREW,DRAWING | S-TYPE M5*10 |
| MV-1511M | WSZ175 | 4E55432A | SCREW,DRAWING | SCREW-C M4*8 |
| MV-1511M | WTP004 | 1TPL0302418 | SCREW TAPPING,PAN HEAD | + 2 CUT D3.0 L8.0 MS |
| MV-1511M | WTP004 | 1TPL0302418 | SCREW TAPPING,PAN HEAD | + 2 CUT D3.0 L8.0 MS |
| MV-1511M | WTP013 | 1TPL0402418 | SCREW TAPPING,PAN HEAD | + 2 CUT D4.0 L8.0 MS |
| MV-1511M | WTP013 | 1TPL0402418 | SCREW TAPPING,PAN HEAD | + 2 CUT D4.0 L8.0 MS |
| MV-1511M | WTP018 | 1TPL0402818 | SCREW TAPPING,PAN HEAD | + 2 CUT D4.0 L12.0 M |
| MV-1511M | WTP018 | 1TPL0402818 | SCREW TAPPING,PAN HEAD | + 2 CUT D4.0 L12.0 M |
| MV-1511M | WTP018 | 1TPL0402818 | SCREW TAPPING,PAN HEAD | + 2 CUT D4.0 L12.0 M |
| MV-1511M | WTP018 | 1TPL0402818 | SCREW TAPPING,PAN HEAD | + 2 CUT D4.0 L12.0 M |
| MV-1511M | WTP018 | 1TPL0402818 | SCREW TAPPING,PAN HEAD | + 2 CUT D4.0 L12.0 M |
| MV-1511M | WTP018 | 1TPL0402818 | SCREW TAPPING,PAN HEAD | + 2 CUT D4.0 L12.0 M |
| MV-1511M | WTT020 | 1TTL0402416 | SCREW TAPPING,TRUSS HEAD | + 2 CUT D4.0 L8.0 MS |
| MV-1511M | WTT020 | 1TTL0402416 | SCREW TAPPING,TRUSS HEAD | + 2 CUT D4.0 L8.0 MS |
| MV-1511M | WTT021 | 1TTL0402418 | SCREW TAPPING,TRUSS HEAD | + 2 CUT D4.0 L8.0 MS |
| MV-1511M | WTT021 | 1TTL0402418 | SCREW TAPPING,TRUSS HEAD | + 2 CUT D4.0 L8.0 MS |
| MV-1511M | WTT021 | 1TTL0402418 | SCREW TAPPING,TRUSS HEAD | + 2 CUT D4.0 L8.0 MS |
| MV-1511M | WTT021 | 1TTL0402418 | SCREW TAPPING,TRUSS HEAD | + 2 CUT D4.0 L8.0 MS |
| MV-1511M | WTT022 | 1TTL0402422 | SCREW TAPPING,TRUSS HEAD | + 2 CUT D4.0 L8.0 MS |
| MV-1511M | WTT027 | 1TTL0402816 | SCREW TAPPING,TRUSS HEAD | + 2 CUT D4.0 L12.0 M |
| MV-1511M | WTT028 | 1TTL0402818 | SCREW TAPPING,TRUSS HEAD | + 2 CUT D4.0 L12.0 M |
| MV-1511M | WTT028 | 1TTL0402818 | SCREW TAPPING,TRUSS HEAD | + 2 CUT D4.0 L12.0 M |
| MV-1511M | WTT028 | 1TTL0402818 | SCREW TAPPING,TRUSS HEAD | + 2 CUT D4.0 L12.0 M |

| | | | |
|----------|--------|-------------|---|
| MV-1511M | WTT028 | 1TTL0402818 | SCREW TAPPING,TRUSS HEAD + 2 CUT D4.0 L12.0 M |
| MV-1511M | WTT033 | 1TTL0403318 | SCREW TAPPING,TRUSS HEAD + 2 CUT D4.0 L20.0 M |
| MV-1511M | WWZ068 | 4B73055A | WASHER,DRAWING ### (08*2) |
| MV-1511M | ZD1 | 0DZ510009AB | DIODE,ZENERS MTZ5.1B TP ROHM-K |
| MV-1511M | ZD2 | 0DZ560009AB | DIODE,ZENERS UZ-5.6BS 0.5W TP PY |