

# Panasonic®

## Operating Instructions

Microwave Oven  
Model NN-S697



Before operating this oven, please read these instructions completely.  
(Antes de operar este producto, lea este instructivo en su totalidad.)

Spanish Operating Instructions can be found on pages 41-53.  
(El manual de instrucciones en español puede ser encontrada en la páginas 41-53)  
To order accessories or parts, see page 40.

Thank you for purchasing the Panasonic Microwave Oven.

## PRECAUTIONS TO AVOID POSSIBLE EXPOSURE TO EXCESSIVE MICROWAVE ENERGY

- (a) Do not attempt to operate this oven with the door open since open-door operation can result in harmful exposure to microwave energy. It is important not to defeat or tamper with the safety interlocks.
- (b) Do not place any object between the oven front face and the door, or allow soil or cleaner residue to accumulate on sealing surfaces.
- (c) Do not operate the oven if it is damaged. It is particularly important that the oven door close properly and that there is no damage to the:
  - (1) door (bent)
  - (2) hinges and latches (broken or loosened)
  - (3) door seals and sealing surfaces.
- (d) The oven should not be adjusted or repaired by anyone except properly qualified service personnel.

### STAPLE YOUR STORE RECEIPT HERE.

The serial number of this product may be found on the right side of the oven door opening. You should note the model number and the serial number of this oven in the space provided and retain this book as a permanent record of your purchase for future reference.

Model No. \_\_\_\_\_

Serial No. \_\_\_\_\_

Date of Purchase \_\_\_\_\_

## Technical Specifications

	NN-S697
Power Source:	120V, 60 Hz
Power Consumption:	13.5 A, 1,550 W
Output:*	1000 W
Outside Dimensions (H x W x D):	12" x 21 <sup>7</sup> / <sub>8</sub> " x 16 <sup>3</sup> / <sub>4</sub> " 306 x 555 x 425mm
Oven Cavity Dimensions (H x W x D):	9 <sup>1</sup> / <sub>8</sub> " x 14 <sup>15</sup> / <sub>16</sub> " x 15 <sup>13</sup> / <sub>16</sub> " 232 x 380 x 402mm
Operating Frequency:	2,450 MHz
Uncrated Weight (Approx.):	38 lbs. (17.2 kg)

\*IEC 705-88 Test Procedure used  
Specifications subject to change without notice.

# CONTENTS

---

## Before Operating

---

<b>Safety Instructions</b> .....	2
<b>Installation Instructions</b> .....	3
<b>Grounding Instructions</b> .....	3
Practical Hints .....	4
Cookware and Utensil Guide .....	5
Feature Diagram .....	6
Control Panel .....	7

---

## Operation & Hints

---

<b>Let's Start to Use Your Oven!</b> .....	8
To Use Function Pad .....	8-9
To Set Clock .....	10
To Reheat using	
Power and Time Setting .....	10
Sensor Reheat Pad .....	13
To Defrost using	
Power and Time Setting .....	10-11
Sensor Defrost .....	12
To Cook using	
Power and Time Setting .....	10
Quick Min Pad .....	15
Sensor Cooking Pads .....	13-14
Popcorn Pad .....	15
To Set Timer (Stand Time/Delay Start) .....	16

---

## Cookbook

---

Food Characteristics .....	17
Cooking Techniques .....	17-18
Appetizers .....	19
Meats .....	20-23
Poultry .....	24-26
Fish and Seafood .....	27-28
Casseroles .....	29
Eggs and Cheese .....	30
Vegetables .....	31-32
Pasta, Rice and Cereal .....	33-34
Quick Breads and Cakes .....	35-36
Pies .....	37
Microwave Shortcuts .....	38

---

## Maintenance

---

Before Requesting Service .....	39
To Order Books, Accessories, etc. ....	40
Care of Your Microwave Oven .....	40
Technical Specifications .....	Inside Front Cover
<b>Quick Guide to Operation</b> .....	Back Cover

---

## Manual de instrucciones (Spanish Operating Instructions)

---

<b>Precauciones</b> .....	41
<b>Instrucciones de seguridad</b> .....	41-42
<b>Instrucciones para Conexión a Tierra</b> .....	42
<b>Instrucciones de instalación</b> .....	43
Sugerencias Útiles .....	44
Panel de Controles .....	45
Procedimientos de Operación .....	46-52
Cuidados de Su Horno de Microondas .....	53
Antes de Acudir a Servicio .....	53

# IMPORTANT SAFETY INSTRUCTIONS

Your microwave oven is a cooking device and you should use as much care as you use with a stove or any other cooking device. When using this electric appliance, basic safety precautions should be followed, including the following:

**WARNING**—To reduce the risk of burns, electric shock, fire, injury to persons or exposure to excessive microwave energy:


1. Read all instructions before using the appliance.
2. Read and follow the specific **“PRECAUTIONS TO AVOID POSSIBLE EXPOSURE TO EXCESSIVE MICROWAVE ENERGY,”** found on back of the front cover.
3. This appliance must be grounded. Connect only to properly grounded outlet. See **“GROUNDING INSTRUCTIONS”** found on page 3.
4. Install or locate this appliance only in accordance with the installation instructions found on page 3.
5. Do not cover or block any openings on this appliance.
6. Do not store or use this appliance outdoors. Do not use this product near water—for example, near a kitchen sink, in a wet basement, or near a swimming pool, and the like.
7. Use this appliance only for its intended use as described in this manual. Do not use corrosive chemicals or vapors in this appliance. This type of oven is specifically designed to heat, cook, or dry food. It is not designed for industrial or laboratory use.
8. When cleaning surfaces of door and oven that come together on closing the door, use only mild, non-abrasive soaps or detergents applied with a sponge or soft cloth.
9. As with any appliance, **close supervision is necessary** when used by children.
10. Do not operate this appliance if it has a damaged cord or plug, if it is not working properly, or if it has been damaged or dropped.
11. Do not immerse cord or plug in water.
12. Keep cord away from heated surfaces.
13. Do not let cord hang over edge of table or counter.
14. This appliance should be serviced only by qualified service personnel. Contact the nearest authorized service facility for examination, repair or adjustment.
15. Some products such as whole eggs and sealed containers—for example, closed glass jars—may explode and should not be heated in this oven.
16. To reduce the risk of fire in the oven cavity:
  - (a) Do not overcook food. Carefully attend appliance if paper, plastic, or other combustible materials are placed inside the oven to facilitate cooking.
  - (b) Remove wire twist-ties from paper or plastic bags before placing bag in oven.
  - (c) If materials inside the oven should ignite, keep oven door closed, turn oven off, and disconnect the power cord, or shut off power at the fuse or circuit breaker panel.

(d) Do not use the cavity for storage purposes.


Do not leave paper products, cooking utensils, or food in the cavity when not in use.

## General Use

1. **DO NOT** tamper with or make any adjustments or repairs to door, control panel housing, safety interlock switches or any other part of the oven. **DO NOT** remove outer panel from oven. Repairs should only be done by a qualified service person.



2. **DO NOT** operate the oven empty. The microwave energy will reflect continuously throughout the oven if food or water is not present to absorb energy. This could damage the oven and result in the danger of a fire.



3. **DO NOT** use this oven to heat chemicals or any other non-food products. **Do NOT** clean this oven with any product that is labeled as containing corrosive chemicals. **The heating of corrosive chemicals in this oven can cause radiation leaks.**
4. **DO NOT** dry clothes, newspapers or other materials in oven. They may catch fire.
5. **DO NOT** use recycled paper products unless the paper product is labeled as safe for microwave oven use. Recycled paper products may contain impurities which may cause sparks and/or fires when used.
6. **DO NOT** use newspapers or paper bags for cooking. Fire can result.
7. **DO NOT** hit or strike control panel. Damage to controls may occur. Fire can result.
8. **POT HOLDERS** should always be used when removing items from the oven. Heat is transferred from the **HOT** food to the cooking container and from the cooking container to the Glass Tray. Glass Tray can be very **HOT** after removing cooking container from oven.
9. **DO NOT** store flammable materials next to, on top of, or in the oven. These could be fire hazards.

## SAVE THESE INSTRUCTIONS

For proper use of your oven read remaining safety cautions and operating instructions.

# INSTALLATION & GROUNDING INSTRUCTIONS

## Examine Your Oven

Unpack oven, remove all packing material, and examine the oven for any damage such as dents, broken door latches or cracks in the door. Notify dealer immediately if oven is damaged. **Do NOT** install if oven is damaged.

## Placement of Oven

- Oven must be placed on a flat, stable surface. For proper operation, the oven must have sufficient air flow. Allow 3 inches (8 cm) of space on both sides of the oven and 1 inch (2.5 cm) of space on top of oven.
  - Do NOT** block air vents.  
If they are blocked during operation, the oven may overheat. If the oven overheats, a thermal safety device will turn the oven off. The oven will remain inoperable until it has cooled.
  - Do NOT** place oven near a hot damp surface such as a gas or electric range.
  - Do NOT** operate oven when room humidity is too high.
- This oven was manufactured for household use only.

## Grounding Instructions

This appliance must be grounded. In the event of an electrical short circuit, grounding reduces the risk of electric shock by providing an escape wire for the electric current. This appliance is equipped with a cord having a grounding wire with a grounding plug. The plug must be plugged into an outlet that is properly installed and grounded.

**WARNING**—Improper use of the grounding plug can result in a risk of electric shock.

Consult a qualified electrician or service person if the grounding instructions are not completely understood, or if doubt exists as to whether the appliance is properly grounded.


If it is necessary to use an extension cord, use only a three wire extension cord that has a three blade grounding plug, and a three slot receptacle that will accept the plug on the appliance. The marked rating of the extension cord should be equal to or greater than the electrical rating of the appliance.

## Power Supply

- A short power-supply cord is provided to reduce the risks resulting from becoming entangled in or tripping over a longer cord.
- Longer cord sets or extension cords are available and may be used if care is exercised in their use.
- If a long cord or extension cord is used, (1) the marked electrical rating of the cord set or extension cord should be at least as great as the electrical rating of the appliance, (2) the extension cord must be a grounding-type 3-wire cord, and (3) the longer cord should be arranged so that it will not drape over the countertop or tabletop where it can be pulled on by children or tripped over accidentally.

## Wiring Requirements

- The oven must be on a **SEPARATE CIRCUIT**. No other appliance should share the circuit with the microwave oven. If it does, the branch circuit fuse may blow, or the circuit breaker may trip or the food may cook slower than the times recommended in this manual.
- The **VOLTAGE** used must be the same as specified on this microwave oven (120V). Using a higher voltage is dangerous and may result in a fire or other accident causing oven damage. Using a lower voltage will cause slow cooking. Panasonic is **NOT** responsible for damage resulting from the use of the oven with other than specified voltage.
- The oven must be plugged into at least a 20 AMP 120 VOLT, 60 Hz **GROUNDING OUTLET**.  
Where a standard two-prong outlet is encountered, it is the personal responsibility and obligation of the consumer to have it replaced with a properly grounded three-prong outlet.



- A **TEMPORARY CONNECTION** with a two-prong adapter may be made where **LOCAL CODES PERMIT**. Unless the cover screw is grounded through the house wiring, attaching the adapter grounding plate to the cover screw will not ground the oven. If there is any doubt that the cover screw is grounded, have it checked by an electrician.



## Radio Interference

- Operation of the microwave oven may cause interference to your radio, TV or similar equipment.
- When there is interference, it may be reduced or eliminated by taking the following measures:
  - Clean door and sealing surfaces of the oven. (See Care of Your Microwave Oven)
  - Place the radio, TV, etc. away from the microwave oven as far as possible.
  - Use a properly installed antenna to obtain stronger signal reception.

# Practical Hints

## Follow These Safety Precautions When Cooking in Your Oven

### 1) HOME CANNING / DRYING FOODS / SMALL QUANTITIES OF FOODS

- **Do not** use your oven for home canning or the heating of any closed jar. Pressure will build up and the jar may explode. Your oven cannot maintain the food at the proper canning temperature. Improperly canned food may spoil and be dangerous to consume.
- Small quantities of food or foods with low moisture content can dry out, burn or catch on fire.
- **Do not** dry meats, herbs, fruits or vegetables in your oven.

### **IMPORTANT**

**Proper cooking depends on time set and weight of food. If you use a smaller portion than recommended and cook at the time for the recommended portion, fire can result.**

**If a fire occurs, turn oven off and leave oven door closed. Disconnect the power cord or shut off power at the fuse or circuit breaker panel.**

### 2) POPCORN

Popcorn must be popped in a microwave oven corn popper. Microwave popcorn which pops in its own package is also available. Follow popcorn manufacturers' directions and use a brand suitable for the wattage of your microwave oven. Never leave oven unattended when popping popcorn. Allow the popcorn bag to cool before opening it. To prevent steam burns, always open the bag away from your face and body.

#### **CAUTION:**

**When using pre-packaged microwave popcorn, follow recommended package instructions. Check package weight before using the popcorn pad. Set the oven for the weight of the popcorn package. (see page 15)**  
**If these instructions are not followed, the popcorn may not pop adequately or may ignite and cause a fire.**

### 3) DEEP FAT FRYING

- **Do not** attempt to deep fat fry in your microwave oven. Cooking oils may burst into flames and may cause damage to the oven and perhaps result in burns. Microwave utensils may not be able to withstand the temperature of the hot oil, and could shatter.

### 4) EGGS

- **Do not** heat eggs in their shell in a microwave oven. Pressure will build up and the eggs will explode.

### 5) FOODS WITH NONPOROUS SKINS

- **Potatoes, apples, egg yolks, whole squash and sausages are examples of foods with nonporous skins.** These types of foods must be pierced before microwave cooking to prevent their bursting.
- Use fresh potatoes for baking and cook until just done. Overcooking causes dehydration and may cause a fire. Use recommended weights or fire may occur.

### 6) LIQUIDS

- Heated liquids can erupt if not mixed with air. **Do not** heat liquids in your microwave oven without first stirring.

### 7) GLASS TRAY / COOKING UTENSILS / FOIL

- Cooking utensils get hot during microwaving. Use potholders when removing utensils from the oven or when removing lids or plastic wrap covers from cooking utensils to avoid burns.
- The glass tray will get hot during cooking. It should be allowed to cool before handling or before paper products, such as paper plates or microwave popcorn bags, are placed in the oven for microwave cooking.
- When using foil, skewers, warming rack or utensils made of metal in the oven, allow at least 1-inch (2.5 cm) of space between metal material and interior oven walls. If arcing occurs (sparking) remove metal material (skewers etc.) and/or transfer to a non-metallic container.
- Dishes with metallic trim should **not** be used, as arcing may occur.

### 8) PAPER TOWELS / CLOTHS

- **Do not** use paper towels or cloths which contain a synthetic fiber woven into them. The synthetic fiber may cause the towel to ignite.
- **Do not** use paper bags or recycled paper products in the microwave oven.

### 9) BROWNING DISHES / OVEN COOKING BAGS

- Browning dishes or grills are designed for microwave cooking only. Always follow instructions provided by the manufacturer. Do not preheat browning dish more than 8 minutes.
- If an oven cooking bag is used for microwave cooking, prepare according to package directions. Do not use a wire twist-tie to close bag.

### 10) THERMOMETERS

- **Do not** use a conventional meat thermometer in your oven. Arcing may occur.

### 11) BABY FORMULA / FOOD

- **Do not** heat baby formula or food in the microwave oven. The glass jar or surface of the food may appear warm while the interior can burn the infant's mouth and esophagus.

### 12) REHEATING PASTRY PRODUCTS

- When reheating pastry products, check temperatures of any fillings before eating. Some foods have fillings which heat faster and can be extremely hot while the surface remains warm to the touch (ex. Jelly Donuts).

### 13) GENERAL OVEN USAGE GUIDELINES / OVEN DOOR

- **Do not** use the oven for any reason other than the preparation of food.
- **Do not** leave oven unattended while in use.

# Cookware and Utensil Guide

ITEM	MICROWAVE	COMMENTS
Aluminum Foil	Yes for Shielding Only	Small strips of foil can be molded around thin parts of meat or poultry to prevent overcooking. Arcing can occur if foil is too close to oven wall or if too much foil is used.
Browning Dish	Yes	Browning dishes are designed for microwave cooking only. Check browning dish information for instructions and heating chart. Do not preheat for more than 8 minutes.
Brown paper bags	No	May cause a fire in the oven.
Dinnerware Microwave-Safe, only	Yes	Check manufacturers' use and care directions for suitability for microwave heating. Some dinnerware may state on the back of the dish, "Oven-Microwave Proof."
Disposable polyester Paperboard Dishes	Yes	Some frozen foods are packaged in these dishes. Can be purchased in grocery stores.
Fast Food Carton with Metal Handle	No	May cause arcing.
Frozen Dinner Tray Metal	Yes	Frozen dinners may be heated in foil tray, if tray is less than 3/4-inch (2 cm) high. Place foil tray in center of oven. Leave at least 1-inch (2.5 cm) space between foil tray and oven walls. Heat only 1 foil tray in the oven at a time. For containers more than 3/4-inch (2 cm) deep, remove food and place in a similar size microwave-safe container.
Microwave-safe	Yes	
Glass Jars	Yes	Remove lid. Heat food until just warm. Most glass jars are not heat resistant.
Glassware Heat Resistant Oven Glassware and Ceramic, only	Yes	Ideal for microwave cooking and browning. See "Container Test" below.
Metal Twist Ties	No	They may cause arcing which could cause a fire in the oven.
Oven Cooking Bag	Yes	Follow manufacturers' directions. Close bag with the nylon tie provided, a strip cut from the end of the bag, or a piece of cotton string. Do not close with metal twist tie. Make six 1/2-inch (1 cm) slits by closure.
Paper Plates & Napkins	Yes	Use to warm cooked foods, and to cook foods that require short cooking times such as hot dogs.
Paper Towels & Napkins	Yes	Use to warm rolls and sandwiches by microwave.
Plastic Microwave-Safe, only Cookware and Storage Dishes	Yes	Should be labeled, "Suitable for microwave heating." Check manufacturers' directions for recommended uses. Some microwave-safe plastic dishes are not suitable for cooking foods with high fat content.
Plastic Foam Cups	Yes	Plastic foam will melt if foods reach a high temperature. Use to bring foods to a low serving temperature.
Plastic Wrap	Yes	Use to cover food during cooking to retain moisture.
Straw, Wicker, Wood	Yes	Use only for short term reheating.
Thermometers Microwave-safe, only Conventional	Yes No	Use only microwave-safe meat and candy thermometers. Not suitable for use in microwave oven.
Wax paper	Yes	Use as a cover to prevent spattering and to retain moisture.

## CONTAINER TEST

TO TEST A CONTAINER FOR SAFE MICROWAVE OVEN USE: Fill a 1 - cup glass measure with water and place it in the microwave oven along with the container to be tested; heat one minute at HIGH. If the container is microwave oven-safe, it should remain comfortably cool and the water should be hot. If the container is hot, it has absorbed some microwave energy and should not be used. This test cannot be used for plastic containers.

# Feature Diagram

## Glass Tray


1. Do not operate the oven without the Roller Ring and Glass Tray in place.
2. Only use the Glass Tray specifically designed for this oven. Do not substitute any other Glass Tray.
3. If Glass Tray is hot, allow to cool before cleaning or placing in water.
4. **Do not** cook directly on Glass Tray. Always place food in a microwave-safe dish, or on a rack set in a microwave-safe dish.
5. If food or utensil on Glass Tray touches oven walls, causing the tray to stop moving, the tray will automatically rotate in opposite direction. This is normal.
6. Glass tray can rotate in either direction.

## See-through Oven Window

(with Vapor Barrier film - do not remove)

## Door Safety Lock System

## External Air Vents



## Identification Plate

## External Air Vents

## Control Panel


## Roller Ring

1. The Roller Ring and oven floor should be cleaned frequently to prevent excessive noise.
2. The Roller Ring must always be used together with the Glass Tray for cooking.

## Door Safety Lock System

## Special Defrost Rack


To be used **ONLY** for defrosting; **NOT** for cooking





# Control Panel

Genius Premier 1000  
NN-S697  
Sensor Defrost




- (1) **Menu Action Screen**  
Step by step instructions scroll for easy operation.
- (2) **Power Level Pad** (☛page 10)
- (3) **Number Pads**
- (4) **Timer/Clock Pad** (☛page 10, 16)
- (5) **Cook Action Display**  
This totally unique feature of your PANASONIC GENIUS guides you through the entire cooking process with its illuminated INTERACTIVE CONTROL PANEL. Once a pad has been selected, the COOK ACTION DISPLAY will prompt you to the NEXT step until cooking starts.
- (6) **Sensor Defrost Pad** (☛page 12)
- (7) **Quick Min Pad** (☛page 16)
- (8) **Popcorn Pad** (☛page 15)
- (9) **Stop/Reset Pad**  
**Before cooking:** One tap clears your instruction.  
**During cooking:** One tap temporarily stops the cooking process. Another tap cancels all your instructions and time of day or colon appears on the screen.
- (10) **Start Pad**  
One tap allows oven to begin functioning. If door is opened or **Stop/Reset** Pad is pressed once during oven operation, **Start** Pad must again be pressed to restart oven.

- (11) **Sensor Reheat Pad** (☛page 13)
- (12) **Sensor Cooking Pads** (☛page 13-14)
- (13) **More/Less Pad**  
One tap allows you to add to the Sensor cooking time. Two taps allows you to program less time when using the Sensor cook pads.
- (14) **Function Pad** (☛page 8-9)
- (15) **Serving/Weight Pad** (☛page 15)

## Prompters:

When pads are pressed, a beep sound is heard and the corresponding letter or word(s) appear and roll across the **Menu Action Screen** (either the **Beep Sound** or screen may be disabled using the **Function Pad**). If a pad is pressed and no beep is heard, the unit has not or cannot accept the instruction. As each pad is pressed the corresponding word(s) roll across the screen. Words will automatically appear to prompt user to perform the next step. It is not necessary to wait for the words to appear before pressing pads for the next step. A two beep sound is usually heard between stages.

# Let's Start to Use Your Oven!



## 1 Plug in


Plug into a properly grounded electrical outlet. "WELCOME TO PANASONIC REFER TO OPERATING INSTRUCTIONS BEFORE USE" scrolls across the Menu Action Screen.

## 2 Place a cup of water in the oven

Open the door and place a cup of water on the Glass Tray in the oven. Then close the door.

## 3 Select Power Level

e.g. MEDIUM Power — Press **Power Level** Pad four times (see page 10 for chart)



## 4 Set Cooking Time using number pads

e.g. 1 minute 30 seconds










## 5 Press Start

► The time in the Menu Action Screen will count down.

A unique feature of your GENIUS Premier 1000w microwave oven is the FUNCTION pad. The initial settings of your microwave are LANGUAGE = ENGLISH, WEIGHT = LB, WORD SPEED = MEDIUM, MENU ACTION SCREEN = ON, CHILD LOCK = OFF, BEEP = ON, REMINDER BEEP = OFF, DAYLIGHT SAVING = OFF, CLOCK = ON, DEMO MODE = OFF. To change any setting, see page 9 (FUNCTION PAD) for other options.

## To Use Function Pad

1)  	Press: FUNCTION. Menu Action Message is "Select Function 0 through 9, 1--LANGUAGE CHOICE --- etc". Number pad flashes.
2) Select a number (0-9) Ex. CHILD LOCK is 5	Press: Menu Action Message is "5 -- CHILD LOCK ON/OFF Numbers  &  flash. ON -- PRESS 1 OFF -- PRESS 2"
3) Select  or  or 	Press: Either number. Your selection is now part of the operating system. You can change it any time.
4) Continue until you have completed your selections.	See page 9 for other options.

# Functions


This unique feature of your PANASONIC microwave oven allows you to establish the initial non-cooking features of your oven such as CHILD LOCK, WORD SPEED, LANGUAGE CHOICE (ENGLISH, SPANISH OR FRENCH), plus many more. See below.



<b>1</b>	<p><b>LANGUAGE CHOICE</b></p> <p>The oven has English, French and Spanish display. The display appears in English when you plug-in.</p> <p>1 ENGLISH → Display appears in English.            2 FRANCAIS → Display appears in French.            3 ESPANOL → Display appears in Spanish.</p>
<b>2</b>	<p><b>Lb/KG CHOICE</b></p> <p>The oven has both imperial and metric weight measurements. The oven displays the weight in imperial when you plug it in.</p> <p>1 Lb → Weight can be set in lb/oz, (Imperial).            2 KG → Weight can be set in kg/g, (Metric).</p>
<b>3</b>	<p><b>WORD SPEED</b></p> <p>The speed of word scrolling in the Display Window can be quickened or slowed down.</p> <p>1 QUICK → Words scroll quickly.            2 MEDIUM → Scrolling speed reverts to initial setting.            3 SLOW → Words scroll slowly.</p>
<b>4</b>	<p><b>MENU ACTION ON/OFF</b></p> <p>MENU ACTION SCREEN helps you to program your oven by prompting the next step to be taken. When you become familiar with your oven, the prompting can be turned off.</p> <p>1 ON → Prompting Guide will reappear.            2 OFF → Prompting Guide will not appear.</p>
<b>5</b>	<p><b>CHILD LOCK ON/OFF</b></p> <p>The oven has Child Safety Lock feature which prevents use by children.</p> <p>1 ON → Child Lock has been set and operation will not be accepted.            2 OFF → Child Lock has been cancelled.</p>
<b>6</b>	<p><b>BEEP ON/OFF</b></p> <p>If you wish to have the oven operate with no beep, it can be eliminated.</p> <p>1 ON → Beep sound will reactivate.            2 OFF → Beep sound will not be heard.</p>
<b>7</b>	<p><b>REMINDER BEEP ON/OFF</b></p> <p>A reminder beep works to remind you to remove the food from the oven after the completion of cooking. It will occur every few seconds.</p> <p>1 ON → Reminder beep will work.            2 OFF → Reminder beep will not work.</p>
<b>8</b>	<p><b>DAYLIGHT SAVING ON/OFF</b></p> <p>1 ON → Time of day will advance one hour.            2 OFF → Time of day revert to original setting.</p>
<b>9</b>	<p><b>CLOCK ON/OFF</b></p> <p>Clock display can be turned off.</p> <p>1 ON → Clock display will appear in the Display Window.            2 OFF → Clock display will not appear in the Display Window.            Time of day will not be lost while the display is off.</p>
<b>0</b>	<p><b>DEMO MODE ON/OFF</b></p> <p>Demo mode is designed for retail store display. In this mode, the oven can be demonstrated with no power in the oven.</p> <p>1 ON → The oven will be in demo mode.            2 OFF → The oven will be out of demo mode.</p>


# Power & Time Setting

## 1 Select Power Level





Press	Power Level	% Power
once	HIGH	100%
twice	DEFROST	30%
3 times	MEDIUM-HIGH	70%
4 times	MEDIUM	55%
5 times	MEDIUM-LOW	30%
6 times	LOW	10%

When selecting **HIGH** Power, you can start from step 2.  
MENU ACTION MESSAGE is " - - - SET TIME".  
(Number pad flashes.)



## 2 Set Cooking Time

(Up to 99 minutes and 99 seconds) e.g. 12 minutes  
Number pad flashes until you enter time.



## 3 START Flashes

MENU ACTION MESSAGE is " - - - PRESS START". If the door is opened "**CLOSE DOOR**".

► Cooking will start. The time in the Menu Action Screen will begin to count down.

To recall the selected power level during cooking, press **Power Level** Pad.

For 2 or 3 stage cooking, repeat above steps 1 and 2 before pressing **Start** Pad.

At the end of cooking, MENU ACTION MESSAGE IS "**ENJOY YOUR MEAL**".

# To Set Clock



1.		PRESS twice for <b>CLOCK</b> . MENU ACTION MESSAGE is " <b>SET TIME</b> : ". Number pad flashes.
2. SET TIME OF DAY (ex. 1:30)		MENU ACTION MESSAGE is " 1:30 - - PRESS CLOCK PAD".
3.		Press once. Menu Action Screen displays time of day (clock is a 12 hour clock).

# Defrosting Tips & Techniques

1. Freeze meats, poultry and fish in packages with **only 1 or 2 layers** of food. Place wax paper between layers.
2. **Package** in heavy-duty plastic wraps, bags or freezer paper.
3. **Remove as much air** as possible.
4. Wrap should be snug against food, sealed securely and labeled.
5. **Remove wrapper** to prevent holding steam and juice. **Juice of food** can get hot and cause the outer surface or bottom of the food to cook; set the food on a microwave roasting rack and drain liquid during defrosting.
6. **Place meat in an appropriate size dish.**
7. **Place roast fat-side down** and **whole poultry breast-side down** on a microwave roasting rack in a dish.
8. Place small items on a microwave roasting rack in a dish.
9. **Large roasts** and **whole poultry** may still be icy in center after defrosting, allow to stand in the refrigerator covered with plastic wrap (see chart below).
10. Fish and seafood should be slightly icy after defrosting, allow to stand and rinse under cold water for 2-3 minutes.
11. Defrosted items in 2 layers should be **rinsed separately** or **have a longer stand time.**

FOOD	DEFROST TIME (min. per pound)	DURING DEFROSTING	AFTER DEFROSTING	
			Stand Time	Rinse
<b>Fish and Seafood</b> [up to 3 lb. (1.5 kg)]				
Crabmeat	12 to 14	Break apart	5 min.	NO
Fish Steaks	6 to 10	Turn over		
Fish Fillets	6 to 8	Turn over/Rearrange		
Sea Scallops	14 to 16	Break apart/Remove defrosted pieces		YES
Shrimp medium	8 to 10	Break apart/Remove defrosted pieces		
Whole fish	10 to 12	Turn over		
<b>Meat</b>				
Ground Meat*	8 to 10	Turn over/Remove defrosted portion/Shield edges	10 min.	NO
Roasts [2½ - 4 lb. (1.2 - 2 kg)]	8 to 12	Turn over/Shield ends and defrosted surface	30 min. in refrig	
Chops/Steak	8 to 10	Separate/Turn over/Rearrange	5 min.	
Ribs/T-bone	8 to 10	Turn over/Shield		
Stew Meat	10 to 12	Break apart/Shield		
Liver (thin sliced)	8 to 10	Drain liquid/Turn over/Separate pieces		
Bacon	4 to 6	Turn over		
<b>Poultry</b>				
Chicken, Whole [up to 3 lb. (1.5 kg)]	6 to 10	Turn over 2 or 3 times/Shield defrosted parts	20 min. in refrig	YES
Cutlets	6 to 8	Turn over	5 min.	NO
Pieces	8 to 10	Separate	10 min.	
Cornish Hens	8 to 12	Turn over/Rearrange		20 min. in refrig
Turkey Breast [5 - 6 lbs. (2.5 - 3 kg)]	8 to 12	Turn over 2 to 3 times		


# Sensor Defrost

<p>1.</p> 	<p>Press Place unwrapped food in the <b>center</b> of the SPECIAL DEFROST RACK which is to be used <b>ONLY</b> for defrosting. MENU ACTION MESSAGE is <b>"SENSOR DEFROST -- PLACE FOOD ON DEFROSTING RACK PRESS START"</b>. <b>START</b> flashes.</p>
<p>2.</p> 	<p>Press <b>Start</b> MENU ACTION MESSAGE is <b>"CLOSE DOOR"</b> <b>"AUTO"</b> appears in the Display Window. After <b>TWO</b> beeps, the remaining defrost time will appear in the Display Window.</p>
	<p>Time will count down. Part-way through the time, <b>TWO</b> beeps sound. MENU ACTION MESSAGE is <b>"TURN OVER"</b>. Time continues to count down. At the end of the time - <b>FIVE</b> beeps will sound and <b>"ENJOY YOUR MEAL"</b> will appear in the Display Window. (See page 11 for proper standing times.)</p>





The SENSOR DEFROST system works by detecting the changes in temperature within the oven cavity and then programming the oven to defrost the food.

1. Prepare foods properly (see "Defrosting Tips and Techniques" on page 11).
2. For optimum results, food weight should be between 0.5 lb. and 7 lbs. (230g - 3 kg). Food less than 0.5 lb. will begin to cook; therefore, use TIME DEFROST (page 10). For smaller portions, see DEFROSTING CHART on page 11 for proper times.
3. The interior of your oven and the glass tray should be clean and dry.
4. Place the UNWRAPPED food in the center of the DEFROST RACK. (RACK is ONLY for defrosting.)
5. Do NOT cover food when using SENSOR DEFROST.
6. Because foods vary in both size and shape, you will find it helpful to turn your food over, pull it apart or rearrange at the second beep. This will give you the BEST results.
7. If the Display Message is "RETURN FOOD TO FREEZER - - -", follow directions. This allows the Defrost Sensor to operate properly.

The food being defrosted must be elevated on the SPECIAL DEFROST RACK to get the desired results.






- A) Always center your uncovered food on the SPECIAL DEFROST RACK when using the SENSOR DEFROST.
- B&C) By placing food directly in dish or directly on the glass turntable, the defrosting process will be inaccurate.
- D) When defrosting small items such as scallops or shrimp, stack them rather than scatter for best results.



# Sensor Reheat / Sensor Cooking

The **GENIUS** feature allows you to reheat/cook most of your favorite foods without having to select reheating/cooking times and power levels. THE OVEN DOES IT ALL FOR YOU.

1) Select SENSOR PAD ex. Potatoes (any quantity) 		PRESS until proper food is displayed. MENU ACTION MESSAGE is <b>"POTATO -- PRESS START"</b> .
2) MORE/LESS* Optional		
3) 	PRESS. MENU ACTION MESSAGE is <b>"POTATO"</b> . Cooking will start. After steam is detected by the SENSOR, 2 beeps will sound, the remaining cooking time appears in the Display Window and begins to count down. To recall the selected category during cooking, press any sensor cooking pad. The category will appear in the display.	

## \*MORE/LESS PAD



Preferences for food doneness vary with each individual. After having used Sensor Cooking a few times, you may decide you would prefer your food cooked to a different doneness. By using the **MORE/LESS** pad, the programs can be adjusted to cook food for a longer or shorter time.

1 tap = MORE cooking

2 taps = LESS cooking

Press **MORE/LESS** before pressing **START**.

## Sensor Reheat Pad

1) 	PRESS. MENU ACTION MESSAGE is <b>"SENSOR REHEAT -- PRESS START"</b> . START flashes.	
2) MORE/LESS* Optional		
3) 	PRESS. MENU ACTION MESSAGE is <b>"SENSOR REHEAT -- CLOSE DOOR"</b> . Sensor evaluation begins. After 2 beeps, display will count-down.	

## NOTES ON SENSOR REHEAT:

Follow the recommendations on page 14, in addition to the following:

### DO NOT:

1. Reheat bread and pastry products. Use manual power and time.
2. Reheat raw or uncooked food.
3. Use if oven cavity is warm.
4. Use for beverages.
5. Use for frozen foods.

**Casseroles** - Add 3 to 4 tablespoons of liquid; cover with lid or plastic wrap. Stir when time appears in the display window.

**Canned foods** - Empty contents into casserole dish or serving bowl; cover dish with lid or plastic wrap. After reheating, release plastic wrap and stand.

**Plate of food** - Arrange food on plate; top with butter, gravy, etc. After reheating, release plastic wrap and stand.

Food	Starting Temp.	Weight per Serving
Plate of Food	Refrig.	12 - 16 oz.
Meat, Poultry	Refrig.	4 - 6 oz.
Casseroles	Refrig.	8 oz.
Side dishes	Refrig. or Room	4 - 6 oz.
Soups, Sauces, Gravies	Refrig. or Room	6 - 8 oz.

# Sensor Cooking

	CATEGORY	WEIGHT RANGE	INSTRUCTIONS
Potato/ Vegetables	1 x Potato	any amount	Pierce several times and place on a microwave safe dish. Do not cover. After beep, turn over.
	2 x Fresh Vegetables	any amount	Add water. Cover loosely with a lid or plastic wrap. After beep, stir or rearrange.
	3 x Frozen Vegetables	any amount	Add 2 tbsp of water. Do not cook with butter or sauce. Cover with plastic wrap. After beep, stir or rearrange.
Rice/Pasta	1 x Rice	Rice . . . Hot water ½ cup . . . 1 cup 1 cup . . . 2 cups 1½ cup . . . 3 cups 2 cups . . . 3½ cups	Place rice and hot water with ¼ to 1 teaspoon salt. Cover with lid or plastic wrap. After beep, stir several times. After cooking, stir and let stand 5 to 10 mins.
	2 x Pasta	4 - 8 oz. (120 - 230 g)	Place 1½-quarts of hot water, pasta, 1 tbsp. oil and 1 tsp. salt in a 4-qt. casserole. Cover with lid. After beep, stir occasionally. After cooking, rinse pasta with cold water.
Frozen Foods	1 x Frozen Entrees	any size	Follow manufacturers' directions for covering or removing covers. For best results, do not use frozen foods packaged in foil tray. After beep, stir if possible or ladle gravy or sauce over.
	2 x Frozen Dinners	any size	
Casserole/ Stew	1 x Casserole	up to 4 qt.	Use appropriate amount of liquid. Cover with casserole lid. Stir occasionally or rearrange after beep. Use recipes in the Cooking Guide section.
	2 x Stew	up to 4 qt.	
Seafood	1 x Fish Fillets	½ lb. min. (230 g min.)	Arrange in a single layer in dish. Cover with lid or plastic wrap. Stir or rearrange after beep.
	2 x Shellfish	½ lb. min. (230 g min.)	
Poultry/Meat	1 x Bacon	2 - 6 slices	Place on microwave safe dish. Cover with paper towels.
	2 x Chicken Pieces	½ lb. min. (230 g min.)	Place skin-side up. Cover with plastic wrap. Rearrange after beep.
	3 x Whole Chicken	up to 6 lb. (3 kg)	Place breast-side down. Cover completely with plastic wrap. After beep, turn breast-side up, recover.
	4 x Pork (roast)	2 - 4 lb. (1 - 2 kg)	Place fat-side down. Cover with plastic wrap. After beep, turn over, recover, shield ends of roast with foil if necessary. Pork must reach 170°F (77°C) before serving.
	5 x Beef-medium	2 - 4 lb. (1 - 2 kg)	Place fat-side up. Cover with plastic wrap.

For best results by Sensor, follow these recommendations.

## BEFORE Reheating/Cooking:

1. The room temperature surrounding the oven should be below 95°F (35°C).
2. Food weight should be between 4 oz (120 g) and 24 oz (680 g).
3. Glass Tray and outside of container should be dry.
4. Cover foods loosely, but completely, with plastic wrap or place foods in a casserole dish with a proper fitting lid.
5. All foods should be taken from their normal storage place.

## DURING Reheating/Cooking:


While "AUTO" is displayed in the Display Window, DO NOT open door. This causes inaccurate cooking results. Once the timer begins to count down, the oven door may be opened to stir, turn, shield or add foods.

## AFTER Reheating/Cooking:

All foods should have a covered stand time.






# Popcorn Function



**1** Press Popcorn

**2** Serving/Weight

<p>1. </p>	<p>PRESS: MENU ACTION MESSAGE is "POPCORN -PRESS SERV/WEIGHT" "SERVING/WEIGHT" flashes.</p>								
<p>2. Ex. 3.0 oz. (90 g)</p> <p></p> <p>2 times is 3.0 oz.</p>	<p>Press: MENU ACTION MESSAGE is "-- PRESS START 3.0 OZ" "START" flashes.</p> <table border="1" data-bbox="1141 703 1468 798"> <thead> <tr> <th>Press</th> <th>Weight</th> </tr> </thead> <tbody> <tr> <td>once</td> <td>3.5 oz. (99 g)</td> </tr> <tr> <td>twice</td> <td>3.0 oz. (90 g)</td> </tr> <tr> <td>three times</td> <td>1.75 oz. (50 g)</td> </tr> </tbody> </table>	Press	Weight	once	3.5 oz. (99 g)	twice	3.0 oz. (90 g)	three times	1.75 oz. (50 g)
Press	Weight								
once	3.5 oz. (99 g)								
twice	3.0 oz. (90 g)								
three times	1.75 oz. (50 g)								
<p>3. </p>	<p>PRESS: Clock counts down. Five beeps are normally heard at end of cooking cycle.</p>								

**NOTE:**

1. Use prepackaged **room temperature** microwave popcorn. Read manufacturers' instructions.
2. Place bag in oven according to manufacturers' directions.
3. Pop only one bag at a time.
4. After popping, allow the contents of the bag to cool for a few minutes before opening. Open bag carefully away from face and body because popcorn and steam are extremely hot.
5. Do not reheat unpopped kernels or reuse bag.
6. **Never** leave oven unattended when popping popcorn.

**CAUTION:** If pre-packaged popcorn is of a different weight than the recommended weight, do not use the popcorn setting, since inadequate popping or a fire may occur. Follow the manufacturers' instructions.

# Quick Min

This feature allows you to set cooking times easily instead of using Number Pads or to add extra cooking time.

**To Set Cooking Time:**



1. Press to set cooking time (up to 10 minutes).
2. Press Start Pad. Cooking will start on HIGH power.

- To use other power levels, select the desired power level before setting the cooking time.
- If you use **Quick Min** Pad to set your cooking time, you cannot use Number Pads to set more time or to change the cooking time. However, you can add more time with **Quick Min** Pad during cooking.

**To Add Extra Cooking Time during cooking:**




Press **Quick Min** Pad to add extra cooking time (up to 10 taps) during cooking.

- Cooking time changes to include extra time and continues to count down in the display.
- Extra time can be added during any of the three stages.

# Timer/Clock Function

This feature allows you to program a standing time after cooking is completed and to program the oven as a minute timer and/or to program delay start.




## To Use as a Timer

### 1 Press Timer

PRESS once for **TIMER**. MENU ACTION MESSAGE is "TIMER -- SET TIME" (up to 99 min & 99 seconds). Number pad flashes.

### 2 Set desired amount of Time

Example: Set the time for 15 minutes using flashing number pad




MENU ACTION MESSAGE is "TIMER 15 min 00 sec -- PRESS START". **Start** flashes.


### 3 Press Start

Display counts down without oven operating. Five beeps will normally sound at the end (see **FUNCTION** pad for options). MENU ACTION MESSAGE is "ENJOY YOUR MEAL".

## To Set Stand Time



## To Set Delay Time



### NOTE:

1. When the first/second stage has finished, a two beep signal is heard. After all the stages have been completed, the oven will beep five times.
2. If oven door is opened during the Stand Time of Kitchen Timer, the time in the display window will continue to count down.
3. Delay Start cannot be programmed before any Sensor Control Function. This is to prevent the starting temperature of the food from rising before defrosting or cooking begins. A change in the starting temperature could cause inaccurate cooking results.
4. Timer can be set up to 99 minutes and 99 seconds.

## Food Characteristics

### Bone and Fat

Both bone and fat affect cooking. Bones may cause irregular cooking. Meat next to the tips of bones may overcook while meat positioned under a large bone, such as a ham bone, may be undercooked. Large amounts of fat absorb microwave energy and the meat next to these areas may overcook.

### Density

Porous, airy foods such as breads, cakes or rolls take less time to cook than heavy, dense foods such as potatoes and roasts. When reheating donuts or other foods with different centers be very careful. Certain foods have centers made with sugar, water or fat and these centers attract microwaves (For ex., jelly donuts). When a jelly donut is heated, the jelly can become extremely hot while the exterior remains warm to the touch. This could result in a burn if the food is not allowed to cool properly in the center.

### Quantity

Two potatoes take longer to cook than one potato. As the quantity of the food increases so does the cooking time. When cooking small amounts of food such as one or two potatoes, do not leave oven unattended. The moisture content in the food may decrease and a fire could result.

### Shape

Uniform sizes heat more evenly. The thin end of a drumstick will cook more quickly than the meaty end. To compensate for irregular shapes, place thin parts toward the center of the dish and thick pieces toward the edge.

### Size


Thin pieces cook more quickly than thick pieces.

### Starting Temperature

Foods that are room temperature take less time to cook than if they are chilled or refrigerated or frozen.

## Cooking Techniques

### Piercing



Foods with skins or membranes must be pierced, scored or have a strip of skin peeled before cooking to allow steam to escape. Pierce whole egg yolks and whites, clams, oysters, chicken livers, whole potatoes and whole vegetables. Whole apples or new potatoes should have a 1-inch strip of skin peeled before cooking. Score sausage and frankfurters.

### Browning




Foods will not have the same brown appearance as conventionally cooked foods or these foods which are cooked utilizing the browning feature. Meats and poultry may be coated with browning sauce, Worcestershire sauce, barbecue sauce or shake-on browning sauce. To use, combine browning sauce with melted butter or margarine; brush on before cooking.

For quick breads or muffins brown sugar can be used in the recipe in place of granulated sugar, or the surface can be sprinkled with dark spices before baking.


# Cooking Techniques

## Spacing



Individual foods, such as baked potatoes, cupcakes and appetizers, will cook more evenly if placed in the oven equal distances apart. When possible, arrange foods in a circular pattern.

## Covering



As with conventional cooking, moisture evaporates during microwave cooking. Casserole lids or plastic wrap are used for a tighter seal. When using plastic wrap, vent the plastic wrap by folding back part of the plastic wrap from the edge of the dish to allow steam to escape. Loosen or remove plastic wrap as recipe directs for stand time. When removing plastic wrap covers, as well as any glass lids, be careful to remove them away from you to avoid steam burns. Various degrees of moisture retention are also obtained by using wax paper or paper towels. However, unless specified, a recipe is cooked uncovered.

## Shielding

Thin areas of meat and poultry cook more quickly than meaty portions. To prevent overcooking, these thin areas can be shielded with strips of aluminum foil. Wooden toothpicks may be used to hold the foil in place.

## Timing

A range in cooking time is given in each recipe. The time range compensates for the uncontrollable differences in food shapes, starting temperature and regional preferences. Always cook food for the minimum cooking time given in the recipe and check for doneness. If the food is undercooked, continue cooking. It is easier to add time to an undercooked product. Once the food is overcooked, nothing can be done.

## Stirring

Stirring is usually necessary during microwave cooking. We have noted when stirring is helpful, using the words once, twice, frequently or occasionally to describe the amount of stirring necessary. Always bring the cooked outside edges toward the center and the less cooked center portions toward the outside of the dish.

## Rearranging

Rearrange small items such as chicken pieces, shrimp, hamburger patties or pork chops. Rearrange pieces from the edge to the center and pieces from the center to the edge of the dish.

## Turning

It is not possible to stir some foods to redistribute the heat. At times microwave energy will concentrate in one area of a food. To help insure even cooking, these foods need to be turned. Turn over large foods, such as roasts or turkeys, halfway through cooking.

## Stand Time

Most foods will continue to cook by conduction after the microwave oven is turned off. In meat cookery, the internal temperature will rise 5°F to 15°F (3°C to 8°C) if allowed to stand, tented with foil, for 10 to 15 minutes. Casseroles and vegetables need a shorter amount of standing time, but this standing time is necessary to allow foods to complete cooking in the center without overcooking on the edges.

## Testing for Doneness

The same tests for doneness used in conventional cooking may be used for microwave cooking. Meat is done when fork-tender or splits at fibers. Chicken is done when juices are clear yellow and drumstick moves freely. Fish is done when it flakes and is opaque.

# Appetizers

## ORIENTAL DUMPLINGS

### Filling:

- ½ pound cooked pork, finely chopped
- ½ pound shrimp, cleaned and finely chopped
- ¼ cup finely chopped green onions
- 1 tablespoon chopped parsley
- 1 jalapeño pepper, finely chopped
- 1 teaspoon salt
- ¼ teaspoon pepper
- 1 egg white

Wonton wrappers, (Approximately 1 lb.)

Water

Yield: Approximately 45 Dumplings

In medium bowl combine all filling ingredients. Place a teaspoon of filling mixture in center of a wonton wrapper. Wet inside edges of wrapper with small amount of water. Fold top left and bottom right corner of wrapper over filling and press together to seal.

Place 11 dumplings on microwave safe rack. Heat 1½ cups water in 2-cup glass measure at **HIGH** 2½ to 3 minutes. Pour water into bottom of 4-quart casserole. Set rack with dumplings in casserole dish. (Rack should be high enough so water does not reach bottom of dumplings.) Brush dumplings with water. Cover with lid. Heat at **HIGH** 2½ to 3 minutes. Turn dumplings over; brush with water. Recover. Heat at **HIGH** 2½ to 3 minutes. Repeat with remaining dumplings. Serve with plum sauce or other dipping sauces.

## STUFFED ZUCCHINI

- 3 zucchini
- 1 tablespoon olive oil
- 2 cloves garlic, chopped
- ½ onion, chopped
- 1 tomato, chopped
- ½ teaspoon pepper
- ¼ teaspoon oregano
- ¼ teaspoon basil
- ¼ teaspoon parsley

Yield: 16 to 20 Appetizers

Halve zucchini lengthwise. Scoop out pulp and set aside. In a small bowl, combine olive oil, garlic and onion. Cook at **HIGH** 1½ minutes. Add zucchini pulp, tomato, pepper, oregano, basil and parsley. Cook at **HIGH** 2 minutes. Stir once. Drain mixture and set aside. Pat zucchini shells dry. Place tomato mixture in each shell. Cut into bite-size pieces. Place on a microwave- and heat-safe serving plate.

Cook at **HIGH** 6 to 7 minutes. Let stand, uncovered, 2 minutes before serving.

## ORIENTAL SPARERIBS

- 2 pounds pork spareribs, cut in 1 rib portions
- ½ cup soy sauce
- ½ cup honey
- ¼ cup green onion, finely chopped
- 1 tablespoon rice wine vinegar
- ½ to 1 tablespoon fresh ginger, finely chopped
- ¼ teaspoon crushed red pepper
- 2 cloves garlic, finely chopped

Yield: 20 Appetizers

Arrange ribs meat-side down in a 2½-quart shallow oval casserole dish. Combine remaining ingredients. Brush ribs with marinade.

Cook at **HIGH** 7 to 8 minutes. Turn ribs over and baste with marinade. Cook at **MEDIUM** 7 to 8 minutes, or until ribs are tender.

## STUFFED MUSHROOMS

- 1 pound medium mushrooms (about 24), cleaned
- 4 slices bacon, chopped
- 1 small onion, finely chopped
- ½ cup dry bread crumbs
- ½ cup white wine or water
- ¼ cup grated Parmesan cheese
- ¼ teaspoon pepper

Yield: 24 Mushrooms (about 6 Servings)

Remove stems from mushrooms. Finely chop enough stems to equal 1 cup; set aside. Place bacon and onion in bowl. Cook at **HIGH** 5 to 6½ minutes, or until bacon is crisp and onion is tender; stir once. Drain. Stir in chopped mushroom stems, bread crumbs, wine, cheese and pepper. Stuff mushroom caps with bread crumb mixture. Arrange half of mushrooms in a circular pattern in a 9-inch microwave-safe pie plate.

Cover with wax paper. Cook at **HIGH** 5 to 5½ minutes. Let stand, uncovered, 2 minutes before serving. Repeat procedure with remaining mushrooms.

# Meats

## Directions for Roasting Meats

**Tender cuts**, such as beef and lamb roasts should be covered with wax paper to prevent spattering. For pork roasts or hams, cover with plastic wrap or place in an oven cooking bag.




**Less tender cuts**, such as pot roasts, should be cooked in liquid. Use 1 cup of liquid such as soup or broth per pound of meat. Use an oven cooking bag or covered casserole. Select a covered casserole deep enough so that the meat does not touch the lid.

### TO COOK BY TIME:

Multiply the weight of the roast by the minimum recommended minutes per pound. Program Power and Time.

### TO COOK BY SENSOR COOKING:

Place meat according to "Special Instructions" below. Cover with plastic wrap. Turn Pork Roast fat-side up halfway through cooking time.

1) 	<b>PRESS</b> once = bacon twice = chicken pieces 3 times = whole chicken 4 times = <b>PORK</b> 5 times = <b>BEEF-MEDIUM</b>
2)  (optional)	<b>SELECT DONENESS</b> once = more twice = less
3) 	<b>PRESS</b>

## Meat Roasting Chart for Sensor & Time Cooking

MEAT	SENSOR COOKING CATEGORY	POWER & TIME COOKING [time in min/lb. (450 g)]		TEMP. AFTER COOKING	SPECIAL INSTRUCTIONS	
<b>BEEF ROASTS</b> [2½ to 4 Lb. (1.2 to 2 kg)] Rib/Boneless Rib/Top Sirloin Rare Medium Well Rump, Eye of round (High Quality) Rare Medium Well	— <b>BEEF-MEDIUM</b> —	<b>MEDIUM</b>	9 to 11	130°F (55°C)	Place roast fat-side up. Cover roast with plastic wrap.	
		<b>MEDIUM</b>	12 to 14	140°F (60°C)		
		<b>MEDIUM</b>	14½ to 16½	160°F (70°C)		
	— <b>BEEF-MEDIUM</b> —	<b>MEDIUM</b>	9 to 12	130°F (55°C)		
		<b>MEDIUM</b>	11 to 13	140°F (60°C)		
		<b>MEDIUM</b>	14 to 17	160°F (70°C)		
<b>BEEF POT ROAST</b> [2½ to 3½ Lb. (1.2 to 1.7 kg)] Chuck, Rump	—	<b>MEDIUM LOW</b>	30 to 35	—	Cover meat with liquid. Turn meat over half of cooking time.	
<b>PORK ROASTS</b> [2½ to 4 Lb. (1.2 to 2 kg)] Bone-in Boneless	PORK PORK	<b>MEDIUM</b>	15 to 18	170°F (77°C)	Place roast fat-side down. Cover pork with plastic wrap. Turn over halfway through cooking time.	
		<b>MEDIUM</b>	15 to 18	170°F (77°C)		
<b>HAM (fully cooked)*</b> Canned [3 Lb. (1.5 kg)] Butt [8 Lb. (4 kg)] Shank [8 Lb. (4 kg)] Slice, 1-inch (2.5 cm) thick [1Lb (500 g)]	—	<b>MEDIUM</b>	8 to 12	140°F (60°C)	Place ham fat-side up. Cover ham with plastic wrap, except slice.	
		<b>MEDIUM</b>	13 to 15	140°F (60°C)		
		<b>MEDIUM</b>	13 to 15	140°F (60°C)		
	<b>HIGH</b>	5 to 8	—			
<b>LAMB ROASTS</b> [2½ to 4 lb. (1.2 to 2 kg)] Bone-in Medium Well Boneless Medium Well	—	<b>MEDIUM</b>	8½ to 13	140°F (60°C)	Place fat-side up. Cover with wax paper.	
		<b>MEDIUM</b>	11 to 16	160°F (70°C)		
		<b>MEDIUM</b>	8 to 11	140°F (60°C)		
	<b>MEDIUM</b>	10 to 15	160°F (70°C)			

\* The recommended maximum weight will vary according to the cavity size of your microwave oven model and the shape of meat.

# Meats

## Directions for Convenience Meats

Pierce sausage links with fork and score frankfurters before cooking.

Arrange food in a single layer in dish. Cover with wax paper to prevent spatter. Bacon may be placed on a microwave-safe dish. Cook according to time given in chart.

Let stand according to recommended time in chart.

### Convenience Meats Chart

MEAT	AMOUNT	POWER	APPROX. COOKING TIME (in minutes)	STAND TIME (in minutes)
Bacon, Slices	2 3 4	HIGH	1 to 2 2 to 2½ 2½ to 3	1
Canadian Bacon, Slices [1 oz. (30 g)]	2 4 6	MEDIUM-HIGH	½ to ¾ 1 to 2 3 to 4	1
Frankfurters, scored	2 4	HIGH	2 to 3 3 to 4	3
Ham, Slices [about 2 oz. (60 g) ea.]	2 4	HIGH	1½ to 2½ 2½ to 3½	2
Hamburgers, well [4 oz. (120 g) ea.]	1 2 4	HIGH	2 to 3 3 to 4 4½ to 5½	2
Lamb Chops, shoulder, ¾-inch (2 cm) thick	2 (about ½ lb.) 4 (about 1 lb.)	MEDIUM-HIGH	5½ to 7 10½ to 12	3
Pork Chops, rib or loin, ½-inch (1 cm) thick	2 (about ½ lb.) 4 (about 1 lb.)	MEDIUM-HIGH	4½ to 5½ 8 to 10	3
Sausage Links, frozen [precooked, brown and serve]	2 4 8	HIGH	1 to 2½ 1½ to 2½ 3 to 4	2
Sausage Links, fresh [2 to 3 oz. (60 to 90 g) ea.]	2 4 8	HIGH	4 to 6 6 to 8 8 to 10	3

# Meats

## CURRY LAMB

1 small onion, finely chopped  
¼ cup butter or margarine  
3 tablespoons flour  
1 pound boneless lamb, cut into 1½-inch cubes  
1 can (10¾ oz.) chicken broth  
⅓ cup raisins  
⅓ cup peanuts  
3 tablespoons lemon juice  
1 tablespoon curry powder  
½ teaspoon ginger  
½ teaspoon salt  
½ cup flaked coconut  
2 cups cooked rice (see page 33)

**Yield:** 4 Servings

Cook onion and butter in 2-quart casserole at **HIGH** 5 to 6 minutes; stir once. Stir in flour, lamb, broth, raisins, peanuts, lemon juice, curry powder, ginger and salt. Cover with lid. Cook at **HIGH** 5 minutes and at **MEDIUM-LOW** 20 to 25 minutes or until lamb is tender; stir twice. Sprinkle with coconut. Let stand, covered, 5 minutes. Serve over hot rice.

## BEEF WITH BROCCOLI

1 tablespoon oil  
¾ pound boneless steak, cut into thin strips  
1 clove garlic, finely chopped  
½ teaspoon ginger  
1½ cups broccoli flowerets  
1 tablespoon cornstarch  
½ cup beef broth  
1 tablespoon sherry  
1 tablespoon soy sauce  
Toasted sesame seeds (see page 38)

**Yield:** 4 Servings

Heat oil in 11 x 7-inch dish at **HIGH** 2 minutes. Stir in beef, garlic and ginger. Cook at **HIGH** 3½ to 4½ minutes. Stir twice. Stir in broccoli. Cover with plastic wrap. Cook at **HIGH** 3 to 5 minutes, or until broccoli is tender-crisp; stir once. Blend cornstarch with broth, sherry, and soy sauce until smooth. Stir into beef mixture. Cook at **HIGH** 3 to 4 minutes, or until sauce is thickened. Stir once. Top with sesame seeds.

## VEAL CUTLETS CORDON BLEU

4 veal cutlets (about 1 lb.), pounded thin\*  
2 thin slices cooked ham, halved  
2 thin slices Swiss cheese halved  
1 cup seasoned dry bread crumbs  
½ teaspoon salt  
¼ teaspoon pepper  
Dash allspice  
1 egg, beaten with ¼ cup water  
3 tablespoons oil

**Yield:** 4 Servings

On one side of each cutlet, place ham and cheese; fold cutlet in half. Pound edges together to seal or secure with wooden toothpicks. Dip cutlets in egg and then in bread crumbs mixed with salt, pepper and allspice. Coat bottom of 2½-quart shallow oval casserole dish with half of oil; place cutlets in dish. Sprinkle remaining oil on cutlets.

Cook at **HIGH** 3½ minutes. Turn cutlets over. Cook at **MEDIUM** 4½ minutes. Let stand, covered with wax paper, 5 minutes before serving.

*\*Variation: Substitute chicken cutlets for veal.*

## BASIC MEAT LOAF

1½ pounds lean ground beef  
1 cup soft bread crumbs  
¼ cup toasted wheat germ  
½ cup milk  
1 medium onion, chopped  
2 eggs, slightly beaten  
1½ teaspoons salt  
¼ teaspoon pepper  
1 can (8 oz.) tomato sauce, optional

**Yield:** 6 Servings

In a large bowl, stir all ingredients except tomato sauce until smooth. Pat mixture in oval shape into 11 x 7-inch dish.

**TO COOK:** Cook at **MEDIUM** 20 to 24 minutes.

**TO COMPLETE:** Let stand, covered, 5 minutes. Drain off excess juice. Invert meat loaf onto serving platter. If desired, spread tomato sauce over meat loaf.



# Meats

## APPLE-STUFFED PORK CHOPS

4 pork chops, 1-inch thick  
¼ cup butter or margarine, melted  
½ cup chopped apple  
½ cup herb-seasoned stuffing mix  
¼ cup (1 oz.) shredded Cheddar cheese  
2 tablespoons chopped celery  
1 tablespoon chopped onion  
1 tablespoon chopped raisins  
2 tablespoons orange juice  
¼ teaspoon Worcestershire sauce  
1 tablespoon water

**Yield:** 4 Servings

Cut a horizontal slit in each pork chop to form pocket. In small mixing bowl, combine butter, apple, stuffing mix, cheese, celery, onion, raisins and orange juice; mix well. Fill each pocket with stuffing mix; secure opening with wooden toothpicks. Arrange pork chops in 11 x 7-inch dish. Mix Worcestershire with water and brush on pork chops.

**TO COOK:** Cook at **HIGH** 17 to 19 minutes.

**TO COMPLETE:** Let stand, covered, 5 minutes. Meanwhile, place remainder of stuffing in a small microwave-safe bowl. Cover with plastic wrap. Cook at **MEDIUM** 2 to 3 minutes, or until hot.

## SPICY SAUSAGE STEW

1 pound Italian sausage links, cut into 1½-inch pieces  
1 pound boneless pork, cut into 1-inch cubes  
1 can (28 oz.) whole tomatoes, chopped  
1 can (8 oz.) tomato sauce  
1 green pepper, cut into chunks  
1 teaspoon basil  
1 teaspoon oregano  
½ teaspoon garlic powder

**Yield:** 6 Servings

In 3-quart casserole dish, heat sausage at **HIGH** 5 to 6 minutes; stir once. Drain. Stir in remaining ingredients. Cover with glass lid.

**TO COOK BY SENSOR COOKING:** Cook on **Stew**. After time appears in Display Window, stir occasionally.

**TO COOK BY TIME:** Heat at **HIGH** for 5 to 6 minutes then at **LOW** for 55 to 58 minutes, or until pork is tender. Stir occasionally.

**TO COMPLETE:** Skim off fat from liquid. Serve, if desired, with rice or pasta.

## SWEET'N SOUR PORK

1 can (8¼ oz.) chunk pineapple in heavy syrup, drained; reserve ½ cup syrup  
¼ cup cider vinegar  
1 tablespoon cornstarch  
2 tablespoons oil  
1 pound boneless pork, cut into ¾ inch cubes  
¼ cup soy sauce  
1 bunch green onions, thinly sliced (about 3 tbsp.)  
1 green pepper, cut into small chunks

**Yield:** 4 Servings

In small glass bowl, combine reserved syrup, vinegar and cornstarch. Cook at **HIGH** 1½ to 2 minutes, or until thickened; stir once.

Heat oil in 8-inch square dish at **HIGH** 2 minutes. Stir in pork, soy sauce and onion. Cook at **HIGH** 7 to 9 minutes; stir twice. Add green pepper and pineapple. Cook, covered with plastic wrap, at **HIGH** 4 to 5 minutes, or until pork is done. Stir in sauce and let stand, covered, 5 minutes before serving.

## IRISH STEW

2 pounds boneless lamb, cut into 1-inch cubes  
2 medium carrots, sliced into ¼-inch pieces  
2 potatoes (about 6 oz. ea.), peeled and cubed  
2½ cups water, divided  
1 envelope (1 oz.) onion-mushroom soup mix  
1 bay leaf  
¼ cup flour

**Yield:** 8 Servings

In 4-quart casserole dish, arrange lamb, carrots and potatoes forming three separate layers. In bowl, combine 2 cups hot water, onion-mushroom mix and bay leaf. Stir together until well blended. Pour mixture over potatoes. Cover with glass lid.

**TO COOK BY SENSOR COOKING:** Cook on **Stew**. After time appears in Display Window, stir twice.

**TO COOK BY TIME:** Heat at **HIGH** 7 to 8 minutes and at **LOW** 70 to 75 minutes. Stir twice.

**TO COMPLETE:** Blend flour with remaining ½ cup water. Stir into dish\*. Heat at **HIGH** 4 to 5 minutes, or until stew is thickened.

\*If desired, add ¼ teaspoon browning sauce.

# Poultry

## Directions for Roasting Poultry

Season as desired, but salt only after cooking. Browning sauce mixed with equal parts of butter will enhance appearance.

Poultry may be stuffed or unstuffed. Tie legs together with cotton string. Whole chicken should be placed **breast-side down** on a microwave roasting rack set in an 8-to 10-inch square dish or 2½-quart shallow oval casserole dish.

Cover with wax paper to prevent spattering.

During cooking it may be necessary to shield legs, wings and breast bone to prevent overcooking. Wooden toothpicks can be used to hold foil in place.

If a large amount of juice accumulates in the bottom of the baking dish, occasionally drain it. If desired, reserve for making gravy.

### To Cook Whole Poultry:

Multiply the weight of the poultry by the minimum recommended minutes per pound. Program Power and Time.




### To Cook Chicken Parts:

Arrange pieces skin-side up, with meatier portions toward edge of dish. Cover with wax paper. Poultry is cooked when juices are clear. If there is a slight pink color in the juice, return poultry parts to the oven and cook one or two minutes longer.

Let stand, covered, 5 minutes before serving.

## TO COOK BY SENSOR COOKING:

Arrange pieces skin-side up, whole poultry breast-side up, with meatier portions towards edge of dish. Cover completely with plastic wrap. Cook on Sensor Cooking Category.

1) 	<b>PRESS</b> once = bacon twice = <b>CHICKEN PIECES</b> 3 times = <b>WHOLE CHICKEN</b> 4 times = pork 5 times = beef-medium
2)  (optional)	<b>SELECT DONENESS</b> once = more twice = less
3) 	<b>PRESS</b>

**After Cooking**, check the temperature of large chickens and turkeys with a meat thermometer. Check the temperature in both thigh muscles. If the thermometer touches bone, the reading may be inaccurate.

**DO NOT use a conventional thermometer in the oven** when cooking by microwave. Use only a microwave-safe thermometer.

## Poultry Chart for Sensor & Time Cooking

POULTRY	SENSOR COOKING CATEGORY	POWER & TIME COOKING [time in min/lb. (450 g)]	TEMP. AFTER COOKING	SPECIAL INSTRUCTIONS	
<b>Cornish Hens, whole</b> [1 to 1½ lb. (500 to 750 g) ea.]	—	<b>HIGH</b>	7 to 9	Place breast-side up.	
<b>Chicken parts</b>	<b>CHICKEN PIECES</b>		7 to 8	Place skin-side up. Cover with plastic wrap	
<b>Chickens</b> [up to 4 lb. (2kg)]	<b>WHOLE CHICKEN</b>	<b>MEDIUM-HIGH</b>	8½ to 11½	Place breast-side down. Turn breast-side up after half of cooking time. Cover with plastic wrap.	
<b>Chickens</b> [4 to 6 lb. (2 to 3 kg)]			14 to 16		180°F–190°F (80°C–90°C)
<b>Turkey Breast</b> [5 to 7 lb. (2.5 to 3.5 kg)]	—	<b>MEDIUM</b>	15 to 17	180°F–190°F (80°C–90°C)	Place breast-side up.
<b>Duck</b> [3 to 5 lb. (1.5 to 2.5 kg)]	—	<b>MEDIUM-HIGH</b>	8 to 10	180°F–190°F (80°C–90°C)	—
<b>Turkey*</b> [8 to 12 lb. (4 to 6 kg)]	—		12 to 14	180°F (80°C)	—

\* The recommended maximum weight of turkey will vary according to the cavity size of your microwave oven model.

# Poultry

## CALIFORNIA CHICKEN

2 chicken breasts, split (1 $\frac{3}{4}$  to 2 lb.)  
2 teaspoons lemon juice  
1 teaspoon dried onion flakes  
Basil  
Pepper  
 $\frac{1}{3}$  cup (3 $\frac{2}{3}$  oz.) shredded Cheddar cheese, divided  
 $\frac{1}{2}$  small avocado, thinly sliced  
4 thin slices tomato

**Yield:** 4 Servings

Arrange chicken in 8-inch square dish with meatier portions toward edge of dish. Sprinkle with lemon juice, onion flakes, basil and pepper.

**TO COOK BY SENSOR COOKING:** Cover completely with plastic wrap. Cook on **CHICKEN PIECES**.

**TO COOK BY TIME:** Cover completely with wax paper. Cook at **HIGH** 12 to 15 minutes, or until chicken is tender.

**TO COMPLETE:** Top chicken with  $\frac{1}{3}$  cup cheese, avocado, tomato and remaining cheese. Cover with wax paper. Cook at **HIGH** 2 minutes. Let stand, covered, 5 minutes before serving.

## STUFFED CORNISH HENS WITH ORANGE SAUCE

2 $\frac{1}{2}$  cups hot water  
1 can (6 oz.) frozen orange juice concentrate, defrosted and divided  
1 package (6 oz.) long grain and wild rice mix  
4 slices bacon, cooked and crumbled  
4 Cornish hens (1 lb. ea.)  
 $\frac{1}{4}$  cup honey  
 $\frac{1}{4}$  to  $\frac{1}{2}$  teaspoon browning sauce

**Yield:** 4 Servings

In 2-quart casserole, combine water,  $\frac{1}{4}$  cup orange juice concentrate and rice. Cover with lid. Cook at **HIGH** 8 minutes and at **MEDIUM-HIGH** 20 minutes, or until rice is tender; stir in bacon. Stuff hens with rice mixture; tie legs together with cotton string. Place hens in a 2 $\frac{1}{2}$ -quart shallow oval casserole dish. Cover with wax paper. Cook at **HIGH** 20 to 25 minutes, or until hens are tender. Meanwhile, combine remaining orange juice concentrate, honey and browning sauce; brush hens every 10 minutes. Let stand, covered, 10 minutes before serving. Cornish hens may be cut in half before serving, if desired.

## CHICKEN PARMIGIANA

1 egg  
 $\frac{1}{4}$  cup water  
2 boneless chicken breasts, halved  
1 cup seasoned dry bread crumbs  
 $\frac{1}{2}$  cup grated Parmesan cheese  
 $\frac{1}{4}$  teaspoon paprika  
2 tablespoons oil  
1 can (8 oz.) tomato sauce or 1 cup spaghetti sauce  
Oregano  
1 cup (4 oz.) shredded mozzarella cheese

**Yield:** 4 Servings

Beat egg with water. Dip chicken in bread crumbs mixed with Parmesan cheese and paprika, then in egg and again in bread crumb mixture. Coat bottom of 8-inch square dish with 1 tablespoon oil. Place chicken in dish; sprinkle with remaining oil. Cook at **HIGH** 3 to 4 minutes; turn chicken. Cook at **HIGH** 3 to 4 minutes. Top with tomato sauce, oregano and cheese.

Cover with wax paper. Cook at **HIGH** 12 to 14 minutes, or until sauce is hot. Sprinkle with mozzarella cheese and let stand, covered, 5 minutes, or until cheese is melted.

## CHICKEN TERIYAKI

2 pounds chicken pieces  
1 can (8 oz.) chunk pineapple in pineapple juice  
1 clove garlic, finely chopped  
 $\frac{1}{4}$  cup soy sauce  
2 tablespoons packed brown sugar  
 $\frac{1}{2}$  teaspoon salt  
 $\frac{1}{4}$  teaspoon ginger

**Yield:** 4 Servings

Arrange chicken skin-side down in 2 $\frac{1}{2}$ -quart shallow oval casserole dish with meatier portions toward edge of dish. In small bowl, combine remaining ingredients; stir well. Pour sauce over chicken.

**TO COOK BY SENSOR COOKING:** Cover completely with plastic wrap. Cook on **CHICKEN PIECES**. After cooking, remove plastic wrap.

**TO COOK BY TIME:** Cover dish with wax paper. Cook at **HIGH** 8 minutes. Turn chicken skin-side up. Cook at **MEDIUM** 12 to 13 minutes.

**TO COMPLETE:** Chicken should be tender. Let stand, covered, 5 minutes. To serve, spoon pineapple sauce over chicken.

# Poultry

## CHICKEN ENCHILADAS

1 large onion, chopped  
1/2 cup chopped green pepper  
2 cups finely chopped cooked chicken or turkey  
1/2 cup chopped ripe olives  
2 cans (10 oz. ea.) mild enchilada sauce, divided  
1 1/2 cups (6 oz.) shredded Cheddar cheese, divided  
8 corn tortillas  
Shredded lettuce, optional  
1/2 cup sour cream, optional

**Yield:** 4 Servings

In medium glass bowl, combine onion and green pepper. Cover with plastic wrap. Cook at **HIGH** 3 minutes; stir once. Stir in chicken, olives and 1/2 cup enchilada sauce. Cover with plastic wrap. Cook at **HIGH** 2 minutes, or until hot. Stir in 1/2 cup cheese. Let stand, covered. Arrange two tortillas side-by-side, on paper towel. Cover with another paper towel. Repeat with remaining tortillas, stacking one layer on top of the other. Heat at **HIGH** 1 minute. (This softens tortillas and makes them easier to roll.) Spoon about 1/3 cup chicken filling down center of each tortilla. Roll up tortilla and place seam-side down in 9 1/2-inch square dish. Pour remaining sauce over tortillas. Cover with wax paper. Cook at **HIGH** 9 to 10 minutes. Top enchiladas with remaining cheese. Cook at **HIGH** 3 minutes. Let stand 3 minutes before serving. Serve garnished with lettuce and sour cream.

## VEGETABLE-STUFFED CHICKEN BREASTS

4 large boneless chicken breasts, skinned, split and pounded thin (about 2 lb.)  
Salt  
Pepper  
1 cup frozen mixed broccoli, carrots and onions, defrosted, finely chopped  
2 tablespoons butter or margarine  
1/2 cup flour  
1 egg, beaten with 2 tablespoons water  
1 cup seasoned dry bread crumbs

**Yield:** 4 Servings

Season breasts with salt and pepper. Spoon 1/4 cup of vegetables onto each breast. Top with 1/2 tablespoon butter, then fold edges over to enclose the filling. Secure with toothpicks. Coat chicken breasts with flour, dip in egg, then in bread crumbs.

Arrange chicken in 8-inch square dish, cover with wax paper. Cook at **MEDIUM** 10 to 12 minutes, or until chicken is done.

## MEXICAN CHICKEN

1 can (15 oz.) tomato sauce  
2 to 3 tablespoons jalapeño peppers, finely chopped  
2 tablespoons chopped onion  
1/4 teaspoon chili powder  
1/4 teaspoon cumin  
1/4 teaspoon red pepper  
2 ounces Monterey Jack cheese, shredded, optional  
2 1/2 to 3 pounds chicken pieces, skinned

**Yield:** 4 Servings

In small bowl, combine tomato sauce, peppers, onion, chili powder, cumin and red pepper.

Arrange chicken skin-side up in 2 1/2-quart shallow oval casserole dish, with meatier portions toward edge of dish. Spread sauce evenly over chicken. Cover with wax paper. Cook at **HIGH** 5 1/2 to 6 minutes. Baste chicken with sauce.

Cook, uncovered, at **MEDIUM** 9 1/2 to 10 minutes, or until chicken is tender. Sprinkle with cheese. Let stand, covered, 5 minutes before serving.

## CHICKEN CACCIATORE

2 1/2 to 3 pound chicken, cut into serving pieces  
1 can (15 oz.) tomato sauce  
1 jar (4 1/2 oz.) sliced mushrooms, drained  
1/2 cup chopped onion  
1 tablespoon sugar (optional)  
1 teaspoon oregano  
1 teaspoon salt  
1 clove garlic, finely chopped  
1/4 teaspoon pepper

**Yield:** 4 Servings

In 2-quart rectangular baking dish, arrange chicken, meatier portions toward edge of dish. In medium bowl, combine remaining ingredients, pour over chicken.

**TO COOK BY SENSOR COOKING:** Cover completely with plastic wrap. Cook on **STEW**. After time appears in Display Window, rearrange chicken; re-cover. After heating, remove plastic wrap.

**TO COOK BY TIME:** Cover with wax paper. Heat at **HIGH** 18 to 20 minutes. Rearrange chicken pieces once.

**TO COMPLETE:** Chicken should be tender. Let stand, covered, 7 minutes; if desired, serve with spaghetti.




# Fish and Seafood

## Directions for Preparing Fish and Seafood

Use fresh or defrosted clean fish. Arrange fish in a single layer in dish. For best results, avoid overlapping edges as this will prevent fish from cooking evenly.

Place thicker sections toward edge of the dish. (i.e., tail sections toward center).

Cover dish loosely, but completely with plastic wrap.

1)		PRESS once = FISH FILLETS twice = SHELLFISH
2)	 (optional)	SELECT DONENESS once = more twice = less
3)		PRESS

**TO COOK BY SENSOR COOKING:** Stir shrimp or scallops when time appears on the screen. Let stand, covered, 5 minutes.

**TO COOK BY TIME:** Arrange shrimp and scallops in single layer in dish. Cook on the recommended power level and minimum time in the chart. Rearrange or stir shrimp or scallops halfway through cooking.

**Test for doneness** before adding extra cooking time. The color of seafood and fish should be opaque and the fish should flake easily when tested with a fork. If undercooked, return to oven and cook 15 to 30 seconds longer at recommended power level.

**After cooking,** let stand, covered, 3 to 5 minutes before serving. Stand time allows the internal temperature to equalize throughout the food and thereby completes the cooking process.

## Fish and Seafood Chart for Sensor & Time Cooking

FISH OR SEAFOOD	SENSOR COOKING		TIME COOKING		
	AMOUNT	CATEGORY	AMOUNT	POWER	APPROX. COOKING TIME (in minutes)
Fish Fillets	½ to 2 lb. (250 g to 1 kg)	FISH FILLETS	1 lb. (500 g)	HIGH	5 to 7½
Fish Steaks [1-inch (2.5 cm) thick]	—	—	1 lb. (500 g)	MEDIUM-HIGH	5½ to 7
Scallops (sea)	½ to 2 lb. (250 g to 1 kg)	SHELLFISH	1 lb. (500 g)	MEDIUM-HIGH	5 to 6
Shrimp, medium size (shelled and cleaned)	½ to 2 lb. (250 g to 1 kg)	SHELLFISH	1 lb. (500 g)	MEDIUM-HIGH	5 to 6
Whole fish, cleaned (stuffed or unstuffed)	—	—	1 to 1½ lb. (500 g–750 g)	HIGH	5 to 7

## TARRAGON HALIBUT STEAKS

3 tablespoons lemon juice  
2 tablespoons oil  
1 teaspoon salt  
½ teaspoon paprika  
½ teaspoon onion powder  
½ teaspoon tarragon  
4 halibut steaks, 1-inch thick (about 8 oz. ea.)

Yield: 4 Servings

In small bowl, mix lemon juice, oil, salt, paprika, onion powder until blended. Arrange halibut steaks in 2½-quart shallow oval casserole dish. Pour marinade over steaks. Cover and marinate 1 hour. Cook at **HIGH** 7 to 9 minutes, or until fish flakes easily. Let stand, covered, 3 minutes before serving.

## FILLET ALMANDINE

3 tablespoons butter or margarine  
3 tablespoons slivered almonds  
½ pound fish fillets  
Salt and pepper to taste  
2 teaspoons lemon juice  
2 teaspoons parsley

Yield: 2 Servings

Place butter and almonds in 8-inch square dish. Cook at **HIGH** 3 to 4 minutes; stir once. Cover fillets with butter. Sprinkle with lemon juice. Cover with plastic wrap. Cook at **HIGH** 4 to 5 minutes, or until fish flakes when tested with a fork. Let stand, covered for 3 minutes. Before serving, season with salt and pepper and sprinkle with parsley.

# Fish and Seafood

## MARYLAND CRAB BAKE

1 cup each chopped celery, green pepper and onion  
3 tablespoons butter or margarine  
2 packages (6 oz. ea.) crabmeat, drained and flaked,  
canned or frozen, defrosted (see page 12)  
1 teaspoon Worcestershire sauce  
½ teaspoon pepper  
½ teaspoon salt  
½ cup buttery cracker crumbs  
1 tablespoon butter or margarine, melted  
Dash paprika

**Yield:** 4 to 6 Servings

In 2-quart casserole, combine celery, green pepper, onion and 3 tablespoons butter. Cover with lid. Cook at **HIGH** 3 to 4 minutes, or until vegetables are tender; stir once. Stir in crab, Worcestershire, pepper and salt. Combine cracker crumbs, melted butter and paprika; sprinkle over casserole.

Cook at **MEDIUM-HIGH** 6 to 7 minutes, or until heated through. Stir twice. Let stand 5 minutes before serving.

## SCALLOPS WITH HERB LEMON BUTTER

¼ cup butter or margarine  
½ teaspoon basil  
½ teaspoon crushed rosemary  
¼ teaspoon salt  
1 pound sea scallops  
Juice from 1 lemon (about 2 tablespoons)  
Paprika

**Yield:** 4 Servings

**TO COOK BY SENSOR COOKING:** In 8-inch square dish, combine all of the above ingredients except paprika. Cover with plastic wrap. Cook on **SHELLFISH**. After time appears on the screen, stir scallops, re-cover and continue cooking.

**TO COOK BY TIME:** In 8-inch square dish, combine butter, basil, rosemary and salt. Cook at **HIGH** 1½ minutes, or until melted. Stir in scallops and sprinkle with lemon juice; spoon butter mixture over scallops. Cover with plastic wrap. Cook at **MEDIUM-HIGH** 6½ to 8½ minutes.

**TO COMPLETE:** Scallops should be tender. Sprinkle with paprika; let stand, covered, 5 minutes before serving.

## BAKED STUFFED CLAMS

18 small (littleneck) clams, scrubbed and opened  
½ to ⅔ cup seasoned dry bread crumbs  
2½ to 3 tablespoons oil  
¼ teaspoon garlic powder  
¼ teaspoon paprika  
¼ teaspoon pepper  
3 slices bacon, crisp-cooked and crumbled  
(see page 14)

**Yield:** 18 Clams

Arrange clams on the half shell in two 8-inch square dishes. Pierce each clam several times with toothpick. Combine bread crumbs, oil, garlic, paprika and pepper. Sprinkle crumbs on clams. Top with bacon.

Cook on **MEDIUM-HIGH** 2 to 3 minutes, or until clams are tender.

## COQUILLE ST. JACQUES

2 tablespoons butter or margarine  
1 small onion, finely chopped  
2 tablespoons flour  
Dash white pepper  
¾ cup milk or half'n half  
1 jar (2½ oz.) sliced mushrooms, drained  
½ cup (1½ oz.) shredded Swiss cheese  
1 pound sea scallops  
¼ cup white wine  
¼ cup buttered bread crumbs  
Parsley flakes




**Yield:** 4 Servings

Place butter and onions in medium glass bowl. Cook at **MEDIUM-HIGH** ¾ to 1 minute; stir in flour and pepper. Gradually add milk, stirring until smooth. Cook at **MEDIUM-HIGH** for 3 to 3½ minutes or until thickened; stir twice. Stir in mushrooms, cheese, scallops and wine. Spoon mixture into 2½-quart shallow oval casserole dish. Top with bread crumbs and parsley. Place dish on rack. Cook at **MEDIUM-HIGH** 5 to 6 minutes.

# Casseroles

## Directions for Preparing Casseroles

Prepare casseroles and stews according to recipe directions. Stew meats are not browned before cooking. Omit any oil or fat and flour used for browning. Fresh and firm vegetables such as potatoes, carrots, rutabagas and beans are added at the beginning of cooking. Frozen vegetables and fresh vegetables with soft texture such as zucchini, tomatoes or mushrooms are added during the last 30 minutes of cooking. Defrosted frozen vegetables and canned vegetables are added with the thickener. Place covered microwave-safe dish in oven.

1)		PRESS 1 x = <b>CASSEROLE</b> 2 x = <b>STEW</b>
2)		SELECT DONENESS 1 x = more 2 x = less
3)		PRESS

## EASY LASAGNA

½ pound ground beef  
1 jar (30 oz.) spaghetti sauce  
½ cup water  
1 container (15 oz.) ricotta or cottage cheese  
1 egg, slightly beaten  
½ teaspoon salt  
1 teaspoon pepper  
9 lasagna noodles (cooked)  
½ pound mozzarella cheese thinly sliced  
½ cup grated Parmesan cheese

**Yield:** 6 Servings

In large glass bowl, crumble ground beef. Heat at **HIGH** 1½ to 2½ minutes, or until beef is browned; stir once. Drain. Stir in spaghetti sauce and water. Heat at **HIGH** 3½ to 4½ minutes or until bubbly. Meanwhile, combine ricotta cheese, egg, salt and pepper. In rectangular baking dish, spoon ½ cup sauce; alternately layer noodles, ricotta cheese mixture, mozzarella cheese and sauce, forming 3 layers.

**TO COOK BY SENSOR COOKING:** Cover dish with plastic wrap. Cook on **CASSEROLE**. After time appears in Display Window, shield ends of dish with foil.

**TO COOK BY TIME:** Cook, covered with plastic wrap, at **HIGH** 8 minutes and at **MEDIUM-LOW** 35 to 38 minutes, or until noodles are tender. If necessary, shield ends of dish with foil, during the last 10 minutes of cooking time.

**TO COMPLETE:** Sprinkle with Parmesan cheese; let stand, covered, 5 minutes before serving.

### TO COOK BY SENSOR COOKING:

Combine ingredients. Cover dish. Select Sensor Category "**Casserole**" and press **Start** Pad.

### TO COOK BY TIME:

Prepare casseroles or stew by microwaving at lower power levels. **MEDIUM** and **MEDIUM-LOW** power levels allow flavors to blend and less tender cuts of meat to become tender. Use our recipes as a guideline for adapting your favorite recipes.

## BAKED ZITI

1 package (8 oz.) ziti macaroni, cooked (see page 33)  
1 jar (15½ oz.) spaghetti sauce  
½ cup (2 oz.) shredded mozzarella cheese

**Yield:** 4 Servings

Combine ziti and spaghetti sauce in 2-quart casserole. Cover with lid.

**TO COOK BY SENSOR COOKING:** Cook on **CASSEROLE**. After time appears in Display Window, stir occasionally.

**TO COOK BY TIME:** Cook at **HIGH** 7 to 9 minutes; stir twice.

**TO COMPLETE:** Sprinkle with cheese. Let stand, covered, 10 minutes before serving.

## MACARONI AND CHEESE

1 package (8 oz.) elbow macaroni, cooked and drained (see page 33)  
¾ pound pasteurized process cheese spread, cut into cubes  
¾ to 1 cup milk  
½ to ¾ teaspoon salt  
¼ teaspoon onion powder  
¼ teaspoon pepper  
¼ teaspoon dry mustard, optional  
Buttered bread crumbs

**Yield:** 4 Servings

In 3-quart casserole, combine macaroni, cheese, milk, salt, onion, pepper and mustard. Cover with lid.

**TO COOK BY SENSOR COOKING:** Cook on **CASSEROLE**. After time appears in Display Window, stir occasionally.

**TO COOK BY TIME:** Cook at **MEDIUM-HIGH** 12 to 15 minutes; stir twice.

**TO COMPLETE:** Top with bread crumbs. Cook, uncovered, at **MEDIUM-HIGH** 3 minutes. Let stand, covered, 10 minutes before serving.

# Eggs and Cheese

## SCRAMBLED EGGS

Beat eggs, 1 tablespoon milk and dash of salt for each egg. Pour into greased glass container. Cook at **MEDIUM-HIGH** according to time in the chart. Stir two-thirds of the way through the cooking time. Stir and let stand. Eggs will continue to cook during stand time and should be slightly undercooked after cooking.

Eggs	Container	Cooking Time (in min.)	Stand Time (in min.)
1	1-cup glass measure	3/4 - 1 1/4	1
2	1-cup glass measure	1 1/2 - 2	1 1/2
4	1-quart bowl	3 3/4 - 3 3/4	1 1/2
6	1 1/2-quart bowl	4 3/4 - 5 1/2	2

## POACHED EGGS

Place 1 1/2 cups hot water and a dash of vinegar and salt in 2-quart casserole and heat at **HIGH** 5 to 7 minutes, or until water boils. Break egg(s) into boiling water and with toothpick pierce egg yolk twice and egg white several times. Cook at **MEDIUM-HIGH** according to the time given in the chart. Let stand. Eggs will continue to cook during stand time and should be slightly undercooked after cooking.

Eggs	Cooking Time (in minutes)	Stand Time (in minutes)
1	1/2 - 3/4	1
2	1 - 1 1/4	2
4	1 3/4 - 2	2

Eggs cannot be hard-cooked in their shells in a microwave oven. Pressure will build up and the egg will explode.

## SPINACH CHEESE RING

2 packages (10 oz. ea.) frozen chopped spinach, cooked and drained  
 1 cup (1/2 pint) cottage cheese  
 2 eggs  
 1/2 cup heavy cream  
 2 tablespoons melted butter  
 1/4 cup finely chopped green onions  
 1/4 cup plain dry bread crumbs  
 3 tablespoons grated Parmesan cheese  
 1/2 teaspoon paprika  
 1/4 teaspoon dill weed  
 Dash pepper

**Yield:** 4 Servings

In medium bowl, combine all ingredients; mix well. Spoon into well greased 1-quart glass ring mold. Cover with plastic wrap. Cook at **MEDIUM-HIGH** 8 to 12 minutes, or until almost set. Let stand, uncovered, 5 minutes.

## BASIC OMELET

1 tablespoon butter or margarine  
 2 eggs  
 2 tablespoons milk  
 1/2 teaspoon salt  
 Dash pepper

**Yield:** 1 Serving

Melt butter in 9-inch pie plate at **HIGH** 1 minute; turn plate to coat bottom with butter. Combine remaining ingredients, pour into pie plate. Cook, covered with plastic wrap, at **MEDIUM-HIGH** 2 to 3 1/2 minutes, or until omelet is almost set; stir after 1 minute. Let stand, covered, 2 minutes. Loosen edges of omelet from plate with spatula; fold into thirds to serve.

*Variations: Try one of these easy variations:*

*For CHEESE Omelet, before folding, sprinkle 1/4 cup shredded cheese down center of omelet.*

*For HAM Omelet, before folding, sprinkle 1/4 cup finely chopped cooked ham down center of omelet.*

*For HERB Omelet, blend 1/2 teaspoon basil, thyme or crushed rosemary with eggs and milk.*

*For JELLY Omelet, before folding, spoon 1/4 cup jelly down center of omelet.*

## CAULIFLOWER AND CARROT QUICHE

1 1/2 cups coarsely chopped cauliflower  
 1 carrot, shredded  
 1 tablespoon water  
 9-inch pie shell, baked (see page 37)  
 1 cup (4 oz.) shredded Swiss cheese  
 1/4 cup grated Parmesan cheese  
 3 eggs  
 1 cup (1/2 pt.) heavy cream  
 1/2 teaspoon pepper

**Yield:** 10 Servings

In 1-quart bowl, combine cauliflower, carrot and water. Cover with plastic wrap. Cook at **HIGH** 5 to 6 minutes. Stir once. Sprinkle vegetables into pie shell. Sprinkle cheeses over vegetables. Pour cream into 2-cup measure. Cook at **MEDIUM-HIGH** 2 to 2 1/4 minutes. Meanwhile, beat eggs in small bowl. Stir a little hot cream into eggs. Blend eggs back into cream. Add pepper. Pour mixture over ingredients in pie shell.

Cook at **MEDIUM** 10 to 12 minutes.



# Vegetables

## To Cook Fresh Vegetables

Weight given in the chart are purchase weights before peeling, trimming, etc. Prepare vegetables for cooking; cut slice or trim as directed in chart. Cook vegetables in covered casserole, except for whole, unpeeled vegetables.

**Whole, unpeeled vegetables**, such as potatoes or eggplant, should be pierced before cooking and arranged on microwave-safe dish in the oven. Arrange potatoes in a circular pattern on dish.

**TO COOK BY TIME:** Cook according to the time recommended in the chart. Two-thirds of the way through cooking, stir, rearrange, and/or turn vegetables over.

**TO COOK BY SENSOR COOKING:** When time appears on the screen, stir vegetables.

**After cooking**, stir vegetables. Let stand, covered, before serving. Vegetables that are cut into pieces should stand 3 minutes. Whole vegetables should stand 5 minutes.




## To Cook Frozen Vegetables

### TO COOK BY SENSOR COOKING:

Empty 10-28 oz. package of frozen vegetables into glass container. Add 2 tablespoons water. Cover dish with lid, or loosely but completely, with plastic wrap. Cook on **Frozen Vegetables**.

**For frozen vegetables in the pouch**, pierce a hole in the pouch, place on a dish and cook on **Frozen Vegetables**. After cooking, stir and let stand, covered, 3 minutes before serving. **DO NOT** cook frozen vegetables which contain any type of butter or sauce by Sensor Cooking Pad.

**Never** leave oven unattended when heating small amounts of foods such as one or two potatoes. Potatoes may catch fire if overcooked and cause severe damage to the oven and surroundings.

1)  <b>Potato/ Vegetable</b>	PRESS once = POTATO twice = FRESH VEGETABLES 3 times = FROZEN VEGETABLES
2)  <b>More/ Less</b> (optional)	SELECT DONENESS once = more twice = less
3) 	PRESS

## Fresh Vegetable Chart for Sensor & Time Cooking

VEGETABLE	AMOUNT	WATER	SENSOR COOKING CATEGORY	APPROX. COOKING TIME at HIGH Power (In minutes)
<b>Artichokes</b> , 6 to 8 oz. ea.	1	2 tablespoons	<b>FRESH VEG.</b>	6 to 7
	2	¼ cup		9 to 11
	4	¼ cup		14 to 16
<b>Asparagus</b> , 6-in spears	1 lb. (500 g)	2 tablespoons		7 to 8
<b>Beans</b> , green/wax, cut into 1½-in. pieces	1 lb. (500 g)	¼ cup		7 to 9
<b>Broccoli</b> , cut into spears	1 lb. (500 g)	¼ cup		7 to 10
<b>Brussels Sprouts</b>	1 tub [10 oz. (300 g)]	2 tablespoons		7 to 9
<b>Cabbage</b> , shredded	1 lb. (500 g)	¼ cup		7 to 9
<b>Carrots</b> , sliced ½-in. thick	1 lb. (500 g)	¼ cup		7 to 9
<b>Corn</b> , fresh on the Cob	1 ear	2 tablespoons		---
	2 ears	2 tablespoons	7 to 9	
	4 ears	¼ cup	12 to 14	
<b>Eggplant</b> , fresh cubed Whole (pierce skin several times)	1 lb. (500 g)	¼ cup	<b>FRESH VEG.</b>	7 to 8½
	1 to 1¼ lb. (500 to 600 g)	---		4½ to 7
<b>Onions</b> , small whole	8 to 10 [1 lb. (500 g)]	¼ cup	---	6½ to 7½
<b>Peas</b> , green, shelled	2 lb. (1kg)	¼ cup	<b>FRESH VEG.</b>	6 to 8
<b>Potatoes</b> , 8 to 9 oz. ea. Cook uncovered, turn over halfway through cooking time. Pierce skin several times before cooking.	1	---	<b>POTATO</b>	5 to 7
	2	---		8 to 10
	4	---		13 to 15½
<b>Spinach</b> , leaf	1 lb. (500 g)	2 tablespoons	---	5½ to 7
<b>Squash, Summer</b> , sliced ½-in. thick	1 lb. (500 g)	2 tablespoons	<b>FRESH VEG.</b>	6 to 8
<b>Squash, Winter</b> , Cut in half, scoop out seeds, place cut-side down.	1 lb. (500 g)	¼ cup	---	6½ to 7½

# Vegetables

## SCALLOPED POTATOES

¼ cup butter or margarine  
1 tablespoon dried onion flakes  
1 teaspoon salt  
¼ teaspoon pepper  
¼ cup flour  
2 cups milk  
6 medium potatoes (about 6 oz. ea.), peeled and thinly sliced

**Yield:** 6 Servings

In 4-cup glass measure, combine butter, onion, salt and pepper. Cook at **HIGH** 1 to 1½ minutes, or until butter is melted. Stir in flour, gradually add milk, stirring until smooth. Cook at **MEDIUM-HIGH** 8 to 9 minutes, or until sauce is thickened; stir twice. In 2-quart casserole, alternately layer potatoes and sauce, forming three layers.

Cover with lid. Cook at **MEDIUM-HIGH** 27 minutes or until potatoes are tender. Let stand, covered, 5 minutes before serving.

## SWISS SCALLOPED CORN

3 slices bacon, crisp-cooked and crumbled  
2 cans (17 oz. ea.) whole kernel corn, drained  
1 cup (4 oz.) shredded Swiss cheese  
1 egg  
1 can (5½ oz.) evaporated milk  
½ teaspoon onion powder  
¼ teaspoon pepper  
1½ tablespoons flour  
¼ cup dry bread crumbs  
1 tablespoon butter or margarine, melted  
Paprika

**Yield:** 6 Servings

In 2½-quart shallow oval casserole dish, combine bacon, corn and cheese. Blend in egg, milk, onion powder, pepper and flour.

Cook at **HIGH** 5 to 6 minutes; stir once. Combine bread crumbs, butter and paprika. Sprinkle over corn. Cover with plastic wrap. Cook at **HIGH** 4 to 5 minutes. Let stand, covered, 5 minutes before serving.

## BAKED STUFFED POTATOES

4 medium potatoes, baked  
½ cup (2 oz.) shredded Cheddar cheese  
½ to ½ cup milk  
2 tablespoons butter or margarine, softened (see page 38)  
1 egg  
Salt and pepper to taste  
Paprika

**Yield:** 4 Servings

Cut a thin slice (lengthwise) from each potato. Scoop out potato, leaving a thin shell. In small bowl, combine potato, cheese, milk, butter, egg, salt and pepper; mash until smooth. Spoon potato mixture into shell; sprinkle with paprika. In 2½-quart shallow oval casserole dish, arrange potatoes in a circle.

**TO COOK BY SENSOR COOKING:** Cover loosely, but completely with plastic wrap. Cook on **POTATO**.

**TO COOK BY TIME:** Cover with wax paper. Cook at **MEDIUM-HIGH** 4 to 6 minutes.

**TO COMPLETE:** Let stand, uncovered, 3 minutes before serving.

## RATATOUILLE

2 medium onions, sliced  
1 medium green pepper, cut into ½-inch slices  
½ cup oil  
2 cloves garlic, finely chopped  
1 medium eggplant (about 1½ lb.), peeled and cut into ¾-inch pieces  
3 medium tomatoes, cut into eighths  
2 medium zucchini (about 1 lb.), cut into ½-inch slices  
¼ cup vegetable juice cocktail or tomato juice  
2 teaspoons each basil and parsley flakes  
1 teaspoon salt  
¼ teaspoons pepper

**Yield:** 6 Servings

In 3-quart casserole, combine onions, green pepper, oil and garlic. Cover with lid. Cook at **HIGH** 4 to 5 minutes; stir once. Stir in remaining ingredients; cover.

**TO COOK BY SENSOR COOKING:** Cook on **FRESH VEGETABLES**. When time appears on the screen, stir twice.

**TO COOK BY TIME:** Cook at **HIGH** 18 to 20 minutes; stir twice.

**TO COMPLETE:** Let stand, covered, 5 minutes before serving.

# Pasta, Rice and Cereal

ITEM	CONTAINER	AMOUNT OF HOT WATER	POWER	APPROX. COOKING TIME (in min.)	STAND TIME (in min.)	SPECIAL INSTRUCTIONS
<b>PASTA</b>						
Egg Noodles medium width (8 oz.)	3-qt. casserole	1½ quarts	<b>HIGH</b>	7 - 9	3	Add 1 teaspoon oil and 1 teaspoon salt to water. Cover and bring hot water to boil at <b>HIGH</b> (approx. 13 - 18 minutes). Stir in pasta. Cook, covered; stirring occasionally. Let stand, covered. Pasta that is to be added to a casserole should be slightly undercooked.
Specialty Noodle (8 oz.)	3-qt. casserole	1½ quarts	<b>HIGH</b>	8 - 12	3	
Spaghetti or Fusilli (8 oz. broken)	3-qt. casserole	2 quarts	<b>HIGH</b>	12 - 14	3	
Frozen Tortellini (16 oz.)	3-qt. casserole	1½ quarts	<b>HIGH</b>	7 - 9	3	
<b>RICE</b>						
Flavored Rice Mix (4.4 to 7.5 oz.)	2-qt. casserole	as pkg. directs	<b>MEDIUM</b>	15 - 30 or as pkg. directs	10	Cover & bring hot water to a boil at <b>HIGH</b> (approx. 4 - 7 min.). Add rice, salt & butter (amount of salt & butter as package directs). Cook covered; stir. Let stand, covered.
Long Grain (1 cup)	2-qt. casserole	2 cups	<b>MEDIUM</b> - <b>LOW</b>	13 - 16	10	
Short Grain (1 cup)	2-qt. casserole	2 cups	<b>MEDIUM</b> - <b>LOW</b>	10 - 12	10	
<b>CEREAL</b>						
Cream of Wheat (Reg.) 1 serving (2½ tbsp.)	1-qt. glass bowl	¾ cup	<b>HIGH</b>	2 - 4	1	Stir cereal into water. Stir frequently. Cook uncovered. Stir once before stand time.
2 servings (½ cup)	1½-qt. glass bowl	1½ cups	<b>HIGH</b>	3 - 5	1	
Farina 1 serving (3 tbsp.)	1-qt. glass bowl	1 cup	<b>HIGH</b>	2 - 3	1	Cover and bring water to a boil at <b>HIGH</b> (approx. 3 to 6 min.) Slowly add cereal; stirring frequently. Cook uncovered. Stir once before stand time.
2 servings (6 tbsp.)	1½-qt. glass bowl	2 cups	<b>HIGH</b>	2 - 4	1	
Oatmeal (Quick) 1 serving (½ cup)	individual serving dish	½ cup	<b>HIGH</b>	1 - 2	1	Combine water and cereal. Cook uncovered. Stir once before stand time.
2 servings (¾ cup)	2 individual serving dishes	1½ cups	<b>HIGH</b>	3 - 4	1	
4 servings (1½ cups)	2-qt. glass bowl	3 cups	<b>HIGH</b>	5 - 6	2	
Wheat Bran Cereal 1 serving (¼ cup)	1-qt. glass bowl	¾ cup	<b>HIGH</b>	3 - 4	1	
2 servings (½ cup)	1½-qt. glass bowl	1½ cups	<b>HIGH</b>	6 - 7½	1	
4 servings (1 cup)	2-qt. glass bowl	3 cups	<b>HIGH</b>	7 - 8	2	

**To prepare Instant Rice:** Combine 1 cup water, 1 teaspoon butter and dash salt in 1-quart casserole. Cover with lid. Cook at **HIGH** 2 to 3 minutes or until water boils. Stir in 1 cup rice. Let stand, covered, 5 minutes. Fluff lightly with fork before serving.

# Pasta, Rice and Cereal

## NOODLE PUDDING

1 package (8 oz.) medium egg noodles  
½ cup butter or margarine  
4 eggs, beaten  
1 cup cottage cheese  
1 cup sour cream  
¼ cup raisins  
½ cup sugar  
1 teaspoon cinnamon  
¼ teaspoon nutmeg

**Yield:** 8 Servings

Cook noodles according to chart on page 33. Heat butter in large glass bowl at **MEDIUM-HIGH** 1 minute, or until melted. Combine remaining ingredients and drained noodles; pour into 2-quart ring mold. Sprinkle, if desired, with additional cinnamon. Cook at **MEDIUM-HIGH** 18 to 20 minutes, or until pudding is set. Let stand, covered with wax paper. Serve warm or chilled.

## GRANOLA CEREAL

2 cups quick or old fashioned oats  
½ cup slivered almonds or chopped nuts  
½ cup wheat germ  
½ cup flaked coconut  
¼ cup raisins (presoaked in ¼ cup hot water and drained)  
1 tablespoon packed brown sugar  
3 tablespoons vegetable oil  
3 tablespoons honey  
1 tablespoon butter  
1 teaspoon vanilla

**Yield:** 3 cups

In 11 x 7-inch dish, combine oats, almonds, wheat germ, coconut, raisins and brown sugar; mix well. Set aside. In a 1-cup glass measuring cup combine oil, honey and butter. Cook at **HIGH** ½ to 1 minute or until butter is melted. Cool 5 minutes. Stir in vanilla and pour over oats. Blend thoroughly. Cook on **HIGH** 7 to 9 minutes, stirring occasionally. Cool. Store in airtight container.

## PASTA PRIMAVERA

1 package (8 oz.), rotelle pasta or spaghetti, broken  
2 cups broccoli flowerets  
2 cups cauliflower  
3 carrots, cut into sticks  
2 cloves garlic, finely chopped  
¼ cup chopped fresh parsley  
2 tablespoons oil  
1 teaspoon basil  
3 tablespoon butter or margarine  
½ cup grated Parmesan cheese  
Pepper to taste

**Yield:** 4 Servings

**TO COOK BY SENSOR COOKING:** Cook pasta according to chart on page 33. In 3-quart casserole, combine broccoli, cauliflower, carrots, garlic, parsley, oil, basil and butter. Cook covered on **PASTA**. Add Parmesan cheese. Season with pepper.

**TO COOK BY TIME:** Cook pasta according to chart on page 33. In 3-quart casserole, combine broccoli, cauliflower, carrots, garlic, parsley, oil, and basil. Cover with lid. Cook at **HIGH** 7 to 9 minutes. Let stand, covered, 3 minutes. Meanwhile, in medium glass bowl, heat butter at **HIGH** 1 to 1½ minutes, or until melted; stir in drained pasta. Add vegetables and cheese; toss well. Season with pepper.

## PEPPERED SESAME NOODLES

8 ounces vermicelli  
3 tablespoons sesame oil  
2 tablespoons peanut oil  
6 to 8 fresh chili or jalapeño peppers, sliced, seeds removed, if desired  
3 tablespoons Worcestershire sauce  
2 tablespoons soy sauce  
4 to 5 green onions, cut diagonally into ½-inch pieces.  
2 tablespoons sesame seeds, toasted

**Yield:** 6 to 8 Servings

Cook vermicelli according to chart on page 33. Drain, rinse and set aside. In 2-cup glass measure blend sesame and peanut oils. Cook at **HIGH** 1 minute. Add chili peppers. Cook at **HIGH** 15 seconds. Add Worcestershire sauce and soy sauce. Pour over cooked vermicelli. Toss to coat. Cook at **HIGH** 3 minutes. Add green onions and sesame seeds. Mix well.

# Quick Breads and Cakes

Layer cakes must be baked **one layer at a time**, or the entire cake mix may be baked in a 16-cup fluted tube dish. Prepare batter according to package, chart or recipe directions.

**Use dishes recommended** in chart or in recipes. Glass dishes allow the bottom of the cakes to be checked for doneness. When the product is removed from the oven, visually check bottom.

If cake is to be inverted or removed from dish, such as layer cakes or upside-down cake, grease sides of dish and line bottom of 8" or 9" round or square dish with wax paper.

If cake is to be served directly from the dish, grease bottom of dish. Never flour cake dishes, fluted tube dishes or muffin pans.

**Cook second layer** of 8" or 9" round or square cake immediately after the first. The remaining batter can be used for cupcakes.

**Check during cooking.** Different brands vary in ingredients and density of batter; cooking times may be slightly different than those given in chart.

**After cooking:**

**Test for doneness.** Check to make sure edges of cake are dry and have begun to pull away from sides of dish, and toothpick inserted near center comes out clean.

**Let stand, uncovered**, on a flat surface for 10 to 15 minutes. Stand time is important to allow cakes and cupcakes to finish baking. Cakes and breads that are to be inverted should be loosened from the sides of the dish. Carefully turn out of dish. Remove wax paper from bottom of cake. Store, covered, until ready to serve.

For best results, it is recommended to follow microwave cooking instructions issued by the individual cake mix manufacturers.

ITEM	AMOUNT OF BATTER	PREPARATION/ DISH SIZE	FIRST STAGE	SECOND STAGE	SPECIAL INSTRUCTIONS	STAND TIME
<b>Quick Bread</b> (14 to 17 oz.)	All batter	Line bottom of 8½" x 4½" x 2½" loaf dish with wax paper.	<b>MEDIUM-LOW</b> 8 - 9 min.	<b>HIGH</b> 4½ - 5½ min.	Shield each end with a 3" strip of foil.	15 min. uncovered
<b>Cornbread</b> (7 or 8 oz.)	All batter	Grease 8" or 9" round or square dish.	<b>MEDIUM-HIGH</b> 4½ - 6 min.	—	Cover with wax paper.	10 min. uncovered
<b>Gingerbread</b> (14 oz.)	All batter	8" square dish	<b>HIGH</b> 10 - 12 min.	—	Shield each corner with a piece of foil. Place dish on a microwave-safe inverted pie plate.	15 min. uncovered
<b>Muffins</b> (Cook 6 at a time)	Fill ½ full	6-cup muffin pan lined with paper baking cups	<b>MEDIUM</b> 3½ - 5 min.	—	—	5 min. uncovered
<b>Cake Mix</b> (18 to 20¼ oz.)	2¼ cups	Wax paper-lined 8" or 9" round or square glass baking dish	<b>MEDIUM-LOW</b> 8 min.	<b>HIGH</b> 3 - 4½ min.	Place dish on microwave-safe inverted pie plate Cover with wax paper.	10 min. uncovered
<b>Cake Mix</b> (18 to 20¼ oz.)	Prepare batter according to package directions. Pour all batter into pan.	Generously grease 16-cup fluted tube pan	<b>MEDIUM-LOW</b> 9 - 10 min.	<b>HIGH</b> 6 - 11 min.	Cover pan with wax paper.	—
<b>Cupcakes</b>	2 rounded tablespoons batter per cupcake. Fill paper baking cups ½ full.	Line microwave muffin pan with paper baking cups. 2 4 6	<b>MEDIUM</b> (in minutes) 1¼ - 2 2 - 2½ 3½ - 4½	—	Cover with wax paper.	5 min. uncovered

# Quick Breads and Cakes

## SOUR CREAM COFFEE CAKE

½ cup sugar  
¼ cup butter  
1½ cups flour  
1 cup sour cream  
2 eggs  
1½ teaspoons vanilla extract  
1 teaspoon baking powder  
1 teaspoon baking soda  
½ teaspoon salt

### Topping:

⅓ cup chopped walnuts  
¼ cup sugar  
½ teaspoon cinnamon

**Yield:** 8 Servings

In large bowl, cream sugar and butter. Add remaining ingredients and beat with electric mixer at low speed for 30 seconds and then medium speed for 2 minutes. Pour into greased 8-inch square baking dish. In separate bowl, combine topping ingredients; sprinkle over batter.

**TO COOK:** Cover with wax paper. Elevate dish on inverted glass pie plate. Cook at **MEDIUM-HIGH** 5½ minutes and at **MEDIUM** 5 to 5½ minutes, or until edges are dry and toothpick inserted near center comes out clean.

**TO COMPLETE:** Let stand, uncovered for 10 minutes. Serve immediately.

## CHERRY BRUNCH ROLLS

½ cup packed brown sugar  
½ cup chopped maraschino cherries  
¼ cup flaked coconut  
1 tablespoon water  
¼ teaspoon cinnamon  
1 can (7.5 oz.) refrigerated biscuits  
3 tablespoons butter or margarine, melted

**Yield:** 10 rolls

In small glass bowl, combine brown sugar, cherries, coconut, water and cinnamon; stir. Cook at **HIGH** 2 to 2½ minutes until boiling. Pour into a greased 5-cup ring mold. Dip each biscuit into melted butter; arrange on top of cherries. Cook at **MEDIUM-HIGH** 6 to 8 minutes.

Cook at **MEDIUM-HIGH** 3 to 4 minutes. Let stand, covered for 5 minutes. Invert onto serving. Store covered.

## BANANA NUT COFFEE CAKE

¼ cup oil  
¼ cup milk  
1 egg  
1 mashed ripe banana  
½ cup packed brown sugar  
¼ cup flour  
½ cup chopped nuts  
¼ teaspoon baking powder  
¼ teaspoon salt  
¼ teaspoon baking soda

### Nut Topping:

¼ cup packed brown sugar  
¼ cup chopped nuts  
2 tablespoons flour  
¼ teaspoon cinnamon  
1 tablespoon butter or margarine, softened

**Yield:** 8 Servings

In medium bowl, combine oil, milk, egg, banana, and sugar. Add flour, nuts, baking powder, salt and baking soda; stir just until flour is moistened. Pour into greased 8- or 9-inch round dish. In small bowl, prepare Nut Topping. Combine brown sugar, nuts, flour, and cinnamon; cut in butter. Sprinkle over batter.

**TO COOK:** Cover with wax paper. Cook on **MEDIUM-HIGH** 5½ to 6 minutes. Cook at **MEDIUM** 5½ to 6 minutes, or until toothpick inserted near center comes out clean.

**TO COMPLETE:** Let stand, uncovered, 10 minutes. Store, covered, until ready to serve.

## SOUTHERN CHEESE SPOON BREAD

½ cup yellow cornmeal  
2 cups milk  
½ teaspoon salt  
2 eggs, beaten  
1 cup (4 oz.) diced American cheese  
2 tablespoons butter or margarine

**Yield:** 6 Servings

In medium glass bowl, combine cornmeal, milk and salt. Cook at **HIGH** for 3 minutes and then at **MEDIUM-HIGH** for 3 to 4 minutes, or until cornmeal is thickened; stir until smooth. Add eggs, cheese and butter, stir until cheese and butter are almost melted. Pour into greased 8-inch round dish. Cover with wax paper. Cook at **MEDIUM** 12 to 14 minutes, or until center is almost set. Let stand 10 minutes before serving.

# Pies

Prepare pastry according to recipe or package directions.

If desired, for a single crust homemade pastry recipe, substitute  $\frac{1}{2}$  cup whole wheat flour for  $\frac{1}{2}$  cup all-purpose flour.

Microwave pie crusts are light in color. A few drops of yellow food coloring may be mixed with the liquid before adding liquid to the flour mixture. This will give the crust a pale yellow color.

Roll dough out and gently place in pie plate.

Trim edge so a  $\frac{3}{4}$ -inch overhang remains. Roll overhang down to rim of pie plate. Flute edge.

Prick bottom and sides of pastry with fork.

Let pie crust rest 10 minutes. This rest time helps reduce shrinkage.

If desired, brush with dark corn syrup or molasses for sweet fillings, or brush with Worcestershire or soy sauce for savory fillings.

**For frozen crust**, thaw and remove from foil pie plate and place in an 8- or 9-inch glass pie plate. Place on an inverted pie plate. Heat  $\frac{1}{2}$  minute, then prick crust and, if desired, brush with dark corn syrup, molasses, Worcestershire or soy sauce.

For crumb crusts, combine  $\frac{1}{3}$  cup butter and  $\frac{1}{4}$  cup sugar in medium bowl. Heat at **HIGH**  $1\frac{1}{2}$  to 2 minutes, or until butter is melted. Stir in  $1\frac{1}{4}$  cups crumbs (graham crackers, chocolate or vanilla wafers). Firmly pat into greased 9-inch pie plate.

Cook according to directions given in chart.

Visually check for doneness. Pastry crusts should be opaque. If crust is undercooked, add cooking time in 15 second increments.

Let stand until cool. Chill crumb crusts.

## PIE CRUST CHART

ITEM	POWER	APPROX. COOKING TIME (in minutes)
Homemade or Mix	<b>HIGH</b>	3 to 4
Refrigerated	<b>MEDIUM-HIGH</b>	$4\frac{1}{2}$ to 5
Frozen	<b>HIGH</b>	2 to $2\frac{1}{2}$
Graham Cracker or Cookie Crumb	<b>MEDIUM-HIGH</b>	2 to $2\frac{1}{2}$

## COCONUT LEMON MERINGUE PIE

**$1\frac{1}{2}$  cups sugar**  
 **$\frac{1}{3}$  cup cornstarch**  
 **$\frac{1}{4}$  teaspoon salt**  
 **$1\frac{1}{2}$  cups boiling water**  
**3 eggs, separated**  
 **$\frac{1}{2}$  cup lemon juice**  
**3 tablespoons butter or margarine**  
**Grated peel of 1 lemon**  
**9-inch pie shell, baked (see chart this page)**  
 **$\frac{1}{2}$  cup sugar**  
 **$\frac{1}{4}$  cup coconut**

**Yield: 8 Servings**

In 3-quart casserole, combine  $1\frac{1}{2}$  cups sugar, cornstarch and salt, stir in boiling water and cover with lid. Cook at **HIGH** for 6 to  $7\frac{1}{2}$  minutes or until thickened. Halfway through cooking, stir twice. Stir small amount of hot mixture into egg yolks; return to hot mixture, beating until well blended. Add lemon juice, butter and lemon peel. Pour into pie shell; set aside. Meanwhile, beat egg whites until soft peaks form; gradually add remaining sugar and beat until stiff. Spread meringue over filling, making sure it touches crust all around the pie edge. Sprinkle with coconut.

Cook at **HIGH** for 4 to 6 minutes, or until meringue is set. Cool completely.

## CHOCOLATE ROCKY ROAD PIE

**1 package (3 $\frac{1}{2}$  oz.) chocolate pudding and pie filling mix**  
 **$1\frac{1}{4}$  cups milk**  
**1 to  $1\frac{1}{2}$  cups miniature marshmallows**  
 **$\frac{1}{2}$  to 1 cup coarsely chopped walnuts**  
**9-inch chocolate cookie crumb crust, baked (see chart this page)**

**Yield: 8 Servings**

Combine pudding mix and milk in 4-cup glass measure. Cook at **MEDIUM-HIGH** for 6 to 8 minutes or until pudding is thickened, stir until smooth. Cook 5 minutes then fold in marshmallows and nuts. Turn into prepared crust; chill until firm. Garnish with toasted coconut or chopped nuts.

# Microwave Shortcuts

FOOD	POWER	TIME (in minutes)	DIRECTIONS
To Melt <b>Butter</b> , ¼ pound To Soften <b>Butter</b> , ¼ pound	<b>MEDIUM</b> <b>MEDIUM-LOW</b>	1 - 2 ½ - 1	Remove wrapper and place butter in a microwave-safe dish.
To Melt <b>Chocolate</b> , 1 square (1 oz.) To Melt <b>Chocolate</b> , ½ cup chips	<b>MEDIUM</b> <b>MEDIUM</b>	2 - 3 2 - 3	Remove wrapper and place chocolate in dish. Stir before adding more time. Chocolate holds its shape even when softened.
To Separate <b>Bacon</b> , 1 lb.	<b>HIGH</b>	½ - 1	Remove wrapper. After heating, use a plastic spatula to separate slices.
To Soften <b>Cream Cheese</b> , 3 oz.	<b>MEDIUM-LOW</b>	½ - 1	Remove wrapper and place in a bowl.
<b>Cup of Water</b> 1 cup (8 oz.) 2 cups (16 oz.) <b>Cup of Milk</b> 1 cup (8 oz.) 2 cups (16 oz.)	<b>HIGH</b> <b>HIGH</b> <b>MEDIUM-HIGH</b> <b>MEDIUM-HIGH</b>	4 6½ 3½ - 4½ 7 - 8	Heated liquids can erupt if not mixed with air. Do not heat liquids in your microwave oven without stirring first.
To Toast <b>Coconut</b> , ½ cup	<b>HIGH</b>	1 - 3	Place in a pie plate or bowl. Stir every 30 seconds.
To Brown <b>Ground Beef</b> , 1 lb.	<b>HIGH</b>	3 - 5	Crumble in microwave-safe colander set in another dish. Stir twice.
To Soften <b>Ice Cream</b> , ½ gallon	<b>MEDIUM-LOW</b>	3 - 4	—————
To Roast <b>Nuts</b> , 1½ cups	<b>HIGH</b>	3 - 5	Spread nuts in 9-inch pie plate. Stir twice.
To Toast <b>Sesame Seeds</b> , ¼ cup	<b>HIGH</b>	2½ - 4	Place in a small bowl. Stir twice.
To Soften <b>Brown sugar</b>	<b>HIGH</b>	½ - ¾	Place 1 cup hard brown sugar in dish with a slice of bread or a wedge of apple. Cover with plastic wrap.
To Remove <b>Oven Odors</b>	<b>HIGH</b>	5	Combine 1 to 1½ cups of water with the juice and peel of one lemon in a small bowl. After heating, wipe interior of oven with damp cloth.



# Before Requesting Service

## All these things are normal:

The oven causes interference with my TV.

Some radio and TV interference might occur when you cook with the microwave oven. This interference is similar to the interference caused by small appliances such as mixers, vacuums, blow dryers, etc. It does not indicate a problem with your oven.

The oven lights dim.

When cooking with a power other than HIGH, the oven must cycle to obtain the lower power levels. The oven light will dim and clicking noises can be heard when the oven cycles.

Steam accumulates on the oven door and warm air comes from the oven vents.

During cooking, steam and warm air are given off from the food. Most of the steam and warm air are removed from the oven by the air which circulates in the oven cavity. However, some steam will condense on cooler surfaces such as the oven door. This is normal.

I accidentally ran my microwave oven without any food in it.

Running the oven empty for a short time will not damage the oven. However, we do not recommend operating the microwave oven without any food in it.

### PROBLEM

### POSSIBLE CAUSE

### REMEDY

Oven will not turn on.

The oven is not plugged in securely.

Remove plug from outlet, wait 10 seconds and reinsert.

Circuit breaker or fuse is tripped or blown.

Reset circuit breaker or replace fuse.

There is a problem with the outlet.

Plug another appliance into the outlet to check if it is working.

Oven will not start cooking.

The door is not closed completely.

Close the oven door securely.

Start Pad was not pressed after programming.

Press **Start Pad**.

Another program entered already in the oven.

Press **Stop/Reset Pad** to cancel the previous program and program again.

The program is not correct.

Program again according to the Operating Instructions.

Stop/Reset Pad has been pressed accidentally.

Program oven again.

The words "DEMO MODE" appear on the screen.

Clock pad has been pressed three times; or check **Function Pad** (p. 9).

Deactivate mode by pressing Clock Pad three times.

When the oven is turning on, there is noise coming from the glass tray.

The roller ring and oven bottom are dirty.

Clean these parts according to Care of Your Oven (next page).

If you have any questions or it seems there is a problem with the oven, contact PANASONIC CUSTOMER SERVICE for assistance.  
1-800-211-PANA (7262) (9 a.m. - 9 p.m., E.S.T)

# Care of Your Microwave Oven

## BEFORE CLEANING:

Unplug at socket of the oven. If impossible, leave oven door open to prevent oven from accidentally turning on.

## AFTER CLEANING:

Be sure to replace the Roller Ring and Glass Tray in the proper position and press **Stop/Reset Pad** to clear the screen.

### Inside of the oven:


Wipe with a damp cloth. Mild detergent may be used if the oven gets very dirty. The use of harsh detergent or abrasives is not recommended.

### Glass Tray:

Remove and wash in warm sudsy water or in a dishwasher.

### Outside oven surfaces.

Clean with a damp cloth. To prevent damage to the operating parts inside the oven, water should not be allowed to seep into ventilation openings.



### Special Defrost Only Rack:

Remove and wash in warm sudsy water.

### Oven Door:

Wipe with a soft cloth when steam accumulates inside or around the outside of the oven door. During cooking, especially under high humidity conditions, steam is given off from the food. (Some steam will condense on cooler surfaces, such as the oven door.) This is normal.

### Roller Ring and oven cavity floor:

Wipe the bottom surface of the oven with mild detergent water or window cleaner and dry. Roller Ring may be washed in mild sudsy water or dishwasher. These areas should be kept clean to avoid excessive noise.

### Control Panel:

\*Covered with a removable protective film to prevent scratches during shipping. Small bubbles may appear under this film. When this happens, remove film carefully. (Hint - apply masking or clear tape to an exposed corner and pull gently to remove).

\*If the control panel becomes wet, clean with a soft, dry cloth. Do not use harsh detergents or abrasives on the control panel.

For more information regarding microwave cooking, order our new COOKING GUIDE.

DESCRIPTION	PART NUMBER	PRICE
Instruction/Operating Manual (this book)	B0003932AAP	①
Cooking Guide (Recipes & Cooking Charts)	B000B8250AP	①
Glass Tray (see diagram on page 6)	A06014000AP	\$24.31
Roller Ring Assembly (see diagram on page 6)	B290D9330AP	\$ 13.16

① For pricing quotes, call or write the Parts & Literature Department at the phone or address listed below. Please have your credit card information readily available.  
*Shipping & handling are not included. Price & availability subject to change. Sorry, no COD's.*

PANASONIC SERVICES COMPANY  
 20421 84th Avenue South  
 Kent, WA 98032

(800) 833-9626 - Phone  
 (800) 237-9080 - FAX

# Instrucciones de Seguridad

Su horno de microondas es un aparato para cocinar y debe usarlo con mucho cuidado al igual que cuando usted usa estufa o cualquier otro aparato para cocinar.

Cuando se usan aparatos eléctricos, se deben seguir precauciones básicas de seguridad, incluyendo las siguientes:

## PRECAUCION

- Para reducir el riesgo de quemaduras, descarga eléctrica, incendio, heridas a personas o exposición excesiva a energía de microondas:

1. Lea todas las instrucciones antes de usar el aparato.
2. Lea y siga las **"PRECAUCIONES PARA EVITAR POSIBLE EXPOSICION EXCESIVA A ENERGIA DE MICROONDAS"** específicas, que se encuentran abajo.
3. Este aparato debe ser conectado a tierra. Conecte solamente a la toma eléctrica debidamente conectada a tierra. Vea las **"INSTRUCCIONES PARA CONEXIÓN A TIERRA"** que se encuentran en la página 42.
4. Instale o ubique este aparato solamente de acuerdo con las instrucciones de instalación que se encuentran en la página 43.
5. No cubra ni tape ninguna de las rendijas de este aparato.
6. No almacene o use este aparato en exteriores. No use este aparato cerca del agua - por ejemplo, cerca del fregadero de la cocina, en una base mojada, o cerca de una alberca, y similares.
7. Use este aparato sólo para los fines para los que fué hecho, tal como se describen en este manual. No use químicos o vapores corrosivos en este aparato. Este tipo de horno está específicamente diseñado para calentar o cocinar alimentos. No fué diseñado para uso industrial o de laboratorio.
8. Cuando limpie las superficies de la puerta y el horno que vienen juntas al cerrar la puerta, use solamente jabones no abrasivos o detergentes suaves aplicados con una esponja o con tela suave.
9. No permita a los niños usar este aparato, a menos que sean supervisados muy de cerca por un adulto.
10. No use este aparato si tiene dañado el cordón o la clavija, si no está trabajando adecuadamente, o si ha sido dañado o se ha dejado caer.
11. No sumergir en agua el cable o la clavija.
12. Mantenga el cordón lejos de superficies calientes.
13. No deje el cordón colgando en el borde de la mesa o mostrador.
14. Este aparato debe recibir mantenimiento sólo de personal calificado. Contacte las instalaciones de servicio autorizadas más cercanas para revisión, reparación o ajuste.
15. Algunos productos, tales como los huevos completos y contenedores sellados - por ejemplo frascos de vidrio cerrados - pueden explotar y no deben ser calentados en este horno.
16. Para reducir el riesgo de incendio en la cavidad del horno:
  - (a) No sobrecocine los alimentos. Preste atención cuidadosamente al aparato. El papel, plástico u otros materiales combustibles son colocados dentro del horno para facilitar la cocción pero si no se utilizan adecuadamente esto puede producir incendio en su horno.
  - (b) Quite los sujetadores de alambre de las bolsas de papel o plástico antes de colocar la bolsa en el horno.
  - (c) Si los materiales dentro del horno se incendiaran, mantenga cerrada la puerta del horno, póngalo en posición de apagado, y desconecte la energía eléctrica, o corte el suministro eléctrico en la caja de fusibles o en el panel de control.
  - (d) No use la cavidad con propósitos de almacenaje. No deje productos de papel, utensillos de cocina o alimentos en la cavidad cuando no esté en uso.

## Guardé estas instrucciones

### PRECAUCIONES PARA EVITAR POSIBLE EXPOSICION EXCESIVA A ENERGIA DE MICROONDAS

- (a) No intente hacer funcionar este horno con la puerta abierta ya que esto puede resultar peligroso. Es importante no anular o bioquear los mecanismos de seguridad.
- (b) No coloque ningún objeto entre el panel frontal del horno y la puerta, ni permita que se acumule basura o residuos de limpiadores en las superficies de sellado.
- (c) No haga funcionar el horno si está dañado, es importante que la puerta del horno abra y cierre apropiadamente:
  - (1) la puerta (combada)
  - (2) bisagras y seguro de la puerta (rotos o sueltos)
  - (3) sellos de las puertas y superficies de sellado
- (d) El horno o deberá ser ajustado o reparado por ninguna persona, excepto el personal de servicio debidamente calificado.

# Instrucciones de Seguridad

## Uso General

1. **NO** altere o haga ningún ajuste o reparación a la puerta, al alojamiento del panel de control, interruptores entrecruzados de seguridad o a cualquier otra parte del horno. **NO** quite el panel exterior del horno. Las reparaciones deben ser hechas solamente por personal de servicio calificado.
2. **NO** opere el horno vacío. La energía de microondas se reflejara en el interior del horno si no hay alimentos o agua para absorber la energía.
3. **NO** utilice este horno para calentar químicos o cualquier otros productos no alimenticios. **NO** limpie este horno con cualquier producto etiquetado con contenido químico corrosivo. El calentamiento de químicos corrosivos en este horno puede causar fugas de radiación.
4. **NO** seque telas, periódicos u otros materiales en el horno. Pueden incendiarse.
5. **NO** use productos de papel reciclado, ya que pueden contener impurezas que pueden causar chispas y/o incendios cuando se usen.
6. **NO** use periódicos o bolsas de papel para cocinar. Puede causar un incendio.
7. **NO** pegue, **NO** golpear el panel de control. Pueden causarse daños a los controles. Puede causar un incendio.
8. Las manoplas para tomar cosas calientes siempre deben ser utilizados cuando se retiren cosas de el horno. El calor se transfiere de los alimentos calientes a los contenedores para cocinar y de los contenedores a la Bandeja de Cristal. La Bandeja de Cristal puede estar muy caliente después de sacar los contenedores para cocinar del horno.
9. **NO** almacene materiales flamables cerca, arriba, o dentro del horno. Pueden ser riesgos de incendio.

# Instrucciones Para Conexión a Tierra

Este aparato debe ser conectado a tierra. En el caso de un corto circuito, la conexión a tierra reduce el riesgo de una descarga eléctrica proporcionando una línea de escape para la corriente eléctrica. Este aparato está equipado con un cable y clavija para conexión a tierra. La clavija debe ser conectada en un tomacorriente que esté instalado adecuadamente y conectado a tierra.

**PRECAUCION** - El uso inapropiado de la clavija para conexión a tierra puede resultar en riesgo de descarga eléctrica.

Consulte a un electricista o a personal de servicio calificados, si las instrucciones para conectar a tierra no son completamente comprendidas o si existe duda de que el aparato está correctamente conectado a tierra. Si es necesario usar un cable de extensión, use solamente cable de extensión de tres hilos que tenga una clavija de tres entradas para conectar a tierra, y un tomacorriente de tres ranuras que acepte la clavija del aparato. El calibre marcado en el cable de extensión debe ser igual o mayor al calibre eléctrico del aparato.

## Suministro Eléctrico

1. Se pruebe un cable de suministro eléctrico corto para reducir los riesgos resultantes de enredarse o tropezarse con un cable más largo.
2. Juegos de cable más largos o extensiones están disponibles y pueden utilizarse si se usan con cuidado.
3. Si se usa un cable más largo o extensión, (1) el calibre eléctrico marcado en el juego de cordón o extensión debe ser al menos tan grande como el calibre eléctrico del aparato, (2) el cable de extensión debe ser de tres hilos del tipo de conexión a tierra, y (3) el cordón más largo debe ser arreglado de tal forma que no caiga sobre la cubierta del mostrador o de la mesa donde pueda ser jalado por niños o tropezarse accidentalmente.

# Instrucciones de Instalación

## Examine Su Horno

Desempaque el horno, quite todo el material de empaque y examine que su horno no tenga ningún daño, tales como abolladuras, seguros de la puerta rotos o resquebraaduras en la puerta. Notifique inmediatamente a su distribuidor si el horno está dañado.



## Ubicación del Horno

1. El horno debe ser colocado en una superficie plana y estable. Para su operación apropiada, el horno debe tener suficiente corriente de aire. Deje 8 cm de espacio de ambos lados del horno y 2.5 cm de espacio en la parte superior del horno.
  - a. **NO** tape las ventilas de aire. Si están tapadas durante su operación, el horno puede sobrecalentarse. Si se sobrecalienta, un dispositivo térmico de seguridad apagará el horno. El horno no operará hasta que se haya enfriado.
  - b. **NO** coloque el horno cerca de una superficie húmeda caliente, tal como un registro de gas o eléctrico.
  - c. **NO** opere el horno cuando la humedad del cuarto sea muy alta.
2. Este horno ha sido fabricado para uso en el hogar solamente.

## Interferencia de Radio

1. La operación de su horno de microondas puede causar interferencia en su radio, TV o equipo similar.
2. Cuando hay interferencia, se puede reducir o eliminar tomando las siguientes medidas:
  - a. Limpie la puerta y las superficies selladoras del horno. (Vea Cuidados de Su Horno de Microondas que se encuentran en la página 53).
  - b. Ponga el radio, TV, etc. lo más lejos posible del horno de microondas.
  - c. Use una antena instalada adecuadamente para obtener una recepción de señal más fuerte.

## Requerimientos de cableado

1. El horno debe estar en un circuito separado. Ningún otro aparato debe compartir el circuito con el horno. Si lo hace el fusible del circuito puede estallar, el bloqueador del circuito trabarse o la comida cocinarse más lento que en los tiempos recomendados en este manual.
2. El voltaje usado debe ser el mismo al especificado en el horno de microondas (120 V.). Usar un voltaje más alto es peligroso y puede resultar en fuego u otro accidente causando daño al horno. Usar un bajo voltaje dará como resultado una cocción más lenta. **PANASONIC** no se hace responsable por daños resultantes del uso del horno con otros voltajes que no sea el especificado.
3. El horno debe ser conectado en un enchufe a tierra de al menos 20 amp 120 volt, 60 Hz. Donde se encuentre un enchufe estándar de 2 entradas es responsabilidad y obligación del consumidor reemplazarlo por un enchufe a tierra de 3 entradas.
4. Una conexión temporal con un adaptador de 2 entradas puede ser hecha donde los CODIGOS LOCALES LO PERMITAN. A menos que el tornillo de la cubierta del enchufe esté conectado a tierra mediante el cableado de la casa, atornillar el adaptador a la tapa del enchufe **NO** pondrá a tierra el horno. Si hay alguna duda de si el tornillo de la tapa del enchufe está a tierra haga que lo cheque un electricista.

# Sugerencias Útiles

## Siga Esta Precauciones de Seguridad Cuando Cocine en Su Horno

### 1) ENLATADO CASERO / ALIMENTOS

#### DESHIDRATADOS / PEQUEÑAS CANTIDADES DE ALIMENTOS

- No use su horno para el enlatado casero o para calentar cualquier frasco cerrado. La presión aumentará y el frasco puede explotar. Su horno no puede mantener los alimentos a la temperatura apropiada de enlatado.
- Pequeñas cantidades de alimento o alimentos con bajo contenido de humedad se pueden secar, quemar o incendiarse.
- No seque alimentos, hierbas, frutas o vegetales en su horno.

#### IMPORTANTE

La cocción adecuada depende del tiempo designado y del peso de los alimentos. Si usa una porción menor de la recomendada y cocina por el tiempo para la porción recomendada, puede resultar un incendio. Si ocurre un incendio, ponga el horno en posición de apagado y manténgalo cerrado. Desconecte la energía eléctrica o desconecte la caja de fusibles o el panel de control.

### 2) PALOMITAS DE MAÍZ

Las palomitas de maíz deben prepararse en un recipiente para palomitas de maíz adecuado para horno de microondas. Palomitas de maíz para horno de microondas que se preparan en su propio paquete también están disponibles. Siga las instrucciones del fabricante de palomitas de maíz y use una marca adecuada para la potencia de su horno de microondas. Nunca deje desatendido el horno cuando prepare palomitas de maíz.

#### PRECAUCIÓN

Cuando use palomitas de maíz para microondas previamente empacado siga las instrucciones recomendadas en el paquete. Revise el peso del paquete antes de usar la teca de palomitas de maíz. Prepare el horno para el peso del paquete de palomitas de maíz (vea página 47). Si no se siguen estas instrucciones, las palomitas de maíz pueden no reventar adecuadamente o pueden encenderse y causar un incendio.

### 3) FREIR CON MUCHA GRASA

- No trate de freír con mucha grasa en su horno de microondas. Cocinar aceites puede estallar en flamas y puede causar daño al horno y quizá acabar en quemaduras. Los utensilios de microondas pueden no ser útiles para soportar la temperatura del aceite caliente, y podrían romperse.

### 4) HUEVOS

- No caliente huevos en su cáscara en el horno de microondas. La presión subirá y el huevo explotará.

### 5) ALIMENTOS CON PIELS NO POROSAS

- Papas, manzanas, yemas de huevo, calabazas completas y salchichas son ejemplos de alimentos con pieles no porosas. Estos tipos de alimentos deben ser perforados antes de cocinarlos en Microondas para evitar que estallen.

- Use papas frescas para hornear y cocínelas hasta que estén listas. Cocinar demasiado causa deshidratación y puede producir un incendio. Use los pesos recomendados o puede ocurrir un incendio.

### 6) LIQUIDOS

- Los líquidos calientes pueden hacer erupción si no se mezclan con el aire. No caliente líquidos en su horno de microondas sin agitatorios antes.

### 7) BANDEJA DE CRISTAL / UTENSILIOS DE COCINA/PAPEL ALUMINIO

- Los utensilios para cocinar se calientan durante la cocción en microondas. Use soportes para lo caliente, cuando saque los utensilios del horno o cuando quite tapas o cubiertas de envoltura de plástico de los utensilios de cocina, para evitar quemaduras.
- La bandeja de cristal se calentará durante la cocción. Debe permitirse que se enfríe antes de manejarla o antes de colocar productos de papel, tales como platos de papel o bolsas de palomitas de maíz para microondas, para cocinar.
- Cuando se use papel aluminio, brochetas, rejillas para calentar o utensilios hechos de metal en el horno, deje por lo menos 2,5 cm de espacio entre el material de metal y las paredes interiores del horno. Si arquea (chispea) quite el material de metal (brochetas etc.) y/o cambíelo a un contenedor no metálico.
- Platos con adornos metálicos no deben ser usados, ya que puede producirse arco eléctrico.

### 8) TOALLAS DE PAPEL / TELAS

- No use toallas de papel o telas que contengan fibras sintéticas en su tejido. La fibra sintética puede causar que la toalla se incendie.
- No use bolsas de papel o productos de papel reciclado en el horno de microondas.

### 9) BANDEJA DORADORA / BOLSAS PARA COCINAR EN HORNO

- Los bandeja doradora o asados son diseñados para cocinar en microondas solamente. Siempre siga las instrucciones dadas por el fabricante. No precaliente la bandeja doradora más de 8 minutos.
- Si se usa una bolsa para cocinar para el Microondas, prepare de acuerdo a las instrucciones del paquete. No use sujetadores de alambre para cerrar la bolsa.


### 10) TERMÓMETROS

- No use termómetros convencionales para alimentos en su horno. Puede producir arco.

### 11) GUÍA DE USO GENERAL DEL HORNO / PUERTA DEL HORNO


- No use el horno por cualquier razón que no sea la preparación de alimentos.
- No deje sin atención el horno mientras esté en uso.

# Diagrama de Características



- ① Ventana del horno
- ② Sistema de seguridad de la puerta
- ③ Orificios de ventilación del horno
- ④ Panel de controles
- ⑤ Placa de identificación
- ⑥ Bandeja de cristal
- ⑦ Anillo de rodillo
- ⑧ Rejilla especial para descongelar

# Panel de Control



- (1) Ventanilla indicadora
- (2) Pulsador de potencia
- (3) Pulsadores de numéricos
- (4) Pulsador de tiempo de espera y reloj
- (5) Pulsador de Acción de Coccion
- (6) Pulsador de Descongelamiento por sensor
- (7) Pulsador de rápido en minutos
- (8) Pulsador de palomitas
- (9) Pulsador Parar/Cancelar
- (10) Pulsador Para Comenzar
- (11) Sensor de recalentamiento automático
- (12) Sensor de cocción automático
- (13) Pulsador de Más/Menos
- (14) Pulsador de funciones
- (15) Pulsador para porciones / peso

# Funciones

Los pulsadores le permiten escoger el sistema en cada característica.








<b>1</b>	<p><b>OPCIÓN DE IDIOMA</b></p> <p>La pantalla de el horno viene en inglés, francés y español. La pantalla aparece en inglés cuando usted conecta el horno.</p> <p>1 ENGLISH → La pantalla aparece en inglés.                  2 FRANCAIS → La pantalla aparece en francés.                  3 ESPAÑOL → La pantalla aparece en español.</p>
<b>2</b>	<p><b>OPCIÓN Lb/Kg.</b></p> <p>El horno tiene medidas de peso métricas e imperiales. El horno estará en la medida de peso imperial cuando lo conecte.</p> <p>1 Lb. → El peso puede ser puesto en lb/oz.                  2 KG → El peso puede ser puesto en kg/g.</p>
<b>3</b>	<p><b>VELOCIDAD DE PALABRA</b></p> <p>La velocidad de las palabras en la pantalla puede correr más rápido o más lento.</p> <p>1 RÁPIDO → Las palabras correrán rápido.                  2 MEDIO → Las palabras correrán a su velocidad inicial.                  3 LENTO → Las palabras correrán lento.</p>
<b>4</b>	<p><b>ACCIÓN DEL MENÚ ENCENDIDO/APAGADO</b></p> <p>La acción del menú en pantalla le ayuda a programar el horno indicando el siguiente paso a fumar por anticipado. Cuando ustedes se familiarize con su horno, esto puede ser apagado.</p> <p>1 ENCENDIDO (ON) → La guía aparecerá.                  2 APAGADO (OFF) → La guía no aparecerá.</p>
<b>5</b>	<p><b>SEGURO PARA NIÑOS ENCENDIDO/APAGADO</b></p> <p>El horno tiene la característica de seguro para niños para prevenir su uso por niños.</p> <p>1 ENCENDIDO (ON) → El seguro ha sido puesto y ninguna operación será aceptada.                  2 APAGADO (OFF) → El seguro ha sido cancelado.</p>
<b>6</b>	<p><b>SONIDO "BEEP" ENCENDIDO/APAGADO</b></p> <p>Si ustedes desea que el horno opere sin sonido "beep", puede ser eliminado.</p> <p>1 ENCENDIDO (ON) → El sonido "beep" reaparecerá.                  2 APAGADO (OFF) → El sonido "beep" no se escuchará.</p>
<b>7</b>	<p><b>SONIDO "BEEP" DE RECORDATORIO ENCENDIDO/APAGADO</b></p> <p>Este sonido "beep" es para recordar le que retire el alimento después de que se ha completado la cocción.</p> <p>1 ENCENDIDO (ON) → El sonido "beep" de recordatorio trabajará.                  2 APAGADO (OFF) → El sonido "beep" de recordatorio no trabajará.</p>
<b>8</b>	<p><b>HORARIO DE VERANO</b></p> <p>1 ENCENDIDO (ON) → Automáticamente ajusta el reloj una hora hacia adelante.                  2 APAGADO (OFF) → Retrasa el reloj a su hora original.</p>
<b>9</b>	<p><b>RELOJ ENCENDIDO/APAGADO</b></p> <p>El reloj puede apagarse.</p> <p>1 ENCENDIDO (ON) → El reloj reaparecerá.                  2 APAGADO (OFF) → El reloj desaparece.                  La hora del día no se perderá si el reloj desaparece de la pantalla.</p>
<b>0</b>	<p><b>MODO DE DEMOSTRACIÓN ENCENDIDO/APAGADO</b></p> <p>El modo de demostración está diseñado para su exhibición en tienda. En este modo, el horno puede ser demostrado sin poder o potencia.</p> <p>1 ENCENDIDO (ON) → El horno estará en modo de demostración.                  2 APAGADO (OFF) → El horno no estará en modo de demostración.</p>



## Para Seleccionar Potencia y Tiempo

Ejem.: Nivel de potencia MEDIO por 5 minutos

1	 4 x	• Seleccione el nivel de potencia.
2	 →  → 	• Seleccione el tiempo de cocción (hasta 99 min y 99 seg).
3		• Presione el pulsador <b>Start</b> .



### NOTA:

- Al seleccionar el nivel de potencia ALTO en la primera etapa, no es necesario presionar el pulsador **Power Level**. Simplemente fije el tiempo de cocción presionando los pulsadores de Tiempo y **Start**.
- Para cocción en 2 o 3 etapas, repetir los pasos arriba citados, antes de apretar el pulsador **Start**.
- Pulsador **Power Level**.

Pulse	Nivel de Potencia	% Potencia
1 vez	ALTO	100%
2 veces	DESCONGELACION	30%
3 veces	MEDIO-ALTO	70%
4 veces	MEDIO	55%
5 veces	MEDIO-BAJO	30%
6 veces	BAJO	10%

## Pulsador de Palomitas de Maíz

Ejem.: Para recalentar 99 g (3.5 oz.) de palomitas de maíz en bolsas especiales para microondas

1	 1 vez	• Seleccione el peso que se indica en la bolsa de palomitas. <table border="1" data-bbox="351 1554 654 1690"> <thead> <tr> <th>Presionar</th> <th>Peso</th> </tr> </thead> <tbody> <tr> <td>1 vez</td> <td>99 g (3.5 oz.)</td> </tr> <tr> <td>2 veces</td> <td>90 g (3.0 oz.)</td> </tr> <tr> <td>3 veces</td> <td>50 g (1.75 oz.)</td> </tr> </tbody> </table>	Presionar	Peso	1 vez	99 g (3.5 oz.)	2 veces	90 g (3.0 oz.)	3 veces	50 g (1.75 oz.)
Presionar	Peso									
1 vez	99 g (3.5 oz.)									
2 veces	90 g (3.0 oz.)									
3 veces	50 g (1.75 oz.)									
2		• Presione. ► El tiempo de cocinado aparece y empieza la cuenta regresiva.								

### NOTA:



Ponga la bolsa en el interior del horno de acuerdo con las instrucciones del fabricante.

## Función Rápido en Minutos

Esta característica le permite ajustar el tiempo de cocción fácilmente en vez de usar los pulsadores numéricos o agregar tiempo de cocción extra.

Para seleccionar el tiempo de cocción:


Ejem.: Nivel de potencia ALTO por 1 minuto

1	 1 vez	• Seleccione el tiempo de cocción (hasta 10 min).
2		• Presione el pulsador <b>Start</b> .

### NOTA:

- Se puede usar otro nivel de potencia, selecciónelos antes de ajustar el tiempo.
- Después de haber ajustado el tiempo por medio del pulsador **Quick Min** no podrá usar los pulsadores numéricos o vice versa.

Para Agregar Tiempo Extra:







	• Oprima para agregar tiempo de cocción (hasta 10 min) durante el cocinado. ► El tiempo de cocinado cambia para incluir el tiempo extra y continúa la cuenta regresiva en la pantalla.
---	---

### NOTA:



Usted puede añadir tiempo de cocción para todos los platillos con las funciones de poder y tiempo.

## Para Ajustar el Reloj

Ejem.: Para fijar 11:25 a.m. o p.m.

1.		• Presione el pulsador. <b>Timer/Clock</b> 1 vez. ► Los dos puntos parpadearán
2.	   	• Fije la hora correcta del día.
3.		• Presione el pulsador. <b>Timer/Clock</b> una vez. ► Los dos puntos dejarán de parpadear. La hora está ingresada y ubicada en la ventanilla indicadora.


# Sensor de Descongelacion

<p>1.</p> 	<p>Presione. Ponga la comida en la parrilla para descongelar. El mensaje de menú es : <b>"Sensor de descongelación -- ponga la comida en la parrilla de descongelación presione COMENZAR". COMENZAR</b> parpadea.</p>
<p>2.</p> 	<p>Presione <b>COMENZAR "Start"</b> El mensaje de menú es : <b>"Cierre la puerta"</b> Aparece <b>"AUTO"</b> en la pantalla, después de dos (2) beeps el tiempo restante aparece en la pantalla.</p>
	<p>Empezará la cuenta regresiva, a la mitad del tiempo suenan dos (2) beeps. El mensaje de menú es : <b>"Voltear"</b>. La cuenta regresiva continúa. Al final del tiempo sonarán cinco (5) beeps y aparecerá en la pantalla <b>"Disfrute sus alimentos"</b> (vea la página 11 para tiempos.)</p>





El sistema de SENSOR DE DEDESCONGELACIÓN funciona detectando los cambios de temperatura dentro del horno y luego programandolo para descongelar la comida.

1. Prepare la comida adecuadamente (vea "Tips y Técnicas para descongelar" en la página 11).
2. Para obtener resultados optimos, el peso debe ser entre 230 g y 3 kg. (0.5 lbs y 7 lbs). La comida de menos de 230 g. empezará la cocción, en ese caso utilice TIEMPO DE DESCONGELACIÓN. Para porciones mas pequeñas vea la tabla de descongelación de la página 11.
3. El interior de su horno y la charola deben estar limpios.
4. Ponga la comida sin tapar en la parrilla de descongelación (la parrilla es solo para descongelar.)
5. No cubra la comida cuando utilice el sensor de descongelación.
6. Debido a que la comida varía en cuanto a forma y tamaño, es conveniente que volteé la comida al escuchar el primer beep.
7. Si el mensaje en la pantalla dice "REGRESE LA COMIDA AL CONGELADOR - - -" siga las instrucciones, esto permite al sensor de descongelación funcionar adecuadamente.

La comida que se está descongelada debe estar en la parrilla de descongelación para obtener los resultados deseados.



- A) Ponga siempre la comida en el centro de la parrilla de descongelación utilice el sensor de descongelación.
- B&C) Si coloca la comida directamente en el plato giratorio o en un plato, el proceso no será el adecuado.
- C) Cuando descongele cosas pequeñas como camarones y veneras apíelos y después sepárelos para mejores resultados.



## Consejos Para Descongelar

### Preparando alimentos para congelar:

1. Congele carne, aves y pescado en paquetes de 1 o 2 rebanadas. Para ayudar a separar las rebanadas, coloque papel encerado entre rebanadas.
2. Envuelva en plástico resistente, bolsas o papel para congelar.
3. Remueva todo el aire posible.
4. La envoltura debe quedar justa.
5. Selle bien



# Técnicas Para Descongelar

1. Remueva la envoltura para prevenir retener vapor y jugo. El jugo del alimento se calentará y puede causar que la superficie o el fondo del alimento se cueza; coloque el alimento en la rejilla de el horno de microondas y deje drenar el liquido durante el descongelado.
2. Coloque la carne en un plato de tamaño apropiado. El tocino puede ser descongelado en su envoltura original.
3. Coloque la carne blanda y la pechuga hacia abajo en un plato sobre la rejilla para descongelar del horno de microondas.
4. Coloque pequeñas piezas como trozos de carne, piezas de pollo, camarones, escalopas o pescado en un plato sobre la rejilla para descongelar del horno de microondas.
5. Carnes grandes y aves enteras pueden quedar congeladas en el centro después de descongelar, deje reposar envueltos en plástico en el refrigerador (ver tabla abajo).
6. Pescados y mariscos deben quedar ligeramente congelados después de descongelar, deje reposar y remoje en agua fría por 2 o 3 minutos.
7. Piezas congeladas en rebanadas deben remojarse separadamente o dejar reposar por más tiempo.

ALIMENTO	TIEMPO DE DESCONGELADO	DURANTE EL DESCONGELADO
<b>Pescado y mariscos</b> <b>[arriba de 3 lb (1.5 kg)]</b> Cangrejo Steaks de pescado Filetes de pescado Escalopas de pescado Camarón mediano Pescado entero	12 a 14 8 a 10 6 a 8 14 a 16 8 a 10 10 a 12	Rompa Voltee Voltee / Arregle Rompa / Remueva las piezas congeladas Rompa / Remueva las piezas congeladas Voltee
<b>Carne</b> Asado 2½ - 4 lb. (1.2 - 2 kg) ♂ Chuletas / Steak Costillas / T-bone Hígado (rebanadas finas) Puerco	8 a 10 8 a 10 8 a 10 8 a 10 4 a 6	Voltee / cubra las orillas y la superficie congelada Separa / Voltee / Arregle Voltee / Cubra Deje escurrir / Voltee / Separe las piezas Voltee
<b>Aves</b> Pollo entero [más de 3 lb. (1 5 kg)] Chuletas Piezas Codorniz Pechuga de pavo	6 a 10 6 a 8 8 a 10 8 a 12 8 a 12	Voltee 2 o 3 veces / Cubra partes descongeladas Voltee Separe Voltee / Arregle Voltee 2 or 3 veces

# Sensor de Recalentamiento/Cocción Automática

## RECALENTAMIENTO

1		• Presione el pulsador de <b>Sensor Reheat</b> .
2		• Presione el pulsador <b>START</b> .



### Para obtener mejores resultados del Sensor de Recalentamiento, siga estas recomendaciones:

1. Todos los alimentos deben ser cocidos previamente y deben estar a temperatura o temperatura de refrigerador.
2. Los alimentos que pesen menos de 100 g y más de 700 g se deben recalentar sólo por tiempo y potencia.

### NO HACER

1. Recalentar pan y productos de pastelería. Use el tiempo y potencia manual.
2. Recalentar alimentos crudos o sin cocer.
3. Usar la función de recalentamiento si el interior del horno está caliente.
4. Usar la función de recalentamiento para bebidas.
5. Usar la función de recalentamiento para alimentos congelados.

## COCCION:

1	Ej. 	• Presione el pulsador de la categoría deseada hasta que aparezca el número e ítem deseado en la ventanilla indicadora.
2		• Presione el pulsador <b>START</b> .

El sistema de SENSOR AUTOMATICO ("AUTO SENSOR") Trabaja detectando el vapor acumulado que despiden los alimentos en la cavidad del horno. Usted podrá cocinar y recalentar muchos de sus alimentos favoritos sin tener que seleccionar temperaturas y niveles de potencia.

### ANTES de cocinar/recalentar:

(para mejores resultados por sensor, verifique lo siguiente)

1. La temperatura ambiente que rodea al horno debe ser menor de 35°C (95°F).
2. El peso de los alimentos no deberá ser menor a 100 g (4 onzas) aprox.
3. El plato giratorio de cristal y el contenedor que se va a utilizar deben estar secos.
4. **Cubra los alimentos** por completo con papel plástico procurando que este no quede muy adherido, o bien, colocarlo en una cacerola con tapa.

### DURANTE la cocción/recalentado:

Mientras la palabra "AUTO" se muestre en la ventanilla indicadora, no deberá abrirse la puerta del horno por más de 1 minuto, esto causaría resultados inadecuados en la cocción. El tiempo restante de cocción aparecerá inmediatamente en la ventanilla indicadora y comenzará a contar en forma descendente. El horno puede ser abierto durante este tiempo restante para voltear, batir o añadir ingredientes.

### DESPUES de la cocción/recalentado:

Todos los alimentos deben estar cubiertos durante un tiempo de 3 a 5 minutos.

### Control de grado de cocción mas/menos (More/Less):

Las preferencias en el grado de cocción de los alimentos varían en cada individuo, con este pulsador usted podrá decidir qué tipo de grado de cocción prefiere en sus alimentos.

Usando este pulsador el Sensor automatico puede ser ajustado para cocinar el alimento por más o menos tiempo. Si usted está satisfecho con los resultados de cocción del programa "auto sensor", no necesitará usar el control más/menos.

Un toque: más cocido con indicador "MAS"

Dos toques: menos cocido con indicador "MENOS"




Tres toques: cocido inicial

# Sensor de Cocción Automática





	CATEGORÍA	PESO	INSTRUCCIONES
Potato/ Vegetables	1 x Papas	Cualquier Cantidad	Abra la piel varias veces y coloque en un molde a prueba de microondas. NO cubra. De la vuelta después del sonido.
	2 x Vegetales Frescos	Cualquier Cantidad	Agregue agua. Cubra con la tapa o cubierta de plástico. Revuelva o reacomode después del sonido.
	3 x Vegetales Congelados	Cualquier Cantidad	Agregue 2 cucharadas soperas de agua. No cocine con mantequilla o salsa. Cubra con la tapa o cubierta de plástico. Revuelva o reacomode después del sonido.
Rice/Pasta	1 x Arroz	Arroz      Agua ½ taza     1 taza 1 taza      2 tazas 1½ taza    3 tazas 2 tazas    3½ tazas	Ponga arroz y agua caliente con 1/4 de cucharadita de sal. Cubra con la cubierta de plástico. Después del "beep", bata muchas veces. Después de cocinar bata y deje reposar de 5 a 10 minutos.
	2 x Pasta	120 - 230 (4 - 8 oz.)	Ponga 1½ cuartos de agua, pasta, 1 cucharada de aceite y 1 cucharadita de sal en una cacerola de 4 qt. Cubra. Después del "beep" bata ocasionalmente.
Frozen Foods	1 x Entradas Congeladas	Cualquier Cantidad	No use alimentos congelados en charolas selladas. Siga las instrucciones del fabricante para cubrir. Revuelva, bañe con la salsa o con el jugo después del sonido.
	2 x Platos Fuertes Congelados	Cualquier Cantidad	No use alimentos congelados en charolas selladas. Siga las instrucciones del fabricante para cubrir. Revuelva, si es posible, después del sonido.
Casserole/ Stew	1 x Plato al Horno	Hasta cuatro quartos	Use la cantidad apropiada de líquido. Cubra con el la tapa de la cacerola. Revuelva ocasionalmente después del sonico
	2 x Guisados	Hasta cuatro quartos	Use la cantidad apropiada de líquido. Cubra con la tapa de la cacerola. Agite ocasionalmente o arregle después del "beep".
Seafood	1 x Filete de Pescado	230g min. (½ lb.)	Acomode en una sola capa en el molde. Cubra con tapa o cubierta de plástico. Reacomode después del sonido.
	2 x Marisco	230g min. (½ lb.)	Acomode en una sola capa en el molde. Cubra con tapa o cubierta de plástico. Revuelva los camarones u ostras después del sonido.
Poultry/Meat	1 x Tocino	2 - 6 rebanadas	Pon las rebanadas en un plato. Tapa con toallas de papel.
	2 x Piezas de Pollo	230g min. (½ lb.)	Coloque el lado de la piel hacia arriba. Cubralo con cubierta de plástico. Después del sonido, reacomódelo.
	3 x Pollo Entero	Hasta 3 kg (6 lb.)	Coloque el lado de la pechuga hacia abajo. Cúbralo con cubierta de plástico. Vootee el lado de la pechuga hacia arriba después del sonido.
	4 x Cerdo	1 - 2 kg. (2 - 4 lb)	Coloque la parte de grasa hacia arriba. Cúbralo con cubierta de plástico. Voltéelo, después del sonido.
	5 x Res Termino Medio	(1 - 2 kg) (2 - 4 lb.)	Coloque la parte de grasa hacia arriba. Cúbralo con cubierta de plástico.

# Temporizador (Timer)





## Para usar como temporizador en la cocina:

Ejem.: Para contar 5 minutos	
1. 	• Presione el pulsador <b>Timer/Clock</b> una vez.
2. 	• Indique la cantidad de tiempo (hasta 99 min y 99 segundos).
3. 	• Presione el pulsador <b>Start</b> . ► El tiempo comenzará a contar en forma descendente sin que el horno esté funcionando.

## Para fijar un tiempo de espera o tiempo de reposo:

Ejem.: Después de la cocción dejar reposar el alimento durante 5 minutos.	
1. Ej. 	• Seleccione el programa de cocción (ver p. 47 para instrucciones).
2. 	• Presione el pulsador de <b>Timer/Clock</b> una vez.
3. 	• Indique la cantidad de tiempo (hasta 99 min y 99 segundos).
4. 	• Presione el pulsador de <b>Start</b> . ► Después de la cocción el tiempo de reposo empezará a contar en forma descendente sin que el horno esté funcionando.

## Para programar un comienzo tardío:

Ejem.: Para empezar a cocinar 5 minutos después	
1. 	• Presione el pulsador <b>Timer/Clock</b> una vez.
2. 	• Indique la cantidad de tiempo que tardará en empezar el programa (hasta 99 min y 99 seg).
3. Ej. 	• Seleccione el programa de cocción (ver p.47 para instrucciones).
4. 	• Presione el pulsador de <b>Start</b> . ► Cuando el tiempo demorado comience la cuenta regresiva y este haya finalizado, la cocción iniciará.

### Notas:

1. Si la puerta del horno es abierta durante el tiempo de espera o cuando se usa como temporizador, el tiempo que se indica en la ventanilla continuará contando en forma regresiva.
2. El comienzo tardío no puede ser programado antes de ninguna función automática.  
Esto es para prevenir que el inicio de la temperatura de los alimentos se incremente antes del descongelamiento o inicio de la cocción. Un cambio en el inicio de la temperatura podría causar resultados inadecuados.

# Cuidados de Su Horno de Microondas

**ANTES DE LIMPIAR:** Apague el horno y desconecte el cable de alimentación para prevenir un encendido accidental.

**Interior del horno:** Limpie su horno con un paño húmedo. Puede utilizar un detergente suave si el horno esta muy sucio. El uso de limpiadores abrasivos no es recomendable.

**Puerta del horno:** Si el vapor se acumula en el interior o alrededor de la puerta del horno, limpie con un paño suave. Esto puede suceder cuando el horno se opera en condiciones demasiado húmedas y no indica mal funcionamiento de la unidad.

**Panel de controles:** Limpie su panel con un paño suave, no use detergentes fuertes ni abrasivos.

**Plato giratorio de cristal:** Remueva el plato de cristal. Cuando este frío y lave con agua tibia y jabonosa o en su lavadora de platos.

**El anillo giratorio:** Limpie el soporte del plato giratorio que se encuentra en el horno con agua jabonosa. El anillo giratorio debe ser limpiado en agua jabonosa o en su lavadora de platos. Estas partes deben estar limpias para evitar un excesivo ruido.

**DESPUES DE LIMPIAR:** Este seguro de colocar el anillo giratorio y el plato de cristal en la posición correcta y presione **Stop/Reset** para limpiar la ventanilla indicadora.

## Antes de Acudir al Servicio

### Todas estas cosas son normales:

Mi horno de microondas causa interferencia con mi televisor.

En algunos radios y televisores puede ocurrir interferencia cuando usted cocine con su horno de micro ondas. Esta interferencia es similar a la interferencia causada por pequeños aparatos eléctricos como batidoras, aspiradoras, secadoras de aire, esto no indica ningún problema.

La luz del horno se atenúa.

Cuando se está cocinado con una temperatura diferente a temperatura alta (HIGH) el horno tiene que recorrer un ciclo para obtener niveles de potencia más bajos. La luz del horno se atenúa y podrá oír ruidos de "click" cuando el horno realiza su ciclo.

Se acumula vapor en la puerta del horno y aire caliente sale de las rejillas de ventilación.

Durante la cocción los alimentos despiden vapor. La mayoría de este vapor es removido por el aire que circula en la cavidad del horno, sin embargo, algo de vapor se condensará en las superficies frías tales como la puerta del horno. Esto es normal.

Accidentalmente encendió su horno de micro ondas sin ningún alimento dentro.

Operar el horno vacío por un corto tiempo no dañará el horno sin embargo no lo recomendamos.

### PROBLEMA

### POSIBLE CAUSA

### SOLUCION

El horno no enciende.



¿Esta el horno conectado en forma segura?

Remueva la clavija de contacto de la toma de corriente. Espere 10 seg. Vuelva a conectar.

El circuito general de luz o el fusible estan fuera de servicio o tienen algún problema interno.

Encienda de nuevo su circuito general de luz (brake) o reemplace el fusible.

Hay un problema en la toma de corriente.

Conecte otro aparato eléctrico para verificar su toma de corriente.

El horno no acepta mi programa.



La puerta del horno no esta bien cerrada.















Cierre la puerta firmemente.

Otro programa se encuentra registrado en su horno.

Presione **Stop/Reset** (parar/borrar) para cancelar el programa anterior y programe de nuevo.

Si al parecer el problema se encuentra en su horno, consulte al centro de servicio más cercano.

# Quick Guide to Operation

Feature	How to Operate
<b>To Set Clock</b> (☛ page 10)	 <p>Enter time of day.</p>
<b>Power and Time Setting</b> (☛ page 10)	 <p>Select power.</p> <p>Set cooking time.</p>
<b>To Defrost using Manual Defrost</b> (☛ page 10)	 <p>Select defrost. (2 x's)</p> <p>Set time.</p>
<b>"Sensor Defrost"</b> (☛ page 12)	
<b>To Reheat using "Sensor Reheat"</b> (☛ page 13)	 <p>optional</p>
<b>To Cook using "Sensor Cooking"</b> (☛ page 13 - 14)	<p>e.g.  →  → </p> <p>Select desired category.</p> <p>optional</p>
<b>To Cook using "Popcorn"</b> (☛ page 15)	 <p>Select weight.</p>
<b>To use as a Timer</b> (☛ page 16)	 <p>Press once.</p>
<b>To use to set Stand Time</b> (☛ page 16)	
<b>To set Delay Start</b> (☛ page 16)	
<b>To Cook using "Quick Min"</b> (☛ page 15)	 <p>Tap desired number of times (up to 10 minutes).</p>
<b>To use "Function Pad"</b> (☛ page 8-9)	 <p>Select category.</p> <p>Select option.</p>