

FISHER PRICE 78410 Owner's Manual

Shop genuine replacement parts for FISHER PRICE 78410



Find Your FISHER PRICE Ride On Parts - Select From 999 Models

----- Manual continues below -----





/ CAUTION

ELECTRIC TOY: Not recommended for children under 1½ years of age. As with all electric products, precautions should be observed during handling and use to prevent electric shock.

Kawasaki[®] ZX-7

Owner's Manual with Assembly Instructions

Please read this manual and save it with your original sale's receipt.

For Model 78410

Tools needed for assembly: Phillips Screwdriver, Slotted Screwdriver, Hammer, Safety Scissors.

Use only with Power Wheels® Type H Battery, Power Wheels® 25 Amp Fuse and

Power Wheels® Type H 6 Volt Charger (all included).




WARNING – SIGNALS SOMETHING THAT COULD HURT YOUR CHILD OR YOU.

The message explains the hazard and how you can avoid it.

⚠ WARNING

- Children can be harmed by small parts, sharp edges and sharp points in the vehicle's unassembled state, or by electrical items. Care should be taken in unpacking and assembly of the vehicle. Children should not handle the battery or other parts, or help in assembly.
- Keep small parts and plastic bags out of children's reach. Dispose of plastic bags properly.
- Adult supervision is required. Children do not have the judgement necessary to avoid many accidents. Be sure that children operating this vehicle can do so safely and that they are supervised at all times.
- Improper use of this vehicle could lead to a serious or fatal accident. Allow children to play with the **Kawasaki® ZX-7** only when you have determined that they can do so safely. Follow all instructions to help your child enjoy this vehicle as safely as possible.
- Never use on or dangerously close to steps, inclines greater than 10°, roadways, bodies of water, low obstructions or in the dark.
- Always wear shoes or sneakers when operating this vehicle.
- Never allow more than one rider.
- The rider should sit on the seat when the vehicle is in motion.
- Observe the maximum weight limit of 50 lbs.
- Never alter this vehicle or its electrical system in any way. Alterations could cause a fire resulting in injury and could also ruin the electrical system.
- Use of the wrong type battery, fuse or charger could cause a fire or explosion, resulting in serious injury.
- Never add unauthorized parts to the vehicle or use substitute parts. Use only specified Power Wheels® replacement parts.
- The battery must be handled by adults only.
- Never lift or carry the battery by the wires or connector. This can damage the battery and possibly cause a fire. Lift and carry the battery by the case only.
- Never permit a child to handle the battery. The battery is heavy and contains sulfuric acid (electrolyte), and if dropped, could result in serious injury. Read the cautions on the back panel of the battery.
- Never allow children to charge the battery. Battery charging must be done by adults only. A child could be injured by the electricity involved in charging the battery.
- Examine the battery, charger and their connectors for excessive wear or damage each time you charge the battery. If damage or excessive wear is detected, do not use the vehicle until you have replaced the worn or damaged part.





/ CAUTION

- Do not operate the vehicle for the first time until you have inserted the 25 amp fuse into the battery and charged the battery for at least 18 hours. Never charge the battery longer than 30 hours.
- After first-time use, recharge the battery for at least 18 hours after each use. Never charge the battery longer than 30 hours.
- Use the charger indoors only.
- Read and follow the Battery Care instructions on page 26. Failure to follow the Battery Care instructions may permanently damage your battery and will void your warranty.
- To avoid damaging the motor and gears, do not overload the vehicle.
 - Never allow more than one child on the vehicle at one time.
 - Do not exceed the maximum weight capacity of 50 lbs.
 - Do not tow anything behind the **Kawasaki® ZX-7**. The extra weight may overload the vehicle.
- Avoid operating the vehicle in wet or snowy conditions, and do not spray the vehicle with a hose. Do not wash the vehicle with soap and water. Water or moisture in the motor or electrical switches can cause them to corrode, and could cause switch failure.
- Avoid operating the vehicle on grass, sand, loose dirt or gravel. Sand, loose dirt and gravel in the electrical switches or motor can cause them to jam, and could cause switch failure. Use the **Kawasaki® ZX-7** on asphalt, cement or other hard surfaces.

Table of Contents

Α	Message to Parents
В	Important Information
С	Parts
D	Parts Diagram
E	Parts List
F	First-Time Battery Charging
G	Assembly
Н	Battery Installation
I	Charging the Battery
J	Battery Handling/Care/Disposal
Κ	Rules for Safe Driving
L	How to Operate Your Vehicle
М	Questions and Answers
N	Problems and Solutions Guide
0	Statement of Limited Warranty
Р	Authorized Service Centers



Message to Parents

Thank you for purchasing the Power Wheels® **Kawasaki® ZX-7!** For over 30 years, Power Wheels® has manufactured high-quality, battery-powered vehicles for children. Our goal is to provide your child with an enjoyable and safe driving experience. To help achieve this goal, it is extremely important that you read this entire manual and share the appropriate information with your child.

The **Kawasaki® ZX-7** requires adult assembly. Please set aside at least 30 minutes for assembly. Read the assembly instructions carefully and identify all parts before assembly. Refer to the Parts Section beginning on page 6 for parts identification. Save all packaging material until assembly is complete to ensure that no parts are discarded.

In the unlikely event that parts are missing or damaged or if you have any questions about your Power Wheels® vehicle, please call our Consumer Affairs toll-free service lines, open from 8 AM to 6 PM (EST) Monday through Friday.

Please call us at 1-800-348-0751.

Trained customer service representatives are available to take your call in English or French.

¿Habla Español? Si usted tiene alguna pregunta ó necesita asistencia llame gratis 1-800-348-0755 para los Estados Unidos. Tenemos representantes que hablan español para atender su llamada. Este manual tambien disponsible en Espanol.

We also have a nationwide Authorized Service Center network – with over 300 Authorized Service Centers. Our Authorized Service Centers will repair or replace parts under warranty at no charge. For vehicles beyond warranty, our Authorized Service Centers will perform repairs for a minimal charge. For the Authorized Service Center nearest you, please see the Authorized Service Center listing beginning on page 35.

B

Important Information

- Carefully read this manual for important safety information and operating instructions before using your vehicle.
- Please complete and return the enclosed Vehicle Registration Card, or call 1-800-348-0751 to register your vehicle by phone.
- The **Kawasaki® ZX-7** is designed for use by children 1¹/₂-4 years.
- Adult assembly is required.
- This vehicle uses a Power Wheels® Type H battery with a Power Wheels® 25 amp fuse and a Power Wheels® Type H 6 volt charger (120 VAC 60 HZ 28W with an output of 6 VDC 1200 mA). Do not substitute any other battery, fuse or charger.
- Before first-time use, charge the battery for at least 18 hours. Never charge the battery longer than 30 hours.
- After the first charge, charge the battery a minimum of 18 hours after each use. Never charge the battery longer than 30 hours.
- Do not run down the battery completely before charging.
- Leaving the battery in a discharged condition will ruin it.
- Charge the battery before storing your vehicle.
- Charge the battery at least once per month, even if the vehicle has not been used.
- Do not store the battery in temperatures above 75° F or below -10° F.
- Even with proper care, the battery will not last forever. The life of the battery depends on how well you follow the Battery Care instructions and the total number of hours the battery is used. Please refer to the Battery Handling/Care/Disposal instructions on page 26 for detailed information about battery care.


- To purchase a Power Wheels® Type H battery, Power Wheels® 25 amp fuse or a Power Wheels® Type H 6 volt charger, please contact:
 - the store where your vehicle was purchased.
 - an Authorized Service Center (see Authorized Service Center list beginning on page 35).
 - Power Wheels® Consumer Affairs at 1-800-348-0751.
- While the battery is charging, the charger may become warm to the touch. This is normal, and does not indicate a problem.
- The Kawasaki® ZX-7 is suitable for use on asphalt, cement or other hard surfaces. To prevent damage to the motor and switches, do not operate the vehicle on loose dirt, gravel or sand.
- The Kawasaki® ZX-7 is not designed for use on grass or hills. For best traction, use only on asphalt, cement, or other flat, hard surfaces.
- To prevent damage to electrical components, store
 the Kawasaki® ZX-7 inside or under a protective
 cover during snowy or rainy weather. Do not leave
 the Kawasaki® ZX-7 out in the rain or let your child
 wash it with soap and water.
- The **Kawasaki® ZX-7** has a special circuit-breaker in the wiring to protect the motor and electrical system. If the vehicle is put under extreme load (driving on rough surfaces, too much weight, climbing too steep of an incline), the circuit-breaker will shut the electrical system down for up to 20 seconds. If the system repeatedly shuts down, the driving conditions may be too demanding (ie: too steep or too much weight).
- Metal parts have been coated with a lubricant to protect them during shipment. Wipe all metal parts with a paper towel to remove any excess lubricant.



Parts

If you experience a problem with this product, or are missing a part, please call us at 1-800-348-0751, rather than return this product to the store.

Please save all packaging material until assembly is complete to ensure that no parts are discarded.



Parts





Radio Knob – 2

Gas Cap



Handlebar Plug - 2



#8 x 7/8" Screw

#8 x 11/2" Screw - 4



#8 x3/4" Screw - 4



#6 x 3/8" Screw - 2

All Screws Shown Actual Size




Wheel Bushing - 2




25 Amp Fuse -2*

and cap nut have been included.


*For your convenience, an extra 25 amp fuse



Key Assembly



Parts Diagram



Kawasaki® ZX-7

FOR MODEL 78410 6 VOLT





Parts List

Note: The parts listed below are not all consumer assembled. Consumer assembled parts are shown on pages 6 and 7 and are highlighted in bold type below.

Item			
No.	Description	Part No.	Qty.
1	Battery	80008-0110	1
2	25 amp Fuse	80014-0070	1
3	Wheel Driver Screw	80006-0017	1
4	Foot Switch	80014-0022	1
5	Motor/Gearbox Assembly	74780-0640	1
6	Wiring Harness	80064-0083	1
7	Driver	80001-0247	1
8	Windshield	80063-0068	1
9	Lens Cover Set	80030-0074	1
10	.354 Retainer w/Body	80047-0104	2
11	⁷ / ₁₆ " Washer	80061-0039	2
12	1 ¹ / ₂ " Screw	80006-0175	5
13	Handgrip	80028-0016	2
14 15	Right Handlebar Shock Set	80029-0020 80001-0435]]
16	Front Axle	80025-0027	i
17	.437 Retainer w/Body	80047-0106	4
18	Front Hubcap	80033-0077	2
19	Wheel Spacer	80009-0060	5
20	Front Wheel	80062-0036	ĭ
21	Footboard Cover	80023-0033	i
22	Foot Pedal w/Spring Clip	80041-0004	i
23	Rear Wheel	80062-0047	2
24	Rear Hubcap	80033-0076	2
25	Motor Cover	80039-0052	ī
26	Rear Axle	80046-0090	1
27	Axle Spacer Tube	80052-0012	1
28	Body	80005-0340	1
29	Trunk Lid	80001-0511	1
30	Battery Retainer	80047-0022	1
31	⁷ /8" Screw	80006-0173	1
32	Seat	80067-0064	1
33	Gas Cap	80001-0512	1
34	Pivot Pin	80006-0027	1
35	Left Handlebar	80029-0041	1
36	Key Housing	80001-0281	1
37	Fairing	80063-0122	1
38 39	Microphone	80038-0009 80006-0171	1 2
39 40	³/8" Screw Dash		1
40 41	Swivel Bracket	80016-0047 80007-0005	; 1
42	3/4" Screw	80006-0172	4
43	Fender	80022-0065	1
44	Motor	80039-0043	i
45	Drive Gear Metal	80026-0098	i
46	Gearbox	80026-0056	i
47	Lock Fastener	80001-0622	i
48	Motor Bolt	80006-0052	2
49	Flex Plate	80001-0305	1
50	Rectangular Wheel Bushing	80009-0052	2
51	1" Screw	80006-0032	1
52	Radio Knobs	80045-0025	2

#6 - 20 x 1" Screw for		
Swivel Bracket	80006-0034	1
11/4" Screw for Flex Plate	80006-0022	2
Handlebar Plugs	80047-0026	2
Literature Bag	80034-0772	1
Adhesive Harness Clip	80023-0088	1
Main Decal Sheet	80017-0458	1
Paper Decal Sheet	80017-0457	1
Headlight Decal Sheet	78410-0300	1



First-Time Battery Charging

We recommend that you begin charging your battery before beginning assembly of your vehicle. Your new battery must be charged for at least 18 hours before using your vehicle for the first time.


! WARNING

- The battery must be handled by adults only.
- Never allow children to charge the battery. Battery charging must be done by adults only. A child could be injured by the electricity involved in charging the battery.
- Use of the wrong type battery, fuse or charger could cause a fire or explosion, resulting in serious injury.
- Children can be harmed by small parts, sharp edges and sharp points in the vehicle's unassembled state, or by electrical items. Care should be taken in unpacking and assembly of the vehicle. Children should not handle the battery or other parts, or help in assembly.
- Never permit a child to handle the battery. The battery is heavy and contains sulfuric acid (electrolyte), and if dropped, could result in serious injury. Read the cautions on the back panel of the battery.
- Never lift or carry the battery by the wires or connector. This can damage the battery and possibly cause a fire. Lift and carry the battery by the case only.
- Examine the battery, charger and their connectors for excessive wear or damage each time you charge the battery. If damage or excessive wear is detected, do not use the charger or the vehicle until you have replaced the worn or damaged part.
- Never alter this vehicle or its electrical system in any way. Alterations could cause a fire resulting in injury and could also ruin the electrical system.
- Never add unauthorized parts to the vehicle or use substitute parts. Use only specified Power Wheels® replacement parts.

! CAUTION


- Do not operate the vehicle for the first time until you have inserted a 25 amp fuse into the battery and charged the battery for at least 18 hours. Never charge the battery longer than 30 hours.
- Read and follow the Battery Care instructions on page 26. Failure to follow the Battery Care instructions may permanently damage your battery and may void your warranty.
- Use the charger indoors only.

First-Time Battery Charging




1

• Insert the 25 amp fuse into the battery.



2

 Squeeze the Lock-In[™] connector tabs on the charger connector and plug it into the battery connector.



3

• Plug the charger into a standard 120 volt wall outlet.

Note: If power flow to the wall outlet is controlled by a switch, make sure the switch is "ON".

 Before first time use, charge the battery for at least 18 hours.
 Never charge the battery longer than 30 hours.


Note: The battery must be upright while charging.



Do Not Omit Any Steps. Please set aside at least 30 minutes for assembly.

! WARNING


- Children can be harmed by small parts, sharp edges and sharp points in the vehicle's unassembled state, or by electrical items. Care should be taken in unpacking and assembly of the vehicle. Children should not handle the battery or other parts, or help in assembly.
- Keep small parts and plastic bags out of children's reach. Dispose of plastic bags properly.








- Position a handlebar plug against the top end of a handlebar.
- Moisten a hand grip with warm water.
- Slide the hand grip onto the end of the handlebar.
- Repeat this procedure to attach the other handlebar plug and handgrip to the other handlebar.



2

- Stand the vehicle body on its rear wheels.
- Slide the left handlebar through the holes in the left side of the swivel bracket.

Please Note: The left handlebar is marked "L"; the right handlebar is marked "R".









#8 x ³/₄" Screw – 2 Shown Actual Size

- Align the screw holes in the left side of the swivel bracket with the screw holes in the left handlebar.
- Insert two #8 x 3/4" screws into the left handlebar.
- Tighten each screw with a Phillips screwdriver. Do not over-tighten.
- Repeat steps 2 and 3 to assemble the right handlebar to the vehicle body.





- Apply labels to the dashboard as shown.
- Make sure the areas where the labels will be applied are clean and dry.
- For best adhesion, avoid applying labels more than once.




5

• Snap the key assembly and radio knobs into the dashboard.

Please Note: Gently squeeze the tabs on the radio knobs together before inserting the knobs into the dashboard.


 Insert the microphone cord through a hole in the dashboard, as shown. Make sure the end of the microphone cord forms a "T" behind the dashboard so that it stays secure in the dashboard.






#8 x $1^{1}/2^{"}$ Screw – 2 Shown Actual Size

- Lay the vehicle body on its belly.
- Fit the dashboard onto the top of the swivel bracket.
- Align the screw holes in the dashboard and swivel bracket.
- Insert two #8 x 1¹/₂" screws into the dashboard.
- Tighten each screw with a Phillips screwdriver. Do not over-tighten.




- Insert the four tabs on the underside of the windshield into the holes in the fairing.
- Press firmly on the windshield to fit the tabs into the holes.







- Turn the fairing over.
- Insert two #6 x ³/₈" screws into the holes in the two long windshield tabs.
- Tighten each screw with a Phillips screwdriver. Do not over-tighten.









#8 x $1^{1}/2^{"}$ Screw – 2 Shown Actual Size

- Stand the vehicle body on its rear wheels.
- Fit the fairing onto the front of the swivel bracket.
- Align the screw holes in the front of the fairing with the holes in the swivel bracket.
- Insert two #8 x 1¹/₂" screws into the fairing.
- Tighten the screws with a Phillips screwdriver. Do not over-tighten.




10


- Fit the fender onto the ends of the handlebars.
- Slide the fender up the handlebars to the fairing.



11

- Fit one end of the front axle into a cap nut.
- Tap the front axle with a hammer to secure the cap nut on the front axle.






12


- Remove the rubber bands from the shock sets and dispose of the rubber bands.
- Using safety scissors, cut the four shock set halves from the runner.
 Carefully trim excess plastic and dispose of the runner and all excess plastic.
- Sort the shock halves into inner shock halves and outer shock halves.

Please Note: The inner shock halves have an extension.




13

- Fit and hold an inner shock half to the inside of a handlebar.
- Fit and hold an outer shock half to the outside of the same handlebar.
- Make sure the top ends of the shock halves fit into the fender.




14

• Slide the front axle through the hole in the shock halves and handlebar.




- Fit a wheel bushing into the hole in the center of the front wheel.
- Repeat this procedure to fit the remaining wheel bushing into the hole on the other side of the front wheel.




16

- Fit and hold the hubcaps to each side of the front wheel.
- Make sure the posts on the inside of the hubcaps fit into the indentations on the front wheel, so that the hubcaps lay flat against the wheel.




17

- Position the front wheel between the handlebars.
- Slide the front axle through the front wheel.




- Fit and hold an inner shock half to the inside of the exposed handlebar.
- Fit and hold an outer shock half to the outside of the same handlebar.
- Make sure the top ends of the shock halves fit into the fender.




19

- Slide the front axle through the handlebar.
- Fit the remaining cap nut on the end of the front axle.
- Support the front axle and tap the cap nut with a hammer to secure it on the end of the front axle.




20

- Position the vehicle upright.
- Apply headlight labels to the fairing as shown.
- Make sure the areas where the labels will be applied are clean and dry.
- For best adhesion, avoid applying labels more than once.



- Align the "L" on the left headlight lens with the "L" in the left headlight on the fairing.
- Insert the tabs on the headlight lens into the slots in the fairing.
- Press firmly to snap the headlight lens into the fairing.
- Repeat this procedure to assemble the right headlight lens (marked "R") to the fairing.




22


 Snap the gas cap into the vehicle body.



23

- Insert the tabs on the front of the seat into the vehicle body.
- Lower the seat.





24

Proper label application will help to keep the labels looking their best!

- Wash your hands before applying the labels.
- Make sure the areas where the labels will be applied are clean and dry. Wipe your vehicle with a clean, soft, dry cloth to remove any dust or oils.
- For best results, avoid applying a label more than once.
- Apply the labels as shown in the illustrations.
- After applying a label, rub the label firmly with a dry cloth to make sure the label is adhered to your vehicle.


One-time assembly is now complete.

Important Note: Please carefully read the owner's information in this manual and teach your child about proper vehicle operation and rules for safe driving before allowing him to drive this vehicle.




Battery Installation

Important Note: Use only a Power Wheels® Type H 6 volt battery with a Power Wheels® 25 amp fuse installed. Use of any other battery or fuse will damage your vehicle. Make sure that you charge the battery for at least 18 hours before operating your vehicle for the first time. After first time use, charge the battery for at least 18 hours after each use. Never charge the battery longer than 30 hours. Failure to follow these instructions may damage your battery and will void your warranty.






 Lift the seat to access the battery compartment.



2


- Place the battery upright in the battery compartment. Make sure the battery connector extends towards the rear of the vehicle.
- Make sure a Power Wheels® 25 amp fuse in good condition is installed in the battery.




3

 Insert the ends of the battery retainer into the holes in the battery compartment.

Battery Installation








#8 $x^7/8$ " Screw – 1 Shown Actual Size

- Lower the battery retainer over the top of the battery.
- Insert a #8 x ⁷/₈" screw through the battery retainer and into the battery compartment.






- Squeeze the tabs on each side of the motor harness connector.
- Plug the battery connector into the motor harness connector.

Please Note: If the battery connector will not plug into the motor harness connector, turn it over and try again! Do not force the battery connector into the motor harness connector.


Battery Installation





Lower the seat.

Note: Make sure the tabs on the lock fastener are aligned with the notches in the lock fastener opening.





- Rotate the lock fastener 1/4 turn using a slotted screwdriver to lock the battery compartment.
- To make sure the lock fastener is locked, insert the blade of the screwdriver under the back of the seat and push down on the screwdriver handle. The seat should not lift.


Charging the Battery

WARNING

- The battery must be handled by adults only.
- Never allow children to charge the battery. Battery charging must be done by adults only. A child could be injured by the electricity involved in charging the battery.
- Use of the wrong type battery, fuse or charger could cause a fire or explosion, resulting in serious injury.
- Never permit a child to handle the battery. The battery is heavy and contains sulfuric acid (electrolyte), and if dropped could result in serious injury. Read the cautions on the back panel of the battery.
- Never lift or carry the battery by the wires or connector.
 This can damage the battery and possibly cause a fire.
 Lift and carry the battery by the case only.
- Examine the battery, charger and their connectors for excessive wear or damage each time you charge the battery. If damage or excessive wear is detected, do not use the vehicle until you have replaced the worn or damaged parts.
- Never alter this vehicle or its electrical system in any way.
 Alterations could cause a fire resulting in injury and could also ruin the electrical system.
- Never add unauthorized parts to the vehicle or use substitute parts. Use only specified Power Wheels® replacement parts.





- Read and follow the Battery Care instructions on page 26.
 Failure to follow the Battery Care instructions may permanently damage your battery and will void your warranty.
- Use the charger indoors only.





Charging the Battery

Important Note: The battery must be upright while charging. You do not have to remove the battery from the vehicle to charge it.











- Rotate the lock fastener on the seat back ¹/₄ turn using a slotted screwdriver to unlock the battery compartment.
- Lift the seat to access the battery.
- Use pliers to remove the fuse from the battery.
- Visually examine the fuse to make sure it is not blown. If the fuse has blown, replace it with a new Power Wheels® 25 amp fuse.
- Reinsert the fuse into the battery before charging. The battery will not charge if a 25 amp fuse in good condition is not inserted into the battery.



 Squeeze the tabs on the motor harness connector to unplug it from the battery connector.



- Squeeze the tabs on the charger connector to plug it into the battery connector 1.
- Plug the charger into a standard 120 volt wall outlet 2.

Note: If power to the outlet is controlled by a wall switch, make sure the switch is "ON".

- Charge the battery a minimum of 18 hours. Never charge the battery longer than 30 hours. Overcharging or undercharging the battery may shorten battery life and decrease vehicle running time.
- Once the battery is charged, reconnect the battery connector and motor harness connector and lower the seat.

Note: Remember to lock the lock fastener to prevent children from accessing the batteries.



Battery Handling/Care/Disposal

WARNING

- The battery must be handled by adults only.
- Never permit a child to handle the battery. The battery is heavy and contains sulfuric acid (electrolyte), and if dropped, could result in a serious injury. Read the cautions on the back panel of the battery.
- Never lift or carry the battery by the wires or connector. This can damage the battery and possibly cause a fire. Lift and carry the battery by the case only.

! CAUTION

 Carefully read the Battery Care instructions to obtain the best battery life. Failure to follow the Battery Care instructions may damage your battery and will void your warranty.

Handling

If a battery leak develops:

- Avoid contact with the leaking acid.
- Place the damaged battery in a plastic bag. See information below for proper disposal.

If acid comes in contact with skin or eyes:

- Flush with cool water for at least 15 minutes.
- Call a physician.

If acid is internally ingested:

- Give water, milk of magnesia or egg whites immediately.
- Never give emetics or induce vomiting.
- Call a physician.

Disposal

- The sealed lead-acid battery must be collected, recycled or disposed of in an environmentally sound manner.
- Do not dispose of the lead-acid battery in your regular, household trash. The incineration, landfilling or mixing of a sealed lead-acid battery with household trash is prohibited by law in most areas.
- Return the battery to a federal or state approved lead-acid battery recycler, such as a Power Wheels® Authorized Service Center or a local seller of automotive battery. In Minnesota, call 1-800-348-0751 if further disposal information is required. Contact your local waste management officials for other information regarding the environmentally sound collection, recycling and disposal of lead-acid batteries.

Care

- Charge a new battery for at least 18 hours before first use. Never charge the battery longer than 30 hours. Overcharging or undercharging the battery may shorten battery life and decrease vehicle running time.
- After the first charge, charge the battery for at least 18 hours after each use. Never charge the battery longer than 30 hours.
- Charge the battery after each use, regardless of how long the vehicle was used.
- The battery must be upright while charging.
- Do not allow the battery to run down completely before charging.
- Charge the battery before storing the vehicle.
- Charge the battery at least once per month, even if the vehicle has not been used.
- Leaving the battery in a discharged condition will rule it
- Do not store the battery in temperatures above 75° F or below -10° F.
- Prevent the battery from moving freely inside the battery compartment. Always use the battery retainer to secure the battery in the battery compartment.
- Examine the battery, charger and their connectors for excessive wear or damage each time you charge the battery. If damage is detected, do not use the charger or the battery until you have replaced the worn or damaged part.
- Charging the battery without a fuse or with a blown fuse will not damage the battery, but the battery will not charge. Check the fuse to make sure it is in good condition each time you charge the battery.



Rules for Safe Driving

! WARNING

- Adult supervision is required. Children do not have the judgement necessary to avoid many accidents. Be sure that children operating this vehicle can do so safely and that they are supervised at all times.
- Never use on or dangerously close to steps, inclines greater than 10°, roadways, bodies of water, low obstructions or in the dark.
- Always wear shoes or sneakers when operating this vehicle.
- Never allow more than one rider.
- The rider should sit on the seat when the vehicle is in motion.
- Improper use of this vehicle could lead to a serious or fatal accident. Allow children to play with the **Kawasaki® ZX-7** only when you have determined that they can do so safely. Follow all instructions to help your child enjoy this vehicle as safely as possible.

CAUTION

- To avoid damaging the motor and gears, do not overload the vehicle.
 - Never allow more than one child on the vehicle at one time.
 - Do not exceed the maximum weight capacity of 50 lbs.
 - Do not tow anything behind the Kawasaki® ZX-7. The extra weight may overload the vehicle.
- Avoid operating the vehicle in wet or snowy conditions, and do not spray the vehicle with a hose. Do not wash the vehicle with soap and water. Water or moisture in the motor or electrical switches can cause them to corrode, and could cause switch failure.
- Avoid operating the vehicle on sand, loose dirt or gravel. Sand, loose dirt and gravel in the electrical switches or motor can cause them to jam, and could cause switch failure. Use the **Kawasaki**® **ZX-7** on asphalt, cement or other hard surfaces.

Teach Safety Rules to Children


While children can quickly develop the skill necessary to drive this vehicle, it is important to remember that their judgment skills are still very immature. Unsupervised driving by children can lead to serious injury. Before children use the **Kawasaki® ZX-7**, an adult should carefully evaluate the driving area as well as the children's skill level and ability to drive this vehicle safely. Children are not always able to recognize or anticipate hazards, even when they have been taught about them. There is no acceptable substitute for adult supervision.

Teach appropriate safety rules to your child before you allow her to operate this vehicle. These rules should also be reviewed with neighborhood children or other playmates who want to drive or ride in this vehicle.

- 1. Do not allow any child to drive the vehicle in the street or near moving (motorized) vehicles.
- 2. Do not allow any child to drive near bodies of water (such as pools or creeks), obstructions (such as furniture, low tree limbs or play equipment), or drop-offs (such as stairs or decks).
- 3. Do not allow any child to drive the vehicle in the dark. A child could encounter unexpected obstacles and have an accident. Operate the vehicle only in the daytime or in a well-lit area.
- **4.** Teach your child to avoid driving on steep inclines or slopes. Restrict your child's driving to areas that are fairly level with gentle inclines or slopes of no more than 10°.
 - While driving down a steep slope, the vehicle may gain unsafe speed, even if the foot pedal is released to stop.


Rules for Safe Driving

- While driving across a steep slope, the vehicle may tilt and tip over. The wheels could lose traction causing the vehicle to slip.
- While driving up a steep incline, the motor may stop and the vehicle could roll backwards at an unsafe speed.




- 5. Operate this vehicle with one rider seated on the seating area. A child who is not sitting on the seat or who is standing on the vehicle could fall off or cause a tip-over. A child could be seriously injured.
- **6.** Always wear shoes or sneakers when operating this vehicle.
- 7. Never put anything near any moving parts. Rotating parts such as the motor, gear boxes and wheels can snag fingers, hair, etc., causing serious injury. Do not allow operation of the vehicle when it is on its side or in an upside-down position.

- 8. Do not operate the vehicle near flammable vapors (gasoline, paint thinner, acetone, liquid wax, etc.). The vehicle's electrical switches, like most electrical switches, emit an internal spark when first turned on. The presence of flammable liquids or vapors could cause an explosion or a fire. Keep all flammable products in tightly sealed containers and away from the vehicle.
- **9.** Do not allow a child to operate the vehicle without proper adult supervision. To prevent unsupervised use of the vehicle, disconnect the motor harness from the battery.
 - Rotate the lock fastener 1/4 turn with a slotted screwdriver to unlock the battery compartment.
 - Raise the seat to access the battery.
 - Squeeze the tabs on the motor harness connector to unplug the battery connector from the motor harness connector.
 - Lower the seat and rotate the lock fastener ¹/₄ turn with a slotted screwdriver to lock the battery compartment.



How to Operate your Vehicle





- Press down on the foot pedal to drive.
- Lift your foot from the foot pedal to stop. Your Kawasaki® ZX-7 has a patented, electronic braking system that automatically stops the vehicle when your child's foot if lifted from the pedal.
- Help your child practice steering and stopping so that he knows how far and how quickly to turn the handlebars, and how to stop easily.



Questions and Answers

Q. How often do I need to charge the battery?

A. Charge the battery for a minimum of 18 hours after each use of the vehicle or whenever the vehicle begins to slow down. When the vehicle is not in regular use, charge the battery at least once a month until normal use is resumed.

Q. How much riding time should I get after charging the battery?

A. You should get from one to three hours of riding time per charge. The riding time is affected by:

- the driving surface,
- passenger weight,
- the charge of the battery,
- whether the vehicle is used intermittently or continuously,
- condition of the electrical switches and connectors,
- the temperature.

Q. What is the life expectancy of the battery?

A. Battery life will vary depending on how well you follow the Charging and Battery Care instructions. It's also affected by the total number of hours the battery is used. Average battery life is one to three years.

Q. Does the fuse have to be inserted into the battery when I'm charging?

A. Yes! The battery must have a good fuse installed when charging and during use. If the fuse is missing, blown or if you are using the wrong type of fuse, the battery will not charge.

Q. How can I tell if the fuse is blown?

A. Use pliers to remove the fuse from the battery and compare the fuse to the illustration on page 25.

Q. How can I tell if the charger is working?

A. There is no sure way to tell if your charger is working unless you have a volt meter. If you suspect there is a problem with your charger, contact your local Power Wheels® Authorized Service Center. They can test your charger for you.

Q. How and when should I store my vehicle?

A. During snowy or rainy weather, the vehicle should be stored inside or under a protective cover. Remember to charge the battery at least once per month while your vehicle is not in regular use.

Q. How should I care for my vehicle?

The vehicle can be wiped down with a soft, dry cloth. For a shiny finish, you can wipe plastic parts with a non-wax furniture polish applied to a soft-cloth. Do not use automotive wax. Do not use soap and water or spray the vehicle with a hose.

To ensure that your vehicle stays in good operating order, we recommend that you periodically have your vehicle checked by a Power Wheels® Authorized Service Center. See page 35 for the list of Authorized Service Centers or call 1-800-348-0751 for the location of the Authorized Service Center nearest you.

Q. If I have a problem that I can't solve myself, what should I do?

A. Power Wheels® has over 300 Authorized Service Center locations. They can repair vehicles under warranty, or out of warranty, or sell you the proper parts for you to do the repair work. These service centers have factory-trained personnel, and use only genuine Power Wheels® replacement parts. If there is not an Authorized Service Center in your area, please call Power Wheels® Consumer Affairs toll-free at: 1-800-348-0751.



IMPORTANT! If you experience a problem with your vehicle, first check the Problems and Solutions Guide below. If you still experience a problem, please contact Power Wheels © Consumer Affairs, toll-free at **1-800-348-0751** between 8 AM and 6 PM (EST) Monday through Friday. Or, contact your local Power Wheels® Authorized Service Center. For the location nearest you, please refer to the Authorized Service Center list beginning on page 35.

Problem	Possible Cause	Solution	
Vehicle does not run	Undercharged battery	Charge the battery. A new battery should have been charged for at least 18 hours before using the vehicle for the first time. After first-time use, recharge battery for at least 18 hours after each use. Never charge the battery longer than 30 hours.	
		tightly plugge	Check all connectors. Make sure the battery connector is tightly plugged into the charger connector, and that the charger is plugged into the wall.
		Make sure power flow to the wall outlet is "ON".	
	Wrong type or improperly installed fuse	Make sure that the battery has a properly installed Power Wheels® 25 amp fuse before charging. For best performance, do not use substitute parts.	
	Blown fuses	Make sure that the fuse in the battery is in good condition. Replace a blown fuse with a Power Wheels® 25 amp fuse. For best performance, do not use substitute parts.	
	Loose wire or loose connectors	Check all wires and connectors. Make sure the battery connector is tightly plugged into the motor harness connector.	
	Dead battery	If your battery is old or if you have not followed Battery Care instructions, your battery may be dead. If you are unsure whether or not the battery is dead, you can have it tested at your local Power Wheels® Authorized Service Center.	
	Electrical switch damage	The electrical switches can become corroded due to exposure to water or moisture, or can jam due to loose dirt, sand or gravel. Contact your local Power Wheels® Authorized Service Center for diagnosis and repair.	
	Motor damage	Contact your local Power Wheels® Authorized Service Center for diagnosis and repair.	

Problem	Possible Cause	Solution
Vehicle was running but suddenly stopped	Loose wire or loose connectors	Check all wires and connectors. Make sure the battery connector is tightly plugged into the motor harness connector.
	Wrong type or improperly installed fuse	Make sure that the battery has a properly installed Power Wheels® 25 amp fuse installed before charging. For best performance, do not use substitute parts.
	Blown fuse	Make sure that the fuse in the battery is in good condition. Replace a blown fuse with Power Wheels® 25 amp fuse. For best performance, do not use substitute parts.
	Vehicle is overloaded	Make sure you do not overload the vehicle by allowing more than 1 rider at one time, by exceeding the 50 lbs. maximum weight capacity, or by towing objects behind the vehicle. If the vehicle is overloaded, it will automatically shut down. The vehicle will reset itself after approximately 20 seconds. Reduce the load on the vehicle to prevent additional automatic shut-downs.
	Driving conditions are too stressful	Use only on gentle inclines or slopes of 10° or less. Extreme temperatures can also affect run time. If the driving conditions are too stressful, the vehicle will automatically shut down. The vehicle will reset itself after approximately 20 seconds. Adjust the driving conditions to prevent additional automatic shut-downs.
Short run time (Less than 1 hour in high speed; less than 3 hours in low speed)	Undercharged battery	Charge the battery. A new battery should have been charged for at least 18 hours before using the vehicle for the first time. After first-time use, recharge the battery for at least 18 hours after each use. Never charge the battery longer than 30 hours.
		Check all wires and connectors. Make sure the battery connector is tightly plugged into the charger connector, and that the charger is plugged into the wall.
		Make sure power flow to the wall outlet is "ON".
	Overcharged battery	Do not charge the battery longer than 30 hours.
	Battery is old and will not accept full charge	Even with proper care, rechargeable batteries do not last forever. Average battery life is 1 to 3 years depending on vehicle use and use conditions. Replace the battery with a Power Wheels® Type H 6 volt battery. For best performance, do not use substitute parts.
	Wrong type or improperly installed fuse	Make sure that the battery has a properly installed Power Wheels® 25 amp fuse installed before charging. For best performance, do not use substitute parts.
	Driving conditions are too stressful	Use only on gentle inclines or slopes of 10° or less. Extreme temperatures can also affect run time. If the driving conditions are too stressful, the vehicle will automatically shut down. The vehicle will reset itself after approximately 20 seconds. Adjust the driving conditions to prevent additional automatic shut-downs.

Problem	Possible Cause	Solution
Vehicle runs sluggishly	Undercharged battery	Charge the battery. A new battery should have been charged for at least 18 hours before using the vehicle for the first time. After first-time use, recharge the battery for at least 18 hours after each use. Never charge the battery longer than 30 hours.
		Check all connectors. Make sure the battery connector is tightly plugged into the charger connector, and that the charger is plugged into the wall.
		Make sure power flow to the wall outlet is "ON".
	Battery needs charging	After approximately 3 hours of constant use, the battery needs charging.
	Wrong type or improperly installed fuse	Make sure that the battery has a properly installed Power Wheels® 25 amp fuse installed before charging. For best performance, do not use substitute parts.
	Battery is old and will not accept full charge	Even with proper care, a rechargeable battery will not last forever. Average battery life is 1 to 3 years depending on the vehicle use and use conditions. Replace the battery with a Power Wheels® Type H 6 volt battery. For best performance, do not use substitute parts.
	Vehicle is overloaded	Make sure you do not overload the vehicle by allowing more than 1 rider at one time, exceeding the 50 lbs. maximum weight capacity, or by towing objects behind the vehicle. If the vehicle is overloaded, it will automatically shut down. The vehicle will reset itself after approximately 20 seconds. Reduce the load on the vehicle to prevent additional automatic shut-downs.
	Driving conditions are too stressful	Use only on gentle inclines or slopes of 10° or less. Extreme temperatures can also affect run time. If the driving conditions are too stressful, the vehicle will automatically shut down. The vehicle will reset itself after approximately 20 seconds. Adjust the driving conditions to prevent additional automatic shut-downs.

Problem	Possible Cause	Solution
Sometimes the vehicle doesn't run, but other times it does	Loose wire or connector	Check all wires around the motor and all connectors to make sure they are tight.
	Motor or electrical switch damage	Contact your local Power Wheels® Authorized Service Center for diagnosis and repair.
When the foot pedal is pressed, the vehicle won't run without	Loose wire or connector	Check all wires around the motor and all connectors to make sure they are tight.
a push	"Dead Spot" on motor	Contact your local Power Wheels® Authorized Service Center for diagnosis and repair.
Vehicle constantly blows fuses	Wrong type of fuse used	Make sure a Power Wheels® 25 amp fuse is properly installed in the battery. For best performance, do not use substitute parts.
Loud clacking or grinding noise from a motor-gearbox	Broken gears	Contact your local Power Wheels® Authorized Service Center for diagnosis and repair.
Charger gets warm during use	It is normal for some chargers to get	No action required.
	warm during use and is not reason for concern. Some chargers do not get warm during use.	If your charger does not get warm during use, it does not mean that it is not working properly.
Battery makes a sizzling or	It is normal for some batteries to make noise and swell slightly while charging and is not reason for concern. Some batteries do not make noise or swell while charging.	No action required.
gurgling noise when charging		If your battery does not make noise or swell slightly during charging, it does not mean that it is not accepting the charge.

If, after reviewing the Problems and Solutions Guide, the vehicle still fails to operate, please contact your nearest Authorized Service Center (see page 35) or contact Power Wheels Consumer Affairs toll-free at **1-800-348-0751**. **Helpful Hint:** For faster service when calling Consumer Affairs, completely charge the battery before calling and have the following available by the phone:

vehicle.

- vehicle model number (see sticker in battery compartment),
- vehicle production run number (see sticker in battery compartment),
- Phillips screwdriver, slotted screwdriver and needle-nose pliers with plastic or rubber handles,
- extra Power Wheels® 25 amp fuses are helpful.



Statement of Limited Warranty

90-day limited warranty for the Power Wheels® Ride-On Toy Vehicle

A 6-month battery warranty applying only to those 6-volt battery which was included by Power Wheels®, with the Power Wheels® vehicle when originally purchased.

This limited warranty covers the Power Wheels® ride-on vehicle and the 6-volt battery, purchased from Power Wheels® by the original purchaser, against defects in materials and workmanship.

This warranty covers normal use and does not cover the Power Wheels® vehicle or battery if damaged by unreasonable use, neglect, accident, abuse, misuse, improper service or other causes not arising out of defects in materials or workmanship. Evidence of any attempt at consumer repair will void this warranty. This warranty does not cover, and is intended to exclude, any liability on the part of Power Wheels®, whether

under this warranty or implied by law or any indirect or consequential damages for breach of warranty. Some states do not allow the exclusion or limitation so this limitation may not apply to you.

Should you need service or assistance with your vehicle during the warranty period, DO NOT RETURN THE VEHICLE TO THE STORE. Power Wheels® has provided a nationwide network of Authorized Service Centers. Please refer to the list in this manual. Power Wheels® is continually expanding our Authorized Service Center network. If there is not an Authorized Service Center in your area, please call Consumer Affairs for information, 1-800-348-0751.

This warranty gives you specific legal rights, and you may also have other rights which may vary from state to state.

PLEASE SAVE YOUR ORIGINAL SALE'S RECEIPT.



Authorized Service Centers

We are continually expanding our Authorized Service Center Network. Please check this listing for the Authorized Service Center nearest you. If there is not one in your area, please call Power Wheels® Consumer Affairs at 1-800-348-0751.

ALABAMA

BIRMINGHAM - Frigid Service & Sales 701 Graymont Ave. North, 35203, (205) 323-5831

BIRMINGHAM - Frigid Service & Sales, 1861 Centerpoint Rd., 35215, (205) 853-3952

BIRMINGHAM (HOMEWOOD) - D & R Appliance

Company, 154 West Valley Ave., 35209, (205) 942-3959

CULLMAN - Robert G. Werner Company, 1115 4th Street S.W., 35055, (205) 734-5673

DECATUR - Peddler II, 1000 B Beltline Road, 35603,

(205) 350-1044

DOTHAN - Bill's Appliance Service, 208 Bic Road, Box 1192, 36303, **(334)** 792-7746

DOUGLAS - Brown Hardware, Highway 75, 35964, (205) 593-6086

HUNTSVILLE - C & G Appliance, 307 Jordan Lane, 35805, (205) 837-4551

MOBILE - Foster's Appliance Repair,1660 South Beltline Hwy., 36693, (205) 666-2670

MONTGOMERY - Acme Service Co., 2603 Highland Ave.,

36107, (205) 264-2456, (800) 285-2160 TUSCALOOSA (NORTHPORT) - Frigid Service & Sales, 2813 Lurleen B. Wallace Blvd., 35476, (205) 339-3624

ALASKA

ANCHORAGE - Ken's Electronics Service, 360 E. International, Ste. 8, 99518, (907) 562-3443

ARIZONA

GLENDALE - Elliott Electric Appliance Service, 6242 N. 43rd Avenue, 85301, (602) 937-2613 SCOTTSDALE - Elliott Electric, 7515 E. McDowell Road,

85257. (602) 946-7487

ARKANSAS

FT. SMITH - Bromley Appliance Service, 614 North 10th Street, 72901, (501) 782-9646

JONESBORO - Best Sewing & Vacuum & Repair, 2235 S. Caraway Road, 72401, **(501)** 935-4739, **(800)** 844-4739

LITTLE ROCK - C & W Tool Repair, 1303 W. Markham, 72201, **(501)** 374-1911

ROGERS - Kressel's Vacuum & Repair, 115 North 5th Street, 72756, (501) 636-7894

STUTTGART - Davis Lumber Company, 301 East Michigan, 72160, (501) 673-3601

CALIFORNIA

BAKERSFIELD - Southwest TV, 6300 White Lane, Suite B, 93309, **(805)** 397-4940

CONCORD - California Electric Service Center, 1170-G Burnett Avenue, 94520, **(510)** 827-1011

COVINA - California Electric Service Center, 612 Shoppers Lane, 91723, (818) 915-4935

DUBLIN - California Electric Service Center, 6759 Sierra Court, Suite B, 94568, (510) 551-3390

FONTANA - California Electric Service Center, 9794 Sierra Avenue, 92335, (909) 355-2500

FORT JONES - Ft. Jones Frontier Hardware,11911 Main Street, 96032, (916) 468-2266

FRESNO - Valley Small Appliance, 4005 E. Ashlan Avenue, 93726, **(209)** 224-5530

FULLERTON - California Electric Service Center, 1208 E. Ash Avenue, 92631-5020, (714) 870-0900 LOS ALAMITOS - California Electric Service Center,

11284 Los Alamitos Blvd., 90720, (310) 430-2668 MERCED - Moosehead Electronics, 920 W. 18th Street,

95340, **(209)** 723-4712

MISSION VIEJO - California Electric Service Center, 23725 Via Fabricante, Unit B, 92691, (714) 586-9440

OAKLAND - California Electric Service Center, 1139 E. 12th Street, 94606, (510) 834-1050

OXNARD - Terry's Inc., The Clean-up Store, 1237 Saviers Road, 93033, **(805)** 487-9401, **(800)** 845-3223

PASADENA - California Electric Service Center, 2594 E. Colorado Blvd., 91107, (818) 792-3194 SACRAMENTO - California Electric Service Center,

1821 "Q" Street, 95814, (916) 443-5711 **SAN CARLOS -** California Electric Service Center, 990 Industrial Road, Suite 102, 94070, **(415)** 593-6696,

SAN DIEGO - California Electric Service Center, 3430

El Cajon Blvd., 92104, (619) 283-6488 SAN FRANCISCO - California Electric Service Center, 1090 Bryant Street, 94103, (415) 431-8494

SAN JOSE - California Electric Service Center, 783 The Alameda, 95126, (408) 295-1723

SANTA ANA - California Electric Service Center, 2025 South Main Street, 92707, (714) 641-0529

SANTA ROSA - Hardisty's Inc., 710 Farmers Lane, 95405, (707) 545-0535

STOCKTON - California Electronics, 929 North Yosemite Street, 95203, (209) 466-5432

TEMECULA - California Electric Service Center, 41715 Enterprise Circle North, Suite 101, 92590, (909) 695-5445, VAN NUYS - California Electric Service Center, 14753 Oxnard Blvd., 91411, (818) 997-8855

WEST LOS ANGELES - California Electric Service Center, 2314 S. Westwood Blvd., 90064, (310) 475-2532

YUCAIPA - Aire-Rite Heating & A/C, 34724 Yucaipa Blvd., 92399, (909) 797-2788

Authorized Service Centers

COLORADO

COLORADO SPRINGS - Nelson Appliance Repair, Inc., 1220 E. Fillmore, 80907, (719) 635-1928

DENVER - Appliance Service, 4262 Lowell Blvd., 80211, (303) 458-1109, (800) 631-0941 (CO, WY only)

DENVER (ENGLEWOOD) - Appliance Service, 3932 S. Broadway, 80110, **(303)** 781-1227 **(800)** 553-1864

GRAND JUNCTION - V & L Appliance Service, 809 North Avenue, 81501, **(970)** 243-3360

CONNECTICUT

HARTFORD (BLOOMFIELD) - Philips Consumer Electronics, 1294 Blue Hills Avenue, 06002, **(203)** 726-9612, **(800)** 862-2225

HARTFORD - Hartford Element & Appliance Service, 1500 Albany Avenue, 06112, (860) 246-7424, (800) 787-7977

NEW HAVEN (HAMDEN) - New Haven Appliance Service Center, 1627 Dixwell Avenue, 06514, (203) 288-6229 SHELTON - Jeff's Appliance, Inc., 500A Howe Avenue,

06484, (203) 924-8997

STAMFORD - Appliance Servicenter of Stamford, 15 Cedar Heights Road, 06905, (203) 322-7656

WATERBURY - P.J. Appliance Repair, 935 South Main Street, 06706, **(203)** 757-1014

DELAWARE

DOVER - Del-Mar Appliance of Delaware, 230 South Governors Avenue, 19904, **(302)** 674-2414,**(800)** 858-3424 WILMINGTON - Lyons Hardware, Inc., 2021 Kirkwood Highway, 19805, **(302)** 995-1260

FLORIDA

ATLANTIC BEACH - First Coast Repair, 25 Seminole Road, 32233, (904) 246-4616

GAINESVILLE - Authorized Appliance Service Co., 2614 S.W. 34th Street, 32608, (904) 375-3886

HIALEAH - S-O Service Co., 925 Hialeah Drive, 33010, (305) 887-6275

HOLLY HILL - Ormond Element, 1668 Ridgewood Avenue, 32117, (904) 677-3497

JACKSONVILLE - Authorized Appliance Service Co., 6120-5 Powers Avenue, 32217, (904) 737-5312

LAKE CITY - S&S Mowers Sales & Service, Route 10, Box 9161, Hwy 47 South & MacFarland Ave., 32055, (904) 755-9375

LAKELAND - Electric Shaver & Small Appliance, 4243 S. Florida Avenue, 33813, (813) 644-4690

NORTH FORT MYERS - Family Hardware,13817 N. Cleveland Ave., 33903, **(813)** 995-6161

OCALA, Vacuums, Inc., 3535 S.E. Maricamp Road, #103, 34471, **(904)** 694-2247

ORLANDO - Philips Consumer Electronics, 2452 Sand Lake Road, 32809, (407) 857-8998, (800) 942-6128

ORLANDO - Pine Hills Appliance Svc. Co., 6100-4 W. Colonial Drive, 32808, **(407)** 299-1271

ORLANDO - Southern Electric Co., 510 N. Parramore Avenue, 32801, **(407)** 841-8824, **(800)** 940-8824

PANAMA CITY, Callaway Vacuum & Sewing, 221 N. Tyndall Prkwy., 32404, (904) 763-6333

PENSACOLA - Foster's Appliance Repair, 3836 North Davis Highway, 32503, (904) 432-8853

POMPANO BEACH - Authorized Appliance Service Co., 2171 N. Dixie Highway, 33060, (305) 941-2038

POMPANO BEACH - Philips Consumer Electronics. 2099 W. Atlantic Blvd., 33069, **(305)** 978-0467, **(800)** 635-6488 PORT ST. LUCIE - Hoppe's Authorized Vac & Appliance, 6735 S. Federal Way, 34592, (407) 464-0102

ROCKLEDGE - Neelco Do-It Center, 400 Barton Blvd., 32955, **(407)** 639-1400

SARASOTA - Sunray Small Appliances,8371 N. Tamiami, 34243, **(941)** 358-9999, **(800)** 895-5655

SEBRING - Sebring Do-It Center, 305 U.S. 27 North, 33870, **(813)** 385-2785

SPRING HILL - Crowder Bros Hardware, 5350 Spring Hill Dr., 34606, **(904)** 686-4743

ST. PETERSBURG - Keystone Electric, 4604 Central Avenue, 33711, **(813)** 321-1124

STUART - Appliance Doctors, 3166 S.E. Dixie Highway, 34997, **(407)** 287-6437

SUNRISE - Muller Appliance Service, 2620 N. University Drive, 33322, (305) 749-5460

TALLAHASSEE - Prescott's Ace Hardware, 4831 Kerry Forest Parkway, 32308, **(904)** 668-3389

TAMPA - Authorized Appliance Service Co., Dibbs Plaza, 4119 Gunn Hwy., Unit 8, 33624, (813) 968-6638

VERO BEACH - Hoppe's Authorized Vac & Appliance, 1872 Commerce Avenue, 32960, (407) 562-4466

WEST PALM BEACH - Satisfaction TV Video Service, Inc., 1701-05 Kirk Road, 33406, **(407)** 439-3733

GEORGIA

ATLANTA - Georgia Service Center, 5366 Buford Hwy., 30340, **(770)** 455-1716, **(800)** 455-1715

ATLANTA (MARIETTA) - Philips Consumer Electronics, 200 N. Cobb Parkway, Bldg. #100, Suite 120, 30062, (770) 795-0085

AUGUSTA - A & A Appliance Parts & Service, 1708 Walton Way, 30904, **(706)** 733-5163

BRUNSWICK - Arco Hardware & Supply, 3711 Community Road, 31520, **(912)** 267-0771

COLUMBUS - Burrell's National Appliance Service, 1728 Warm Springs Road, 31904, (706) 327-0523

MACON - Capitol Cycle Company, 1090 Washington Avenue, 31201, (912) 745-3946

SAVANNAH - Hagins Appliance Service, 3 West Victory Drive, 31405, (912) 233-8372

TIFTON - Western Auto, 354 S. Main St., 31794, (912) 382-5767

HAWAII

HONOLULU - McCully Bicycle & Sporting Goods, 932 Hausten Street, 96826, (808) 946-1192

WAILUKU (MAUI) - Tom's Appliance Sales & Service, 891 Eha Street, 96793, **(808)** 244-6278

WAIPAHU - Waipahu Bicycle, 94-320 Depot Street, 96797, (808) 671-4091

IDAHO

BOISE - Boise Appliance, 1503 Main Street, 83702, **(208)** 343-0102

ILLINOIS

CHAMPAIGN - Appliance Parts & Service, 905 Francis, 61821, **(217)** 355-0220

CHICAGO - Chicagoland Bicycle,10126 S. Western Ave., 60643, **(312)** 445-0811

CHICAGO (BERWYN) - Brand Service Center, 6739 West Cermak, 60402, (708) 749-4315

CHICAGO (DOWNER'S GROVE) - Authorized Appliance Service Co., 1644 W. Ogden Avenue, 60515, (708) 852-1550, (800) 829-1798

CHICAGO (MORTON GROVE) - Brand Service Center, Inc., 5618 Dempster Street, 60053, **(708)** 965-5900

JACKSONVILLE- Rexx Battery Specialists, 847 South Main Street, 62650, (217) 245-2713

NASHVILLE - Kesel Hardware, 173 West St. Louis, 62263,

NILES - Household Appliance Sales & Serv., 7411 N. Milwaukee Ave., 60714, **(708)** 647-8250, **(800)** 572-6826, Fax **(708)** 647-2214

PEORIA - Brand Service Center, 6926-I North University Street, Tanglewood Center, 61614, (309) 691-7588

ROCKFORD - Sun Appliance Sales & Service, 3112 N. Rockton Avenue, 61103, (815) 964-3866

SPRINGFIELD - Bannon Electronics, 1224 N. Franklin, 62702, **(217)** 523-0313

WAUKEGAN - Brand Service Center, 2850 Belvidere Road, 60085, (708) 244-5800

INDIANA

EVANSVILLE - Electro Hygiene Co., 1614 South Kentucky, 47714, (812) 425-2671

FT. WAYNE - Don's Harware, 5701 Coventry Lane, in the Village of Coventry, 46804, (219) 436-2278

FT. WAYNE - Sun Appliance Service & Sales, 3523 N. Anthony Blvd., 46805, (219) 482-1702

HAMMOND - Brand Service Center, Inc., 6347 Indianapolis Blvd., 46320, (219) 844-0920

INDIANAPOLIS - Brand Service Center, 1827 N. Meridian Street, 46202, (317) 924-1386

INDIANAPOLIS - Sullivan Hardware Do-It Center, 7021 N. Keystone, 46220, (317) 255-9230

MUNCIE - Joel's Appliance Service, 4405 N. Old State Road 3, 47303, **(317)** 286-2896

NEW ALBANY - Wells Hardware, Inc., 1011 Vincennes Street, 47150, **(812)** 944-4523

SOUTH BEND - Ray's TV and Appliance, 60717 US 31 South, 46614, **(219)** 291-1630

SOUTH BEND (OSCEOLA) - AAA Appliance Service Co., 11868 Lincoln Way West, 46561, (219) 679-4981

TERRE HAUTE - Alex TV & Appliance Sales & Service, 924 South 8th Street, 47802, (812) 232-8786

IOWA

BETTENDORF - K & K True Value Hardware, 1818 Grant Street, 52722, **(319)** 359-4473

CEDAR RAPIDS - Stalker Electric, Inc.,110 3rd Ave. SW, 52404, (319) 364-5646

DES MOINES - Quality Appliance Repair Center, 1417 Walnut Street, 50309, (515) 288-0108

DUBUQUE - Shaver's Plus, 11 Bluff Street, 52001, (319) 556-4442

SIOUX CITY - Millard Television Inc., 1419 Hamilton Blvd., 51103, (712) 258-3435

KANSAS

COLBY - Gavon's Electronics, 1870 South Range, 67701, **(913)** 462-6601

JUNCTION CITY - R/C Hobbies, 115 W. 7th Street, 66441.

KANSAS CITY (OVERLAND PARK) - Mar-Beck Appliance Service Co., 8471 West 95th Street, 66212, (913) 642-1557

WICHITA - Alan Appliance Service, Inc., 1300 E. Central, 67214, **(316)** 262-7228, **(800)** 290-7228

KENTUCKY

GREENVILLE – Malone Lumber Do-It Center, 204 W. Depot Street, 42345, **(502)** 338-3252

LEXINGTON - Factory Electronics, 2422 Palumbo Drive, 40509, **(606)** 269-7341

LEXINGTON (VERSAILLES) - Deaver's Hardware, 221 N. Main St., 40383, (606) 873-7396

LOUISVILLE - Maury's Fluorescent & Appliance Service, 1521 Bardstown Road, 40205, (502) 456-1671

MADISONVILLE - Kuester's Hardware, N. Main St., Martin Mall, 42431, (502) 825-2818

OWENSBORO - Kuester's Hardware, 1210 Carter Road, 42301, **(502)** 685-4916

PADUCAH - Hank Brothers True Value, 3101 Lone Oak Rd., 42003, **(502)** 554-4001

LOUISIANA

BATON ROUGE - Home Appliance Service, Inc., 10781 Florida Blvd., 70815, (504) 272-7727 LAFAYETTE - Cullen's Playland, 4498 Johnston Street, 70503, (318) 981-2929

LAKE CHARLES - Capitol Schwinn Cyclery, 722 E. Prien Lake Road, 70605, (318) 474-9090

NEW ORLEANS (METAIRIE) - Le Jouet, Inc., 1700 Airline Hwy., 70001, **(504)** 837-0533

SHREVEPORT - Shreveport Shaver and Appliance, 9750 St. Vincent, Burt Kouns Ind. Loop, 71106, (318) 865-5088, (800) 349-7722

WEST MONROE - West Monroe Small Appliance Repair, 1300 N. 7th Street, Suite F., 71291, (318) 323-5088

MAINE

BANGOR - Adco Surgical Supply Co., 1292 Hammond St., 04401, **(207)** 942-5273

PORTLAND - Colonial Electronics, Inc., 259 St. John Street, 04102, **(207)** 774-6666

MARYLAND

BALTIMORE (ELLICOTT CITY) - Clark Do-It Center, 10325 Baltimore National Pk., 21042, (410) 313-8100

BALTIMORE (TOWSON) - Duran Service Company, 8741 Mylander Lane, 21286, (410) 321-9033

EASTON - Easton Schwinn Cyclery 723 Goldsboro Street, 21601, (410) 822-7433

GAITHERSBURG - Waters Appliance Service, 216 E. Diamond Avenue, 20877, **(301)** 258-7500, **(800)** 225-5009

SALISBURY - Cycle and Sports Outlet, 2505 N. Salisbury Blvd., 21801, **(410)** 860-0400

TANEYTOWN - MacHenry Services, 68 Frederick Street, 21787, (410) 756-6659, (800) 276-1301

WASHINGTON D.C. (BELTSVILLE) - Philips Consumer Electronics, 10800 Rhode Island Avenue, 20705, **(301)** 595-5330, **(800)** 438-9647

Authorized Service Centers

MASSACHUSETTS

BOSTON (MEDFIELD) - Wills Hardware, 5 Janes Avenue, 02052, **(508)** 359-4381

BOSTON (WALTHAM) - Suburban Appliance Service Center, Inc., 271 Moody Street, 02154, (617) 893-6694

QUINCY - Appliance Service and Parts, Inc., 582 Washington Street, Route 3A, 02169, (617) 773-6656

SALEM - Fix Master, Inc., 190 North Street, 01970, **(508)** 745-0004

SPRINGFIELD - Utility Electric Service, Inc., 810 Main Street, 01101, (413) 781-1635

MICHIGAN

ALMONT - Almont Hardware, 4545 Van Dyke, P.O. Box 511, 48003, **(810)** 798-8922

BAY CITY - Bay Vac & Pedal, 805 Columbus Ave., 48708, (517) 892-7516

DEARBORN - McNichols Electric Service, 1836 Grindley Park, 48124, **(313)** 563-7550

DETROIT - McNichols Electric Service, 13725 W. McNichols, 48235, **(313)** 342-6070, **(800)** 562-4226

DETROIT (ROYAL OAK) - McNichols Electric Service, 4115 West 13 Mile Road, 48072, **(810)** 288-5135

DETROIT (UTICA) - McNichols Electric Service, 49600 Van Dyke, 48317, **(810)** 726-8290

FLINT (DAVISON) - Gill-Roy's Hardware, 8405 East Davison, 48423, **(810)** 653-2288

FLINT (SWARTZ CREEK) - Gill-Roy's Hardware, 9061 Miller Road, 48473, (810) 635-2020

GRAND RAPIDS - Superior Appliance Service Co., 1050 Scribner Avenue, NW, 49504, **(616)** 459-3271

JACKSON - Hammond Hardware, 1800 Francis St., P.O. Box 7, 49204, **(517)** 782-0704

KALAMAZOO - Consumer Repair, 1710 West Main Street, 49007, (616) 344-1200

LANSING - Rapid Appliance Service, Inc., 1454 E. Michigan Avenue, 48912, (517) 485-1320

MIDLAND - Knopic's Do-It Center, 3128 Jefferson Ave., 48640, (517) 832-2774

TRAVERSE CITY - De Weese Hardware Inc., 1029 Carver Street, 49685, (616) 947-7670

MINNESOTA

DULUTH - Mr. Fix it - Metro Appl. Service Center, Inc., 2020 W. Superior St., 55806, **(218)** 722-9063

MINNEAPOLIS (ST. LOUIS PARK) - Barness, 4631 Excelsior Blvd., 55416, (612) 926-0521

ROCHESTER - Robert's Electronics, 611 6th Ave. NW, 55901, **(507)** 282-2140

ST. PAUL - Barness, 1573 University Avenue, 55104, **(612)** 646-3109

MISSISSIPPI

HATTIESBURG - Champion Cycle & Fitness, 104 S. 37th Avenue, 39401, **(601)** 264-8233, **(800)** 273-4158

IUKA - W. H. Fairless Hardware Co., Inc., 117 Fulton Street, 38852, (601) 423-2233, (800) 797-9457

JACKSON (RIDGELAND) - Propeller Service, 291 Hwy. 51, Suite D6, 39157, **(601)** 856-3191

MERIDIAN - Broadmoor Home Center, 2420 Old North Hills Street, P.O. Box 3280, 39305, **(601)** 483-7373

NATCHEZ - Western Auto, 180 Seargent Prentiss Dr., 39120, **(601)** 445-4186

STARKVILLE - East Mississippi Lumber Co., 300 Russell Street, 39759, (601) 323-3554

MISSOURI

INDEPENDENCE - Mar-Beck Appliance Service Co., 4476 South Noland Road, 64055, (816) 478-1889

KANSAS CITY - Mar-Beck Appliance Service Co., 303 W. 79th Street, 64114, **(816)** 523-6931

KANSAS CITY (GLADSTONE) - Mar-Beck Appliance Serv. Co., 6559 N. Oak Traffic Way, 64118, (816) 436-9191

POPLAR BLUFF - Mills Iron & Supply, 1919 S. Westwood Blvd., 63901, (314) 785-2628

SPRINGFIELD - Mar-Beck Appliance Service Co., 2704 S. Glenstone Avenue, 65804, **(417)** 882-3070

ST. LOUIS - Authorized Appliance, Inc., 2355 Hampton Avenue, 63139, **(314)** 647-4250

ST. LOUIS - Brand Service Center, Inc., 1624 S. Broadway, 63104, (314) 231-0751

MONTANA

BILLINGS - Radio Equipment Company, 1120 16th Street West, 59104, **(406)** 256-9778

GREAT FALLS - Arrowhead Electronics, Inc., 2026 2nd Avenue North, 59401, (406) 761-1666

NEBRASKA

GRAND ISLAND - Mundt's Small Appliance & Vacuum Repair, 1822 W. Northfront Street, 68803, (308) 382-5084

LINCOLN - CB Small Appliance, 432 South 11th Street, 68508. (402) 475-2546

LINCOLN - Sperry TV, 1115 North 47th St., 68503, **(402)** 464-9181

LINCOLN - Sperry TV, 2013 Highway 2, 68502,

NORTH PLATTE - Sperry TV, 1855 West A Street, Westfield Shopping Center, 69010, (308) 532-5200 **OMAHA -** Myers Electric Co., 7571 Dodge Street, 68114, **(402)** 393-8388, **(800)** 234-1414

OMAHA - Myers Electric Co., Inc., 1458 South 16th Street, 68108, (**402**) 342-7710

NEVADA

LAS VEGAS - Burney's Commercial Service, Inc., 4480 Aldebaran Avennue, 89103, (702) 736-0006

MINDEN - Valley Home & Sport Center, 1587 Highway 395, 89423, **(702)** 782-5111

NEW HAMPSHIRE

CONCORD (BOW) - Casco Food Equipment Service, 10 Dunklee, 03304, **(603)** 224-2663, **(800)** 660-2058

NEW JERSEY

HAWTHORNE - Ter Kuile, Inc., 206 Diamond Bridge Avenue, 07506, (201) 423-1142

HIGHLAND PARK - Dash Electronics, 10 N. 2nd Street, 08904, **(908)** 247-5124

HOWELL - South Jersey TV Service, Inc., 4232 Rt. 9 South, 07731, **(908)** 363-5550, **(800)** 244-3094

OCEAN - South Jersey TV Service, Inc., 1719 Route 35, 07712, (908) 531-3565

SICKLERVILLE - Sicklerville Hardware, 540 Williamstown Road, 08081, (609) 728-3800 TOMS RIVER - South Jersey TV Service, Inc., Stella Towne Center, 1258 Route 166, 08753, (908) 505-1771

TOTOWA - Philips Consumer Electronics, 140J Commerce Way, 07512, (201) 890-7200, (800) 276-9933

TRENTON - Tattersall, Inc., 309 N. Willow Street, 08618, (609) 393-4293

NEW MEXICO

ALBUQUERQUE - Appliance Service Center, 5505 Silver Avenue, SE, 87108, **(505)** 265-7774

CLOVIS - Burns Hardware, 1511 N. Prince, 88101, (505) 769-2528

NEW YORK

BAYSHORE, L.I. - Turnpike Appliance of Suffolk, Inc., 1253 Sunrise Highway, 11706, (516) 665-8311

BINGHAMTON - Hardware Fare DO-IT Center, 1139 Front Street, Nimmonsburg Square, 13905, (607) 722-9202

BUFFALO - Buffalo Appliance Repair Center, Inc., 20 Pannell Street, 14214, (716) 833-4677

BUFFALO (WILLIAMSVILLE) - Hector's Hardware, 876 Maple Road, 14221, **(716)** 688-4488

COMMACK, L.I. - Turnpike Appliance Service, 6181 Jericho Turnpike, 11725, (516) 499-3355

ELMIRA - Capabilities, Inc., 1149 Sullivan Street, 14901, (607) 734-2006

GREAT NECK - Turnpike Appliance Service Center, 45 Northern Boulevard, 11021, (516) 466-0644

HUDSON - Sweeps Vacuum & Repair Center, Inc. 705 Warren Street, 12534, **(518)** 828-5457

PEEKSKILL - Clark Appliance & Vacuum Service Corp. 950 Main Street, 10566, (914) 737-1368, (800) 765-0649

POUGHKEEPSIE - S & S Appliance Sales & Service, 390 Violet Avenue, 12601, (914) 452-6122

QUEENSBURY - Greene's Service, 681 Upper Glen Street,12804, **(518)** 792-1101

RICHMOND HILL - Lockdoctor Locksmiths, 104-37 Atlantic Ave., 11418 (718) 441-6242 ROCHESTER - Benfante Appliance Service, 1286

Mt. Hope Avenue, 14620, (716) 473-8765

SCHENECTADY - Greene's Service, 1877 State Street, 12304, **(518)** 370-5021

SEA CLIFF, L.I. - Shabra Electronics, 400 Glen Cove Avenue, 11579, **(516)** 671-2218

STATEN ISLAND - Springstead Lumber 6232, 4255 Amboy Road, 10308, (718) 984-0300

SYRACUSE - County Wide Appliance, 1001 N. State Street, 13208, **(315)** 479-5253, **(800)** 333-3243

TUCKAHOE - Authorized Appliance of Westchester, 26 Columbus Ave., 10707, (914) 961-8011

UTICA - Oneida Bicycle & Sports Center, 2107 Whitesboro St., 13502, (315) 724-6084

WARWICK - Wadeson Home Center, 60 Forester Avenue, 10990, (914) 986-2215, (800) 982-2215 (NY only)

W. HEMPSTEAD L.I. - Turnpike Appliance Service, 86 Hempstead Turnpike, 11552, (516) 486-5700, (800) 628-3911

NORTH CAROLINA

ASHEVILLE - Skyland Hardware, 3179 Sweeten Creek Road, 28803, (704) 684-0308

CHARLOTTE - Authorized Appliance Servicenter, 1020 Tuckaseegee Road, 28208, **(704)** 377-4501, (800) 532-6127

CLINTON - Danny's Service Center, 119 Vance Street, 28328, (910) 592-3200

ELIZABETH CITY - Coastal Office Equipment Co., 501 East Church Street, 27909, **(919)** 335-2927

GREENSBORO - Greensboro Shaver & Appliance, 414 North Eugene Street, 27401, **(910)** 273-1065 (800) 200-4855

HICKORY - First Flight Bicycles, 2435 N. Center Street, 28601, (704) 324-9350

RALEIGH - Authorized Appliance Service Center, 800 North Person Street, 27604, (919) 834-3476

STATESVILLE - First Flight Bicycles, 216 S. Center St., 28677, **(704)** 878-9683

WILMINGTON - D.C. Electric Co., 102 Eastwood Road, Ste. D-9, 28403, **(910)** 392-5784, **(800)** 280-5784

WINSTON-SALEM - Authorized Appliance Servicenter, 904 South Marshall Street, 27117, (910) 725-5396

FARGO - General Parts & Supply Co., 10 S. 18th Street, 58103, **(701)** 235-4161, **(800)** 279-9987

OHIO

AKRON - Advanced Appliance Service Company, 73 W. Exchange Street, 44308, **(216)** 762-8968

CANTON - Appliance Parts Co., 1267 Dueber Avenue, SW, 44706, **(216)** 453-8077

CINCINNATI - H&S Service, 458 Cincinnati Batavia Pike, 45244, **(513)** 528-0808 **(800)** 344-4210

CINCINNATI (CHEVIOT) - Brand Service Center, 3806 North Bend Road, 45211, (513) 661-1615

CINCINNATI (SILVERTON) - Brand Service Center, Inc., 6944 Plainfield Road, 45236, (513) 793-1170

CLEVELAND - Majors Appliance, 5845 Turney Road, 44125, **(216)** 663-4650

CLEVELAND (MENTOR) - Lake Erie Lawn & Garden, 7833 Munson Rd., 44060, **(216)** 257-9000 **CLEVELAND (PARMA)** - Majors Appliance, 5785 Ridge Road, 44129, **(216)** 884-7200

CLEVELAND (WESTLAKE) - Philips Consumer Electronics, 24090 Detroit Avenue, 44145, **(216)** 899-2040, **(800)** 331-7037

COLUMBUS - Philips Consumer Electronics, 6333 Busch Blvd., 43229, (614) 781-2605

DAYTON - Layer Electric, 603 South Ludlow Street, 45402, **(513)** 224-9608

DAYTON (NEW CARLISLE) - Hess Hardware Do-It Center, 3300 South Dayton Lakeview Rd., 45344,

(513) 849-1306, (800) 786-1308 **LIMA -** Crouse Lumber Do-It Center, 333 E. Market Street, 45801, **(419)** 229-9070, **(800)** 826-9663

NEW BOSTON - True Value Toy Town, Rt. 52 & 139, 45662, (614) 456-5704

STRYKER - Short's Hardware, 115 N. Depot Street, 43557, (419) 682-4231

TOLEDO - Broadway Sales and Appliance Repair, 1621 Broadway, 43609, **(419)** 241-9731, **(800)** 436-5415

YOUNGSTOWN - O'Connor's, 3224 Market Street, 44507,



Authorized Service Centers

OKLAHOMA

OKLAHOMA CITY - Brand Service Center, 538 N. Pennsylvania Avenue, 73107, (405) 235-0583 TULSA - H.L. Moss, Inc., 1714 E. 15th Street, 74104, (918) 744-1305, (800) 248-5948

OREGON

PORTLAND - Oregon Appliance 2137 East Burnside Street, 97214, **(503)** 235-6681,

PENNSYLVANIA

ALTOONA - Frye's Sweeper & Sewing Center, Inc., 1400 Valley View Boulevard, 16602, **(814)** 943-5001, (800) 640-1308

HARRISBURG - C.A. Juillard, Inc., 2301 North Seventh Street, 17110, **(717)** 233-3488, **(800)** 633-3488

JOHNSTOWN - Cambria True Value Hardware, West Hills Square, Goucher Street, 15905, (814) 255-4752

KINGSTON - Vac-Way Appliance & Service, 595 Market Street, 18704, (717) 288-4508

MOSCOW - Vac-Way Appliance & Service,RR #6 Box 6237, 18444, (717) 842-4668

MOSCOW - Vac-Way Appliance & Service,RR #6 Box 6237, 18444, (717) 842-4668

ORANGEVILLE - Hess Do-It Center & Market, Route 487, Box 4 M, 17859, (717) 683-5162

PHILADELPHIA - Appliance Care/Service Corp., 6407 Rising Sun Ave., 19111, (215) 725-3112

PHILADELPHIA (COLLINGDALE) - J.F. Kenney Electric, 920 MacDade Boulevard, 19023, (610) 534-7373

PITTSBURGH - Ferry Electric Service Co., 7498 McKnight Road, 15237, (412) 364-3403

PITTSBURGH - Ferry Electric Service Co., 140 Clairton Blvd., 15236, (412) 653-6004

READING - Electric Repair Co., 502-504 North 9th Street, 19604, **(610)** 376-5444, **(800)** 422-8171 (PA only)

SCRANTON - Vac-Way Appliance and Service, 601 Cedar Avenue, 18505, (717) 343-1121

SHAMOKIN DAM - Willard Battery Outlet, 138 S. Old Trail, 17876, **(717)** 743-5383

TROY - Hoover hardware, 9 Canton, 16947, (800) 251-2156, (717) 297-3445

WASHINGTON - Murphy Family Inc., 585 East National Pike, 15301, **(412)** 225-0324

WILKES-BARRE - Walter Hardware DO-IT Center, 57 N. Welles Street, 18702, (717) 823-1406

YORK - Parcel Plus, 2549 E. Market Street, York Market Place, 17402, (717) 757-1875

PUERTO RICO

HATILLO - Tropical Parts Service, P.O. Box 1335, Road 130 KM 8.5, 00659, **(809)** 898-6474

MAYAGUEZ - Cardona Appliance Service, 8 San Vicente St., 00680, (809) 832-8366

MAYAGUEZ - Melendez Home Appliance Repair, Calle Post 319 Sur, 00680, (809) 832-5225

PONCE - Ferreteria Vivian, Centro Comercial, Los Caobos #7, 00731, (809) 840-0677

PUERTO NUEVO - Buckeye Service, 1013 Jesus T. Pinero Avenue, 00920, **(809)** 782-6175

RHODE ISLAND

PROVIDENCE - Marshall Electric Co., 200 Broad Street, 02903, (401) 331-4482

SOUTH CAROLINA

CHARLESTON HEIGHTS - Dorchester Electric Service, 3575 Dorchester Avenue, 29405, (803) 747-5221

COLUMBIA - Authorized Appliance Servicenter, 1811 Taylor Street, 29202, **(803)** 254-8414

FLORENCE - The Hobby Center of Florence, 919-C South Cashua, 29501, (803) 664-9226

GREENWOOD - Bikes & Boards & Mopeds, 203A Montague Avenue, 29646, (803) 229-2453

SPARTANBURG - Boiling Springs Hardware, 3124 Boiling Springs Rd, 29303, **(803)** 578-1852

VARNVILLE - P&S Small Engine & Variety Shop. 105 Carolina Avenue, West, 29944, (803) 943-9141

TENNESSEE

CHATTANOOGA - Light Electric Co., 732 East 11th Street, 37403, (615) 267-9224

KNOXVILLE - Authorized Appliance Service Center, 1206 North Central Street, 37917, **(615)** 524-3376

KNOXVILLE - Philips Consumer Electronics, 6700 D Papermill Road, Papermill Plaza, 37919, **(615)** 584-6614, **(800)** 821-1767

MEMPHIS - Camp Electric Co., 647 Madison Avenue, 38103, **(901)** 527-7543, **(800)** 238-7345

NASHVILLE - Webb's Appliance Service Center, Inc., 1519 Church Street, 37203, (615) 329-4079, (800) 899-4079

TEXAS

ABILENE - Metro Small Appliance Service Co., 141 S. Clyde, 79605, **(915)** 672-1853

AMARILLO - Reid's Appliance Service, Inc., 906 Georgia, 79102, **(806)** 373-8812

ANTHONY - Villarreal & Sons Elec., 512 S. Third Street, 79821, **(915)** 886-3362

AUSTIN - Harrell Supply and Service, Inc., 5435 Burnet Road, 78756, **(512)** 451-6464, **(800)** 332-7250 (TX only)

AUSTIN - Harrell Supply and Service, Inc., 1409 West Oltorf, 78704, **(512)** 442-5966

AUSTIN (ROUND ROCK) - Harrell Supply, 907c Interstate Highway 35, 78664, (512) 388-0866

CORPUS CHRISTI - Brand Service Center, 2751 S. Staples Street, 78404, **(512)** 854-1851

DALLAS - Pearsol Appliance Co., 3127 Main Street, 75226, **(214)** 939-0930

DALLAS - All Type Sales and Service Co., Inc 2835 Irving Blvd., 75207, (214) 638-1170, (800) 717-1170

DALLAS (GARLAND)- Pearsol Appliance Co., 2406 South Jupiter Road, 75041, **(214)** 840-0622, **(800)** 527-7385

FT. WORTH - Ft. Worth Shaver and Appliance Center. 1012 West 7th Street, 76102, (817) 335-9970

HOUSTON - Brand Service Center, 5727 Richmond Avenue, 77057, (713) 782-8910, (800) 705-2929 **HOUSTON -** Brand Service Center, 1970 FM 1960, 77090, **(713)** 537-7795

LAREDO - Rubio Electric, 1719 San Bernardo, 78040, (210) 722-3908

LONGVIEW - Toys and Things, 918 NW Loop 281, 75604, **(903)** 759-3939

LUBBOCK - Minter's, 4409 50th Street, 79414, (806) 799-3170

LUFKIN - STS Audio and Video, 1505 South First Street, 75901, **(409) 6**39-4529

MC ALLEN - All-In-One Repair Shop, 2313 Lark Avenue, 78504, **(210)** 682-8858 MIDLAND - Midland Tool Specialty, 918 South Main, 79701,

(915) 682-4647, **(800)** 499-0755

PASADENA - Larry's TV Service, 3520 Fairmont Parkway, 77504, **(713)** 998-0122, **(800)** 244-0281

ROMA - True Value Hardware, 1004 E. Highway 83, (210) 849-1322

SAN ANTONIO - Brand Service Center, 7065 San Pedro Avenue, 78216, (210) 344-8577

SEYMOUR - Western Auto, 211 N. Main Street, 76308, (817) 888-3980

TEMPLE - Master Tech Repairs, 2819 West Avenue North, 76504, **(817)** 773-8991

WICHITA FALLS - Burke's Appliance Service, 2410 10th Street, 76309, (817) 723-6211

OREM - The Mending Shed, 1735 South State Street, 84058, **(801)** 225-8012, **(800)** 339-9297

SALT LAKE CITY - Appliance Service Center, Inc., 210 East 6th South, 84111, (801) 328-9703

VERMONT

RUTLAND - Appliance Service Center Ltd., 152 Woodstock Avenue, 05701, **(802)** 773-8917

VIRGINIA

HARRISONBURG (PENN LAIRD) - J.L. Maintenance & Repair, Inc., Route 1, Box 183, 22846, (703) 289-9844,

NEWPORT NEWS - Commonwealth Electric Shaver Sales & Service, Inc., 10105 Jefferson Ave., 23605, **(804)** 595-6712

NORFOLK - Commonwealth Electric Shaver Sales & Service, Inc., 6612 E. Virginia Beach Blvd., 23502, **(804)** 461-4475

ROANOKE - Commonwealth Shaver & Appliance Service, 5524 Williamson Road, NW, 24012, (703) 366-6038

VIENNA - Appliance Fix-It, 8455 Tyco Road, 22182,

WINCHESTER - Battery Mart of Winchester, Inc., 1 Battery Dr., 22601, (703) 655-0065

WOODBRIDGE - Baker's Appliance, 13314 Occoquan Road, 22191, (703) 690-3214

WASHINGTON

SEATTLE - Ajax Electric, 2911 First Avenue South, 98134, **(206)** 622-9945

SEATTLE (BELLEVUE) - Action Small Appliance Service, 1500 145th Place, SE, 98007, (206) 643-9806

SPOKANE - SPARCO, West 45 2nd Avenue, 99204, (509) 624-8965

SPOKANE - SPARCO, N. 1119 Pines Rd., 99206, **(509)** 922-9666

WEST VIRGINIA

BECKLEY - Jerry's Detectors, Vacuum & Appl. Svc., 411 Second Street. 25801, **(304)** 253-3521

CHARLESTON - Sneed's Vacuum & Sewing Center, 2614 7th Avenue, 25312, (304) 744-3670, (800) 245-8048 (WV only)

HARRISVILLE - Western Auto, 1107 E. Main St., 26362, (304) 643-2226

HUNTINGTON - Mike's Appliance and Service, 212 20th Street, 25703, (304) 522-0737, (800) 244-9152

MARTINSBURG - Battery Mart, 1161-3 Winchester Avenue, 25401, (304) 267-7033, (800) 464-7918 WHEELING - Fast Service Center, 1058 Main Street, 26003, (304) 232-5561 (800) 874-4090

WISCONSIN

APPLETON - G/Tech Electric Tool & Housewares Service, 600 W. College Ave., 54911, **(414)** 739-6064, (800) 400-6064

LACROSSE - Paul's Shaver Service, 1224 Caledonia Street, 54603, (608) 782-6291

MADISON (MONONA) - Kiefer's Shaver and Appliance, 4511 Monona Drive, 53716, **(608)** 221-3322

MAUMETTE - Della Do-It Center, W 1536 Highway 41, 54143, **(715)** 732-1768

MILWAUKEE - Brand Service Center, 3707 North 92nd Street, 53222, (414) 461-0440

MILWAUKEE - Brand Service Center, 6000 W. Oklahoma Street, 53219, (414) 541-4340