


**Friedrich®**

**2001**

**HAZARDGARD®**

**ROOM AIR CONDITIONER**



**Models**

**SH14J30A-1**

**SH14J30A-A**

**SH20J30A-1**

**SH20J30A-A**

**Service & Parts**

**Manual**

**AMERICA'S BEST AIR CONDITIONER**

# TABLE OF CONTENTS

	PAGE
Specifications .....	4
Performance Data .....	6
Component Operation & Testing .....	4
Compressors .....	4
Thermal Overload .....	4
Checking Compressor Efficiency .....	5
Fan Motor .....	5
System Control Switch .....	5
Run Capacitor .....	6
Thermostat .....	6
Triac/Control Assembly .....	7
Low Ambient By-Pass Valve .....	8
Sealed Refrigeration System Repairs .....	8
Hermetic Component Replacement .....	9
Special Procedure in the case of Compressor Motor Burn-Out .....	9
Rotary Compressor Special Troubleshooting & Service .....	10
Refrigerant Charge .....	10
<b>TROUBLESHOOTING</b>	
Troubleshooting SH14J30A .....	11
Troubleshooting SH20J30A .....	16
<b>WIRING DIAGRAM</b>	
SH14J30A / SH20J30A .....	14
<b>PARTS LIST</b>	
SH14J30A / SH20J30A Model Chassis Parts List .....	18
SH20J30A / SH20J30A Model Cabinet Parts List .....	19

<b>SPECIFICATIONS</b>	<b>SH14J30A-1 SH14J30A</b>	<b>SH20J30A-1 SH20J30A</b>
BTUH	14000/14000	19000/18800
E.E.R. - Btu/watt	8.0/8.0	8.5/8.5
Volts	230/208	230/208
Hertz/Phase	60/1	60/1
Amperes	7.8/8.5	9.9/10.8
Total Watts	1750/1750	2235/2210
Fuse/Breaker Size	15	20
Fan RPM	1095	1095
Evaporator Air CFM	375	425
Dehumidification-Pts./hr.	4.0	5.7
Width	25-15/16"	25-15/16"
Height	15-15/16"	17-15/16"
Depth	27-3/8"	27-3/8"
Min. Ext. into Room	5-7/8"	5-7/8"
Min. Ext to Outside	16-15/16"	16-15/16"
Net Weight	129 Lbs.	177 Lbs.
Shipping Weight	147 Lbs.	199 Lbs.

Maximum Temperature Rating  
for Class 1, Division 2, Group D

120° C (248° F) Ignition Temperature Rating

PERFORMANCE DATA *	EVAPORATOR AIR TEMP° F		OPERATING PRESSURES		ELECTRICAL RATINGS		R-22 REFRIG.	COMP. OIL
	DISCHARGE AIR	TEMP DROP °F	SUCTION	DISCHARGE	AMPS	LOCKED ROTOR AMPS	CHARGE IN OUNCES	CHARGE IN FLUID OZ.
SH14J30A-1 SH14J30A-A	56.78	23.22	79	296	7.8 8.5	43	28	32
SH20J30A-1 SH20J30A-A	52.83	27.16	79.5	282	9.8 10.4	52	39	32

\* Rating Conditions: 80° F. Room Air Temperature and 59% Relative Humidity with 95° F. Outside Air Temperature at 40% Relative Humidity.

## COMPONENT OPERATION AND TESTING

### WARNING

**DISCONNECT ELECTRICAL POWER TO THE UNIT BEFORE SERVICING OR TESTING**

## COMPRESSORS

Compressors are single phase, 208/230 volt. All compressor motors are permanent split capacitor type, using only a running capacitor across the start and run terminal.


All compressors are internally spring mounted and externally mounted on rubber isolators.

### Line Voltage Overload


The compressor is equipped with an internal line voltage overload. This overload is embedded in the windings of the motor to sense the motor temperature. The overload will open and disconnect the power to the motor due to high temperatures caused by:

1. A locked rotor.
2. Excessive running amps.
3. High discharge temperature.
4. Low refrigerant charge.

**FIGURE 1 COMPRESSOR WINDING TEST**



**FIGURE 2 TYPICAL GROUND TEST**



## COMPRESSOR WINDING TEST

(See Figure 1.)

Remove the compressor terminal box cover and disconnect the wires from the terminals. Using an ohmmeter, check continuity across the following:


### Testing Procedures

1. Terminal "C" and "S" - no continuity - open winding - replace compressor.
2. Terminal "C" and "R" - no continuity - open winding - replace compressor.
3. Terminal "R" and "S" - no continuity - open winding - replace compressor.
4. Terminal "C" and the shell of the compressor - continuity - grounded motor - replace compressor.
5. Should continuity exist between terminals "R" and "S", but not between terminals "C" and "S" and "C" and "R", the internal overload may be open. If the compressor is extremely hot, allow it sufficient time to cool. It may require as long as one hour for the compressor to cool sufficiently for the internal overload to close.


## GROUND TEST

Use an ohmmeter set on its highest scale. Touch one lead to the compressor body (clean point of contact, as a good connection is a must) and the other probe in turn to each compressor terminal. (See Figure 2.) If a reading is obtained, the compressor is grounded and must be replaced.

**FIGURE 2 TYPICAL GROUND TEST**



**FIGURE 2 INTERNAL OVERLOAD**



## FAN MOTOR

A 230 volt single phase permanent split capacitor motor is used to drive the evaporator blower and condenser fan. A running capacitor is wired across the start and run terminals of the motor.

The motor is totally enclosed and is protected with a line voltage overload located internally of the motor. The motor shaft is stainless steel to resist corrosion.

## CHECKING COMPRESSOR EFFICIENCY

The reason for compressor inefficiency is normally due to broken or damaged suction and/or discharge valves, reducing the ability of the compressor to pump refrigerant gas.

## FAN MOTOR – TEST

Disconnect power to the unit.

1. Determine that the capacitor is serviceable.
2. Disconnect the black lead from the circuit board.
3. Apply "live" test cord leads to the common terminal of the capacitor and the black lead. The motor should run at high speed.

### This condition can be checked as follows:


1. Install a piercing valve on the suction and discharge or liquid process tube.
2. Attach gages to the high and low sides of the system.
3. Start the system and run a "cooling or heating performance test."

### If test shows:

- A. Below normal high side pressure.
- B. Above normal low side pressure.
- C. Low temperature difference across the coil.

**The compressor valves are faulty - replace the compressor.**


**FIGURE 5 SWITCH, ON-OFF**



## SYSTEM CONTROL SWITCH

(Figure 5)


This switch is double pole, single throw. Check for continuity between terminals 2 and 3, and 5 and 6.



**CAPACITOR, RUN**

A run capacitor is wired across the auxiliary and main winding of a single phase permanent split capacitor motor such as the compressor and fan motors. A single capacitor can be used for each motor or a dual rated capacitor can be used for both.

The capacitor's primary function is to reduce the line current while greatly improving the torque characteristics of a motor. The capacitor also reduces the line current to the motor by improving the power factor of the load. The line side of the capacitor is marked with a red dot and is wired to the line side of the circuit. (See Figure 6.)




**CAPACITOR – TEST**

1. Remove the capacitor from the unit.
2. Check for visual damage such as bulges, cracks, or leaks.
3. For dual rated capacitors, apply an ohmmeter lead to the common (C) terminal and the other probe to the compressor (HERM) terminal. A satisfactory capacitor will cause a deflection on the pointer, then gradually move back to infinity.
4. Reverse the leads of the probe and momentarily touch the capacitor terminals. The deflection of the pointer should be two times that of the first check if the capacitor is good.
5. Repeat steps 3 and 4 to check the fan motor capacitor.

*NOTE: A shorted capacitor will indicate a low resistance and the pointer will move more to the "0" end of the scale and remain there as long as the probes are connected. An open capacitor will show no movement of the pointer when placed across the terminals of the capacitor.*

**THERMOSTAT**

A cross ambient thermostat is used to maintain the desired comfort level. The thermostat reacts only to a change in temperature at the bulb location. Important to the successful operation of the unit is the position of the sensing bulb in relation to the evaporator. See Figure 7.



**FIGURE 7 SENSING BULB LOCATION**


**RANGE:**  
**Thermostat**  
 (Part No. 618-225-02)  
**60° F ( ± 2° ) to 90° F ( ± 4° )**

## TEST

Remove the wires from the thermostat. Turn the thermostat to its coldest position. Check to see if there is continuity between the two terminals. Turn the thermostat to its warmest position. Check continuity to see if the thermostat contacts open.

Note: The temperature must be within the range listed to check the thermostat. Refer to the troubleshooting section in this manual for additional information on thermostat testing.


## CONTROL ASSEMBLY — PRINTED CIRCUIT BOARD



ITEM NO.	DESCRIPTION	NO. REQ
1	SEE TRIAC MANUFACTURER'S TABLE	1
2	.1 MFD. CAPACITOR .630 V DC MIN.	2
3	100 OHMS RESISTOR 1/2 WATT	2
4	470 OHMS RESISTOR 5 WATT	2
5	.0265 A FUSE (1/16 AMP) (UL LISTED)	2
6	MALE 1/4" QUICK CONNECT	10
7	TECCOR HT-32, -35, GT-32, -35 OR HUTSON D-30 DIAC	2
8	SIEMENS S20K275 OR G.E. V275LA40A VARISTORS	2

## TRIAC


With the system switch in the "On" position and the thermostat closed, current flows through the control components of the printed circuit board to the TRIAC causing it to switch on, starting the compressor. If the compressor fails to start and the compressor has been tested by the direct start method, and the thermostat tests satisfactorily, **replace both the TRIAC and the printed circuit control.** The TRIAC is located on the evaporator header inside the control panel.



## LOW AMBIENT BY-PASS VALVE

The HazardGard unit is designed to operate at low outside ambient temperatures. This is accomplished by the use of a by-pass valve installed in the refrigeration circuit. The valve is connected between the discharge line at the compressor and the suction process tube. The valve responds to suction pressure which, when reduced in the system, causes the valve to open and by-pass hot gas from the high pressure side to the low pressure side of the system. The hot gas entering the compressor mixes with the cool gas returned through the suction line, thus increasing the suction pressure. The valve is preset to open when the suction pressure reaches 50 psig. This pressure setting cannot be altered. The system can be operated at outdoor temperatures as low as 45° F before the evaporator coil will begin to accumulate frost.

To determine if the valve operates, block the return air to the evaporator coil. Turn on the unit and touch the tube at the by-pass valve outlet which connects to the suction process tube. When the low side pressure reaches approximately 50 psig, the valve will begin to open and the tube will get hot. This method will determine if the valve is responding to the suction pressure change.



## SEALED REFRIGERATION SYSTEM REPAIRS EQUIPMENT REQUIRED

1. Voltmeter
2. Ammeter
3. Ohmmeter
4. E.P.A Approved Refrigerant Recovery System
5. Vacuum Pump (capable of 200 microns or less vacuum).
6. Acetylene Welder
7. Electronic Halogen Leak Detector G.E. Type H-6 or equivalent).
8. Accurate refrigerant charge measuring device such as:
  - a. Balance Scales - 1/2 oz. accuracy
  - b. Charging Board - 1/2 oz. accuracy
9. High Pressure Gauge - (0-400 lbs.)
10. Low Pressure Gauge - (30" - 150 lbs.)
11. Vacuum Gauge - (0-1000 microns)

### EQUIPMENT MUST BE CAPABLE OF:

1. Recovering CFC's as low as 5%.
2. Evacuation from both the high side and low side of the system simultaneously.
3. Introducing refrigerant charge into the high side of the system.
4. Accurately weighing the refrigerant charge actually introduced into the system.
5. Facilities for flowing nitrogen through the refrigeration tubing during all brazing processes.



## HERMETIC COMPONENT REPLACEMENT

The following procedure applies when replacing components in the sealed refrigeration circuit or repairing refrigerant leaks. (Compressor, condenser, evaporator, capillary tube, refrigerant leaks, etc.)

1. Recover the refrigerant from the system at the process tube located on the high side of the system by installing a line tap on the process tube. Apply the gauge from the process tube to EPA approved gauges from the process tube to the EPA approved recovery system. Recover the CFC's in the system to at least 5%.
2. Cut the process tube below the pinch off in the suction side of the compressor.
3. Connect the line from the nitrogen tank to the suction process tube.
4. Drift dry nitrogen through the system and unsolder the more distant connection first. (Filter drier, high side process tube, etc.)
5. Replace the inoperative component, and always install a new filter drier. Drift dry nitrogen through the system when making these connections.
6. Pressurize the system to 30 PSIG with proper refrigerant and boost the refrigerant pressure to 150 PSIG with dry nitrogen.
7. Leak test the complete system with the electric halogen leak detector, correcting any leaks found.
8. Reduce the system to zero gauge pressure.
9. Connect the vacuum pump to the high side and low side of the system with deep vacuum hoses, or copper tubing. (Do not use regular hoses.)

10. Evacuate the system to an absolute holding pressure of 200 microns or less.

**NOTE:** This procedure can be speeded up by the use of heat lamps, or by breaking the vacuum with refrigerant or dry nitrogen at 5,000 microns. Pressure system to 5 PSIG and leave in the system a minimum of 10 minutes. Recover refrigerant, and proceed with evacuation to a pressure of 200 microns or a minimum of 10%.

11. Break the vacuum by charging the system from the high side with the correct amount of refrigerant specified. This will prevent boiling the oil out of the crankcase.

**NOTE:** If the entire charge will not enter the high side, allow the remainder to enter the low side in small increments while operating the unit.

12. Restart the unit several times after allowing pressures to stabilize. Pinch off the process tubes, cut and solder the ends. Remove the pinch off tool, and leak check the process tube ends.

## SPECIAL PROCEDURES IN THE CASE OF COMPRESSOR MOTOR BURN-OUT

1. Recover all refrigerant and oil from the system.
2. Remove the compressor, capillary tube and filter drier from the system.
3. Flush the evaporator, condenser and all connecting tubing with dry nitrogen, or equivalent, to remove all contamination from the system. Inspect the suction and discharge lines for carbon deposits. Remove and clean if necessary.
4. Reassemble the system, including a new drier-strainer and capillary tube.
5. Proceed with processing as outlined under hermetic component replacement.

## ROTARY COMPRESSOR SPECIAL TROUBLESHOOTING AND SERVICE

Basically, troubleshooting and servicing rotary compressors is the same as on the reciprocating compressor with only a few exceptions.

1. Because of the spinning motion of the rotary, the mounts are critical. If vibration is present, check the mounts carefully.
2. The electrical terminals on the rotary are in a different order than the reciprocating compressors. The terminal markings are on the cover gasket. Use your wiring diagram to insure the correct connections.

## REFRIGERANT CHARGE

1. The refrigerant charge is extremely critical. Measure the charge carefully and as exactly as possible to the nameplate charge.
2. The correct method for charging the rotary is to introduce liquid refrigerant into the high side of the system with the unit off. Then start the compressor and enter the balance of the charge, gas only, into the low side.

The introduction of liquid into the low side, without the use of a capillary tube, will cause damage to the discharge valve of the rotary compressor.

### NOTE:

All inoperative compressors returned to Friedrich must have all lines properly plugged with the plugs from the replacement compressor.

## TROUBLESHOOTING

PROBLEM	POSSIBLE CAUSE	TO CORRECT
<b>Unit does not run.</b>	Power disconnected.	Check power source.
	System switch in "Off" position.	Set switch correctly.
	Branch circuit fuse blown or circuit breaker tripped.	Replace fuse, reset breaker. If repeats, check fuse or breaker size. Check for shorts in unit wiring and components.
	Inoperative system switch.	Test for continuity.
	Loose or disconnected wiring at switch.	Check wiring and connections. Connect per wiring diagram.
	Inoperative switch (On-Off).	Test for continuity, 3 and 2, 5 and 6.

PROBLEM	POSSIBLE CAUSE	TO CORRECT
<b>Evaporator coil freezes up.</b>	Dirty Filter.	Clean as recommended in Owner's Manual.
	Restricted air flow.	Check for dirty or obstructed coil - clean as required.
	Inoperative thermostat.	Test for shorted thermostat or stuck contacts.
	Short of refrigerant.	De-ice coil and check for leak.
	Partially restricted capillary.	De-ice coil. Check temperature differential across coil. Touch test coil return bends for same temperature. Test for low running current.
	Inoperative fan motor.	Test and replace if inoperative.
	Heat sink triac shorted.	If thermostat is functioning properly and compressor cycles, replace both heat sink and printed circuit board.

PROBLEM	POSSIBLE CAUSE	TO CORRECT
<b>Compressor runs continually. Does not cycle off.</b>	Excessive heat load.	Test cooling performance of unit. Unit undersized.
	Restriction in line.	Check for partially iced coil. Check temperature split across coil.
	Refrigerant leak.	Check for presence of oil on silver soldered connections. Check for partially iced coil. Check split across coil. Check for low running amperage.
	Thermostat contacts stuck.	Check operation of thermostat. Replace if contacts remain closed.
	Heat sink triac shorted.	Replace both heat sink assembly and printed circuit control.

PROBLEM	POSSIBLE CAUSE	TO CORRECT
<b>Thermostat does not turn unit on.</b>	Loss of charge in thermostat bulb.	Place jumper across thermostat terminals. If unit operates, replace thermostat.
	Loose or broken parts in thermostat.	Check as above.
	Incorrect wiring.	Connect per wiring diagram.
	System switch open.	Test for continuity at switch terminals 5 and 6.

PROBLEM	POSSIBLE CAUSE	TO CORRECT
<b>Thermostat does not turn unit off.</b>	Thermostat set at coldest point	Turn to highest temperature setting to see if unit will cycle off. Disconnect power to the unit. Remove cover of thermostat
	Thermostat contacts stuck.	and check if contact is stuck, if so replace thermostat. Test switch for open contacts at terminals 5 and 6, 2 and 3
	Switch (On - Off) shorted.	with switch in "Off" position.

**TROUBLESHOOTING (Continued)**

PROBLEM	POSSIBLE CAUSE	TO CORRECT
Compressor attempts to start, or runs for short periods only. Cycles on overload.	Compressor attempts to start before system pressures are equalized.	Allow a minimum of two (2) minutes to allow pressures to equalize before attempting to start.
	Low or fluctuating voltage.	Check voltage with unit operating. Check for other appliances on the circuit. Unit should be on separate circuit for proper voltage, and be fused separately.
	Incorrect wiring.	Connect per wiring diagram.
	Shorted or incorrect capacitor.	Check by substituting a known good capacitor of correct rating.
	Restricted or low air flow through condenser coil.	Check for proper fan speed or blocked condenser.
	Compressor running abnormally hot.	Check for kinked discharge line or restricted condenser. Check amperage.
	Overload opens too soon.	Change compressor if all other corrections above are normal.

PROBLEM	POSSIBLE CAUSE	TO CORRECT
Compressor does not start - fan motor runs.	Thermostat contacts not closing.	Check continuity of thermostat at coldest setting. Jump contacts, if compressor runs, replace thermostat.
	Low voltage supply.	Check for nameplate voltage.
	Switch (On-Off) inoperative.	Test for continuity.
	Open capacitor.	Check by substituting a known good capacitor of correct rating.
	Heat sink triac open.	Replace both heat sink assembly and printed circuit control.
	Internal overload open.	Check voltage at compressor terminals. If voltage is satisfactory, replace compressor.
	Open or shorted compressor windings	Check windings for continuity and resistance. Direct test compressor. If direct test fails, replace compressor.

PROBLEM	POSSIBLE CAUSE	TO CORRECT
Does not cool, or cools only slightly	Thermostat open or inoperative.	Set to coldest position. Test thermostat and replace if necessary.
	Dirty air filter.	Clean as recommended in Owner's Manual.
	Dirty or plugged condenser or evaporator coil.	Use steam or detergents to clean.
	Poor air circulation in area being cooled.	Adjust air louvers.
	Low capacity - undercharge.	Clean, check for leak and make repair.
	Compressor not pumping properly.	Check amperage draw against nameplate. If not conclusive, make pressure test.

PROBLEM	POSSIBLE CAUSE	TO CORRECT
Fan motor does not run.	Defective switch (On-Off).	Check continuity across terminals 2 and 3.
	Fan capacitor open.	Check by substituting a known good capacitor of the same rating.
	Inoperative fan motor.	Direct test fan motor.
	Incorrect wiring of fan circuit.	Connect per wiring diagram.
	Printed circuit triac open.	Replace both printed circuit control and heat sink assembly.
	Check for seized motor bearings.	Rotate by hand, add oil, if noisy, replace.
	Bound fan blade or blower wheel.	Adjust for proper clearance.

**TROUBLESHOOTING (Continued)**



<b>PROBLEM</b>	<b>POSSIBLE CAUSE</b>	<b>TO CORRECT</b>
Switch (On-Off) does not cut fan motor off.	Printed circuit triac shorted.	Replace both printed circuit control and heat sink assembly.

<b>PROBLEM</b>	<b>POSSIBLE CAUSE</b>	<b>TO CORRECT</b>
Noisy and/or vibration.	Poor installation.	Refer to Installation Instructions for proper installation.
	Fan blade striking chassis.	Adjust motor mount to attain proper fan blade and blower wheel clearance.
	Compressor vibrating.	Check for deteriorated compressor grommets, or missing mounting parts.
	Loose cabinet parts, improperly mounted components, tubing rubbing.	Adjust and tighten as required.


<b>PROBLEM</b>	<b>POSSIBLE CAUSE</b>	<b>TO CORRECT</b>
Water leaks into room.	Evaporator drain pan overflowing.	Clean obstructed drain trough.
	Condensation forming on bottom of base pan.	Evaporator drain pan broken or cracked. Reseal or replace.
	Water dripping from discharge air grilles.	Dirty evaporator coil, or extremely high humidity conditions. Clean coil with steam or detergent.

<b>PROBLEM</b>	<b>POSSIBLE CAUSE</b>	<b>TO CORRECT</b>
Outside water leaks.	Evaporator drain pan cracked or obstructed.	Repair and clean, or replace as required.
	Water in center section of base pan (compressor area).	Remove condenser shroud, Clean and remove old sealer from base pan and shroud. Apply new sealer, reinstall and check.
	Dirty Condenser coil.	Clean with steam or detergent.
	Fan blade and slinger ring improperly positioned.	Adjust fan blade to 1/2" clearance from condenser coil.


# WIRING DIAGRAM FOR SH14J30A & SH20J30A



# Hazardgard Cabinet Parts



# Hazardgard Chassis Parts





# HAZARDGARD PARTS LIST

REF.	PART NO.	DESCRIPTION	APPLICATION			
			S H 1 4 J 3 0 A -1	S H 1 4 J 3 0 A -A	S H 2 0 J 3 0 A -1	S H 2 0 J 3 0 A -A
<b>ELECTRICAL PARTS</b>						
1	611-935-49	Compressor, Tecumseh, 230/208V; 60 Hz 1 Ph, Model AWG5515EXN..	1	1		
1	611-935-50	Compressor, Tecumseh, 230/208 V; 60 Hz 1 Ph, Model AWG5519EXN .			1	1
2	618-714-26	Motor, Fan 1/8 HP .....	1	1		
2	618-714-27	Motor, Fan 1/4 HP .....			1	1
3	617-682-00	Box, Electrical Wiring.....	1	1	1	1
4	613-892-00	Cover, Assembly Box .....	1	1	1	1
5	609-353-00	Switch, On-Off DPST .....	1	1	1	1
*	618-295-00	Circuit board, Support .....	4	4	4	4
*	611-086-02	Control Assembly, Printed Circuit Board .....	1	1	1	1
*	618-297-00	Insulator, Electrical .....	1	1	1	1
*	618-296-00	TRIAC – Heatsink .....	1	1	1	1
*	618-332-00	Strap, TRIAC .....	1	1	1	1
6	618-225-02	Thermostat .....	1	1	1	1
7	610-803-46	Capacitor 20/7.5 MFD, 440 Volt .....	1	1		
7	610-803-47	Capacitor 25/7.5 MFD, 440 Volt .....			1	1
8	618-298-00	Holder, Thermostat .....	1	1	1	1
*	613-891-00	Connector, E.M.T. ....	1	1	1	1
*	618-212-00	Harness, Wire, Compressor .....	1	1	1	1
*	618-208-01	Harness wire, Fan Motor .....	1	1	1	1
<b>REFRIGERATION SYSTEM COMPONENTS</b>						
9	618-501-03	Coil, Evaporator .....	1	1		
9	618-500-08	Evaporator .....			1	1
10	618-503-10	Condenser .....	1	1		
10	618-503-11	Condenser .....			1	1
*	013-900-05	†Capillary Tube .064 I.D. x 25" Long .....	1	1		
*	037-605-18	†Capillary Tube .054 I.D. x 27 3/8" Long .....			1	1
*	608-095-00	Valve, By-Pass .....	1	1	1	1
*	603-081-01	Filter Drier (Install during sealed system repairs) .....	1	1	1	1
<b>CHASSIS PARTS</b>						
11	614-939-05	Knob, Control .....	1	1	1	1
12	618-205-05	Panel, Control Mtg .....	1	1		
12	618-205-06	Panel, Control Mtg .....			1	1
*	600-713-12	Bushing, Snap .....	1	1	1	1
*	600-713-11	Bushing, Snap .....	1	1	1	1
*	618-293-00	Panel Plate .....	1	1	1	1
*	618-299-00	Block, Insert .....	1	1	1	1
13	618-120-06	Panel Assembly, left side .....	1	1		
13	618-120-07	Panel Assembly, left side .....			1	1
*		<b>NOT SHOWN</b>				
†		<b>CAPILLARY LENGTH MAY VARY, FLOW RATE IS THE SAME.</b>				

# HAZARDGARD PARTS LIST

REF.	PART NO.	DESCRIPTION	APPLICATION			
			S H 1 4 J 3 0 A - 1	S H 1 4 J 3 0 A - A	S H 2 0 J 3 0 A - 1	S H 2 0 J 3 0 A - A
<b>CHASSIS PARTS (Cont.)</b>						
14	618-028-01	Partition, Control Box .....	1	1		
14	618-043-01	Partition, Control Box .....	1	1		
15	618-204-00	Bracket, Capacitor Mtg. ....	1	1	1	1
16	618-207-00	Strap, Capacitor .....	1	1	1	1
17	618-226-01	Decorative Panel .....	1	1	1	1
*	618-306-00	Plate, Inner Wall .....	1	1	1	1
18	618-172-00	Cover, Top .....	1	1	1	1
19	618-167-00	Insulation, Top Cover .....	1	1	1	1
*	618-168-00	Insulation, Left Side Deck .....	1	1	1	1
20	618-171-00	Deck .....	1	1	1	1
*	608-658-08	Filter, Air .....	1	1		
*	608-658-09	Filter, Air .....			1	1
*	618-230-00	Holder, Filter .....	2	2	2	2
21	618-202-00	Airfoil .....	1	1	1	1
*	618-206-00	Bracket, Resistor Block .....	1	1	1	1
*	915-003-01	Clamp, Supply Cord .....	1	1	1	1
22	605-420-03	Fan Blade .....	1	1		
22	605-420-04	Fan Blade .....			1	1
23	606-106-03	Blower Wheel .....	1	1		
23	606-106-01	Blower Wheel .....			1	1
24	618-033-00	Inner Wall .....	1	1		
24	618-047-00	Inner Wall .....			1	1
25	618-025-00	Mount, Motor .....	1	1		
25	618-041-00	Mount, Motor .....			1	1
26	618-036-00	Shroud .....	1	1		
26	618-049-00	Shroud .....			1	1
27	618-026-00	Brace, Shroud .....	3	3	3	3
28	618-169-00	Insulation, Inner Wall .....	1	1		
28	618-169-01	Insulation, Inner Wall .....			1	1
29	618-173-00	Blower Front .....	1	1		
29	618-174-00	Blower Front .....			1	1
30	618-149-00	Scroll .....	1	1		
30	618-175-00	Scroll .....			1	1
31	618-215-00	Door, Slide Assembly .....	1	1	1	1
32	618-034-05	Base Pan .....	1	1		
32	618-034-11	Base Pan .....			1	1
*	618-038-00	Drain Pan .....	1	1	1	1
*	618-188-00	Rear Grille .....	1	1		
*	618-188-01	Rear Grille .....	1	1		
33	610-289-00	Grommet, Compressor .....	3	3	3	3
34	914-004-00	Bolt, Compressor Mounting .....	3	3	3	3
35	618-102-00	Plenum Assembly .....	1	1	1	1
*	618-093-00	Knob, Fresh Air & Exhaust .....	1	1	1	1
*		<b>NOT SHOWN</b>				

# HAZARDGARD PARTS LIST

REF.	PART NO.	DESCRIPTION	APPLICATION			
			S H 1 4 J 3 0 A - 1	S H 1 4 J 3 0 A - A	S H 2 0 J 3 0 A - 1	S H 2 0 J 3 0 A - A
<b>CHASSIS PARTS (Cont.)</b>						
*	618-092-00	Lever, Fresh Air & Exhaust .....	1	1	1	1
*	618-062-00	Connector, Louver .....	2	2	2	2
*	618-063-00	Louver, Grille .....	20	20	20	20
*	618-063-01	Louver with Handle .....		2	2	2
36	618-032-03	Outer Shell .....	1	1		
36	618-046-00	Outer Shell .....			1	1
37	618-089-00	Grille, Intake .....	1	1		
37	618-111-00	Grille, Intake .....			1	1
*	618-199-00	Latch, Intake Grille .....	2	2	2	2
38	602-944-08	Wingboard .....	1	1		
38	602-944-09	Wingboard .....			1	1
*	611-050-04	Accessory Package .....	1	1		
*	611-050-05	Accessory Package .....			1	1
39	611-095-03	Bracket, Support .....	2	2	2	2
40	618-197-01	Angle, Wingboard (Top) .....	1	1	1	1
41	618-198-01	Angle, Wingboard (Side) .....	2	2		
41	618-198-03	Angle, Wingboard (Side) .....			2	2
42	606-103-03	Gasket (Vinyl) .....	1	1	1	1
*	608-460-16	Bag (Assembly Hardware) .....	1	1	1	1
*	617-173-01	Gasket, Chassis (Foam) .....	1	1	1	1
*	618-116-20	Carton, Shipping .....	1	1		
*	618-116-21	Carton, Shipping .....			1	1
*	618-139-00	Pad, Shipping .....	1	1	1	1
*	618-118-00	Pad, Shipping .....	2	2		
*	618-118-01	Pad, Shipping .....			2	2
*	618-141-01	Pad, Shipping (Top) .....	1	1	1	1
43	600-733-00	Gasket, Window (Foam) .....	1	1	1	1
*	Not Shown					
<b>OPTIONAL ACCESSORIES</b>						
*	01900-235	Drain – Condensate Connection Kit, DC-2 .....	x	x	x	x
*	01900-312	Start Kit, Capacitor/Relay (Pow-R-Pak) .....	x	x	x	x
*	HG2001	Parts Manual (7/01) .....	x	x	x	x
*	92002403	Installation Manual .....	x	x	x	x

# Use Factory Certified Parts...



**Friedrich Air Conditioning Co.**

4200 North Pan Am Expressway

P.O. Box 1540, San Antonio, Texas 78295-1540, USA

Tel. (210) 357/4400 Fax: (210) 357/4480