



PORTABLE AIR CONDITIONER CLIMATISEUR PORTATIF ACONDICIONADOR DE AIRE PORTATIL



Model# Modèle# Modelo#

APO99R



A Word From Amana

Thank You for buying a dependable, energy saving and easy to operate AMANA air conditioner. This manual contains useful information for you to maintain, operate, install and safely use your air conditioner. Your air conditioner cleans, cools and dehumidifies the air in your room to provide you with the ultimate level of comfort.

Please read instructions carefully before using the product. Also, do not forget to fill out and mail the **Product Registration Card**.

Product Registration

Record Your Model and Serial Number.

For all your service calls during the warranty period the following information will be needed. Attach the sales receipt to this guide and keep for future reference. This information can be obtained from the serial plate, which is on your air conditioner.

| Model Number: | | | |
|-----------------------|------|------|--|
| Serial Number: | | | |
| Date of Purchase: | | | |
| Dealer's Name: | | | |
| Dealers Address: | | | |
| Dealers Phone Number: | | | |

| TABLE | | | | | | |
|--|--------|------|--------|-----|----|--|
| RECEPTACLE AND FUSE TYPES | | | | | | |
| RATED VOLTS | 125/60 | | 250/60 | | | |
| AMPS | 15 | 20 | 15 | 20 | 30 | |
| WALL OUTLET | | | | | | |
| FUSE SIZE | 15 | 20* | 15 | 20* | 30 | |
| TIME DELAY FUSE (or circuit braker) | Plug | Plug | Plug | | | |

SAFETY PRECAUTIONS

WARNING: Following these basic precautions will reduce the risk of fire, electrical shock, injury or death when using your air conditioner.

- Air conditioner must be connected to proper electrical outlet with the correct electrical supply. (see table)
- Proper grounding must be ensured to reduce the risk of shock and fire. DO NOT CUT OR REMOVE THE GROUNDING PRONG. If you do not have a three-prong electric receptacle outlet in the wall, have a certified electrician install the proper receptacle. The wall receptacle MUST be properly grounded.
- ▲ 3) Do not operate air conditioner if power cord is frayed or otherwise damaged. Also avoid using it if there are cracks or abrasion damage along the length, plug connector or if the unit malfunctions or is damaged in any manner. Contact an authorized service for examination, repairs or adjustments.
- **A** 4) DO NOT USE AN ADAPTER OR AN EXTENSION CORD.
 - 5) Do not block airflow around the air conditioner. Also the exhaust hose should be free of any obstructions.
 - 6) Always unplug the air conditioner before servicing it or moving it.
 - 7) Do not install or use the air conditioner in any area where the atmosphere contains combustible gases or where the atmosphere is oily or sulphurous. Avoid any chemicals coming in contact with your air conditioner.
 - 8) Do not place any object on the top of the unit.
 - 9) Never operate the air conditioner without the filters in place.
 - 10) Do not use the air conditioners near a bathtub, shower or wash basin.

PAGE


Table Of Contents


| A Word From AMANA | 1 |
|----------------------------|---|
| Product Registration | 1 |
| Safety Precautions | 2 |
| AdvantagesAdvantages | |
| Parts and Features | |
| Assembly and Installation | |
| Operation | |
| · Product Specification | |
| Care and Cleaning | |
| Storage | |
| Trouble Shooting | |
| Warranty Information | |


Advantages of this Model

- 1. This model is easy to operate. The electronic control panel has a timer, thermostat, three speed cooling speeds, three fan speeds and one speed dehumidification function (dry).
- 2. This portable air conditioner does not require water to be added.
- 3. The unit has a unique design which evaporates the water. Therefore no condensation tank is necessary, thus avoiding you to have to wake up in the middle of the night to empty the bucket and turn on the unit.
- 4. Easy to install window kit is included which consists of the, exhaust hose, 2 hose nozzle, the window panel kit, exhaust hose connector and cover for the exhaust hose connector.
- 5. Full directional casters are included to help to move the unit to be conveniently used in almost any area.
- 6. The filter screen is designed for easily accessibility of the filter.
- 7. Portable air conditioners are easy to store when not in use.

Parts and Features









Assembly and Installation

A. Connect exhaust hose to the back of the unit. Extend hose to desired length and connect with window kit.


USING EXHAUST DUCT SET






- 2. Fix the Exhaust duct "A" to the exhaust outlet on the rear of the unit.


 This is achieved by sliding the appropriate connector downwards over the exhaust outlet ensuring that the lugs on the outlet are engaged with the grooves on the connector.
- 3. Extend the Exhaust hose and close the Window as far as possible trapping the air outlet nozzle.















USING WINDOW PANEL KIT

- 1. Plastic panel 1 piece
- 2. Nozzle Fitting 1 piece
- 3. Screws 4 pieces





Exhaust Duct Adapter



Operation

NOTE: Wait for 24 hours to turn on air conditioner if the unit has been tilted for any reason. This is for the oils and the coolants to settle and level off.

- 1. Wait for 3 minutes before restarting the unit after a normal shut down so as to complete the compressor cycle.
- 2. Use an 115v 15 amp outlet for the air conditioner. Do not use any other electrical appliances on this line or you may trip the fuse. Use a dedicated line for this air conditioner.
- 3. Do not place the air conditioner in direct sunlight or close to any heating appliances. ex. baseboard heaters, stoves, etc.
- 4. Operate on a flat surface only.
- 5. Keep the unit free of any obstructures such as drapes, curtains, blinds, etc.
- 6. Keep unit at least 1 foot away from the wall.
- 7. Check and clean the filter once every week to get the highest efficiency.

NOTE: Do not use unit without filter.

8. If the unit is not being used for a long period of time remove the plug from the water drain pipe and drain out any condensed water.

When turning on the unit first time after plugging it into an electrical outlet the unit will start in a low fan cool mode. The temperature read out on the LED will be the room temperature. When turning on the unit in regular usage it will remember the last shut off setting. If you want to operate the air conditioner as a dehumidifier then adjust to dry mode.

Setting The Temperature

To set the temperature press the + or the - key to raise or lower the temperature. The temperature can be raised or lowered in the cool or dry mode. The temperature cannot be adjusted in the fan mode.

Fan Speeds

There are 3 adjustable speeds in the cool and fan mode: Low, Medium & High. In the dry or dehumidification mode the fan will only operate at low speed.

On/Off Time Set

The air conditioner has a 1-12 hour on/off built-in timer. To delay start the unit from 1-12 hours at a 1 hour interval, simply press the time/set key and then press the + or - key to adjust the start time. Note that the unit has to be plugged in to an electrical outlet for the timer to operate.

To auto shut-off the unit press the time/set key while the unit is running and then press the + or - key to adjust the off time. The auto shut-off switch operates in all 3 modes: Cool, Dry & Fan.

NOTE: The temperature can be set between 60°F to 89°F.

Product Specification

| Voltage and Frequency | 115V / 60Hz | | |
|----------------------------------|-----------------------------|--|--|
| Input Power | 900 W | | |
| Cooling Capacity | 9000 BTU | | |
| Moisture Removal (pints/hr) | 3.8 | | |
| Coolant | R22 / 0.99 lbs | | |
| Timer | 12 Hours | | |
| Operating Temperature Range | 64.4°F - 100°F | | |
| Unit Dimensions (WxDxH) (inches) | 18 9/16 x 14 1/16 x 34 3/16 | | |
| Net Weight lbs. approximate | 79.4 lbs. | | |
| Power Cord | 84" | | |
| Exhaust Hose | 4 Feet | | |

Care and Cleaning Guide

- Always unplug your air conditioner before cleaning.
- Air filter needs to be cleaned at least once a week for your unit to operate at optimum
 efficiency. The filter can be slid out from the back by pulling on the tab. The filter may
 be washed or vacuumed. Remove the excess water from the filter by gently shaking the
 filter. This will remove dust and particles trapped in the filter. After cleaning, reinstall the
 filter. DO NOT use your air conditioner without the air filter in place.
- To clean the cabinet **DO NOT** use harsh chemicals, abrasives, ammonia, chlorine, bleach, concentrated detergents, solvents or metal scouring pads. Some of these chemicals may dissolve, damage and/or discolor your air conditioner.
- Always use a soft cloth dampened with water or mild soap and water solution to wipe the front of the cabinet. Wipe dry with a soft cloth.

Storage

 To store your air conditioner when not being used for a long period of time, drain condensed water using the drain pipe. Remove exhaust hose, clean filters, cover with plastic bag and store away.

Trouble-Shooting

If air conditioner does not operate:

- Check if unit is plugged in. The plug may have come loose.
- Check if the electrical wall receptacle is of proper voltage.
- Check if the circuit breaker needs to be reset or if the fuse needs to be replaced.
- Check if the unit is in "Off" mode.
- The tank full warning light is on. Call for service.

Air conditioner working but room not cooling:

- Room may have appliances that produce heat. Use an exhaust fan to remove excess heat.
- Check exhaust hose for proper installation.
- Redirect the airflow. Remove any obstacles.
- All doors and windows need to be closed so cool air does not escape the room.
- Air filter may be blocked or may need cleaning.
- Unit BTU may be too low for the required cooling area.
- On extreme hot & humid days air conditioners may take a little longer to cool.
- Drain the water drain pipe by removing the plug.
- Unit may be in fan or dry mode. Put air conditioner in cool mode.

Limited Warranty

This warranty covers all defects in workmanship or materials for:

- 1. The mechanical and electrical parts (including labor costs) contained in this Haier product, for a period of 12 months, from the date of purchase, (commercial or rental application, the warranty is 90 days).
- 2. The sealed system and compressor contained in this Haier product is for a period of 5 years, from the date of purchase (excluding labor costs after the initial 12 month period). In commercial or rental use, the additional limited compressor warranty is for 1 year and 9 months, (excluding labor costs after the initial 90 days period).

You must keep and be able to provide your original sales receipt as proof of the date of purchase.

Who is covered?

The original retail purchaser of this Haier product.

What will be done?

Haier will repair or replace, in your home, any mechanical, electrical part or the compressor, which proves defective in normal household, use for a period of 12 months. Haier will repair or replace (excluding labor costs) the sealed system and compressor (parts only) for an additional 4 year period.

How can you get service?

- 1. Contact your nearest Haier authorized Service Depot. For the name of the Service Depot nearest you, contact Haier at (877) 337-3639.
- 2. All service must be performed, by an authorized Haier Service Depot.

THIS WARRANTY COVERS UNITS WITHIN THE CONTINENTAL UNITED STATES, CANADA AND PUERTO RICO AND DOES NOT COVER:

- Damages from improper installation
- Damages in shipping
- Damages from misuse, abuse, accident, alteration, lack of proper care and maintenance
- Damages from service, by other than an authorized dealer or service center
- Labor, service, transportation and shipping charges for the removal of defective parts and installation of a replacement part, beyond the initial 12 month period.

THIS LIMITED WARRANTY IS GIVEN
IN LIEU OF ALL OTHER WARRANTIES, EXPRESS
OR IMPLIED, INCLUDING THE WARRANTIES OF
MERCHANTABILITY AND FITNESS FOR A
PARTICULAR PURPOSE.

The remedy provided in this warranty is exclusive and is granted in lieu of all other remedies. This warranty does not cover incidental or consequential damages. Some states do not allow the exclusion of incidental or consequential damages, so this limitation may not apply to you. Some states do not allow limitations on how long an implied warranty lasts, so this limitation may not apply to you. This warranty gives you specific legal rights, and you may also have other rights, which vary from state to state.