


This Owner's Manual is provided and hosted by [Appliance Factory Parts](http://ApplianceFactoryParts.com).



FRIEDRICH MWM12Y1J Owner's Manual

[Shop genuine replacement parts for FRIEDRICH
MWM12Y1J](#)



[Find Your FRIEDRICH Air Conditioner Parts - Select From 1577 Models](#)

----- Manual continues below part list -----

Available Replacement Parts for FRIEDRICH MWM12Y1J

| | |
|---------------------------|---------------------|
| P69700295 | Display Board |
| P69700313 | Remote Controller |
| P69700337 | Filter Sub Assembly |
| P69700347 | Motor Sub Assembly |
| P69700349 | Cross Flow Fan |
| P69700361 | Main Board |
| P69700362 | Temperature Sensor |
| P69700363 | Temperature Sensor |



F R I E D R I C H

Service Manual

Models: MWM09Y1J/MRM09Y1J
MWM12Y1J/MRM12Y1J
(Refrigerant R410A)

Table of Contents

| | |
|--|----|
| Part I : Technical Information | 1 |
| 1. Summary | 1 |
| 2. Specifications | 2 |
| 2.1 Specification Sheet..... | 2 |
| 2.2 Operation Characteristic Curve..... | 4 |
| 2.3 Capacity Variation Ratio According to Temperature..... | 4 |
| 2.4 Cooling and Heating Data Sheet in Rated Frequency..... | 5 |
| 2.5 Noise Curve..... | 5 |
| 3. Outline Dimension Diagram | 6 |
| 3.1 Indoor Unit..... | 6 |
| 3.2 Outdoor Unit..... | 6 |
| 4. Refrigerant System Diagram | 7 |
| 5. Electrical Part | 8 |
| 5.1 Wiring Diagram..... | 8 |
| 5.2 PCB Printed Diagram..... | 10 |
| 6. Function and Control | 12 |
| 6.1 Remote Controller Introduction..... | 12 |
| 6.2 Brief Description of Modes and Functions..... | 15 |
| Part II : Installation and Maintenance | 21 |
| 7. Notes for Installation and Maintenance | 21 |
| 8. Installation | 23 |
| 8.1 Installation Dimension Diagram..... | 23 |
| 8.2 Installation Parts-checking..... | 25 |
| 8.3 Selection of Installation Location..... | 25 |
| 8.4 Electric Connection Requirement..... | 25 |
| 8.5 Installation of Indoor Unit..... | 25 |
| 8.6 Installation of Outdoor Unit..... | 27 |
| 8.7 Vacuum Pumping and Leak Detection..... | 29 |
| 8.8 Check after Installation and Test Operation..... | 29 |

| | |
|---|----|
| 9. Maintenance | 30 |
| 9.1 Error Code List | 30 |
| 9.2 Troubleshooting for Main Malfunction | 38 |
| 9.3 2-way, 3-way Valve Appearance..... | 47 |
| 9.4 Troubleshooting for Normal Malfunction..... | 54 |
| 10. Exploded View and Parts List | 56 |
| 10.1 Indoor Unit..... | 56 |
| 10.2 Outdoor Unit | 58 |
| 11. Removal Procedure | 60 |
| 11.1 Removal Procedure of Indoor Unit | 60 |
| 11.2 Removal Procedure of Outdoor Unit | 66 |
| Appendix: | 70 |
| Appendix 1: Reference Sheet of Celsius and Fahrenheit | 70 |
| Appendix 2: Configuration of Connection Pipe..... | 70 |
| Appendix 3: Pipe Expanding Method | 71 |
| Appendix 4: List of Resistance for Temperature Sensor | 72 |

2. Specifications

2.1 Specification Sheet


| Model | | | MWM09Y1J MRM09Y1J | MWM12Y1J MRM12Y1J | |
|---------------------------------|---------------------------------------|-----------------|----------------------|--------------------------|--------------------------|
| Product Code | | | CB146035101_L13396 | CB146035001_L13396 | |
| Power Supply | Rated Voltage | V~ | 115 | 115 | |
| | Rated Frequency | Hz | 60 | 60 | |
| | Phases | | 1 | 1 | |
| Power Supply Mode | | | Outdoor | Outdoor | |
| Cooling Capacity (Min~Max) | | Btu/h | 9000(3500~11000) | 11800(3300~12500) | |
| Heating Capacity (Min~Max) | | Btu/h | 9800(2500~11000) | 13000(3400~13500) | |
| Cooling Power Input (Min~Max) | | W | 750(220~1100) | 1260(260~1340) | |
| Heating Power Input (Min~Max) | | W | 830(230~1230) | 1320(250~1360) | |
| Cooling Power Current | | A | 9 | 15 | |
| Heating Power Current | | A | 9.5 | 15.5 | |
| Rated Input | | W | 1230 | 1360 | |
| Rated Current | | A | 17.0 | 18.2 | |
| Air Flow Volume(SH/H/M/L/SL) | | CMF | 330/277/224/188/- | 341/288/235/200/- | |
| Dehumidifying Volume | | Pint/h | 1.69 | 2.96 | |
| EER | | (Btu/h)/W | 12 | 9.4 | |
| COP | | (Btu/h)/W | 12 | 9.8 | |
| SEER | | (Btu/h)/W | 16 | 16 | |
| HSPF | | (Btu/h)/W | 8.6 | 8.6 | |
| Application Area | | yd ² | 14.4-21.5 | 19.14-28.7 | |
| Indoor Unit | Model of indoor unit | | MWM09Y1J | MWM12Y1J | |
| | Product Code | | CB146N35100_L13396 | CB146N35000_L13396 | |
| | Fan Type | | Cross-flow | Cross-flow | |
| | Diameter Length(DXL) | | inch | Φ3 5/8X23 3/8 | Φ3 5/8X23 3/8 |
| | Fan Motor Cooling Speed (SH/H/M/L/SL) | | r/min | 1300/1100/900/700/- | 1350/1150/950/750/- |
| | Fan Motor Heating Speed (SH/H/M/L/SL) | | r/min | 1300/1150/980/820/- | 1350/1200/1000/850/- |
| | Output of Fan Motor | | W | 15 | 15 |
| | Fan Motor RLA | | A | 0.38 | 0.38 |
| | Fan Motor Capacitor | | μF | 4 | 4 |
| | Input of Heater | | W | / | / |
| | Evaporator Form | | | Aluminum Fin-copper Tube | Aluminum Fin-copper Tube |
| | Pipe Diameter | | inch | Φ2/7 | Φ2/7 |
| | Row-fin Gap | | inch | 2-1/18 | 2-1/18 |
| | Coil Length (LXDXW) | | inch | 24X17/18X11 4/7 | 24X17/18X11 4/7 |
| | Swing Motor Model | | | MP24BA | MP24BA |
| | Output of Swing Motor | | W | 2.4 | 2.4 |
| | Fuse | | A | 3.15 | 3.15 |
| | Sound Pressure Level (SH/H/M/L/SL) | | dB (A) | 41/37/35/32/- | 43/39/35/32/- |
| | Sound Power Level (SH/H/M/L/SL) | | dB (A) | 51/47/45/42/- | 53/49/45/42/- |
| | Dimension (WXHXD) | | inch | 30 1/3X11 1/7X8 | 30 1/3X11 1/7X8 |
| Dimension of Carton Box (LXWXH) | | inch | 33 2/9X13 1/2X10 2/7 | 33 2/9X13 1/2X10 2/7 | |
| Dimension of Package (LXWXH) | | inch | 33 1/3X13 4/7X10 6/7 | 33 1/3X13 4/7X10 6/7 | |
| Net Weight | | lb | 19 | 19 | |
| Gross Weight | | lb | 23 | 23 | |

| | | | | |
|---------------------------------|-----------------------------------|----------------------|----------------------------------|----------------------------------|
| Outdoor Unit | Model of Outdoor Unit | | MRM09Y1J | MRM12Y1J |
| | Product Code | | CB146W0431_L13396 | CB146W0451_L13396 |
| | Compressor Manufacturer/Trademark | | ZHUHAI LANDA COMPRESSOR CO., LTD | ZHUHAI LANDA COMPRESSOR CO., LTD |
| | Compressor Model | | QXA-A091ZE190 | QXA-A091ZE190 |
| | Compressor Oil | | FVC68D | FVC68D |
| | Compressor Type | | Rotary | Rotary |
| | L.R.A. | A | / | / |
| | Compressor RLA | A | 6 | 6 |
| | Compressor Power Input | W | 980 | 980 |
| | Overload Protector | | 1NT11L-6233 | 1NT11L-6233 |
| | Throttling Method | | Electron expansion valve | Electron expansion valve |
| | Operation temp | °F | 61~86 | 61~86 |
| | Ambient temp (cooling) | °F | 64~113 | 64~113 |
| | Ambient temp (heating) | °F | 5~75 | 5~75 |
| | Condenser Form | | Aluminum Fin-copper Tube | Aluminum Fin-copper Tube |
| | Pipe Diameter | inch | Φ2/7 | Φ2/7 |
| | Rows-fin Gap | inch | 2-1/18 | 2-1/18 |
| | Coil Length (LXDXW) | inch | 29 8/11X1X19 8/17 | 29 8/11X1X19 8/17 |
| | Fan Motor Speed | rpm | 900 | 900 |
| | Output of Fan Motor | W | 30 | 30 |
| | Fan Motor RLA | A | 0.17 | 0.17 |
| | Fan Motor Capacitor | μF | / | / |
| | Air Flow Volume of Outdoor Unit | CFM | 1059 | 1059 |
| | Fan Type | | Axial-flow | Axial-flow |
| | Fan Diameter | inch | Φ15 10/13 | Φ15 10/13 |
| | Defrosting Method | | Auto Defrosting | Auto Defrosting |
| | Climate Type | | T1 | T1 |
| | Isolation | | I | I |
| | Moisture Protection | | IP24 | IP24 |
| | Design Pressure(High) | PSIG | 550 | 550 |
| | Design Pressure(Low) | PSIG | 240 | 240 |
| | Sound Pressure Level (H/M/L) | dB (A) | 53/-/- | 55/-/- |
| | Sound Power Level (H/M/L) | dB (A) | 63/-/- | 65/-/- |
| | Dimension (WXHXD) | inch | 33 2/5X21 1/4X12 3/5 | 33 2/5X21 1/4X12 3/5 |
| Dimension of Carton Box (LXWXH) | inch | 34 4/7X14 1/6X22 5/6 | 34 4/7X14 1/6X22 5/6 | |
| Dimension of Package (LXWXH) | inch | 34 2/3X14 2/7X23 3/7 | 34 2/3X14 2/7X23 3/7 | |
| Net Weight | lb | 68 | 68 | |
| Gross Weight | lb | 77 | 77 | |
| Refrigerant | | R410A | R410A | |
| Refrigerant Charge | oz | 35.28 | 35.28 | |
| Connect on Pipe | Length | ft | 24.6 | 24.6 |
| | Gas Additional Charge | oz/ft. | 0.21 | 0.21 |
| | Outer Diameter Liquid Pipe | inch | Φ1/4 | Φ1/4 |
| | Outer Diameter Gas Pipe | inch | Φ3/8 | Φ3/8 |
| | Max Distance Height | ft | 32.8 | 32.8 |
| | Max Distance Length | ft | 49.2 | 49.2 |


The above data is subject to change without notice. Please refer to the nameplate of the unit.

2.2 Operation Characteristic Curve

Cooling




Heating




2.3 Capacity Variation Ratio According to Temperature

Cooling



Heating



5. Electrical Part

5.1 Wiring Diagram


● **Instruction**

| Symbol | Symbol Color | Symbol | Symbol Color | Symbol | Name |
|--------|--------------|--------|--------------|--------|----------------|
| WH | White | GN | Green | CAP | Jumper cap |
| YE | Yellow | BN | Brown | COMP | Compressor |
| RD | Red | BU | Blue | | Grounding wire |
| YEGN | Yellow/Green | BK | Black | / | / |
| VT | Violet | OG | Orange | / | / |

Note: Jumper cap is used to determine fan speed and the swing angle of horizontal louver for this model.

● **Indoor Unit**

MWM09Y1J MWM12Y1J





13. TURBO button

Press this button to activate / deactivate the Turbo function which enables the unit to reach the preset temperature in the shortest time. In COOL mode, the unit will blow strong cooling air at super high fan speed. In HEAT mode, the unit will blow strong heating air at super high fan speed. (This function is not applicable for some models).



14. SLEEP button

Press this button to go into the SLEEP operation mode. Press it again to cancel this function. This function is available in COOL or DRY mode to maintain the most comfortable temperature for you.

15. LIGHT button

Press LIGHT button to turn on the display's light and press this button again to turn off the display's light. If the light is turned on,  is displayed. If the light is turned off,  disappears.


Combination of "▲" and "▼" buttons: About lock

Press "▲" and "▼" buttons simultaneously to lock or unlock the keypad. If the remote controller is locked,  is displayed. In this case, pressing any button,  blinks three times.

Combination of "MODE" and "-" buttons:


Allows you to toggle between Fahrenheit and Celsius. When the unit is OFF, press "MODE" and "▼" buttons simultaneously to switch between °C and °F.

Replacement of Batteries in Remote Controller

1. Press the back side of remote controller marked with  as shown in the fig, and then push out the cover of battery box along the arrow direction.
2. Replace two 7# (AAA 1.5V) dry batteries, and make sure the position of "+" polar and "-" polar are correct.
3. Reinstall the cover of battery box.

Note:

- During operation, point the remote control signal sender at the receiving window on indoor unit.
- The distance between signal sender and receiving window should be no more than 8m, and there should be no obstacles between them.
- Signal may be interfered easily in the room where there is fluorescent lamp or wireless telephone; remote controller should be close to indoor unit during operation.
- Replace new batteries of the same model when replacement is required.
- When you don't use remote controller for a long time, please take out the batteries.
- If the display on remote controller is fuzzy or there's no display, please replace batteries.



Sketch map for replacing batteries

rotate to place D. Under other state, the horizontal louver will rotate to level L. If the swing function is set when starting the unit, the horizontal louver will swing between place L and D. there are 7 states for the louver: in Place L, Place A, Place B, Place C, Place D, and swing between Place L and place D, stop in any place between Place L and place D. When the unit is turned off, the louver will stay in place 0. The swing is available only when the swing function is set and the indoor fan is running.

Note: When place L to B, place A to C, and place B and D is set, the horizontal louver will swing between place L to D. L←→A←→B←→C←→D

(8) Sleep Function

Sleeping mode is available only in cooling and heating modes;

Cooling mode: at the base of initial set temperature by remote controller, the set temperature will increase automatically according to people's coziness within several hours after setting sleep function.

Heating mode: at the base of initial set temperature by remote controller, the set temperature will decrease automatically according to people's coziness within several hours after setting sleep function.

(9) Timer Function

The main board has general timer function and clock function. The timer function can be selected by remote controller with different function

1.General timer (start and stop time can be set. The accuracy is minute. E.g.: timer on for 1 hour; timer off for 1.5 hours.)

Timer on: after setting timer on, the unit will run at setting time according to the original setting mode. The timing interval is 0.5hour, and the setting range is 0.5~24hours.

Timer off: the timer off function can be set when the unit is on. When the setting time for timer off is reached, the unit will stop. The timing interval is 0.5hour, and the setting range is 0.5~24hours.

2.Clock (start and stop time can be set. The accuracy is minute. E.g.: timer on at 8:00a.m.; timer off at 17:30p.m.)

Timer on: if the timer on function is set when the system is on, the system will go on running. If the timer on function is set when the system is off, the system will start running in the previously set mode when the setting time is reached.

Timer off: if the timer off function is set when the system is off, the system will keep off even though the setting time is reached. If the timer off function is set when the system is on, the system will stop running when the setting time is reached.

Timer modification: when the system is under timer state, start or stop of the unit can be set via remote ON/OFF button and the timer can be reset. The system runs according to the latest setting state.

When both the timer on and timer off are set: the system runs according to the current setting state. When the setting time is reached, the unit will start and stop running. In that case, the unit will run according to the previously setting mode when the setting time for timer on is reached. The unit will stop running while the setting time for timer off is reached.

If the setting time for timer on and timer off is the same, the unit will stop running no matter what the current state is.

(10) Auto-Restart Function

Memory: mode, up and down swing, light, setting temperature, setting fan speed, general timer (not clock), Fahrenheit / Celsius. After de-energized, the unit can run according to the memory if it is energized again. If the timer function is not set in the last remote control, the system will run according to the last remote control. If the timer function is set in the last control before it is de-energized, the system will memorize the last timer setting. The setting time is recalculated since the energization of the unit. If the timer function is set in the last control and the setting time is reached before the unit is de-energized, the unit will run according to the previous running mode after it is energized again. But the timer function will terminate. The clock will not be memorized.

In cooling and heating mode (not available in auto, dehumidify, fan mode), press the Turbo button, the fan speed displayed super high speed in the remote controller and the indoor fan rotates at super high speed.

(11) Turbo Function

In cooling and heating mode (not available in auto, dehumidify, fan mode), press the Turbo button, the fan speed displayed super high speed in the remote controller and the indoor fan rotates at super high speed.

(12) Health Function

When the indoor fan motor is running, the Health function is set by pressing remote controller (If there is no Health button on the remote controller, the health function opening is defaulted).


(13) I Feel Function

If the remote controller receives the I Feel order, the controller will work at the ambient temperature value which is sent by remote controller (Except the defrosting and anti-cool wind, which still adopts the sampling value of AC itself ambient temperature sensor), the remote controller will send ambient temperature value to controller every 10mins. After 11mins, if the controller hasn't received the ambient temperature value from the remote controller for long time, then it will run according to the current ambient temperature of AC.

If the function has not been set, the ambient temperature will adopt the sensor sampling value of AC itself. If power off happens, this function will not be memorized.

Troubleshooting of Temperature Sensor

(1) Indoor Temperature Sensor



Management within the Zones

| Zone | Control contents |
|---------------------|--|
| Stop zone | When the temperature reaches the stop zone, stop the compressor and correct abnormality. |
| Drooping zone | Start the timer, and the frequency will be drooping. |
| Keep zone | Keep the upper limit of frequency. |
| Return / Reset zone | Cancel the upper limit of frequency. |

Input Current Control


Outline

Detect an input current by the CT during the compressor is running, and set the frequency upper limit from such input current.

In case of heat pump model, this control is the upper limit control function of the frequency which takes priority of the lower limit of four way valve activating compensation.

Detail

The frequency control will be made within the following zones.



When a “stop current” continues for 2.5 seconds after rushing on the stop zone, the compressor operation stops.

If a “drooping current” is continues for 1.0 second after rushing on the drooping zone, the frequency will be 2 Hz drooping.

Repeating the above drooping continues until the current rushes on the drooping zone without change.

In the keep zone, the frequency limit will remain.

In the return / reset zone, the frequency limit will be cancelled.

Limitation of current drooping and stop value according to the outdoor air temperature

1. In case the operation mode is cooling

* The current droops when outdoor air temperature becomes higher than a certain level (model by model).

2. In case the operation mode is heating

* The current droops when outdoor air temperature becomes higher than a certain level (model by model).

Freeze-up Protection Control

Outline


During cooling operation, the signals being sent from the indoor unit allow the operating frequency limitation and then prevent freezing of the indoor heat exchanger. (The signal from the indoor unit must be divided into the zones as the followings.)

Detail

1. Conditions for Start Controlling

Judge the controlling start with the indoor heat exchanger temperature after 2 sec from operation start.

2. Control in Each Zone



3. Fan OFF delay when stopped
4. ON/OFF control in cooling operation
5. Tap control when drooping function is working
6. Fan control in forced operation
7. Fan control in indoor/outdoor unit silent operation
8. Fan control in powerful mode
9. Fan control in normal operation

Detail

Fan OFF Control when Stopped

* Fan OFF delay for 60 seconds must be made when the compressor is stopped.

Tap Control in indoor/outdoor unit silent operation

1. When Cooling Operation

When the outdoor air temperature is lower than 99°F, the fan tap must be set to L.

2. When Heating Operation

When the outdoor air temperature is higher than 39°F, the fan tap must be turned to L (only for heat pump model).

Refrigerant Recycling Function (applicable when changing installation location or in maintenance)

(1) Enter refrigerant recycling function

Within 5min after energizing (unit ON or OFF status is ok), continuously press LIGHT button for 3 times within 3s to enter refrigerant recycling mode; Fo is displayed and refrigerant recycling function is started. At this moment, the maintenance people closes liquid valve. After 5min, stick the thimble of maintenance valve with a tool. If there is no refrigerant spraying out, close the gas valve immediately and then turn off the unit to remove the connection pipe.

(2) Exit refrigerant recycling function

After entering refrigerant recycling mode, when receive any remote control signal or enter refrigerant recycling mode for 25min, the unit will exit refrigerant recycling mode automatically. If the unit is in standby mode before refrigerant recycling, it will be still in standby mode after finishing refrigerant recycling; if the unit is in ON status before refrigerant recycling, it will still run in original operation mode.

Compulsive Defrosting Function

(1) Start up compulsory defrosting function

Under ON status, set heating mode with remote controller and adjust the temperature to 16°C(61°F). Press “+, -, +, -, +,-” button successively within 5s and the complete unit will enter into compulsory defrosting status. Meanwhile, defrosting mark H1 will be shown. (Note: If complete unit has malfunction or stops operation due to protection, compulsory defrosting function can be started up after malfunction or protection is resumed.

(2) Exit compulsory defrosting mode

After compulsory defrosting is started up, the complete unit will exit defrosting operation according to the actual defrosting result, and the complete unit will resume normal heating operation.

Part II : Installation and Maintenance

7. Notes for Installation and Maintenance

Safety Precautions: Important!

Please read the safety precautions carefully before installation and maintenance.

The following contents are very important for installation and maintenance.

Please follow the instructions below.

- The installation or maintenance must accord with the instructions.
- Comply with all national electrical codes and local electrical codes.
- Pay attention to the warnings and cautions in this manual.
- All installation and maintenance shall be performed by distributor or qualified person.
- All electric work must be performed by a licensed technician according to local regulations and the instructions given in this manual.
- Be caution during installation and maintenance. Prohibit incorrect operation to prevent electric shock, casualty and other accidents.



Warnings

Electrical Safety Precautions:

1. Cut off the power supply of air conditioner before checking and maintenance.
2. The air condition must apply specialized circuit and prohibit share the same circuit with other appliances.
3. The air conditioner should be installed in suitable location and ensure the power plug is touchable.
4. Make sure each wiring terminal is connected firmly during installation and maintenance.
5. Have the unit adequately grounded. The grounding wire can't be used for other purposes.
6. Must apply protective accessories such as protective boards, cable-cross loop and wire clip.
7. The live wire, neutral wire and grounding wire of power supply must be corresponding to the live wire, neutral wire and grounding wire of the air conditioner.
8. The power cord and power connection wires can't be pressed by hard objects.
9. If power cord or connection wire is broken, it must be replaced by a qualified person.

10. If the power cord or connection wire is not long enough, please get the specialized power cord or connection wire from the manufacture or distributor. Prohibit prolong the wire by yourself.

11. For the air conditioner without plug, an air switch must be installed in the circuit. The air switch should be all-pole parting and the contact parting distance should be more than 1/8 inch.

12. Make sure all wires and pipes are connected properly and the valves are opened before energizing.

13. Check if there is electric leakage on the unit body. If yes, please eliminate the electric leakage.

14. Replace the fuse with a new one of the same specification if it is burnt down; don't replace it with a cooper wire or conducting wire.

15. If the unit is to be installed in a humid place, the circuit breaker must be installed.

Installation Safety Precautions:

1. Select the installation location according to the requirement of this manual.(See the requirements in installation part)
2. Handle unit transportation with care; the unit should not be carried by only one person if it is more than 44.09lb.
3. When installing the indoor unit and outdoor unit, a sufficient fixing bolt must be installed; make sure the installation support is firm.
4. Ware safety belt if the height of working is above 78 3/4 inch.
5. Use equipped components or appointed components during installation.
6. Make sure no foreign objects are left in the unit after finishing installation.

Refrigerant Safety Precautions:


1. Avoid contact between refrigerant and fire as it generates poisonous gas; Prohibit prolong the connection pipe by welding.
2. Apply specified refrigerant only. Never have it mixed with any other refrigerant. Never have air remain in the refrigerant line as it may lead to rupture or other hazards.
3. Make sure no refrigerant gas is leaking out when installation is completed.
4. If there is refrigerant leakage, please take sufficient measure to minimize the density of refrigerant.
5. Never touch the refrigerant piping or compressor without wearing glove to avoid scald or frostbite.

Improper installation may lead to fire hazard, explosion, electric shock or injury.

Main Tools for Installation and Maintenance

| | | |
|--|---|--|
| <p>1. Level meter, measuring tape</p>  | <p>2. Screw driver</p>  | <p>3. Impact drill, drill head, electric drill</p>  |
| <p>4. Electroprobe</p>  | <p>5. Universal meter</p>  | <p>6. Torque wrench, open-end wrench, inner hexagon spanner</p>  |
| <p>7. Electronic leakage detector</p>  | <p>8. Vacuum pump</p>  | <p>9. Pressure meter</p>  |
| <p>10. Pipe pliers, pipe cutter</p>  | <p>11. Pipe expander, pipe bender</p>  | <p>12. Soldering appliance, refrigerant container</p>  |

Installation procedures



Note: this flow is only for reference; please find the more detailed installation steps in this section.

8.2 Installation Parts-checking

| No. | Name | No. | Name |
|-----|------------------------------|-----|---|
| 1 | Indoor unit | 8 | Sealing gum |
| 2 | Outdoor unit | 9 | Wrapping tape |
| 3 | Connection pipe | 10 | Support of outdoor unit |
| 4 | Drainage pipe | 11 | Fixing screw |
| 5 | Wall-mounting frame | 12 | Drainage plug(cooling and heating unit) |
| 6 | Connecting cable(power cord) | 13 | Owner's manual, remote controller |
| 7 | Wall pipe | | |

⚠ Note:

- 1.Please contact the local agent for installation.
- 2.Don't use unqualified power cord.

8.3 Selection of Installation Location

1. Basic Requirement:

Installing the unit in the following places may cause malfunction. If it is unavoidable, please consult the local dealer:

- (1) The place with strong heat sources, vapors, flammable or explosive gas, or volatile objects spread in the air.
- (2) The place with high-frequency devices (such as welding machine, medical equipment).
- (3) The place near coast area.
- (4) The place with oil or fumes in the air.
- (5) The place with sulfureted gas.
- (6) Other places with special circumstances.

2. Indoor Unit:

- (1) There should be no obstruction near air inlet and air outlet.
- (2) Select a location where the condensation water can be dispersed easily and won't affect other people.
- (3) Select a location which is convenient to connect the outdoor unit and near the power socket.
- (4) Select a location which is out of reach for children.
- (5) The location should be able to withstand the weight of indoor unit and won't increase noise and vibration.
- (6) The appliance must be installed 98 3/7inch above floor.
- (7) Don't install the indoor unit right above the electric appliance.
- (8) The appliance shall not be installed in the laundry.

3. Outdoor Unit:

- (1) Select a location where the noise and outflow air emitted by the outdoor unit will not affect neighborhood.
- (2) The location should be well ventilated and dry, in which the outdoor unit won't be exposed directly to sunlight or strong wind.
- (3) The location should be able to withstand the weight of outdoor unit.
- (4) Make sure that the installation follows the requirement of installation dimension diagram.
- (5) Select a location which is out of reach for children and far away from animals or plants.If it is unavoidable, please add fence for safety purpose.

8.4 Electric Connection Requirement

1. Safety Precaution

- (1) Must follow the electric safety regulations when installing the unit.
- (2) According to the local safety regulations, use qualified power supply circuit and air switch.
- (3) Make sure the power supply matches with the requirement of air conditioner. Unstable power supply or incorrect wiring may result in electric shock,fire hazard or malfunction. Please install proper power supply cables before using the air conditioner.
- (4) Properly connect the live wire, neutral wire and grounding wire of power socket.
- (5) Be sure to cut off the power supply before proceeding any work related to electricity and safety.
- (6) Do not put through the power before finishing installation.
- (7) For appliances with type Y attachment,the instructions shall contain the substance of thefollowing.If the supply cord is damaged,it must be replaced by the manufacturer,its service agent or similarly qualified persons in order to avoid a hazard.
- (8) The temperature of refrigerant circuit will be high, please keep the interconnection cable away from the copper tube.

2. Grounding Requirement:

- (1) The air conditioner is first class electric appliance. It must be properly grounding with specialized grounding device by a professional. Please make sure it is always grounded effectively, otherwise it may cause electric shock.
- (2) The yellow-green wire in air conditioner is grounding wire, which can't be used for other purposes.
- (3) The grounding resistance should comply with national electric safety regulations.
- (4) The appliance must be positioned so that the plug is accessible.
- (5) An all-pole disconnection switch having a contact separation of at least 3mm in all poles should be connected in fixed wiring.
- (6) Including an air switch with suitable capacity, please note the following table. Air switch should be included magnet buckle and heating buckle function, it can protect the circuit-short and overload. (Caution: please do not use the fuse only for protect the circuit)

8.5 Installation of Indoor Unit

1. Choosing Installation location

Recommend the installation location to the client and then confirm it with the client.


2. Install Wall-mounting Frame

- (1) Hang the wall-mounting frame on the wall; adjust it in horizontal position with the level meter and then point out the screw fixing holes on the wall.
- (2) Drill the screw fixing holes on the wall with impact drill (the specification of drill head should be the same as the plastic expansion particle) and then fill the plastic expansion particles in the holes.


(3) Fix the wall-mounting frame on the wall with tapping screws (ST4.2X25TA) and then check if the frame is firmly installed by pulling the frame. If the plastic expansion particle is loose, please drill another fixing hole nearby.

3. Install Wall-mounting Frame

(1) Choose the position of piping hole according to the direction of outlet pipe. The position of piping hole should be a little lower than the wall-mounted frame.(As show in Fig.1)



(2) Open a piping hole with the diameter of 2 1/6inch on the selected outlet pipe position. In order to drain smoothly, slant the piping hole on the wall slightly downward to the outdoor side with the gradient of 5-10°.(As show in Fig.2)





⚠ Note:

- (1) Pay attention to dust prevention and take relevant safety measures when opening the hole.
- (2) The plastic expansion particles are not provided and should be bought locally.



4. Outlet Pipe

- (1) The pipe can be led out in the direction of right, rear right, left or rear left.(As show in Fig.3)
- (2) When selecting leading out the pipe from left or right, please cut off the corresponding hole on the bottom case.(As show in Fig.4)



5. Connect the Pipe of Indoor Unit

- (1) Aim the pipe joint at the corresponding bellmouth.(As show in Fig.5)
- (2) Pretightening the union nut with hand.
- (3) Adjust the torque force by referring to the following sheet. Place the open-end wrench on the pipe joint and place the torque wrench on the union nut. Tighten the union nut with torque wrench.(As show in Fig.6)
- (4) Wrap the indoor pipe and joint of connection pipe with insulating pipe, and then wrap it with tape.(As show in Fig.7)




Refer to the following table for wrench moment of force:

| Hex nut diameter(inch) | Tightening torque(ft-lbf) |
|------------------------|---------------------------|
| Φ1/4 | 11~14.7 |
| Φ3/8 | 22.8~29.5 |
| Φ1/2 | 33.2~40.6 |
| Φ5/8 | 44.3~47.9 |
| Φ3/4 | 51.6~55.3 |


6. Install Drain Hose

- (1) Connect the drain hose to the outlet pipe of indoor unit.(As show in Fig.8)
- (2) Bind the joint with tape.(As show in Fig.9)




⚠ Note:

- (1) Add insulating pipe in the indoor drain hose in order to prevent condensation.
- (2) The plastic expansion particles are not provided.(As show in Fig.10)




7. Connect Wire of Indoor Unit

(1) Open the panel, remove the screw on the wiring cover and then take down the cover.(As show in Fig.11)



(2) Fix the wire crossing board on connection wire sleeve at the bottom case; let the connection wire sleeve go through the wire crossing hole at the back of indoor unit, and then pull it out from the front.(As show in Fig.12)



(3) Remove the wire clip; connect the power connection wire to the wiring terminal; tighten the screw and then fix the power connection wire with wire clip.(As show in Fig.13)




Fig.13

(4) Put wiring cover back and then tighten the screw.
(5) Close the panel.

⚠ Note:

- (1) All wires of indoor unit and outdoor unit should be connected by a professional.
- (2) If the length of power connection wire is insufficient, please contact the supplier for a new one. Avoid extending the wire by yourself.
- (3) For the air conditioner with plug, the plug should be reachable after finishing installation.
- (4) For the air conditioner without plug, an air switch must be installed in the line. The air switch should be all-pole parting and the contact parting distance should be more than 1/8inch.


8. Bind up Pipe

(1) Bind up the connection pipe, power cord and drain hose with the band.(As show in Fig.14)

(2) Reserve a certain length of drain hose and power cord for installation when binding them. When binding to a certain degree, separate the indoor power and then separate the drain hose.(As show in Fig.15)

(3) Bind them evenly.

(4) The liquid pipe and gas pipe should be bound separately at the end.



⚠ Note:

- (1) The power cord and control wire can't be crossed or winding.
- (2) The drain hose should be bound at the bottom.

9. Hang the Indoor Unit

(1) Put the bound pipes in the wall pipe and then make them pass through the wall hole.

(2) Hang the indoor unit on the wall-mounting frame.

(3) Stuff the gap between pipes and wall hole with sealing gum.

(4) Fix the wall pipe.

(As show in Fig.16)

(5) Check if the indoor unit is installed firmly and closed to the wall.(As show in Fig.17)




Fig.16




Fig.17

⚠ Note:

Do not bend the drain hose too excessively in order to prevent blocking.

8.6 Installation of Outdoor Unit

1. Fix the Support of Outdoor Unit(Select it according to the actual installation situation)

- (1) Select installation location according to the house structure.
- (2) Fix the support of outdoor unit on the selected location with expansion screws.

⚠ Note:

- (1) Take sufficient protective measures when installing the outdoor unit.
- (2) Make sure the support can withstand at least four times the unit weight.
- (3) The outdoor unit should be installed at least 1 1/6inch above the floor in order to install drain joint.(As show in Fig.18)
- (4) For the unit with cooling capacity of 2300W~5000W, 6 expansion screws are needed; for the unit with cooling capacity of 6000W~8000W, 8 expansion screws are needed; for the unit with cooling capacity of 10000W~16000W, 10 expansion screws are needed.




Fig.18




Fig.19

2. Install Drain Joint(Only for cooling and heating unit)

- (1) Connect the outdoor drain joint into the hole on the chassis.
 - (2) Connect the drain hose into the drain vent.
- (As show in Fig.19)

3. Fix Outdoor Unit

- (1) Place the outdoor unit on the support.
 - (2) Fix the foot holes of outdoor unit with bolts.
- (As show in Fig.20)




Fig.20




Fig.21

4. Connect Indoor and Outdoor Pipes

- (1) Remove the screw on the right cable cross plate sub-assy and valve cover of outdoor unit and then remove the cable cross plate sub-assy and valve cover.(As show in Fig.21)
- (2) Remove the screw cap of valve and aim the pipe joint at the bellmouth of pipe.(As show in Fig.22)




Fig.22

- (3) Pretightening the union nut with hand.
- (4) Tighten the union nut with torque wrench .

Refer to the following table for wrench moment of force:

| Hex nut diameter(inch) | Tightening torque(ft·lbf) |
|------------------------|---------------------------|
| Φ1/4 | 11~14.7 |
| Φ3/8 | 22.8~29.5 |
| Φ1/2 | 33.2~40.6 |
| Φ5/8 | 44.3~47.9 |
| Φ3/4 | 51.6~55.3 |

5. Connect Outdoor Electric Wire

- (1) Put power connection wire and power wire through the wire-passing hole.
- (2) Remove the wire clip; connect the power connection wire and power wire to the wiring terminal; fix them with screws.(As show in Fig.23)
- (3) Fix the power connection wire and power wire with wire clip.
- (4) Install the cable cross plate sub-assy.





Fig.23

⚠ Note:

- (1) After tightening the screw, pull the power cord slightly to check if it is firm.
- (2) Never cut the power connection wire to prolong or shorten the distance.
- (3) The connecting wire and connection pipe cannot touch each other.
- (4) Top cover of outdoor unit and electric box assembly should be fixed by the screw. Otherwise, it can cause a fire, or short circuit caused by water or dust.

Install the over line pipe



6. Neaten the Pipes

- (1) The pipes should be placed along the wall, bent reasonably and hidden possibly. Min. semidiameter of bending the pipe is 4inch.
- (2) If the outdoor unit is higher than the wall hole, you must set a U-shaped curve in the pipe before pipe goes into the room, in order to prevent rain from getting into the room.(As show in Fig.24)





Fig.24

Fig.25

⚠ Note:


- (1) The through-wall height of drain hose shouldn't be higher than the outlet pipe hole of indoor unit.(As show in Fig.25)
- (2) Slant the drain hose slightly downwards. The drain hose can't be curved, raised and fluctuant, etc.(As show in Fig.26)
- (3) The water outlet can't be placed in water in order to drain smoothly.(As show in Fig.27)



8.7 Vacuum Pumping and Leak Detection

1. Use Vacuum Pump

- (1) Remove the valve caps on the liquid valve and gas valve and the nut of refrigerant charging vent.
- (2) Connect the charging hose of piezometer to the refrigerant charging vent of gas valve and then connect the other charging hose to the vacuum pump.
- (3) Open the piezometer completely and operate for 10-15min to check if the pressure of piezometer remains in -0.1MPa.
- (4) Close the vacuum pump and maintain this status for 1-2min to check if the pressure of piezometer remains in -0.1MPa. If the pressure decreases, there may be leakage.
- (5) Remove the piezometer, open the valve core of liquid valve and gas valve completely with inner hexagon spanner.
- (6) Tighten the screw caps of valves and refrigerant charging vent.(As show in Fig.28)



2. Leakage Detection

- (1) With leakage detector:
Check if there is leakage with leakage detector.
- (2) With soap water:
If leakage detector is not available, please use soap water for leakage detection. Apply soap water at the suspected position and keep the soap water for more than 3min. If there are air bubbles coming out of this position, there's a leakage.

8.8 Check after Installation and Test Operation

1. Check after Installation

Check according to the following requirement after finishing installation.

| No. | Items to be checked | Possible malfunction |
|-----|--|---|
| 1 | Has the unit been installed firmly? | The unit may drop, shake or emit noise. |
| 2 | Have you done the refrigerant leakage test? | It may cause insufficient cooling (heating) capacity. |
| 3 | Is heat insulation of pipeline sufficient? | It may cause condensation and water dripping. |
| 4 | Is water drained well? | It may cause condensation and water dripping. |
| 5 | Is the voltage of power supply according to the voltage marked on the nameplate? | It may cause malfunction or damage the parts. |
| 6 | Is electric wiring and pipeline installed correctly? | It may cause malfunction or damage the parts. |
| 7 | Is the unit grounded securely? | It may cause electric leakage. |
| 8 | Does the power cord follow the specification? | It may cause malfunction or damage the parts. |
| 9 | Is there any obstruction in air inlet and air outlet? | It may cause insufficient cooling (heating). |
| 10 | The dust and sundries caused during installation are removed? | It may cause malfunction or damaging the parts. |
| 11 | The gas valve and liquid valve of connection pipe are open completely? | It may cause insufficient cooling (heating) capacity. |

2. Test Operation

- (1) Preparation of test operation
 - The client approves the air conditioner installation.
 - Specify the important notes for air conditioner to the client.
- (2) Method of test operation
 - Put through the power, press ON/OFF button on the remote controller to start operation.
 - Press MODE button to select AUTO, COOL, DRY, FAN and HEAT to check whether the operation is normal or not.
 - If the ambient temperature is lower than 60.8°F, the air conditioner can't start cooling.

9. Maintenance

9.1 Error Code List

1. Malfunction display requirement

When there are several malfunctions, they will be displayed circularly.

2. Malfunction display method

(1) Hardware malfunction: immediate display; refer to "error code list";

(2) Operation state: immediate display; refer to "error code list";

(3) Other malfunctions: it is displayed after the compressor stops for 200s; refer to "error code list".

Note: when the compressor is restarted, the malfunction display delay time (200s) is cleared.

3. Display control viaremote controller

Enter display control: press light button successively for 4 times within 3s to display the corresponding malfunction code;

Exit display control: pressing light button successively for 4 times within 3s or after display is shown for 5min, the display will terminate.

| No. | Malfunction Name | Display Method of Indoor Unit | | | Display Method of Outdoor Unit | | | A/C status | Possible Causes | |
|-----|---|-------------------------------|---|--------------------------|--------------------------------|---|---------------------------|--------------------------|--|--|
| | | Dual-8 Code Display | Indicator Display (during blinking, ON 0.5s and OFF 0.5s) | | | Indicator has 3 kinds of display status and during blinking, ON 0.5s and OFF 0.5s | | | | |
| | | | Power Indicator | Cool Indicator | Heating Indicator | Yellow Indicator | Red Indicator | | | Green Indicator |
| 1 | High pressure protection of system | E1 | OFF 3s and blink once | | | | | | During cooling and drying operation, except indoor fan operates, all loads stop operation. During heating operation, the complete unit stops. | Possible reasons: 1. Refrigerant was superabundant; 2. Poor heat exchange (including fifth blockage of heat exchanger and bad radiating environment); Ambient temperature is too high. |
| 2 | Antifreezing protection | E2 | OFF 3S and blink twice | | | | OFF 1S and blink 3 times | | During cooling and drying operation, compressor and outdoor fan stop while indoor fan operates. | 1. Poor air-return in indoor unit; 2. Fan speed is abnormal; 3. Evaporator is dirty. |
| 3 | In defect of refrigerant | F0 | | | | | | OFF 1S and blink 9 times | The Dual-8 Code Display will show F0 and the complete unit stops. | 1.In defect of refrigerant; 2.Indoor evaporator temperature sensor works abnormally; 3.The unit has been plugged up somewhere. |
| 4 | High discharge temperature protection of compressor | E4 | OFF 3S and blink 4 times | | | | OFF 1S and blink 7 times | | During cooling and drying operation, compressor and outdoor fan stop while indoor fan operates. During heating operation, all loads stop. | Please refer to the malfunction analysis (discharge protection, overload). |
| 5 | Overcurrent protection | E5 | OFF 3S and blink 5 times | | | | OFF 1S and blink 5 times | | During cooling and drying operation, compressor and outdoor fan stop while indoor fan operates. During heating operation, all loads stop. | 1. Supply voltage is unstable; 2. Supply voltage is too low and load is too high; 3. Evaporator is dirty. |
| 6 | Communication Malfunction | E6 | OFF 3S and blink 6 times | | | | Always ON | | During cooling operation, compressor stops while indoor fan motor operates. During heating operation, the complete unit stops. | Refer to the corresponding malfunction analysis. |
| 7 | High temperature resistant protection | E8 | OFF 3S and blink 8 times | | | | OFF 1S and blink 6 times | | During cooling operation: compressor will stop while indoor fan will operate. During heating operation, the complete unit stops. | Refer to the malfunction analysis (overload, high temperature resistant). |
| 8 | EEPROM malfunction | EE | | | OFF 3S and blink 15 times | | OFF 1S and blink 11 times | | During cooling and drying operation, compressor will stop while indoor fan will operate; During heating operation, the complete unit will stop | Replace outdoor control panel AP1 |
| 9 | Limit/ decrease frequency due to high temperature of module | EU | | OFF 3S and blink 6 times | OFF 3S and blink 6 times | | | | All loads operate normally, while operation frequency for compressor is decreased | Discharging after the complete unit is de-energized for 20mins, check whether the thermal grease on IPM Module of outdoor control panel AP1 is sufficient and whether the radiator is inserted tightly. If its no use, please replace control panel AP1. |
| 10 | Malfunction protection of jumper cap | C5 | OFF 3S and blink 15 times | | | | | | Wireless remote receiver and button are effective, but can not dispose the related command | 1. No jumper cap insert on mainboard. 2. Incorrect insert of jumper cap. 3. Jumper cap damaged. 4. Abnormal detecting circuit of mainboard. |

| No. | Malfunction Name | Display Method of Indoor Unit | | | Display Method of Outdoor Unit | | | A/C status | Possible Causes | |
|-----|--|-------------------------------|---|------------------------------|--------------------------------|---|--------------------------|------------|---|---|
| | | Dual-3 Code Display | Indicator Display (during blinking, ON 0.5s and OFF 0.5s) | | | Indicator has 3 kinds of display status and during blinking, ON 0.5s and OFF 0.5s | | | | |
| | | | Power Indicator | Cool Indicator | Heating Indicator | Yellow Indicator | Red Indicator | | | Green Indicator |
| 11 | Gathering refrigerant | Fo | OFF 3S and blink 1 times | OFF 3S and blink 1 times | | OFF 1S and blink 17 times | | | When the outdoor unit receive signal of Gathering refrigerant ,the system will be forced to run under cooling mode for gathering refrigerant | Nominal cooling mode |
| 12 | Indoor ambient temperature sensor is open/short circuited | F1 | | OFF 3S and blink once | | | | | During cooling and drying operation, indoor unit operates while other loads will stop; during heating operation, the complete unit will stop operation. | 1. Loosening or bad contact of indoor ambient temp. sensor and mainboard terminal. 2. Components in mainboard fell down leads short circuit. 3. Indoor ambient temp. sensor damaged.(check with sensor resistance value chart) 4. Mainboard damaged. |
| 13 | Indoor evaporator temperature sensor is open/short circuited | F2 | | OFF 3S and blink twice | | | | | AC stops operation once reaches the setting temperature. Cooling, drying: internal fan motor stops operation while other loads stop operation; heating: AC stop operation | 1. Loosening or bad contact of Indoor evaporator temp. sensor and mainboard terminal. 2. Components on the mainboard fall down leads short circuit. 3. Indoor evaporator temp. sensor damaged.(check temp. sensor value chart for testing) 4. Mainboard damaged. |
| 14 | Outdoor ambient temperature sensor is open/short circuited | F3 | | OFF 3S and blink 3 times | | | OFF 1S and blink 6 times | | During cooling and drying operating, compressor stops while indoor fan operates; During heating operation, the complete unit will stop operation | Outdoor temperature sensor hasnt been connected well or is damaged. Please check it by referring to the resistance table for temperature sensor) |
| 15 | Outdoor condenser temperature sensor is open/short circuited | F4 | | OFF 3S and blink 4 times | | | OFF 1S and blink 5 times | | During cooling and drying operation, compressor stops while indoor fan will operate; During heating operation, the complete unit will stop operation. | Outdoor temperature sensor hasnt been connected well or is damaged. Please check it by referring to the resistance table for temperature sensor) |
| 16 | Outdoor discharge temperature sensor is open/short circuited | F5 | | OFF 3S and blink 5 times | | | OFF 1S and blink 7 times | | During cooling and drying operation, compressor will sop after operating for about 3 mins, while indoor fan will operate; During heating operation, the complete unit will stop after operating for about 3 mins. | 1.Outdoor temperature sensor hasnt been connected well or is damaged. Please check it by referring to the resistance table for temperature sensor) 2.The head of temperature sensor hasnt been inserted into the copper tube |
| 17 | Limit/ decrease frequency due to overload | F6 | | OFF 3S and blink for 6 times | | | OFF 1S and blink 3 times | | All loads operate normally, while operation frequency for compressor is decreased | Refer to the malfunction analysis (overload, high temperature resistant) |
| 18 | Decrease frequency due to overcurrent | F8 | | OFF 3S and blink 8 times | | | OFF 1S and blink once | | All loads operate normally, while operation frequency for compressor is decreased | The input supply voltage is too low; System pressure is too high and overload |

| No. | Malfunction Name | Display Method of Indoor Unit | | | Display Method of Outdoor Unit | | | A/C status | Possible Causes | |
|-----|--|-------------------------------|---|---|---|---|---------------|---------------------------|--|--|
| | | Dual-8 Code Display | Indicator Display (during blinking, ON 0.5s and OFF 0.5s) | | | Indicator has 3 kinds of display status and during blinking, ON 0.5s and OFF 0.5s | | | | |
| | | | Power Indicator | Cool Indicator | Heating Indicator | Yellow Indicator | Red Indicator | | | Green Indicator |
| 19 | Decrease frequency due to high air discharge | F9 | | OFF 3S and blink 9 times | | | | OFF 1S and blink twice | All loads operate normally, while operation frequency for compressor is decreased | Overload or temperature is too high; Refrigerant is insufficient; Malfunction of electric expansion valve (EKV) |
| 20 | Limit/decrease frequency due to antifreezing | FH | | OFF 3S and blink 2 times | OFF 3S and blink 2 times | | | OFF 1S and blink 4 times | All loads operate normally, while operation frequency for compressor is decreased | Poor air-return in indoor unit or fan speed is too low |
| 21 | Voltage for DC bus-bar is too high | PH | | OFF 3S and blink 11 times | | | | OFF 1S and blink 13 times | During cooling and drying operation, compressor will stop while indoor fan will operate; During heating operation, the complete unit will stop operation. | 1. Measure the voltage of position L and N on wiring board (XT), if the voltage is higher than 265VAC, turn on the unit after the supply voltage is increased to the normal range. 2.If the AC input is normal, measure the voltage of electrolytic capacitor C on control panel (AP1), if its normal, theres malfunction for the circuit, please replace the control panel (AP1) |
| 22 | Voltage of DC bus-bar is too low | PL | | | OFF 3S and blink 21 times | | | OFF 1S and blink 12 times | During cooling and drying operation, compressor will stop while indoor fan will operate; During heating operation, the complete unit will stop | 1. Measure the voltage of position L and N on wiring board (XT), if the voltage is higher than 150VAC, turn on the unit after the supply voltage is increased to the normal range. 2.If the AC input is normal, measure the voltage of electrolytic capacitor C on control panel (AP1), if its normal, theres malfunction for the circuit, please replace the control panel (AP1) |
| 23 | Compressor Min frequency in test state | P0 | | (during blinking, ON 0.25s and OFF 0.25s) | (during blinking, ON 0.25s and OFF 0.25s) | | | | | Showing during min. cooling or min. heating test |
| 24 | Compressor rated frequency in test state | P1 | | (during blinking, ON 0.25s and OFF 0.25s) | (during blinking, ON 0.25s and OFF 0.25s) | | | | | Showing during nominal cooling or nominal heating test |
| 25 | Compressor maximum frequency in test state | P2 | | (during blinking, ON 0.25s and OFF 0.25s) | (during blinking, ON 0.25s and OFF 0.25s) | | | | | Showing during max. cooling or max. heating test |


| No. | Malfunction Name | Display Method of Indoor Unit | | | Display Method of Outdoor Unit | | | A/C status | Possible Causes |
|-----|---|-------------------------------|---|---|---|--------------------------|---------------|---|--|
| | | Dual-8 Code Display | Indicator Display (during blinking, ON 0.5s and OFF 0.5s) | | Indicator has 3 kinds of display status and during blinking, ON 0.5s and OFF 0.5s | | | | |
| | | | Power Indicator | Cool Indicator | Heating Indicator | Yellow Indicator | Red Indicator | | |
| 26 | Compressor intermediate frequency in test state | P3 | | (during blinking, ON 0.25s and OFF 0.25s) | (during blinking, ON 0.25s and OFF 0.25s) | | | | Showing during middle cooling or middle heating test |
| 27 | Overcurrent protection of phase current for compressor | P5 | | OFF 3S and blink 15 times | | | | During cooling and drying operation, compressor will stop while indoor fan will operate; During heating operation, the complete unit will stop operation. | Refer to the malfunction analysis (IPM protection, loss of synchronism protection and overcurrent protection of phase current for compressor). |
| 28 | Charging malfunction of capacitor | PU | | | OFF 3S and blink 17 times | | | During cooling and drying operation, compressor will stop while indoor fan will operate; During heating operation, the complete unit will stop | Refer to the part three—charging malfunction analysis of capacitor |
| 29 | Malfunction of module temperature sensor circuit | P7 | | | OFF 3S and blink 18 times | | | During cooling and drying operation, compressor will stop while indoor fan will operate; During heating operation, the complete unit will stop | Replace outdoor control panel AP1 |
| 30 | Module high temperature protection | P8 | | | OFF 3S and blink 19 times | | | During cooling operation, compressor will stop while indoor fan will operate; During heating operation, the complete unit will stop | After the complete unit is de-energized for 20mins, check whether the thermal grease on IPM Module of outdoor control panel AP1 is sufficient and whether the radiator is inserted tightly. If its no use, please replace control panel AP1. |
| 31 | Decrease frequency due to high temperature resistant during heating operation | H0 | | | OFF 3S and blink 10 times | | | All loads operate normally, while operation frequency for compressor is decreased | Refer to the malfunction analysis (overload, high temperature resistant) |
| 32 | Static dedusting protection | H2 | | | OFF 3S and blink twice | | | | |
| 33 | Overload protection for compressor | H3 | | | OFF 3S and blink 3 times | OFF 1S and blink 8 times | | During cooling and drying operation, compressor will stop while indoor fan will operate; During heating operation, the complete unit will stop operation. | 1. Wiring terminal OVC-COMP is loosened. In normal state, the resistance for this terminal should be less than 10hm. 2. Refer to the malfunction analysis (discharge protection, overload) |

| No. | Malfunction Name | Display Method of Indoor Unit | | | Display Method of Outdoor Unit | | | A/C status | Possible Causes | |
|-----|--|-------------------------------|---|----------------|--------------------------------|---|---------------------------|------------|---|--|
| | | Dual-8 Code Display | Indicator Display (during blinking, ON 0.5s and OFF 0.5s) | | | Indicator has 3 kinds of display status and during blinking, ON 0.5s and OFF 0.5s | | | | |
| | | | Power Indicator | Cool Indicator | Heating Indicator | Yellow Indicator | Red Indicator | | | Green Indicator |
| 34 | System is abnormal | H4 | | | OFF 3S and blink 4 times | OFF 1S and blink 6 times | | | During cooling and drying operation, compressor will stop while indoor fan will operate; During heating operation, the complete unit will stop operation. | Refer to the malfunction analysis (overload, high temperature resistant) |
| 35 | IPM protection | H5 | | | OFF 3S and blink 5 times | OFF 1S and blink 4 times | | | During cooling and drying operation, compressor will stop while indoor fan will operate; During heating operation, the complete unit will stop operation. | Refer to the malfunction analysis (IPM protection, loss of synchronism protection and overcurrent protection of phase current for compressor. |
| 36 | Module temperature is too high | H5 | | | OFF 3S and blink 5 times | OFF 1S and blink 10 times | | | | |
| 37 | Internal motor (fan motor) do not operate | H6 | OFF 3S and blink 11 times | | | | | | Internal fan motor, external fan motor, compressor and electric heater stop operation,guide louver stops at present location. | 1. Bad contact of DC motor feedback terminal. 2. Bad contact of DC motor control end. 3. Fan motor is stalling. 4. Motor malfunction. 5. Malfunction of mainboard rev detecting circuit. |
| 38 | Desynchronizing of compressor | H7 | | | OFF 3S and blink 7 times | | | | During cooling and drying operation, compressor will stop while indoor fan will operate; During heating operation, the complete unit will stop operation. | Refer to the malfunction analysis (IPM protection, loss of synchronism protection and overcurrent protection of phase current for compressor. |
| 39 | PFC protection | HC | | | OFF 3S and blink 6 times | OFF 1S and blink 14 times | | | During cooling and drying operation, compressor will stop while indoor fan will operate; During heating operation, the complete unit will stop operation. | Refer to the malfunction analysis |
| 40 | Outdoor DC fan motor malfunction | L3 | OFF 3S and blink 23 times | | | | OFF 1S and blink 14 times | | Outdoor DC fan motor malfunction lead to compressor stop operation, | DC fan motor malfunction or system blocked or the connector loosed |
| 41 | power protection | L9 | OFF 3S and blink 20 times | | | OFF 1S and blink 9 times | | | compressor stop operation and Outdoor fan motor will stop 30s latter , 3 minutes latter fan motor and compressor will restart | To protect the electrical components when detect high power |
| 42 | Indoor unit and outdoor unit doesn't match | LP | OFF 3S and blink 19 times | | | OFF 1S and blink 16 times | | | compressor and Outdoor fan motor can't work | Indoor unit and outdoor unit doesn't match |
| 43 | Failure start-up | LC | | | OFF 3S and blink 11 times | | | | During cooling and drying operation, compressor will stop while indoor fan will operate; During heating operation, the complete unit will stop operation. | Refer to the malfunction analysis |


| No. | Malfunction Name | Display Method of Indoor Unit | | | Display Method of Outdoor Unit | | | A/C status | Possible Causes | |
|-----|---|-------------------------------|---|---------------------------|--------------------------------|---|---------------------------|------------|---|---|
| | | Dual-8 Code Display | Indicator Display (during blinking, ON 0.5s and OFF 0.5s) | | | Indicator has 3 kinds of display status and during blinking, ON 0.5s and OFF 0.5s | | | | |
| | | | Power Indicator | Cool Indicator | Heating Indicator | Yellow Indicator | Red Indicator | | | Green Indicator |
| 44 | Malfunction of phase current detection circuit for compressor | U1 | | | OFF 3S and blink 13 times | | | | During cooling and drying operation, compressor will stop while indoor fan will operate; During heating operation, the complete unit will stop | Replace outdoor control panel AP1 |
| 45 | Malfunction of voltage dropping for DC bus-bar | U3 | | | OFF 3S and blink 20 times | | | | During cooling and drying operation, compressor will stop while indoor fan will operate; During heating operation, the complete unit will stop | Supply voltage is unstable |
| 46 | Malfunction of complete units current detection | U5 | | OFF 3S and blink 13 times | | | | | During cooling and drying operation, the compressor will stop while indoor fan will operate; During heating operating, the complete unit will stop operation. | Theres circuit malfunction on outdoor units control panel AP1, please replace the outdoor units control panel AP1. |
| 47 | The four-way valve is abnormal | U7 | | OFF 3S and blink 20 times | | | | | If this malfunction occurs during heating operation, the complete unit will stop operation. | 1. Supply voltage is lower than AC175V; 2. Wiring terminal 4V is loosened or broken; 3. 4V is damaged, please replace 4V. |
| 48 | Zero-crossing malfunction of outdoor unit | U9 | OFF 3S and blink 18 times | | | | | | During cooling operation, compressor will stop while indoor fan will operate; during heating, the complete unit will stop operation. | Replace outdoor control panel AP1 |
| 49 | Frequency limiting (power) | | | | | | OFF 1S and blink 13 times | | | |
| 50 | Compressor running | | | | | OFF 1S and blink once | | | | |
| 51 | The temperature for turning on the unit is reached | | | | | | OFF 1S and blink 8 times | | | |
| 52 | Frequency limiting (module temperature) | | | | | | OFF 1S and blink 11 times | | | |

9.2 Troubleshooting for Main Malfunction


1. Malfunction of Temperature Sensor F1, F2




3. Malfunction of Protection of Jumper Cap C5




4. Malfunction of Zero-crossing Inspection Circuit Malfunction of the IDU Fan Motor U8



5. Malfunction of communication E6






8. Temperature sensor malfunction

Main detection points:

- Is outdoor ambient temperature within the normal range?
- Is indoor and outdoor fan running normally?
- Is the radiating environment inside and outside the unit good enough?

Malfunction diagnosis process:




11. Diagnosis of overload and discharge malfunction

Main detection points:


- Is electric expansion valve well connected? Is it damaged?
- Is refrigerant leaked?
- Is overload wire connection normal?

Malfunction diagnosis process:



Air purging

CAUTION: Do not leak the gas in the air during Air purging.



* Procedure


- (1) Connect the charge hose from the manifold valve to the service port of the gas side packed valve.
- (2) Connect the charge hose to the port of the vacuum pump.
- (3) Open fully the low pressure side handle of the gauge manifold valve.
- (4) Operate the vacuum pump to begin evacuating. Perform evacuating for about 15 minutes if the piping length is 20 meters (15 minutes for 20 meters) (assuming a pump capacity of 27 liters per minute). Confirm that the compound pressure gauge reading is -101 kPa (-76 cmHg).
- (5) Close the low pressure valve handle of gauge manifold.
 - Check the flare connections for gas leakage.
- (6) Use torque wrench to tighten the service port nut to a torque of 1.8 kg.cm.
- (7) Set the 3-way valve to the back seat.
- (8) Mount the valve stem nuts to the 2-way and 3-way valves.
- (9) Check for gas leakage.
 - At this time, especially check for gas leakage from the 2-way and 3-way valves stem nuts, and from the service port nut.

CAUTION:

If gas leakage are discovered in step 5 above, take the following measures :

If the gas leaks stop when the piping connections are tightened further, continue working from step 6. If the gas leaks do not stop when the connections are retightened, repair the location of the leak, discharge all of the gas through the service port, and then recharge with the specified amount of gas from a gas cylinder.

Re-air Purging



• Procedure

(1) Confirm that both the liquid side valve and the gas side valve are set to the closed position.

(2) Connect the charge set and a gas cylinder to the service port of the Gas side valve.

– Leave the valve on the gas cylinder closed.

(3) Air purging.

– Open the valves on the gas cylinder and the charge set. Purge the air by loosening the flare nut on the liquid side valve approximately 45° or 3 seconds then closing it for 1 minute; repeat 3 times.

– After purging the air, use a torque wrench to tighten the flare nut on liquid side valve.

(4) Check for gas leakage.

– Check the flare connections for gas leakage.

(5) Discharge the refrigerant.

– Close the valve on the gas cylinder and discharge the refrigerant until the gauge indicates 3 to 5 kg/cm²g.

(6) Disconnect the charge set and the gas cylinder, and set the Liquid side and Gas side valves to the open position.

– Be sure to use a hexagonal wrench to operate the valve stems.

(7) Mount the valve stem nuts and the service port nut.


– Use torque wrench to tighten the service port nut to a torque of 1.8 kg.m.

– Be sure to check for gas leakage.

CAUTION: Do not leak the gas in the air during Air Purging.

Evacuation

(All amount of refrigerant leaked)



• Procedure

(1) Connect the vacuum pump to the center hose of charge set center hose

(2) Evacuation for approximately one hour.

– Confirm that the gauge needle has moved toward -76cmHg (vacuum of 4 mmHg or less).

(3) Close the valve (Lo side) on the charge set, turn off the vacuum pump, and confirm that the gauge needle does not move (approximately 5 minutes after turning off the vacuum pump).

(4) Disconnect the charge hose from the vacuum pump.

– Vacuum pump oil.

If the vacuum pump oil becomes dirty or depleted, replenish as needed.

9.4 Troubleshooting for Normal Malfunction

1. Air Conditioner Can't be Started Up

| Possible Causes | Discriminating Method (Air conditioner Status) | Troubleshooting |
|---|---|--|
| No power supply, or poor connection for power plug | After energization, operation indicator isn't bright and the buzzer can't give out sound | Confirm whether it's due to power failure. If yes, wait for power recovery. If not, check power supply circuit and make sure the power plug is connected well. |
| Wrong wire connection between indoor unit and outdoor unit, or poor connection for wiring terminals | Under normal power supply circumstances, operation indicator isn't bright after energization | Check the circuit according to circuit diagram and connect wires correctly. Make sure all wiring terminals are connected firmly |
| Electric leakage for air conditioner | After energization, room circuit breaker trips off at once | Make sure the air conditioner is grounded reliably Make sure wires of air conditioner is connected correctly Check the wiring inside air conditioner. Check whether the insulation layer of power cord is damaged; if yes, place the power cord. |
| Model selection for air switch is improper | After energization, air switch trips off | Select proper air switch |
| Malfunction of remote controller | After energization, operation indicator is bright, while no display on remote controller or buttons have no action. | Replace batteries for remote controller Repair or replace remote controller |

2. Poor Cooling (Heating) for Air Conditioner

| Possible Causes | Discriminating Method (Air conditioner Status) | Troubleshooting |
|--|---|---|
| Set temperature is improper | Observe the set temperature on remote controller | Adjust the set temperature |
| Rotation speed of the IDU fan motor is set too low | Small wind blow | Set the fan speed at high or medium |
| Filter of indoor unit is blocked | Check the filter to see it's blocked | Clean the filter |
| Installation position for indoor unit and outdoor unit is improper | Check whether the installation position is proper according to installation requirement for air conditioner | Adjust the installation position, and install the rainproof and sunproof for outdoor unit |
| Refrigerant is leaking | Discharged air temperature during cooling is higher than normal discharged wind temperature; Discharged air temperature during heating is lower than normal discharged wind temperature; Unit's pressure is much lower than regulated range | Find out the leakage causes and deal with it. Add refrigerant. |
| Malfunction of 4-way valve | Blow cold wind during heating | Replace the 4-way valve |
| Malfunction of capillary | Discharged air temperature during cooling is higher than normal discharged wind temperature; Discharged air temperature during heating is lower than normal discharged wind temperature; Unit's pressure is much lower than regulated range. If refrigerant isn't leaking, part of capillary is blocked | Replace the capillary |
| Flow volume of valve is insufficient | The pressure of valves is much lower than that stated in the specification | Open the valve completely |
| Malfunction of horizontal louver | Horizontal louver can't swing | Refer to point 3 of maintenance method for details |
| Malfunction of the IDU fan motor | The IDU fan motor can't operate | Refer to troubleshooting for H6 for maintenance method in details |
| Malfunction of the ODU fan motor | The ODU fan motor can't operate | Refer to point 4 of maintenance method for details |
| Malfunction of compressor | Compressor can't operate | Refer to point 5 of maintenance method for details |

3. Horizontal Louver Can't Swing

| Possible Causes | Discriminating Method (Air conditioner Status) | Troubleshooting |
|---|--|--|
| Wrong wire connection, or poor connection | Check the wiring status according to circuit diagram | Connect wires according to wiring diagram to make sure all wiring terminals are connected firmly |
| Stepping motor is damaged | Stepping motor can't operate | Repair or replace stepping motor |
| Main board is damaged | Others are all normal, while horizontal louver can't operate | Replace the main board with the same model |

4. ODU Fan Motor Can't Operate

| Possible causes | Discriminating method (air conditioner status) | Troubleshooting |
|---|---|--|
| Wrong wire connection, or poor connection | Check the wiring status according to circuit diagram | Connect wires according to wiring diagram to make sure all wiring terminals are connected firmly |
| Capacity of the ODU fan motor is damaged | Measure the capacity of fan capacitor with an universal meter and find that the capacity is out of the deviation range indicated on the nameplate of fan capacitor. | Replace the capacity of fan |
| Power voltage is a little low or high | Use universal meter to measure the power supply voltage. The voltage is a little high or low | Suggest to equip with voltage regulator |
| Motor of outdoor unit is damaged | When unit is on, cooling/heating performance is bad and ODU compressor generates a lot of noise and heat. | Change compressor oil and refrigerant. If no better, replace the compressor with a new one |

5. Compressor Can't Operate

| Possible causes | Discriminating method (air conditioner status) | Troubleshooting |
|---|---|--|
| Wrong wire connection, or poor connection | Check the wiring status according to circuit diagram | Connect wires according to wiring diagram to make sure all wiring terminals are connected firmly |
| Capacity of compressor is damaged | Measure the capacity of fan capacitor with an universal meter and find that the capacity is out of the deviation range indicated on the nameplate of fan capacitor. | Replace the compressor capacitor |
| Power voltage is a little low or high | Use universal meter to measure the power supply voltage. The voltage is a little high or low | Suggest to equip with voltage regulator |
| Coil of compressor is burnt out | Use universal meter to measure the resistance between compressor terminals and it's 0 | Repair or replace compressor |
| Cylinder of compressor is blocked | Compressor can't operate | Repair or replace compressor |

6. Air Conditioner is Leaking

| Possible causes | Discriminating method (air conditioner status) | Troubleshooting |
|-----------------------|---|---|
| Drain pipe is blocked | Water leaking from indoor unit | Eliminate the foreign objects inside the drain pipe |
| Drain pipe is broken | Water leaking from drain pipe | Replace drain pipe |
| Wrapping is not tight | Water leaking from the pipe connection place of indoor unit | Wrap it again and bundle it tightly |


7. Abnormal Sound and Vibration

| Possible causes | Discriminating method (air conditioner status) | Troubleshooting |
|---|--|--|
| When turn on or turn off the unit, the panel and other parts will expand and there's abnormal sound | There's the sound of "PAPA" | Normal phenomenon. Abnormal sound will disappear after a few minutes. |
| When turn on or turn off the unit, there's abnormal sound due to flow of refrigerant inside air conditioner | Water-running sound can be heard | Normal phenomenon. Abnormal sound will disappear after a few minutes. |
| Foreign objects inside the indoor unit or there're parts touching together inside the indoor unit | There's abnormal sound fro indoor unit | Remove foreign objects. Adjust all parts' position of indoor unit, tighten screws and stick damping plaster between connected parts |
| Foreign objects inside the outdoor unit or there're parts touching together inside the outdoor unit | There's abnormal sound fro outdoor unit | Remove foreign objects. Adjust all parts' position of outdoor unit, tighten screws and stick damping plaster between connected parts |
| Short circuit inside the magnetic coil | During heating, the way valve has abnormal electromagnetic sound | Replace magnetic coil |
| Abnormal shake of compressor | Outdoor unit gives out abnormal sound | Adjust the support foot mat of compressor, tighten the bolts |
| Abnormal sound inside the compressor | Abnormal sound inside the compressor | If add too much refrigerant during maintenance, please reduce refrigerant properly. Replace compressor for other circumstances. |

10. Exploded View and Parts List


10.1 Indoor Unit

MWM09Y1J MWM12Y1J



10.2 Outdoor Unit

MRM09Y1J MRM12Y1J







| No. | Description | Part Code | | Qty |
|-----|-------------------------------|-----------|----------|-----|
| | | MRM09Y1J | MRM12Y1J | |
| 1 | Front Grill | 69700000 | 69700000 | 1 |
| 2 | Cabinet | 69700273 | 69700273 | 2 |
| 3 | Axial Flow Fan | 69700280 | 69700280 | 1 |
| 4 | Fan Motor | 69700281 | 69700281 | 1 |
| 5 | Chassis Sub-assy | 69700270 | 69700270 | 1 |
| 6 | Drainage Connector | 69700164 | 69700164 | 1 |
| 7 | Compressor Gasket | 69700284 | 69700284 | 1 |
| 8 | Compressor and Fittings | 69700268 | 69700268 | 2 |
| 9 | Electric Expansion Valve Sub- | 69700288 | 69700009 | 2 |
| 10 | Valve Cover | 69700289 | 69700010 | 1 |
| 11 | Valve | 69700009 | 69700011 | 1 |
| 12 | Valve | 69700010 | 69700276 | 1 |
| 13 | Valve Support | 69700011 | 69700272 | 1 |
| 14 | Cable Cross Plate 2 | 69700286 | 69700014 | 1 |
| 15 | Cable Cross Plate 1 | 69700276 | 69700283 | 1 |
| 16 | Right Side Plate Assy | 69700272 | 69700279 | 1 |
| 17 | Cover of Pass Wire | 69700014 | 69700278 | 1 |
| 18 | Electric Expand Valve Fitting | 69700291 | 69700213 | 1 |
| 19 | Temperature Sensor | 69700283 | | 1 |
| 20 | 4-Way Valve Assy | 69700278 | 69700274 | 1 |
| 21 | Magnet Coil | 69700213 | 69700269 | 1 |
| 22 | Compressor Overload | 69700285 | 69700271 | 1 |
| 23 | Rear Grill | 69700274 | 69700025 | 1 |
| 24 | Condenser Assy | 69700269 | 69700275 | 1 |
| 25 | Clapboard Sub-Assy | 69700271 | 69700027 | 1 |
| 26 | Top Cover Plate | 69700025 | 69700282 | 1 |
| 27 | Motor Support Spot Weld | 69700026 | 69700277 | 1 |
| 28 | Electric Box Cover Sub-Assy | 69700027 | 69700196 | 1 |
| 29 | Main Board | 69700290 | 69700000 | 1 |
| 30 | Electric Box Assy | 69700287 | 69700273 | 1 |
| 31 | Terminal Board | 69700196 | 69700280 | 1 |
| 32 | Front Grill | 69700000 | 69700281 | 1 |
| 33 | Cabinet | 69700273 | 69700270 | 1 |
| 34 | Axial Flow Fan | 69700280 | 69700164 | 1 |
| 35 | Fan Motor | 69700281 | 69700284 | 1 |



Above data is subject to change without notice.




11. Removal Procedure

⚠ Warning: Be sure to wait for a minimum of 20 minutes after turning off all power supplies and discharge the refrigerant completely before removal.

11.1 Removal Procedure of Indoor Unit

| Steps | Procedure | Points |
|--|--|---|
| <p>1. External features</p> |  | <p>If ON/OFF button is kept pushing for 5 seconds, a forced cooling operation will be carried out for approx. 15 minutes.</p> |
| <p>2. Removing air filters</p> <p>a Pull protrusions on left and right sides of panel with fingers and open front panel all the way.</p> <p>b Lift center section of air filter and disengage hooks.</p> <p>c Remove air filter by pulling forward.</p> |   <p style="text-align: center;">Air filter</p> <p style="text-align: center;">Hooks</p>  | <p>Left and right filters are interchangeable.</p> <p>To re-install, insert air filter along the guide.</p> |



| Steps | Procedure | Points |
|--|---|---|
| <p>4. Opening and closing of service cover</p> <p>Remove a service cover mounting screw. Open service cover upward.</p> |  | <p>A switch for field setting is not provided in particular.</p> |
| <p>5. Removal of front grille assembly</p> <p>a Remove the 5 screws, in the right and the left, which fix the main body with the front grille.</p> <p>b Disengage the 3 hooks on the upper part. In case that the hooks are not pressed from above, remove the front panel and then remove the grille while pushing the hook through a clearance between the front grille and the heat exchanger.</p> <p>c The front grille can be removed in a manner to pull out the upper part forward and lift up the lower part.</p> |  <p>screws</p> <p>Hooks</p> <p>Left Center Right</p> | <p>Screw stoppers inside the flap which were equipped in the existing models are not provided.</p> <p>At the upper part there are 2 hooks in the left and the right.</p> <p>Disengage the hooks by pressing knobs with a screwdriver.</p> |




| Steps | Procedure | Points |
|---------------------------|---|--------|
| 7. Remove piping fixture. | | |
| a | <p>Remove Pipe Clamp</p>  <p>Auxiliary piping Piping fixture</p> | |
| b | <p>Adjust the pipeline slightly</p>  <p>Auxiliary piping</p> | |
| c | <p>Loosen the screws, in the right and the left, which fix the Evaporator Assy. Remove Evaporator Assy</p>  <p>Heat exchanger</p> | |

11.2 Removal Procedure of Outdoor Unit



Caution: discharge the refrigerant completely before removal.

| Steps | Procedure | Points |
|-----------------------------------|---|--------|
| <p>1. Features</p> | <p>a</p> <p>Loosen the screw of the cable cross plate sub-assy and remove it. Pull down the stop valve cover and remove it.</p>  | |
| <p>2. Remove top panel</p> | <p>a</p> <p>Loosen the 3 screws (right, left) and lift the top panel.</p>  | |

| Steps | Procedure | Points |
|--|---|---|
| <p>b</p> | <p>Twist off the 4 tapping screws fixing the motor, pull out the pin of leading wire of motor and then remove the motor. Twist off the 2 tapping screws on motor support and 1 screws on electric box, pull it upward and then remove the motor support.</p> |  <p>Fan motor fixing frame</p> <p>Fan motor</p> |
| <p>4.Remove the electric box.</p> | | |
| | <p>Twist off the 2 screws fixing the electric box cover with screwdriver, pull it upwardly and then remove the electric box cover. Twist off the screws fixing the electric box with screwdriver, loosen the wireline, pull out the wiring terminal, pull it upward and then remove the electric box.</p> |  <p>Electrical box</p> |
| <p>5.Remove the partition plate.</p> | | |
| <p>a</p> | <p>Loosen the 2 screws.</p> |  <p>Partition plate</p> |
| <p>b</p> | <p>The partition plate has a hook on the lower side. Lift and pull the partition plate to remove.</p> | |
| <p>■ The partition plate is fixed to the bottom frame with a hook.</p> | | |

Appendix:

Appendix 1: Reference Sheet of Celsius and Fahrenheit

Conversion formula for Fahrenheit degree and Celsius degree: $T_f = T_c \times 1.8 + 32$

Set temperature

| Fahrenheit display temperature (°F) | Fahrenheit (°F) | Celsius (°C) | Fahrenheit display temperature (°F) | Fahrenheit (°F) | Celsius (°C) | Fahrenheit display temperature (°F) | Fahrenheit (°F) | Celsius (°C) |
|-------------------------------------|-----------------|--------------|-------------------------------------|-----------------|--------------|-------------------------------------|-----------------|--------------|
| 61 | 60.8 | 16 | 69/70 | 69.8 | 21 | 78/79 | 78.8 | 26 |
| 62/63 | 62.6 | 17 | 71/72 | 71.6 | 22 | 80/81 | 80.6 | 27 |
| 64/65 | 64.4 | 18 | 73/74 | 73.4 | 23 | 82/83 | 82.4 | 28 |
| 66/67 | 66.2 | 19 | 75/76 | 75.2 | 24 | 84/85 | 84.2 | 29 |
| 68 | 68 | 20 | 77 | 77 | 25 | 86 | 86 | 30 |

Ambient temperature

| Fahrenheit display temperature (°F) | Fahrenheit (°F) | Celsius (°C) | Fahrenheit display temperature (°F) | Fahrenheit (°F) | Celsius (°C) | Fahrenheit display temperature (°F) | Fahrenheit (°F) | Celsius (°C) |
|-------------------------------------|-----------------|--------------|-------------------------------------|-----------------|--------------|-------------------------------------|-----------------|--------------|
| 32/33 | 32 | 0 | 55/56 | 55.4 | 13 | 79/80 | 78.8 | 26 |
| 34/35 | 33.8 | 1 | 57/58 | 57.2 | 14 | 81 | 80.6 | 27 |
| 36 | 35.6 | 2 | 59/60 | 59 | 15 | 82/83 | 82.4 | 28 |
| 37/38 | 37.4 | 3 | 61/62 | 60.8 | 16 | 84/85 | 84.2 | 29 |
| 39/40 | 39.2 | 4 | 63 | 62.6 | 17 | 86/87 | 86 | 30 |
| 41/42 | 41 | 5 | 64/65 | 64.4 | 18 | 88/89 | 87.8 | 31 |
| 43/44 | 42.8 | 6 | 66/67 | 66.2 | 19 | 90 | 89.6 | 32 |
| 45 | 44.6 | 7 | 68/69 | 68 | 20 | 91/92 | 91.4 | 33 |
| 46/47 | 46.4 | 8 | 70/71 | 69.8 | 21 | 93/94 | 93.2 | 34 |
| 48/49 | 48.2 | 9 | 72 | 71.6 | 22 | 95/96 | 95 | 35 |
| 50/51 | 50 | 10 | 73/74 | 73.4 | 23 | 97/98 | 96.8 | 36 |
| 52/53 | 51.8 | 11 | 75/76 | 75.2 | 24 | 99 | 98.6 | 37 |
| 54 | 53.6 | 12 | 77/78 | 77 | 25 | | | |

Appendix 2: Configuration of Connection Pipe

- Standard length of connection pipe
 - 16.40ft, 24.61ft, 26.25ft.
- Min. length of connection pipe is 9.84ft.
- Max. length of connection pipe and max. high difference.
- The additional refrigerant oil and refrigerant charging required after prolonging connection pipe
 - After the length of connection pipe is prolonged for 32.81ft at the basis of standard length, you should add 5ml of refrigerant oil for each additional 16.40ft of connection pipe.
 - The calculation method of additional refrigerant charging amount (on the basis of liquid pipe):

| Cooling capacity | Max length of connection pipe | Max height difference |
|----------------------|-------------------------------|-----------------------|
| 5000 Btu/h(1465 W) | 49.21ft | 16.40ft |
| 7000 Btu/h(2051 W) | 49.21ft | 16.40ft |
| 9000 Btu/h(2637 W) | 49.21ft | 32.81ft |
| 12000 Btu/h(3516 W) | 65.62ft | 32.81ft |
| 18000 Btu/h(5274 W) | 80.02ft | 32.81ft |
| 24000 Btu/h(7032 W) | 80.02ft | 32.81ft |
| 28000 Btu/h(8204 W) | 98.43ft | 32.81ft |
| 36000 Btu/h(10548 W) | 98.43ft | 65.62ft |
| 42000 Btu/h(12306 W) | 98.43ft | 65.62ft |
| 48000 Btu/h(14064 W) | 98.43ft | 65.62ft |

- When the length of connection pipe is above 16.40ft, add refrigerant according to the prolonged length of liquid pipe. The additional refrigerant charging amount per meter is different according to the diameter of liquid pipe. See the following sheet.
- Additional refrigerant charging amount = prolonged length of liquid pipe X additional refrigerant charging amount per meter

| Additional refrigerant charging amount for R22, R407C, R410A and R134a | | | |
|--|----------------|-----------------------|-----------------------------|
| Diameter of connection pipe | | Outdoor unit throttle | |
| Liquid pipe(inch) | Gas pipe(inch) | Cooling only(oz/ft.) | Cooling and heating(oz/ft.) |
| Φ1/4 | Φ3/8 or Φ1/2 | 0.2 | 0.2 |
| Φ1/4 or Φ3/8 | Φ5/8 or Φ3/4 | 0.2 | 0.2 |
| Φ1/2 | Φ3/4 or Φ7/8 | 0.3 | 1.3 |
| Φ5/8 | Φ1 or Φ1 1/4 | 0.7 | 1.3 |
| Φ3/4 | / | 2.7 | 2.7 |
| Φ7/8 | / | 3.8 | 3.8 |

Appendix 4: List of Resistance for Temperature Sensor

Resistance Table of Ambient Temperature Sensor for Indoor and Outdoor Units(15K)

| Temp.(°F) | Resistance(kΩ) | Temp.(°F) | Resistance(kΩ) | Temp.(°F) | Resistance(kΩ) | Temp.(°F) | Resistance(kΩ) |
|-----------|----------------|-----------|----------------|-----------|----------------|-----------|----------------|
| -2.2 | 138.1 | 68 | 18.75 | 138.2 | 3.848 | 208.4 | 1.071 |
| -0.4 | 128.6 | 69.8 | 17.93 | 140 | 3.711 | 210.2 | 1.039 |
| 1.4 | 121.6 | 71.6 | 17.14 | 141.8 | 3.579 | 212 | 1.009 |
| 3.2 | 115 | 73.4 | 16.39 | 143.6 | 3.454 | 213.8 | 0.98 |
| 5 | 108.7 | 75.2 | 15.68 | 145.4 | 3.333 | 215.6 | 0.952 |
| 6.8 | 102.9 | 77 | 15 | 147.2 | 3.217 | 217.4 | 0.925 |
| 8.6 | 97.4 | 78.8 | 14.36 | 149 | 3.105 | 219.2 | 0.898 |
| 10.4 | 92.22 | 80.6 | 13.74 | 150.8 | 2.998 | 221 | 0.873 |
| 12.2 | 87.35 | 82.4 | 13.16 | 152.6 | 2.896 | 222.8 | 0.848 |
| 14 | 82.75 | 84.2 | 12.6 | 154.4 | 2.797 | 224 3/5 | 0.825 |
| 15.8 | 78.43 | 86 | 12.07 | 156.2 | 2.702 | 226.4 | 0.802 |
| 17.6 | 74.35 | 87.8 | 11.57 | 158 | 2.611 | 228.2 | 0.779 |
| 19.4 | 70.5 | 89.6 | 11.09 | 159.8 | 2.523 | 230 | 0.758 |
| 21.2 | 66.88 | 91.4 | 10.63 | 161.6 | 2.439 | 231.8 | 0.737 |
| 23 | 63.46 | 93.2 | 10.2 | 163.4 | 2.358 | 233.6 | 0.717 |
| 24.8 | 60.23 | 95 | 9.779 | 165.2 | 2.28 | 235.4 | 0.697 |
| 26.6 | 57.18 | 96.8 | 9.382 | 167 | 2.206 | 237.2 | 0.678 |
| 28.4 | 54.31 | 98.6 | 9.003 | 168.8 | 2.133 | 239 | 0.66 |
| 30.2 | 51.59 | 100.4 | 8.642 | 170.6 | 2.064 | 240.8 | 0.642 |
| 32 | 49.02 | 102.2 | 8.297 | 172.4 | 1.997 | 242.6 | 0.625 |
| 33.8 | 46.6 | 104 | 7.967 | 174.2 | 1.933 | 244.4 | 0.608 |
| 35.6 | 44.31 | 105.8 | 7.653 | 176 | 1.871 | 246.2 | 0.592 |
| 37.4 | 42.14 | 107.6 | 7.352 | 177.8 | 1.811 | 248 | 0.577 |
| 39.2 | 40.09 | 109.4 | 7.065 | 179.6 | 1.754 | 249.8 | 0.561 |
| 41 | 38.15 | 111.2 | 6.791 | 181.4 | 1.699 | 251.6 | 0.547 |
| 42.8 | 36.32 | 113 | 6.529 | 183.2 | 1.645 | 253.4 | 0.532 |
| 44.6 | 34.58 | 114.8 | 6.278 | 185 | 1.594 | 255.2 | 0.519 |
| 46.4 | 32.94 | 116.6 | 6.038 | 186.8 | 1.544 | 257 | 0.505 |
| 48.2 | 31.38 | 118.4 | 5.809 | 188.6 | 1.497 | 258.8 | 0.492 |
| 50 | 29.9 | 120.2 | 5.589 | 190.4 | 1.451 | 260.6 | 0.48 |
| 51.8 | 28.51 | 122 | 5.379 | 192.2 | 1.408 | 262.4 | 0.467 |
| 53.6 | 27.18 | 123.8 | 5.197 | 194 | 1.363 | 264.2 | 0.456 |
| 55.4 | 25.92 | 125.6 | 4.986 | 195.8 | 1.322 | 266 | 0.444 |
| 57.2 | 24.73 | 127.4 | 4.802 | 197.6 | 1.282 | 267.8 | 0.433 |
| 59 | 23.6 | 129.2 | 4.625 | 199.4 | 1.244 | 269.6 | 0.422 |
| 60.8 | 22.53 | 131 | 4.456 | 201.2 | 1.207 | 271.4 | 0.412 |
| 62.6 | 21.51 | 132 4/5 | 4.294 | 203 | 1.171 | 273.2 | 0.401 |
| 64.4 | 20.54 | 134.6 | 4.139 | 204.8 | 1.136 | 275 | 0.391 |
| 66.2 | 19.63 | 136.4 | 3.99 | 206.6 | 1.103 | 276.8 | 0.382 |

Resistance Table of Tube Temperature Sensors for Indoor and Outdoor (20K)

| Temp.(°F) | Resistance(kΩ) | Temp.(°F) | Resistance(kΩ) | Temp.(°F) | Resistance(kΩ) | Temp.(°F) | Resistance(kΩ) |
|-----------|----------------|-----------|----------------|-----------|----------------|-----------|----------------|
| -2.2 | 181.4 | 68 | 25.01 | 138.2 | 5.13 | 208.4 | 1.427 |
| -0.4 | 171.4 | 69.8 | 23.9 | 140 | 4.948 | 210.2 | 1.386 |
| 1.4 | 162.1 | 71.6 | 22.85 | 141.8 | 4.773 | 212 | 1.346 |
| 3.2 | 153.3 | 73.4 | 21.85 | 143.6 | 4.605 | 213.8 | 1.307 |
| 5 | 145 | 75.2 | 20.9 | 145.4 | 4.443 | 215.6 | 1.269 |
| 6.8 | 137.2 | 77 | 20 | 147.2 | 4.289 | 217.4 | 1.233 |
| 8.6 | 129.9 | 78.8 | 19.14 | 149 | 4.14 | 219.2 | 1.198 |
| 10.4 | 123 | 80.6 | 18.13 | 150.8 | 3.998 | 221 | 1.164 |
| 12.2 | 116.5 | 82.4 | 17.55 | 152.6 | 3.861 | 222.8 | 1.131 |
| 14 | 110.3 | 84.2 | 16.8 | 154.4 | 3.729 | 224 3/5 | 1.099 |
| 15.8 | 104.6 | 86 | 16.1 | 156.2 | 3.603 | 226.4 | 1.069 |
| 17.6 | 99.13 | 87.8 | 15.43 | 158 | 3.481 | 228.2 | 1.039 |
| 19.4 | 94 | 89.6 | 14.79 | 159.8 | 3.364 | 230 | 1.01 |
| 21.2 | 89.17 | 91.4 | 14.18 | 161.6 | 3.252 | 231.8 | 0.983 |
| 23 | 84.61 | 93.2 | 13.59 | 163.4 | 3.144 | 233.6 | 0.956 |
| 24.8 | 80.31 | 95 | 13.04 | 165.2 | 3.04 | 235.4 | 0.93 |
| 26.6 | 76.24 | 96.8 | 12.51 | 167 | 2.94 | 237.2 | 0.904 |
| 28.4 | 72.41 | 98.6 | 12 | 168.8 | 2.844 | 239 | 0.88 |
| 30.2 | 68.79 | 100.4 | 11.52 | 170.6 | 2.752 | 240.8 | 0.856 |
| 32 | 65.37 | 102.2 | 11.06 | 172.4 | 2.663 | 242.6 | 0.833 |
| 33.8 | 62.13 | 104 | 10.62 | 174.2 | 2.577 | 244.4 | 0.811 |
| 35.6 | 59.08 | 105.8 | 10.2 | 176 | 2.495 | 246.2 | 0.77 |
| 37.4 | 56.19 | 107.6 | 9.803 | 177.8 | 2.415 | 248 | 0.769 |
| 39.2 | 53.46 | 109.4 | 9.42 | 179.6 | 2.339 | 249.8 | 0.746 |
| 41 | 50.87 | 111.2 | 9.054 | 181.4 | 2.265 | 251.6 | 0.729 |
| 42.8 | 48.42 | 113 | 8.705 | 183.2 | 2.194 | 253.4 | 0.71 |
| 44.6 | 46.11 | 114.8 | 8.37 | 185 | 2.125 | 255.2 | 0.692 |
| 46.4 | 43.92 | 116.6 | 8.051 | 186.8 | 2.059 | 257 | 0.674 |
| 48.2 | 41.84 | 118.4 | 7.745 | 188.6 | 1.996 | 258.8 | 0.658 |
| 50 | 39.87 | 120.2 | 7.453 | 190.4 | 1.934 | 260.6 | 0.64 |
| 51.8 | 38.01 | 122 | 7.173 | 192.2 | 1.875 | 262.4 | 0.623 |
| 53.6 | 36.24 | 123.8 | 6.905 | 194 | 1.818 | 264.2 | 0.607 |
| 55.4 | 34.57 | 125.6 | 6.648 | 195.8 | 1.736 | 266 | 0.592 |
| 57.2 | 32.98 | 127.4 | 6.403 | 197.6 | 1.71 | 267.8 | 0.577 |
| 59 | 31.47 | 129.2 | 6.167 | 199.4 | 1.658 | 269.6 | 0.563 |
| 60.8 | 30.04 | 131 | 5.942 | 201.2 | 1.609 | 271.4 | 0.549 |
| 62.6 | 28.68 | 132 4/5 | 5.726 | 203 | 1.561 | 273.2 | 0.535 |
| 64.4 | 27.39 | 134.6 | 5.519 | 204.8 | 1.515 | 275 | 0.521 |
| 66.2 | 26.17 | 136.4 | 5.32 | 206.6 | 1.47 | 276.8 | 0.509 |

Resistance Table of Discharge Temperature Sensor for Outdoor(50K)

| Temp.(°F) | Resistance(kΩ) | Temp.(°F) | Resistance(kΩ) | Temp.(°F) | Resistance(kΩ) | Temp.(°F) | Resistance(kΩ) |
|-----------|----------------|-----------|----------------|-----------|----------------|-----------|----------------|
| -20.2 | 853.5 | 50 | 98 | 120.2 | 18.34 | 190.4 | 4.754 |
| -18.4 | 799.8 | 51.8 | 93.42 | 122 | 17.65 | 192.2 | 4.609 |
| -16.6 | 750 | 53.6 | 89.07 | 123.8 | 16.99 | 194 | 4.469 |
| -14.8 | 703.8 | 55.4 | 84.95 | 125.6 | 16.36 | 195.8 | 4.334 |
| -13 | 660.8 | 57.2 | 81.05 | 127.4 | 15.75 | 197.6 | 4.204 |
| -11.2 | 620.8 | 59 | 77.35 | 129.2 | 15.17 | 199.4 | 4.079 |
| -9.4 | 580.6 | 60.8 | 73.83 | 131 | 14.62 | 201.2 | 3.958 |
| -7.6 | 548.9 | 62.6 | 70.5 | 132 4/5 | 14.09 | 203 | 3.841 |
| -5.8 | 516.6 | 64.4 | 67.34 | 134.6 | 13.58 | 204.8 | 3.728 |
| -4 | 486.5 | 66.2 | 64.33 | 136.4 | 13.09 | 206.6 | 3.619 |
| -2.2 | 458.3 | 68 | 61.48 | 138.2 | 12.62 | 208.4 | 3.514 |
| -0.4 | 432 | 69.8 | 58.77 | 140 | 12.17 | 210.2 | 3.413 |
| 1.4 | 407.4 | 71.6 | 56.19 | 141.8 | 11.74 | 212 | 3.315 |
| 3.2 | 384.5 | 73.4 | 53.74 | 143.6 | 11.32 | 213.8 | 3.22 |
| 5 | 362.9 | 75.2 | 51.41 | 145.4 | 10.93 | 215.6 | 3.129 |
| 6.8 | 342.8 | 77 | 49.19 | 147.2 | 10.54 | 217.4 | 3.04 |
| 8.6 | 323.9 | 78.8 | 47.08 | 149 | 10.18 | 219.2 | 2.955 |
| 10.4 | 306.2 | 80.6 | 45.07 | 150.8 | 9.827 | 221 | 2.872 |
| 12.2 | 289.6 | 82.4 | 43.16 | 152.6 | 9.489 | 222.8 | 2.792 |
| 14 | 274 | 84.2 | 41.34 | 154.4 | 9.165 | 224 3/5 | 2.715 |
| 15.8 | 259.3 | 86 | 39.61 | 156.2 | 8.854 | 226.4 | 2.64 |
| 17.6 | 245.6 | 87.8 | 37.96 | 158 | 8.555 | 228.2 | 2.568 |
| 19.4 | 232.6 | 89.6 | 36.38 | 159.8 | 8.268 | 230 | 2.498 |
| 21.2 | 220.5 | 91.4 | 34.88 | 161.6 | 7.991 | 231.8 | 2.431 |
| 23 | 209 | 93.2 | 33.45 | 163.4 | 7.726 | 233.6 | 2.365 |
| 24.8 | 198.3 | 95 | 32.09 | 165.2 | 7.47 | 235.4 | 2.302 |
| 26.6 | 199.1 | 96.8 | 30.79 | 167 | 7.224 | 237.2 | 2.241 |
| 28.4 | 178.5 | 98.6 | 29.54 | 168.8 | 6.998 | 239 | 2.182 |
| 30.2 | 169.5 | 100.4 | 28.36 | 170.6 | 6.761 | 240.8 | 2.124 |
| 32 | 161 | 102.2 | 27.23 | 172.4 | 6.542 | 242.6 | 2.069 |
| 33.8 | 153 | 104 | 26.15 | 174.2 | 6.331 | 244.4 | 2.015 |
| 35.6 | 145.4 | 105.8 | 25.11 | 176 | 6.129 | 246.2 | 1.963 |
| 37.4 | 138.3 | 107.6 | 24.13 | 177.8 | 5.933 | 248 | 1.912 |
| 39.2 | 131.5 | 109.4 | 23.19 | 179.6 | 5.746 | 249.8 | 1.863 |
| 41 | 125.1 | 111.2 | 22.29 | 181.4 | 5.565 | 251.6 | 1.816 |
| 42.8 | 119.1 | 113 | 21.43 | 183.2 | 5.39 | 253.4 | 1.77 |
| 44.6 | 113.4 | 114.8 | 20.6 | 185 | 5.222 | 255.2 | 1.725 |
| 46.4 | 108 | 116.6 | 19.81 | 186.8 | 5.06 | 257 | 1.682 |
| 48.2 | 102.8 | 118.4 | 19.06 | 188.6 | 4.904 | 258.8 | 1.64 |



JF00302172