## MAJESTIC

# DVH SERIES DIRECT VENT GAS FIREPLACE

## INSTALLATION AND OPERATING INSTRUCTIONS

MODELS: 500DVHNV/PV/NE/PE/RNV/RPV


#### **WARNINGS**

IF THE INFORMATION IN THESE INSTRUCTIONS ARE NOT FOLLOWED EXACTLY, A FIRE OR EXPLOSION MAY RESULT CAUSING PROPERTY DAMAGE, PERSONAL INJURY OR LOSS OF LIFE.

- Do not store or use gasoline or other flammable vapors and liquids in the vicinity of this or any other appliance.
- WHAT TO DO IF YOU SMELL GAS
  - Do not try to light any appliance.
  - Do not touch any electrical switch; do not use any phone in your building.
  - Immediately call your gas supplier from a neighbor's phone. Follow the gas supplier's instructions.
  - If you cannot reach your gas supplier, call the fire department.
- Installation and service must be performed by a qualified installer, service agency or the gas supplier.

WARNING: Improper installation, adjustment, alteration, services or maintenance can cause injury or property damage. Refer to this manual. For assistance or additional information consult a qualified installer, service agency or the gas supplier.

This appliance may be installed in an OEM installation in manufactured home (USA only) or mobile home and must be installed in accordance with the manufacturer's instructions and the manufactured home construction and safety standard, *Title 24 CFR, Part 3280 or Standard for Installation in Mobile Homes. CAN/CSA Z3-240MH.* This appliance is only for use with the type(s) of gas indicated on the rating plate unless a certified kit is used.





#### **WARNINGS**



DUE TO HIGH TEMPERATURES, THE APPLIANCE SHOULD BE LOCATED OUT OF TRAFFIC AND AWAY FROM FURNITURE AND DRAPERIES.

CHILDREN AND ADULTS SHOULD BE ALERTED TO THE HAZARDS OF HIGH SURFACE TEMPERATURE AND SHOULD STAY AWAY TO AVOID BURNS OR CLOTHING IGNITION.

YOUNG CHILDREN SHOULD BE SUPERVISED WHEN THEY ARE IN THE SAME ROOM AS THE APPLIANCE.

CLOTHING OR OTHER FLAMMABLE MATERIAL SHOULD NOT BE PLACED ON OR NEAR THE APPLIANCE.

KEEP THE ROOM AREA CLEAR AND FREE FROM COMBUSTIBLE MATERIALS, GASOLINE, AND OTHER FLAMMABLE VAPORS AND LIQUIDS.

#### **CONTENTS**

## Thank you and congratulations on your purchase of a Majestic Fireplace.

PLEASE READ THE INSTALLATION AND OPERATION INSTRUCTIONS BEFORE USING THE APPLIANCE! IMPORTANT: Read all instructions and warnings carefully before starting installation. Failure to follow these instructions may result in a possible fire hazard and will void the warranty.

Important Safety Information 3	Electrical Insta
Product Features 5	Electrical Wi
Code Approval 5	Remote Wal
Pre-Installation Information	Electronic Pi
Installing Above 2000 Feet 6	Remote Wal
Orifice Sizes, Pressures and BTUs6	Optional DC
Before You Start 6	Remote Hi/L
Fireplace Framing 7	Canopy Installa
Fireplace Dimensions 8	Glass Remova
Fireplace Location9	Floor Brick Ins
Securing Fireplace to Floor or Framing 10	Log and Rocky
Clearances11	Operating Instr
Installation Information 12	Lighting Pilo
Vent Installation13	Millivolt & Re
Installation Precautions	Lighting Pilo
Optional Top Vent Application 14	Lighting Burr
Installation Planning15	To Turn Off (
Installation for Vertical Termination 15	Lighting Elec
For Horizontal Termination 16	To Turn Off (
How to Use a Vent Graph 17	Remote Hi/L
Rear Wall Vent Installation 18	Cleaning and M
Horizontal (Through-the-Wall) Termination	Burner, Pilot
Configurations 21	Burner Flam
Horizontal with Vertical Rise	Vent System
(Through-the-Wall) Applications	Glass Door.
Below Grade Installation	Logs
Vertical Through-the-Roof Installation 24	Rock Wool .
Installation for Vertical Termination 26	Replacement P
Flat Ceiling Installation26	Logs
Fireplace Installation 28	Vent Compo
Check Gas Type28	Vent Compo
Installing Gas Piping to Fireplace/Burner	Firebox Com
Checking Gas Pressure 30	Additional Ad
	Standing Pile
	Electronic Ig
	Pemote Hi/L

Electrical Installation	. 31
Electrical Wiring	. 31
Remote Wall Mounted Switch - Millivolt	. 31
Electronic Pilot Ignition Wiring	. 32
Remote Wall Mounted Switch - Electronic	. 32
Optional DC Remote System	. 32
Remote Hi/Lo with Blower	. 33
Canopy Installation	. 34
Glass Removal	. 35
Floor Brick Installation	. 36
Log and Rockwool Installation	. 37
Operating Instructions	. 40
Lighting Pilot for the First Time -	
Millivolt & Remote Hi/Lo	40
Lighting Pilot - Millivolt and Remote Hi/Lo	41
Lighting Burner - Millivolt	42
To Turn Off Gas - Millivolt	42
Lighting Electronic Ignition	43
To Turn Off Gas - Electric Ignition	43
Remote Hi/Lo with Blower Instructions	44
Cleaning and Maintenance	. 51
Burner, Pilot and Control Compartment	. 51
Burner Flame	. 51
Vent System	. 52
Glass Door	. 52
Logs	. 52
Rock Wool	. 52
Replacement Parts	. 53
Logs	
Vent Components for 4"x65/8"	. 54
Vent Components for 5"x8"	. 55
Firebox Components	. 56
Additional Accessories	
Standing Pilot - Millivolt Control	60
Electronic Ignition	
Remote Hi/Lo with Blower	
For Massachusetts Residents Only	
Troubleshooting	. 68
Warranty Back Co	\/OF

#### **INSTALLER**

Please leave these instructions with the appliance.

#### OWNER

Please retain these instructions for future reference.

## ARNING

- Read this owner's manual carefully and completely before trying to assemble, operate, or service this fireplace.
- Any change to this fireplace or its controls can be dangerous.
- Improper installation or use of this fireplace can cause serious injury or death from fire, burns, explosions, electrical shock and carbon monoxide poisoning.

This fireplace is a vented product. This fireplace must be properly installed by a qualified service person. The glass door must be properly seated and sealed. If this unit is not properly installed by a qualified service person with glass door properly seated and sealed, combustion leakage can occur.

**CARBON MONOXIDE POISONING:** Early signs of carbon monoxide poisoning are similar to the flu with headaches, dizziness and/or nausea. If you have these signs, the fireplace may not have been installed properly. Get fresh air at once! Have the fireplace inspected and serviced by a qualified service person. Some people are more affected by carbon monoxide than others. These include pregnant women, people with heart or lung disease or anemia, those under the influence of alcohol, and those at high altitudes.

Propane/LP gas and natural gas are both odorless. An odormaking agent is added to each of these gases. The odor helps you detect a gas leak. However, the odor added to these gases can fade. Gas may be present even though no odor exists.

Make certain you read and understand all warnings. Keep this manual for reference. It is your guide to safe and proper operation of this fireplace.

- 1. This appliance is only for use with the type of gas indicated on the rating plate. This appliance is not convertible for use with other gases unless a certified kit is used.
- 2. For propane/LP fireplace, do not place propane/LP supply tank(s) inside any structure. Locate propane/LP supply tank(s) outdoors. To prevent performance problems, do not use propane/LP fuel tank of less than 100 lbs. capacity.
- 3. If you smell gas
  - shut off gas supply.
  - do not try to light any appliance.
  - do not touch any electrical switch; do not use any phone in your building.
  - immediately call your gas supplier from a neighbor's phone. Follow the gas supplier's instructions.

- 4. Never install the fireplace
  - in a recreational vehicle
  - where curtains, furniture, clothing, or other flammable objects are less than 42" from the front, top, or sides of the fireplace
  - in high traffic areas
  - in windy or drafty areas
- 5. This fireplace reaches high temperatures. Keep children and adults away from hot surfaces to avoid burns or clothing ignition. Fireplace will remain hot for a time after shutdown. Allow surfaces to cool before touching.
- 6. Carefully supervise young children when they are in the room with fireplace.
- 7. Do not modify fireplace under any circumstances. Any parts removed for servicing must be replaced prior to operating fireplace.
- 8. Turn fireplace off and let cool before servicing, installing, or repairing. Only a qualified service person should install, service, or repair the fireplace. Have burner system inspected annually by a qualified service person.
- 9. You must keep control compartments, burners, and circulating air passages clean. More frequent cleaning may be needed due to excessive lint and dust from carpeting, bedding material, pet hair, etc. Turn off the gas valve and pilot light before cleaning fireplace.
- 10. Have venting system inspected annually by a qualified service person. If needed, have venting system cleaned or repaired. See *Cleaning and Maintenance*, page 32.
- 11. Keep the area around your fireplace clear of combustible materials, gasoline, and other flammable vapor and liquids. Do not run fireplace where these are used or stored. Do not place items such as clothing or decorations on or around fireplace.

Continued on page 4

3

56D3049

#### IMPORTANT SAFETY INFORMATION

Continued from page 3

- 12. Do not use this fireplace to cook food or burn paper or other objects.
- 13. Never place anything on top of fireplace.
- 14. Do not use any solid fuels (wood, coal, paper, cardboard, etc.) in this fireplace. Use only the gas type indicated on rating plate.
- 15. This appliance, when installed, must be electrically grounded in accordance with local codes or in the absence of local codes, with the *National Electrical Code*, *ANSI/NFPA 70*, or the *Canadian Electrical Code*, *CSA C22.1*.
- 16. Do not obstruct the flow of combustion and ventilation air in any way. Provide adequate clearances around air openings into the combustion chamber along with adequate accessibility clearance for servicing and proper operation.
- 17. When the appliance is installed directly on carpeting, tile or other combustible material other than wood flooring, you must set appliance on a metal or wood panel or hearth pad extending the full width and depth of the appliance.
- 18. Do not use fireplace if any part has been exposed to or has been under water. Immediately call a qualified service person to arrange for replacement of the unit.
- 19. Do not operate fireplace if any log is broken.
- 20. Do not use a blower insert, heat exchanger insert, or any other accessory not approved for use with this fireplace.
- 21. Do not operate the fireplace with glass door removed, cracked, or broken.
- 22. For Massachusetts residents only see pages 58 and 59.

### IMPORTANT: PLEASE READ THE FOLLOWING CAREFULLY

It is normal for fireplaces fabricated of steel to give off some expansion and/or contraction noises during the start up or cool down cycle. Similar noises are found with your furnace heat exchanger or car engine.

### IMPORTANT: PLEASE READ THE FOLLOWING CAREFULLY

It is not unusual for gas fireplace to give off some odor the first time it is burned. This is due to the manufacturing process.

Please ensure that your room is well ventilated during burn off — open all windows.

It is recommended that you burn your fireplace for at least ten (10) hours the first time you use it. Place the fan switch in the "OFF" position during this time.



We suggest that our gas hearth products be installed and serviced by professionals who are certified in the U.S. by the National Fireplace Institute<sup>®</sup> (NFI) as Gas Specialists.

www.nficertified.org

/ARNING

Never connect unit to private (non-utility) gas wells. This gas is commonly known as wellhead gas.

#### PRODUCT FEATURES AND CODE APPROVAL

Hood

Nailing Flange//

Flange

Insulation

**Board** 

#### PRODUCT SPECIFICATIONS

- This appliance has been certified for use with either natural or propane gas. See appropriate data plates.
- This appliance is not for use with solid fuels.
- The appliance is approved for bedroom or bedsitting room installations.
- The appliance must be installed in accordance with local codes if any. If none exist use the current installation code. ANSI Z223.1/NFPA 54 in the USA, CSA B149 in Canada.
- This appliance is mobile home approved.
- The appliance must be properly con-

#### nected to a venting system. The appliance is not approved for closet or recessed installations. **WARNING** 5/8" Do not remove **Nailing** insulation board. Flange Hi/Lo Knob Off/Pilot/On Knob On/Off/RS Switch Figure 1 - 500DVH Fireplace Ignitor (Millivolt Unit Shown -Blower Control Also Available in Electronic **Optional Remote** Ignition and Remote Hi/Lo with 1/2" Nailing

#### **CODE APPROVAL**

**Blower Models**)

Direct Vent type appliances draw all combustion air from outside of the dwelling through the vent pipe.

These appliances have been tested by CSA and found to comply with the established standards for DIRECT VENT GAS FIREPLACE HEATERS in the USA and Canada as follows:

Receiver

#### LISTED VENTED GAS FIREPLACE HEATER

TESTED TO: ANSI Z21.88b-2008/CSA 2.33b-2008 STANDARDS

A manufactured home (USA only) or mobile home OEM installation must conform with the *Manufactured Home Con*struction and Safety Standard, Title 24 CFR, Part 3280, or when such a standard is not applicable, the Standard for Manufactured Home Installations, ANSI/NCSBCS A225.1, or Standard for Gas Equipped Recreational Vehicles and Mobile Housing, CSA Z240.4.

56D3049 5

#### PRE-INSTALLATION INFORMATION

#### **INSTALLING ABOVE 2000 FEET**

- In the USA, the appliance must be derated 4% for every 1,000 ft above 2,000 ft elevations.
- In Canada, these appliances are certified for altitudes of 0 2000 ft, and must be de-rated by 10 percent for installations between 2000 and 4,500 ft. (derate an additional 4% for every 1,000 ft. above 4,500 ft. elevations).

If the heating value of the gas has been reduced, these rules do not apply. To identify the proper orifice size, check with local gas utility.

If installing this appliance at an elevation above 4,500 feet (in Canada), check with local authorities.

#### ORIFICE SIZES, PRESSURES AND BTUS

#### NATURAL GAS PROPANE GAS

Manifold Press: (W.C.)	3.5"	Manifold Press: (W.C.)	10"
Maximum Supply Pressure	10.5"	Maximum Supply Pressure	13"
Minimum Supply Pressure	4"	Minimum Supply Pressure	11"

Model Number	500DVH	
Model Number	Natural	Propane
Max. Btu/hr Input	41,000	40,000
Min. Btu/hr Input	28,000	32,000
Front Burner Orifice size (as shipped)	2.30mm	#55
Rear Burner Orifice size (as shipped)	#37	#53

#### **BEFORE YOU START**

Read this homeowner manual thoroughly and follow all instructions carefully. Inspect all contents for shipping damage and immediately inform your dealer if any damage is found. Do not install any unit with damaged, incomplete, or substitute parts. Check your packing list to verify that all listed parts have been received. You should have the following:

- Fireplace (Firebox and Burner System)
- White Toggle Switch
- Log Set
- Canopy

- Fasteners
- Rock Wool
- Switch Cover Plate
- Restrictor Plate/Disc (2)
- Front Floor Brick (2 Pieces)
- Non-Combustible Panel

#### ITEMS REQUIRED FOR INSTALLATION

#### Tools:

- Phillips Screwdriver
- Hammer
- · Saw and/or saber saw
- Level
- Measuring Tape
- Electric Drill and Bits
- Pliers
- Square
- Pipe Wrench


#### **Building Supplies:**

- Framing Materials
- Wall Finishing Materials
- Caulking Material (Noncombustible)
- Fireplace Surround Material (Noncombustible)
- Piping Complying with Local Codes
- Tee Joint
- Pipe Sealant Approved for use with Propane/LPG (Resistant to Sulfur Compounds)

#### FIREPLACE FRAMING

Firebox framing can be built before or after the appliance is set in place. Construct firebox framing following Figure 2 and the chart below for your specific installation requirements. See Figure 3 on Page 8 for firebox dimensions. The framing headers may rest on the top of the firebox standoffs.

The firebox may be installed directly on a combustible floor or raised on a platform of an appropriate height. When the firebox is installed directly on carpeting, tile, or other combustible material, other than wood flooring, the firebox shall be installed on a metal or wood panel extending the full width and depth of the enclosure.



56D3049

#### PRE-INSTALLATION INFORMATION

## FIREPLACE DIMENSIONS 500DVH




Figure 3 - 500DVH Fireplace Dimensions

#### PRE-INSTALLATION INFORMATION

#### FIREPLACE LOCATION

Plan for the installation of your appliance. This includes determining where the unit is to be installed, the vent configuration to be used, framing and finishing details, and whether any optional accessories (i.e. blower, wall switch, or remote control) are desired. Consult your local building code agency to ensure compliance with local codes, including permits and inspections.

The following factors should be taken into consideration:

- Clearance to side-wall, ceiling, woodwork, and windows. Minimum clearances to combustibles **must be maintained.**
- This fireplace may be installed along a wall, across a corner, or use an exterior chase. See Figure 4 for suggested locations.
- Location should be out of high traffic areas and away from furniture and draperies due to heat from appliance.
- Never obstruct the front opening of the fireplace.
- Do **not** install in the vicinity where gasoline or other flammable liquids may be stored.
- Vent pipe routing. See *Venting* section found in this manual for allowable venting configurations.
- These units can be installed in a bedroom. See National Fuel Gas Code ANSI Z233.1/NFPA 54 (current edition), the Uniform Mechanical Code (current edition), and Local Building Codes for specific installation requirements.

Α	Flat on Wall
В	Cross Corner
С	Island**
D	Room Divider*
Е	Flat on Wall Corner*
F	Chase Installation
Υ	6" Minimum




Figure 4 - Locating Gas Fireplace

- \*\* Island (C) and room divider (D) installation is possible as long as the horizontal portion of vent system (X) does not exceed 20'. See *Installing Horizontal Termination Configuration* on pages 20 through 22.
- \* When you install your fireplace in (D) room divider or (E) flat on wall corner positions (Y), a minimum of 6" clearance must be maintained from perpendicular wall and front of fireplace.

#### SECURING FIREPLACE TO FLOOR OR FRAMING

The fireplace must be secured to the floor and/or to framing studs as shown in *Figure 5*. Use two (2) wood screws or masonry/concrete screws to secure fireplace to the floor. Use four (4) screws to attach fireplace to framing. The side brackets or nailing flanges are designed to accommodate two thickness of wall boards ( $^{1}/_{2}$ " or  $^{5}/_{8}$ ").





Figure 5 - Securing Fireplace to Floor and Framing Studs

#### **CLEARANCES TO COMBUSTIBLES**

Follow these instructions carefully to ensure safe installation. Failure to follow instructions exactly can create a fire hazard.

The appliance cannot be installed on a carpet, tile or other combustible material other than wood flooring. If installed on carpet or vinyl flooring, the appliance shall be installed on a metal, wood or noncombustible material panel extending full width and depth of the appliance.



56D3049

#### INSTALLATION INFORMATION

#### **FINISHING MATERIAL**

NOTE: Any remote wiring (i.e. remote control, wall switch, and optional fan) must be done prior to final finishing to avoid costly reconstruction.

WARNING

Never obstruct or modify the air inlet or outlet grills (louvers). This may create a fire hazard.

Only noncombustible materials (i.e. brick, tile, slate, steel, or other materials with a UL fire rating of Zero) may be used to cover the black surface of the appliance. A 300°F minimum adhesive may be used to attach facing materials to the black surface. If joints between the finished wall and the fireplace surround are sealed, a 300°F minimum sealant material (General Electric RTV103 or equivalent) must be used.

#### **VENT INSTALLATION**

WARNING

Read all instructions completely and thoroughly before attempting installation. Failure to do so could result in serious injury, property damage or loss of life. Operation of improperly installed and maintained venting system could result in serious injury, property damage or loss of life.

NOTICE

Failure to follow these instructions will void the warranty.

#### INSTALLATION PRECAUTIONS

Consult local building codes before beginning the installation. The installer must make sure to select the proper vent system for installation. Before installing vent kit, the installer must read this fireplace manual and vent kit instructions.

Only a qualified installer/service person should install the venting system. The installer must follow these safety rules:

- Wear gloves and safety glasses for protection.
- Use extreme caution when using ladders or when on rooftops.
- Be aware of electrical wiring locations in walls and ceilings.

The following actions will void the warranty on your venting system:

- Installation of any damaged venting component.
- Unauthorized modification of the venting system.
- Installation of any component part not manufactured or approved by MHSC
- Installation other than permitted by these instructions.

This fireplace must be vented to the outside. The venting system must NEVER be attached to a chimney serving a separate solid fuel burning appliance. Each gas appliance must use a separate vent system. Do not use common vent systems.




Figure 8 - Combustible Clearances for Vent Pipe

#### **VENT INSTALLATION**

#### OPTIONAL TOP VENT APPLICATION

The appliance is shipped as a rear vent unit. If the installation layout requires the unit to be a top vent configuration the appliance can be converted by following the steps below.

When removing and refitting the plates and adapter be sure the associated gaskets are undamaged and refitted as required.

- 1. Remove the eight (8) screws securing the flue pipe adapter to the fireplace body. *See Figure 9*.
- Set the flue pipe adapter aside, complete with the gasket. Do not damage the gaskets as the adapter and gasket must be refitted.
- 3. Remove the eight (8) screws securing the flue pipe cover to the top of the intake box and remove the cover and gasket. *See Figure 9*.
- 4. Remove six (6) screws securing the flue pipe to the back of the intake box and remove the pipe and gasket. *See Figure 10*.
- 5. Replace flue pipe to top of firebox. Ensure the gasket is in place and undamaged. Secure with six (6) screws. *See Figure 11*.
- 6. Place the flue pipe cover and gasket removed in step 3 over the flue opening in bottom of the intake box.
- 7. Refit the flue pipe adapter and gasket to the top of fireplace. Secure the adapter with six (6) screws removed in step 1.




Figure 10 - Removing Flue Pipe

MARNING

After conversion to top vent configuration the 5" (127mm) flue pipe should be concentric with the 8" (203mm) outer collar within  $^{1}/_{4}$ ".




Figure 9 - Removing sixteen (16) Screws from Flue Pipe Adapter and Flue Pipe Cover




Figure 11 - Attaching Flue Pipe to Top Vent Configurations

15

#### INSTALLATION PLANNING

There are two basic types of direct-vent installation:

- Horizontal Termination
- Vertical Termination

It is important to select the proper length of vent pipe for the type of termination you choose. It is also important to note the wall thickness.

#### FOR HORIZONTAL TERMINATION

Select the amount of vertical rise desired. All horizontal run of venting must have <sup>1</sup>/<sub>4</sub>" rise for every 12" of run towards the termination.

You may use up to three 90° elbows in this vent configuration. See *Horizontal Termination Configurations* on pages 20 and 21.

WARNING

Never run the vent pipe level or downward. This may cause excessive temperatures which could cause a fire.

#### FOR VERTICAL TERMINATION

Measure the distance from the fireplace floor to the ceiling. Add the ceiling thickness, the vertical rise in an attic or second story, and allow for sufficient vent height above the roof line.

NOTE: You may use two 45° elbows in place of a 90° elbow. You must follow rise to run ratios when using 45° elbows. The appliance is approved for use with three 90° elbows maximum or a combination of 90° and 45° elbows up to a maximum of 270°.

For two-story applications, firestops are required at each floor level. If an offset is needed in the attic, additional pipe and elbows will be required.

You may use a chase with a vent termination with exposed pipe on the exterior of the house. See *Installing Vent System in a Chase* below. If pipe is enclosed in chase, it is not exposed.

It is very important that the venting system maintain its balance between the combustion air intake and the flue gas exhaust. Certain limitations apply to vent configurations and must be strictly followed.

#### **INSTALLING A VENT SYSTEM IN AN OUTSIDE CHASE**

A chase is a vertical boxlike structure built to enclose venting that runs along the outside of a building. A chase is required for such venting.

NOTICE

Treatment of firestops and construction of the chase may vary from building type to building type. These instructions are not substitutes for the requirements of local building codes. You must follow all local building codes.

IOTICE

When installing in a chase, you should insulate the chase as you would the outside walls of your home. This is especially important in cold climates. Insulation should be considered a combustible material. Maintain proper clearances to all combustible materials.

56D3049

#### **VENT INSTALLATION**




Figure 12 - Horizontal Vent Termination Location


#### **MINIMUM DISTANCES**


- A = Clearance above the grade, a veranda, porch, deck, or balcony [\*12" (305mm) minimum].
- B = Clearance to window or door that may be opened [\*12" (305mm) minimum].
- C = Clearance to permanently closed window [\*minimum 12" (305mm) recommended to prevent condensation on window]
- D = Vertical clearance to ventilated soffit located above the terminal within a horizontal distance of two (2) feet (610mm) from the centerline of the terminal [18" (457mm) minimum].
- E = Clearance to unventilated soffits [12" (305mm) minimum]. Clearance to vinyl soffit [30" (762mm)].
- F = Clearance to an outside corner. See Figure 13, page 17.
- G = Clearance to an inside corner. See Figure 13, page 17.
- H = Not to be installed above a gas meter/regulator assembly within three (3) feet (914mm) horizontally from the centerline of the regulator.
- I = Clearance to service regulator vent outlet [\*3' (914mm) minimum].
- J = Clearance to non-mechanical air supply inlet to building or the combustion air inlet to any other appliance [\*12" (305mm) minimum].
- K = Clearance to a mechanical air supply inlet [\*6' (1829mm) minimum].
- L= Clearance above a paved sidewalk or paved driveway located on public property [\*\*7' (2133mm) minimum].
- M = Clearance under veranda, porch, deck, or balcony. **See Figure 13, page 17.** [For Canada \*12" (305mm) minimum\*\*\*].
- N = Clearance above a roof shall extend a minimum of 24" (610mm) above the highest point when it passes through the roof surface and any other obstruction within a horizontal distance of 18" (457mm).
- \* As specified in CSA B149 Installation Codes. Note: Local codes or regulations may require different clearances.
- \*\* A vent must not terminate directly above a sidewalk or paved driveway, which is located between two single-family dwellings and serves both dwellings.
- \*\*\* Only permitted if veranda, porch, deck, or balcony is fully open on a minimum of two sides beneath the floor.

VARNING


Always maintain minimum clearances around vent systems. The minimum clearances to combustibles for horizontal vent pipe are 3" at the top and 1" at the sides and bottom of the vent system until the pipe penetrates the outside vertical wall (1" required). A 1" minimum clearance all around the pipe must be maintained. Do not pack the open air spaces with insulation or other materials. This could cause high temperatures and may present a fire hazard.


#### TERMINATION CLEARANCES FOR BUILDINGS WITH COMBUSTIBLE AND NONCOMBUSTIBLE EXTERIORS











**Balcony with No Side Wall Balcony with Perpendicular** Side Wall

D = Minimum width for back wall of alcove location Combustible - 38" (965mm)

for alcove location

C = Maximum depth of 48" (1219mm)

Noncombustible - 24" (610mm)

E = Clearance from corner in alcove location

Combustible - 6" (152mm) Noncombustible - 2" (51mm)

**Alcove Location** 

Figure 13 - Allowable Venting Chart

#### HOW TO USE THE VENT GRAPH


The Vent Graph should be read in conjunction with the following vent installation instructions to determine the relationship between the vertical and horizontal dimensions of the vent system.

- 1. Determine the height of the center of the horizontal vent pipe exiting through the outer wall. Using this dimension on the Sidewall Vent Graph below, locate the point intersecting with the slanted graph line.
- 2. From the point of this intersection, draw a vertical line to the bottom of the graph.
- 3. Select the indicated dimension, and position the fireplace in accordance with same.

Example A: If the vertical dimension from the floor of the fireplace is 11' (3.4m) the horizontal run to the face of the outer wall must not exceed 14' (4.3m).

Example B: If the vertical dimension from the floor of the unit is 7' (2.14m), the horizontal run to the face of the outer wall must not exceed 81/2' (2.6m).

Sidewall Vent Graph showing the relationship between vertical and horizontal dimensions for a Direct Vent flue system.



Horizontal Dimension From the Outside Face of the Wall to the Back of the Fireplace

Figure 14 - Rear Wall Venting Graph


56D3049

#### VENTING INSTALLATION

#### **REAR WALL VENT INSTALLATION (5"x8" VENTING ONLY)**

When installed as a rear vent unit this appliance may be vented directly to a termination located on the rear wall behind the appliance

- The maximum horizontal distance between the rear of the appliance and the termination is 20" (508 m). See Figure 15.
- Only one 45° elbow is allowed in these installations.



Top View Flat Installation

Figure 15 - Rear Vent Application, Maximum Horizontal Distance

 Rigid vent pipes and fittings have special twist-lock connections. Assemble the desired combination of pipe and elbows to the appliance adaptor.

**Twist-lock Procedure:** The female ends of the pipes and fittings have three locking lugs (indentations). These lugs will slide straight into matching slots on the male end of adjacent pipes and fittings. Push the pipe sections together and twist one section clockwise approximately one-quarter turn until the sections are fully locked. *See Figure 16*.

- 2. See venting and termination instructions for further instructions.
- 3. Locate and cut the vent opening in the wall. For combustible walls first frame in opening.

Combustible Interior Walls: Cut a  $12\frac{1}{2}$ "H x  $10\frac{1}{2}$ " W hole through the interior wall.

**Combustible Exterior Walls:** Cut a  $10^{1/2}$ "H x  $10^{1/2}$ "W square hole through the exterior wall frame. *See Figure 17*.

**Noncombustible Walls:** Hole opening should be  $8^{1}/2$ " (216mm) in diameter.

4. The center of the hole should line up with the center line of the horizontal rigid vent pipe end. Allow <sup>1</sup>/<sub>4</sub>" minimum rise per foot. *See Figure 17*.




Figure 16 - Rigid Vent Pipe Connections




Figure 17 - Exterior Wall Framing Dimensions

#### REAR WALL VENT INSTALLATION (continued)

4. Apply a bead of non-hardening mastic around the outside edge of vent cap. Position the vent cap in the center of hole on the exterior wall with the word "UP" on the vent cap facing up. Insure proper clearance of 1" to combustibles is maintained. Attach the vent cap with four wood screws supplied. See Figure 18.

VARNING

Do not recess vent termination into any wall. This will cause a fire hazard.

## NOTE: Replace the wood screws with appropriate fasteners for stucco, brick, concrete, or other types of siding.

For vinyl siding, stucco, or wood exterior use vinyl siding standoffs between vent cap and exterior wall for Simpson or Selkirk Terminations only. The vinyl siding standoff prevents excessive heat from melting the vinyl siding material. *Note:* MHSC Terminations does not require standoff. Bolt the vent cap to the standoff or wall. Apply non-hardening mastic around outside edge of the standoff instead of the vent cap assembly. Use wood screws provided to attach the standoff. *See Figure 19.* 

- 5. Slide the wall thimble over the vent pipe before connecting the horizontal run to the vent cap. *See Figure 20*.
- 6. Carefully move the fireplace with vent assembly attached toward the wall and insert the vent pipe into the horizontal termination. The pipe overlap should be a minimum of 1<sup>1</sup>/4". Apply silicone to the outer pipe connection. Fasten all vent connections with screws provided.
- 7. Slide the wall thimble against the interior wall surface and attach with screws. *See Figure 20*.

NOTICE

For more information, follow instructions that comes with terminations.




Figure 18 - Installing Horizontal Vent Cap




Figure 19 - Installing Vinyl Siding Standoff and Termination




Figure 20 - Connecting Vent Cap with Horizontal Vent Pipe

#### **VENT INSTALLATION**

## HORIZONTAL WITH VERTICAL RISE (THROUGH-THE-WALL) TERMINATION CONFIGURATIONS

Since it is very important that the venting system maintain its balance between the combustion air intake and the flue gas exhaust, certain limitations as to vent configurations apply and must be strictly adhered to.

The Vent Graph, showing the relationship between vertical and horizontal side wall venting, will help to determine the various dimensions allowable. *See page 17*.

Minimum clearance between vent pipes and combustible materials is 3" on top and 1" from bottom and sides unless otherwise noted (Exception: Outside wall with firestop: 1" all around pipes are allowed).

When vent termination exits through foundations less than 20" below siding outcrop, the vent pipe must flush up with the siding.

It is best to locate the fireplace in such a way that minimizes the number of offsets and horizontal vent length.

The horizontal vent run refers to the total length of vent pipe from the flue collar of the fireplace (or the top of the transition elbow) to the face of the outer wall or the mounting flange of the termination.

MARNING

When installing the appliance as a rear vent unit, the 90° 45° transition elbow attached directly to the rear of the unit is NOT INCLUDED in the following criteria and calculations, and unless specifically mentioned should be ignored when calculating venting layouts.

- The maximum number of 90° elbows per side wall installation is three (3). See Figure 21.
- If a 90° elbow is fitted directly on top of the fireplace flange, the maximum horizontal vent run before the termination or a vertical rise is 36" (914mm). *See Figure 22*.




Figure 21 - Maximum Three (3) 90° Elbows
Per Installation




Figure 22 - Maximum Horizontal Run with No Rise

## HORIZONTAL (THROUGH-THE-WALL) TERMINATION CONFIGURATION (Continued)

• If a 90° elbow is used in the horizontal vent run (level height maintained) the horizontal vent length is reduced by 36" (914 mm) (Fig. 21 A and B) This does not apply if the 90° elbows are used to increase or redirect a vertical rise. *See Figure 24*.

Example: According to the vent graph (page 17) the maximum horizontal vent length in a system with a 7.5' vertical rise is 20' (6m) and if a 90° elbow is required in the horizontal vent it must be reduced to 17' (5.2 m).

*In Figures 23 and 24*, Dimension A plus B must not be greater than 17' (5.2m).

- The maximum number of 45° elbows permitted per side wall installation is two (2). These elbows can be installed in either the vertical or horizontal run.
- For each 45° elbow installed in the horizontal run, the length of the horizontal run MUST be reduced by 18" (45cm). This does not apply if the 45° elbows are installed on the vertical part of the vent system.
- The maximum number of elbow degrees in a system is 270°. *See Figure 25*.




Figure 24 - Maximum Vent Run with Elbows




Figure 23 - Horizontal Run Reduction

Example: Elbow 1 = 90° Elbow 2 = 45° Elbow 3 = 45° Elbow 4 = 90°

Total Angular Variation = 270°




Figure 25 - Maximum Elbow Usage

21

#### HORIZONTAL WITH VERTICAL RISE (THROUGH-THE-WALL) APPLICATIONS

1. Locate and cut the vent opening in the wall. For combustible walls first frame in opening.

Combustible Interior Walls: Cut a  $12^{1}/2$ "H x  $10^{1}/2$ " W hole through the interior wall.

**Combustible Exterior Walls:** Cut a  $10^{1}/2$ "H x  $10^{1}/2$ "W square hole through the exterior wall frame. *See Figure 17*.

**Noncombustible Walls:** Hole opening should be  $8\frac{1}{2}$ " (216mm) in diameter.

2. The center of the hole should line up with the center line of the horizontal rigid vent pipe end. Allow <sup>1</sup>/<sub>4</sub>" minimum rise per foot. *See Figure 26*.

You may use a reducer from 5"x8" to 4"x6<sup>5</sup>/<sub>8</sub>" for horizontal with vertical rise application. ONLY use framing instructions below when using 4"x6<sup>5</sup>/<sub>8</sub>" venting.

If the reducer is installed at the rear of the unit, you must immediately follow with a 90° elbow for a vertical rise before continuing with any horizontal run.

1. Locate and cut the vent opening in the wall. For combustible walls first frame in opening.

Combustible Interior Walls: Cut a  $11\frac{1}{2}$ "H x  $9\frac{1}{2}$ " W hole through the interior wall.

**Combustible Exterior Walls:** Cut a  $9\frac{1}{2}$ "H x  $9\frac{1}{2}$ "W square hole through the exterior wall frame. See Figure 16.

**Noncombustible Walls:**Hole opening should be  $7^{1}/2$ " (190mm) in diameter.

2. The center of the hole should line up with the center line of the horizontal rigid vent pipe end. Allow <sup>1</sup>/<sub>4</sub>" minimum rise per foot. *See Figure 27*.




Figure 26 - Exterior Wall Framing Dimensions for 5"x8"

NOTE: #1222DA reducer must be used when 4x6<sup>5</sup>/<sub>8</sub>" venting is preferred. Reducer must be installed directly onto unit at pipe adaptor before vertical rise.




Figure 27 - Exterior Wall Framing Dimensions for 4"x65/8"

#### **BELOW GRADE INSTALLATIONS**

When it is not possible to meet the required vent terminal clearances of 12" above grade level, a snorkel kit is recommended. It allows installation depth down to 7" (178mm) below grade level. The 7" (178mm) is measured from the center of the horizontal vent pipe as it penetrates through the wall.

Ensure that sidewall venting clearances are observed. If venting system is installed below ground, we recommend a window well with adequate and proper drainage to be installed around the termination area.

If installing a snorkel, a minimum 24" vertical rise is necessary. The maximum horizontal run with the 24" vertical pipe is 36". This measurement is taken from the collar of the fireplace (or transition elbow) to the face of the exterior wall. See the Sidewall Venting Graph for extended horizontal run if the vertical exceeds 24".

- 1. Establish vent hole through the wall. See Figure 17, page 18.
- 2. Remove soil to a depth of approximately 16" below base of snorkel. Install drain pipe. Install window well (not supplied). Refill hole with 12" of coarse gravel leaving a clearance of approximately 4" below snorkel. *See Figure 28*.
- 3. Install vent system.
- 4. Ensure a watertight seal is made around the vent pipe coming through the wall.
- 5. Apply high temperature sealant caulking (supplied) around the 5" and 8" snorkel collars.
- 6. Slide the snorkel into the vent pipes and secure to the wall.
- 7. Level the soil so as to maintain a 4" clearance below snorkel. See Figure 28.

**NARNING** 

- · Do not back fill around snorkel.
- A clearance of at least 4" must be maintained between the snorkel and the soil.

If the foundation is recessed, use recess brackets (not supplied) for securing lower portion of the snorkel. Fasten brackets to wall first, then secure to snorkel with self drilling  $\#8x^{1/2}$  sheet metal screws. It will be necessary to extend vent pipes out as far as the protruding wall face. *See Figure 29*.




Figure 28 - Below Grade Installation




Figure 29 - Snorkel Installation, Recessed Foundation

#### **VENT INSTALLATION**

#### VERTICAL THROUGH-THE-ROOF APPLICATIONS

NOTICE

A restrictor disc must be installed on any vertical termination that is higher than 12'.

Install restrictor disc as shown in Figure 30 for vertically vented applications.

Up to three (3) restrictor discs may be needed for 40' installation.

The two (2) restrictor discs suppled will work for most installations. If a third disc is needed order Part No. 56D3027.

You may use a reducer to 4"x6<sup>5</sup>/8" in vertically vented applications.




Figure 30 - Installing Restrictor Disc into Stove Collar

#### **VERTICAL THROUGH-THE-ROOF APPLICATIONS (continued)**

This Gas Fireplace has been approved for,

• Vertical installations up to 40' (12m) in height. Up to a 10' (3m) horizontal vent run can be installed within the vent system using a maximum of two 90° elbows. See Figure 31.




Figure 31 - Support Straps for Horizontal Runs

• Up to two 45° elbows may be used within the horizontal run. For each 45° elbow used on the horizontal plane, the maximum horizontal length must be reduced by 18" (450mm).

#### Example: Maximum horizontal length

No elbows = 10' (3m)  $1x45^{\circ}$  elbows = 8.5' (2.6m) $2x45^{\circ}$  elbows = 7' (2.1m)

- A minimum of an 8' (2.5m) vertical rise is required.
- Two sets of 45°elbows offsets may be used within the vertical sections. From 0 to a maximum of 8' (2.5 m) of vent pipe can be used between elbows. See Figure 32.
- Determine the roof pitch and use the appropriate starter kit for offset installation.
- The maximum angular variation allowed in the system is 270°. See Figure 32.
- The minimum height of the vent above the highest point of penetration through the roof is 1' (305mm).




Figure 32 - Maximum elbow Usage

#### **VENT INSTALLATION**

#### INSTALLATION FOR VERTICAL TERMINATION

1. Determine the route your vertical venting will take. If ceiling joist, roof rafters or other framing will obstruct the venting system, consider an offset. *See Figure 33* to avoid cutting load bearing members.

NOTE: Pay special attention to these installation instructions for required clearances (air space) to combustibles when passing through ceilings, walls, roofs, enclosures, attic rafters, etc. Do not pack air spaces with insulation. Also note maximum vertical rise of the venting system and any maximum horizontal offset limitations. Offsets must fall within the parameters shown in Figure 14, page 17.

2. Set fireplace in desired location. Drop a line plumb down from the ceiling to the position of the flue exit. Mark the center point where the vent will penetrate the ceiling. Drill a small locating hole a this point.

Drop a plumb line from the inside of the roof to the ceiling locating hole in the ceiling. Mark the center point where the vent will penetrate the roof. Drill a small locating hole at this point.

#### FLAT CEILING INSTALLATION

- 1. Cut a 10<sup>1</sup>/<sub>2</sub>" (267mm) square hole in the ceiling using the locating hole as a center point The opening should be framed to 10<sup>1</sup>/<sub>2</sub>"x10<sup>1</sup>/<sub>2</sub>" (267mm x 267mm) inside dimensions as shown in *Figure 34* using framing lumber the same size as the ceiling joist. If the area above the ceiling is an insulated ceiling or a room, nail firestop from the top side. This prevents loose insulation from falling into the required clearance space. *See Figure 34*. Otherwise, install firestop below the framed hole. The firestop should be installed with no less than three nails per side. *See Figure 35*.
- 2. Assemble the desired lengths of pipe and elbows necessary to reach from the burner system flue up through the firestop. Be sure pipe and elbow connections are fully twist-locked. *See Figure 16, page 18.*
- 3. Cut a hole in the roof using the locating hole as a center point. (Cover any exposed open vent pipes before cutting hole in roof). The 10<sup>1</sup>/<sub>2</sub>"x10<sup>1</sup>/<sub>2</sub>" (267mm x 267mm) hole must be measured on the horizontal. Actual length may be larger depending on the pitch of the roof. There must be a 1" minimum clearance from the vent pipe to combustible materials. (Insulation should be considered a combustible material) Frame the opening as shown in *Figure 17 on page 18*.




Figure 33 - Offset with Wall Strap and 45° Elbows




Figure 34 - If area above is a room, install firestop above framed hole as shown




Figure 35 - If area above is not a room, install firestop below framed hole as shown

Continued on next page

#### **INSTALLATION FOR VERTICAL TERMINATION** (CONTINUED)

4. Connect a section of pipe and extend up through the hole.

NOTE: If an offset is needed to avoid obstructions, you must support the vent pipe every three (3) feet. Use wall straps for this purpose. See Figure 33, page 26. Whenever possible, use 45° elbows instead of 90° elbows. The 45° elbow offers less restriction to the flow of the flue gases and intake air.

- 5. Place the flashing over the pipe section(s) extending through the roof. Secure the base of the flashing to the roof and framing with roofing nails. Be sure roofing material overlaps the top edge of the flashing. There must be a 1" clearance from the vent pipe to combustible materials.
- 6. Continue to add pipe sections until the height of the vent cap meets the minimum requirements below.

NOTE: You must increase vent height for steep roof pitches. Nearby trees, adjoining roof lines, steep pitched roofs, and other similar factors may cause poor draft or down-drafting in high winds. Increasing the vent height may solve this problem.

NOTE: If the vent pipe passes through any occupied areas above the first floor, including storage spaces and closets, you must enclose pipe. You may frame and sheetrock the enclosure with standard construction material. Make sure to meet the minimum allowable clearances to combustibles. Do not fill any of the required clearance spaces with insulation.




Figure 36 - Minimum Chimney Clearance

TERMINATION HEIGHT TABLE Use this table to determine the minimum height above the roof.			
	Minimum Height		
Roof Pitch	Feet	Meters	
Flat to 7/12	1	0.3	
Over 7/12 to 8/12	1.5	0.46	
Over 8/12 to 9/12	2	0.61	
Over 9/12 to 10/12	2.5	0.76	
Over 10/12 to 11/12	3.25	0.99	
Over 11/12 to 12/12	4	1.22	
Over 12/12 to 14/12	5	1.52	

#### FIREPLACE INSTALLATION

#### **CHECK GAS TYPE**

Use proper gas type for the fireplace you are installing. If you have conflicting gas type, do not install fireplace. See dealer where you purchased the fireplace for proper fireplace according to your gas type.

#### INSTALLING GAS PIPING TO FIREPLACE LOCATION

#### **INSTALLATION ITEMS NEEDED**

Before installing fireplace and burner system, make sure you have the items listed below.

- External regulator (supplied by installer) Tee joint
- Piping (check local codes)
- Pipe wrench
- Sealant (resistant to propane/LP gas)
- Test gauge connection\*
- Sediment trap (optional but recommended)
- approved flexible gas line with gas connector (if allowed by local codes — not provided)
- \* A CSA design-certified equipment shutoff valve with <sup>1</sup>/<sub>8</sub>" NPT tap is an acceptable alternative to test gauge connection. Purchase the CSA design-certified equipment shutoff valve from your dealer.

VARNIN

A qualified installer or service person must connect appliance to gas supply. Follow all local codes.

CAUTION

For propane/LP units, never connect fireplace directly to the propane/LP supply. This burner system requires an external regulator (not supplied). Install the external regulator between the burner system and propane/LP supply.

For propane/LP connections only, the installer must supply an external regulator. The external regulator will reduce incoming gas pressure. You must reduce incoming gas pressure to between 11 and 13 inches of water. If you do not reduce incoming gas pressure, burner system regulator damage could occur. Install external regulator with the vent pointing down as shown in *Figure 37*. Pointing the vent down protects it from freezing rain or sleet.




Figure 37 - External Regulator with Vent Pointing Down (Propane/LP Only)

When using copper or flex connectors use only fittings approved for gas connections. The gas control inlet is <sup>3</sup>/<sub>8</sub>" NPT.

SAUTION

Use only new black iron or steel pipe. Internally tinned copper or copper tubing can be used per National Fuel Code, section 2.6.3, providing gas meets hydrogen sulfide limits, and where permitted by local codes. Gas piping system must be sized to provide minimum inlet pressure (listed on data plate) at the maximum flow rate (BTU/hr). Undue pressure loss will occur if the pipe is too small.

ARNING

External regulators may be necessary for natural gas. One- or two-pound systems will damage this appliance and may cause fire hazard.

WARNING

Only persons licensed to work with gas piping may make the necessary gas connections to this appliance.

AUTION

A manual shutoff valve must be installed upstream of the appliance. Union tee and plugged 1/8" NPT pressure tapping point should be installed upstream of the appliance. See Figure 38.

NOTE: The gas line connection may be made using 1/2" rigid tubing or an approved flex connector. Since some municipalities have additional local codes it is always best to consult your local authorities and the current edition of the National Fuel Gas Code ANSI.Z223.1, NFPA54. In Canada CAN/CGA-B149 (1 or 2) Installation Code.

A listed manual shutoff valve must be installed upstream of the appliance. Union tee and plugged <sup>1</sup>/<sub>8</sub>" NPT pressure tapping point should be installed upstream of the appliance. *See Figure 38*.

IMPORTANT: Install main gas valve (equipment shutoff valve) in an accessible location. The main gas valve is for turning on or shutting off the gas to the fireplace.

Check your building codes for any special requirements for locating equipment shutoff valve to fireplaces.

Apply pipe joint sealant lightly to male threads. This will prevent excess sealant from going into pipe. Excess sealant in pipe could result in clogged burner system valves.

Use pipe joint sealant that is resistant to liquid petroleum (LP) gas.

We recommend that you install a sediment trap/drip leg in supply line as shown in *Figure 38*. Locate sediment trap/drip leg where it is within reach for cleaning. Install in piping system between fuel supply and burner system. Locate sediment trap/drip leg where trapped matter is not likely to freeze. A sediment trap traps moisture and contaminants. This keeps them from going into the burner system gas controls. If sediment trap/drip leg is not installed or is installed wrong, burner system may not run properly.




Figure 38 - Gas Connection

#### **CHECKING GAS PRESSURE**

- 1. Check gas type. The gas supply must be the same as stated on the appliance's rating decal. If the gas supply is different from the fireplace, STOP! Do not install the appliance. Contact your dealer immediately.
- 2. To ease installation, a 18" (457mm) flex line with manual shut-off valve has been provided with on this appliance. Install and attach <sup>1</sup>/<sub>2</sub>" gas line onto shut-off valve.
- 3. After completing gas line connection, purge air from gas line and test all gas joints from the gas meter to the fireplace for leaks. Use a solution of 50/40 water and soap or a gas sniffer.
- 4. To adjust flame height, turn HI/LO knob to HI to get maximum pressure to burner. Turn HI/LO knob to LO to get minimum pressure.
- 5. To check gas pressures at valve, turn captured screw counter clockwise 2 or 3 turns and then place tubing to pressure gauge over test point. Turn unit to high. *See Figure 39*. After taking pressure reading, be sure and turn captured screw clockwise firmly to reseal. Do not over torque. Check test points for gas leaks.

NOTE: Captured screws for pressure reading are located in the same place in all three valve types: Millivolt, Electronic and Remote Hi/Lo.




Figure 39 - Gas Pressure Check at Gas Valve (Millivolt Valve Shown)

**VARNING** 

Do not use open flame to check for gas leaks.

31

#### **ELECTRICAL WIRING**

This fireplace will work without any electrical supply except to operate blowers, electronic ignition system and Hi/Lo remote control receiver.

NOTE: If installed in mobile home, fireplace must be bolted securely to floor.

**MARNING** 

Electrical connections should only be performed by a qualified, licensed electrician. Main power must be off when connecting to main electrical power supply or performing service. All wiring shall be in compliance with all local, city, and state codes. The appliance, when installed, must be electrically grounded in accordance with local codes, or in the absence of local codes, with the *National Electrical Code ANSI/ NFPA 70 (latest edition) and Canadian Electrical Code, CSA C22.1.* 

**AUTION** 


Label all wires before disconnecting when servicing controls. Wiring errors can cause improper and dangerous operation.

Verify proper operation after servicing.

#### REMOTE WALL MOUNTED SWITCH FOR MILLIVOLT VALVES ONLY

A remote wall switch and up to fifteen (15) feet of 18 Ga. wire may be used with this appliance. Attach the wall switch in a junction box at the desired location on the wall. *See Figure 40*. Do not extend beyond the wall switch wire length provided.

*NOTE:* Extended lengths of wire may cause the fireplace not to function properly. Longer length of wire is permitted if the wire is made out of larger gauge (diameter) wire. Always check with local code.



56D3049

#### **ELECTRICAL INSTALLATION**

#### **ELECTRONIC PILOT IGNITION WIRING**

WARNING

Do not connect 110-120 VAC to the Remote Wall Switch. The appliance will malfunction.




Figure 41 - Electronic Ignition System Wiring Diagram

#### **REMOTE WALL SWITCH**

Position the wall switch. Do not extend beyond the 15 feet of wire.

#### **OPTIONAL DC REMOTE SYSTEMS**

These instructions replace the section entitled *Hearth Mount* in the Millivolt hand held remote instructions supplied with the remote.

- 1. Follow instructions on remote control to snap remote cover plate to remote receiver.
- 2. Connect the wire terminal from the remote receiver. This replaces the 15' wall switch connection to the switch. *See Figure* 41.
- 3. Use screws that came with remote control to mount remote control receiver at junction box (for your wall switch) or at control panel (when installation in unit is preferred).

#### REMOTE HI/LO WITH BLOWER WIRING DIAGRAM






Figure 42 - Remote Hi/Lo with Blower Wiring Diagram

#### **CANOPY INSTALLATION**



#### **GLASS FRAME REMOVAL**

- 1. Remove louver assembly from the top.
- 2. Release three (3) clamps on bottom of fireplace. See Figure 45.
- 3. Tilt glass frame out and lift glass frame up until it clears hook on top of fireplace.
- 4. Set glass frame aside.



#### **BRICK INSTALLATION**

#### FLOOR BRICK INSTALLATION

Install floor brick before installing logs or rock wool.

- 1. Remove floor brick from packaging.
- 2. Put left and right brick pieces together as shown in Figure 46.
- 3. Match two (2) firebox tabs with two (2) slots on bottom of brick. See Figure 46.
- 4. Push brick down until it makes contact with bottom of firebox.

Note: Remove floor brick to install brick walls. Remove floor brick for cleaning.




Figure 46 - Installing Floor Brick

#### LOG AND ROCK WOOL INSTALLATION

#### INSTALLING LOGS AND ROCK WOOL (EMBER MATERIAL) IN FIREBOX

- 1. Carefully remove logs from wrapping.
- 2. Remove glass frame. See Glass Frame Removal, page 35.
- 3. Break rock wool into dime-sized pieces. Cover rear burner completely with rock wool. On front burner, only cover the ports. Do not exceed 1/2" depth of coverage. *See Figure 47*.
- 4. Place bottom right log (#3) on two pins against right side of firebox. See Figure 48.
- 5. Place rear log (#1) on two pins against back side of firebox. See Figure 49.
- 6. Place bottom left log (#2) on two pins against left side of firebox. See Figure 50.




Figure 47 - Installing Rock Wool




Figure 49 - Installing Rear Log (#1)




Figure 48 - Installing Bottom Right Log (#3)




Figure 50 - Installing Bottom Left Log (#6)

#### LOG AND ROCK WOOL INSTALLATION

- 7. Place right mid log (#7) on two right pins on burner assembly. See Figure 51.
- 8. Place left mid log (#6) on two left pins on burner assembly. See Figure 52.
- 9. Place right top log (#5) on top of right mid log and top of bottom right log. See Figure 53.
- 10. Place top left log (#4) on top of left mid log and top of bottom left log. See Figure 54.




Figure 51 - Installing Right Mid Log (#7)




Figure 53 - Installing Right Top Log (#5)




Figure 52 - Installing Right Mid Log (#6)




Figure 54 - Installing Top Left Log (#4)

#### **ROCK WOOL INSTALLATION**

- 11. Place top center log (#8) across rear log (#1) and left mid log (#6). See Figure 55.
- 12. Cover any exposed burner surface with rock wool. For best flame and glow, do not block air space between burners and logs with rock wool. *See Figures 56 and 57*.




Figure 55 - Installing Center Top Log (#8)




Figure 56 - All Logs on Burner with Rock Wool




Figure 57 - Rock Wool Placement after Logs are Installed (Top View)

#### OPERATING INSTRUCTIONS - MILLIVOLT AND REMOTE HI/LO WITH BLOWER

#### FOR YOUR SAFETY READ BEFORE LIGHTING

WARNING

If you do not follow these instruction exactly, a fire or explosion may result causing property damage, personal injury or loss of life.

- **A.** This appliance is equipped with a pilot which must be lit with built-in ignitor while following these instructions exactly.
- **B.** BEFORE OPERATING smell all around the appliance area for gas. Be sure to smell next to the floor because some gas is heavier than air and will settle on the floor.

#### WHAT TO DO IF YOU SMELL GAS:

- Turn off all gas to the appliance.
- Open windows.
- Do not attempt to light any appliance.
- Do not touch any electric switch; do not use any phone in your building.
- Immediately call your gas supplier from a neighbor's phone. Follow the gas supplier's instructions.
- If you cannot reach your gas supplier, call the fire department.
- **C.** Use only your hand to push in, or turn the gas control knob. Never use tools. If the knob will not push in or turn by hand, don't try to repair it. Call a qualified service technician. Force or attempted repair may result in a fire or explosion.
- **D.** Do not use this appliance if any part of it has been under water. Immediately call a qualified service technician to inspect the appliance and to replace any part of the control system and any gas control that has been under water.

#### LIGHTING PILOT FOR THE FIRST TIME

#### **INITIAL LIGHTING**

Purge air from the supply line as follows:

- Open main shutoff valve.
- Unscrew main pressure test point.
- Leave inlet test screw open until gas comes in.
- When gas is flowing, tighten inlet screw immediately.

## VARNING

Never use an open flame to check for gas leaks.

#### LEAK TESTING

- 1. Follow the pipe from the gas supply line connection to the gas valve. Check connection for leaks with soap and water mixture.
- 2. Next check for gas leaks at the burner with soap and water mixture.
- 3. Check the pilot for gas leaks with soap and water mixture.

Continued on next page

## LIGHTING PILOT FOR THE FIRST TIME MILLIVOLT AND REMOTE HI/LO

#### APPROVED LEAK TESTING METHOD

You may check for gas leaks with the following methods only:

- Soap and water solution
- An approved leak testing spray
- Electronic sniffer

ANGE

Never check for gas leak with open flame!

VARNING

If using a soap and water solution to test for leaks, DO NOT spray solution onto control body.

NOTE: Remove any excessive pipe compound from the connections. Excessive pipe compound can set off electronic sniffers.

Check for gas leaks in each of the following locations:

- Pipe from the gas supply line connection to the gas valve
- Burner connections
- Pilot
- Each joint or connection

- Field made joints / gas shutoff valve
- Factory made joints
- All joints on valve and control body

#### LIGHTING PILOT - MILLIVOLT AND REMOTE HI/LO

- 1. Depress and turn knob counterclockwise **x** to pilot position.
- 2. Depress fully and hold pilot gas knob. Depress piezo ignitor as many times as needed to ignite the pilot. Keep knob fully depressed for a few seconds. Release and check that pilot continues to burn.

If the pilot does not stay lit, repeat steps 1 and 2.




Figure 58 - Pilot Position

For lighting burner on Millivolt units, see page 42.

For lighting burner on Remote HI/LO units, see page 44.

Continued on next page

#### LIGHTING BURNER - MILLIVOLT

#### MAIN BURNER SWITCH

The "ON/OFF/RS" switch for the main burner can be found behind door of the fireplace. This switch allows you to turn on and to turn off the main burner without using the gas valve knob. Make sure the button is in the "ON" position to light the main burner. *See Figure 59*.

#### LIGHTING THE BURNER

Depress and turn the knob counterclockwise to the "ON" position. *See Figure 60*. It will take less than four (4) seconds for the burner to ignite.



Figure 59 -On/Off/RS Switch




Figure 60 - On Position

#### PILOT POSITION

Depress and turn knob to pilot position to keep burner off while maintaining the pilot light. *See Figure 61*.




Figure 61 - Pilot Position

#### TO TURN OFF GAS - MILLIVOLT

Depress and turn knob clockwise to "OFF" position. See Figure 62.

WARNING

The control is fitted with a safety interlock device which prevents unsafe ignition of the pilot burner after the control knob has been turned to the OFF position. The knob may only be rotated back to the PILOT position after the safety magnet has been released (approximately 60 seconds). You will hear a "click" when the safety magnet releases.




Figure 62 - Off Position

Continued on next page

#### FOR YOUR SAFETY READ BEFORE LIGHTING

- **A.** This appliance is equipped with an ignition device (Piezo) which automatically lights the pilot. Do **NOT** try to light the burner by hand.
- **B.** BEFORE OPERATING smell all around the appliance area for gas. Be sure to smell next to the floor because some gas is heavier than air and will settle on the floor.

## NARNING

If you do not follow these instructions exactly, a fire or explosion may result causing property damage, personal injury or loss of life.

#### **WARNING**

Never use an open flame to check for gas leak.

#### WHAT TO DO IF YOU SMELL GAS:

- Turn off all gas to the appliance.
- Open windows.
- Do not attempt to light any appliance.
- Do not touch any electric switch; do not use any phone in your building.
- Immediately call your gas supplier from a neighbor's phone. Follow the gas supplier's instructions.
- If you cannot reach your gas supplier, call the fire department.
- C. Turn off all electric power to appliance.
- **D.** Do not use this appliance if any part of it has been under water. Immediately call a qualified service technician to inspect the appliance and to replace any part of the control system and any gas control that has been under water.

#### LIGHTING ELECTRONIC IGNITION

- 1. STOP! Read the safety information above.
- 2. Set switch to "OFF".
- 3. Turn off all electric power to the appliance.
- 4. This appliance is equipped with an ignition device which automatically lights the burner. Do not try to light the burner by hand.
- 5. Wait 5 minutes to clear out any gas. Then smell for gas, including near the floor. If you smell gas STOP! Follow "B" What to Do if You Smell Gas above. If you do not smell gas, go to the next step.




Figure 63 - Electronic Gas Valve

- 6. Turn on all electric power to appliance.
- 7. Turn RS-OFF-ON rocker switch to "ON".
- 8. If the appliance will not operate, follow the instruction *To Turn Off Gas* below and call your service technician or gas supplier.

#### TO TURN OFF GAS - ELECTRONIC IGN

- 1. Open lower door.
- 2. Turn RS-OFF-ON rocker switch to "OFF".
- 3. Turn off all electric power to the appliance if service is to be performed.
- 4. Close lower door.

#### LIGHTING PILOT AND BURNER

#### **LIGHTING PILOT**

See instructions on pages 40 and 41.

Depress and turn knob clockwise

#### LIGHTING THE BURNER

Depress and turn the knob counterclockwise to the "ON" position. *See Figure 64*. Use remote control transmitter to turn "ON" burner. See detailed instructions on *pages 45 - 50*.




Figure 64 - On Position

#### LIGHTING THE BURNER IN POWER OUTAGES

After the pilot has been lit and the valve knob moved to the "ON" position, slide remote receiver switch to "ON" position. See Figure 78, page 49.




Figure 65 - Pilot Position

#### **PILOT POSITION**

Depress and turn knob to pilot position to keep burner off while maintaining the pilot light. In this position, remote control will not be able to operate burner. *See Figure 65*.

#### TO TURN

➤ to "OFF" position. See Figure 66.

OFF GAS

WARNING

The control is fitted with a safety interlock device which prevents unsafe ignition of the pilot burner after the control knob has been turned to the OFF position. The knob may only be rotated back to the PILOT position after the safety magnet has been released (approximately 60 seconds). You will hear a "click" when the safety magnet releases.




Figure 66 - Off Position

Continued

This remote control system provides a safe, reliable and user-friendly remote control for the millivolt valve gas, blower speed and flame height adjustment. The system can be manually or thermostatically turned on and off with the transmitter.

#### FEATURES/SPECIFICATIONS

- Easy Access Thermostatic Control
- Low battery Indication for Transmitter and Receiver
- Three Speed Control for Blower
- Programmable Timer to turn blower on and off
- 16 Security Codes
- Quick Disconnect Wiring Assembly

- Battery Powered Transmitter
- Compact 120 VAC Adapter with 30" wire
- Three Flame Height Setting
- Child Proof Lock-out
- 6-hour Shut Down (Optional) on receiver
- Reset Button for transmitter

# WARNING

- This remote control system requires three (3) "AAA" alkaline batteries to power the transmitter. The receiver is powered by external AC Adapter (see page 33 diagram).
- Do not short (or jumper) across the gas valve terminals to test the remote control installation. This could damage the unit and void the warranty.
- Only use remote control system as described in this manual. Any other use is not recommended and will void the warranty.

NOTICE

The monitoring components in the transmitter are very sensitive. Let the transmitter stabilize to room temperature before accurate room temperatures are displayed. If the transmitter is activated from a severe cold condition, wait 15 minutes for accurate temperature readings to appear on the LCD display.

## ARNING

Turn appliance OFF and allow to cool before installing or servicing. DO NOT connect 110-120 VAC wiring to the millivolt gas control valve. Any modification of components will void the warranty and may cause a fire hazard.

# **MARNING**

Turn appliance OFF (at the appliance or remote receiver) if you are away from your house for an extended period of time. Never leave anything on top of the surface of the transmitter.

Continued

56D3049

45

#### REMOTE TRANSMITTER

#### **INSTALLING BATTERIES**

The remote transmitter uses three (3) "AAA" batteries.

To install batteries...

- 1. Press down the battery door tab. Pull out to remove the battery door.
- 2. Install the batteries as indicated on transmitter.
- 3. Close the battery door and snap in place.
- 4. When three batteries are installed, the transmitter will initialize for 10 seconds and then is ready for use.
- 5. The batteries should be replaced at least once every 6 months or when the low battery icon indicator is displayed.

#### SETTING PRIVACY (DIP) SWITCH ON RECEIVER AND TRANSMITTER:

The remote receiver and transmitter privacy (DIP) switches are preset at the factory. In the event of activation or interference from other nearby transmissions, reset the code using the following procedure:

- 1. Slide the code switches on the transmitter and receiver to your choice of ON or OFF position. Switches #1, #2, #3 and #4 are preset to "ON" for both the transmitter and receiver.
- 2. The switches on the transmitter and receiver must match in order for the system to work.
- 3. To check, press either the On or Off button on the transmitter and the receiver indicator light will blink. If not repeat step 2.
- 4. The system is now ready to operate.




Figure 67 - Dip Switch Set at Default

VARNING

Do not use two (2) or more remote control systems in the same area with the same dip switch settings, as they will communicate with each other. This may cause the appliances to malfunction.

Continued

#### **RESET BUTTON**

1. The reset button can be used to reset the transmitter if transmitter is not working properly. The reset button is located behind the battery door cover in the lower left corner of battery compartment. Using a paper clip, press the reset button and the transmitter will reset and initialize for 10 seconds before it can be used.

Auto/Flame Button

#### TRANSMITTER - See Figure 68

#### **GENERAL**

This remote control has two (2) operating modes — Manual and Thermostatic.

The control system can be set to temperature ranges between 45°F and 90°F. The blower speed and flame height can be adjusted in either the manual and thermostatic mode.

The transmitter (See Figure 65) will operate the remote receiver from 1 ft. to a maximum of 30 feet. The distance is reduced when batteries are low or when the receiver is inside a metal enclosure.



- 1. After initial power up or when RESET button is pressed, the transmitter is reset. The reset button is located behind the battery door of transmitter.
- 2. During system reset, all features of the LCD DISPLAY will be visible. After one second, the LCD will be initialized. A typical reset display is shown in *Figure 65*. Note that the temperature scale is degree F.
- 3. Press On button to select between °C and °F display. It will exit setting mode automatically after 10 seconds if no key is pressed. The transmitter will send an Off signal after reset.
- 4. After reset, the transmitter is operating in manual mode. See Figure 69.

#### MANUAL MODE - See Figure 70

- 1. Press the ON button once to turn on the appliance with max flame height.
- 2. Press the OFF button to decrease flame height.
  - The first two pressing will decrease flame height to lower level.
  - The third pressing will turn fireplace off.
- 3. If holding on OFF button for more than 3 second, fireplace will be shut off

#### THERMOSTATIC MODE - See Figure 71

- 1. Press the AUTO/FLAME button to enter the thermostatic mode.
- 2. In thermostatic mode, press the ON/ button or OFF/ button to set the desired set temperature.
- 3. Once the setting is completed, the transmitter will automatically turn on the fireplace when the room temperature is below the set temperature and turn off the appliance when the room temperature is above the set temperature within 1 degree.
- 4. There will be a slight delay in the response of the unit (on/off) to a temperature. Room temperature is monitored every 3 minutes.
- 5. Press the AUTO/FLAME button to exit the thermostatic mode. The transmitter will be in the manual off mode and the fireplace will be shut off.




Figure 68 - Transmitter




Figure 69 - Reset Mode



Figure 70 - Manual Mode



Figure 71 - Thermostatic Mode

Continued

#### 3-SPEED BLOWER CONTROL - See Figure 72

- 1. Press FAN button once to enter blower speed setup mode at low speed initially and one of the three blade icon will display darken on LCD display.
- 2. Continue to press FAN button to set up the blower speed you desire.
- 3. If there is no input within 3 seconds, the new setting will be transmitted to receiver. If fireplace is on, the blower speed will take effect right away; if fireplace is off, the receiver will remember this setting and blower is still off.
- 4. If you continue to press FAN button to the position that all blade is gone, the FAN icon will disappear and turn the blower off.

### BLOWER ON DELAY TIME AND OFF DELAY TIME SETTING - See Figure 73

- 1. Hold FAN button for 5 second and two numbers will show up in LCD screen. The upper one is On Delay Time and the bottom is Off Delay Time.
- 2. Use the ON/ button to set the desired On Delay Time from 0 to 15 min.
- 3. Use the OFF/ button to set the desired Off Delay Time from 0 to 15 min.
- 4. If there is no input within 3 seconds, the new setting will be transmitted to receiver.
- 5. The default settings for both transmitter and receiver are 5 minutes for On Delay Time and 8 minutes for Off Delay Time, as shown in this picture.

NOTE: The most efficient setting for your fireplace blower is when blower comes on and off and it is blowing warm air only not hot air, giving the fireplace enough time to discharge as much warm air as possible before turning off.

### FLAME HEIGHT SETTING FOR THERMOSTATIC MODE - See Figure 74

- 1. Hold AUTO/FLAME button for 5 seconds and a number and flame icon will show up on the LCD screen, as show in the right figure.
- 2. Use the ON / or OFF / button to set the desired flame height to 1 (Min), 2 (Medium) and 3 (Max).
- 3. If there is no input within 3 seconds, the new setting will be transmitted to receiver. This setting only affects auto mode operation.
- 4. The default setting for transmitter is 2 (Medium), as shown in right picture.

#### **LOW BATTERY DETECTION - See Figure 75**

- 1. Battery voltage is checked once a minute. When the battery voltage drops to a certain level, the low-battery icon will display on LCD, and the transmitter will turn off the appliance. The transmitter will not function anymore until fresh batteries are installed.
- 2. When the batteries are low, the LCD displays a low battery indicator. The low battery indicator will be displayed in any mode.
- The transmitter will not operate with low batteries. Change the batteries before the batteries are too weak for normal operation. TURN THE UNIT OFF BEFORE REPLACING BATTERIES.



Figure 72 -3-Speed Blower Mode



Figure 73 -Blower On Delay Time and Off Delay Time



Figure 74 -Flame Height Setting



Figure 75 -Low Battery Detection

Continued

Switch

#### CHILD-PROOF PROTECTION - See Figure 76

- 1. Press and hold the ON and OFF buttons simultaneously for 3 seconds to enter childproof mode as shown in this picture.
- 2. The transmitter will not send a signal again until childproof mode is deactivated by pressing the ON and OFF buttons simultaneously for 3 seconds to exit childproof mode and the Childproof indicator disappears from LCD.

#### TRANSMITTER THERMAL SHUTDOWN - See Figure 77

- 1. If transmitter measures a room temperature exceeding 99 degrees Fahrenheit, the LCD will display "HI" and the transmitter will turn off the appliance.
- 2. Transmitter will not function until the room temperature has dropped below 99° Fahrenheit. If transmitter measures a room temperature less than 40° Fahrenheit, the LCD will display "LO" and **NO SIGNAL will be sent to turn on the appliance.**



Figure 76 -Child Proof Protection



Figure 77 -Transmitter Thermal Shutdown

## RECEIVER - See Figure 78 SLIDE SWITCH

- 1. **ON position:** the main burner will ignite and blower will come on when Blower on Delay Time is reached and fan speed has been enabled, the flame height is max; otherwise just the burner will ignite until the slide switch is placed in the OFF or RS positions.
- 2. **RS position:** the system will only operate if the remote receiver receives a signal from the transmitter.
- 3. **OFF position:** the system is off. If fan speed has been enabled blower will continue to operate until Off Delay Time expires. **The slide switch should be placed in the OFF position if you will be away for an extended period of time.** The OFF position also functions as a safety device by both turning the system off and rendering the receiver inoperable.




Figure 78 - Receiver

#### **OPTIONAL 6-HOUR SHUTDOWN**

- 1. The receiver comes preset from the factory with a 6-hour shutdown from its last ON or flame lower operation. This is done to prevent the appliance from continuing to run if unattended.
- 2. You may disable this feature if you wish. To disable, change the receiver privacy (DIP) switch #1 ONLY to the OFF position. Make sure the transmitter privacy (DIP) switches are set the same as the receiver. Follow the instructions on how to set the privacy (DIP) switch setting.
- 3. If you disable this feature, your appliance will continue to run unattended.

Continued

#### TESTING YOUR NEW REMOTE CONTROL SYSTEM

- 1. Light your gas appliance following the appliance lighting instructions on *Page 41*.
- 2. Slide the 3 position button on the remote receiver to the ON position and the main gas flame should ignite.
- 3. Slide the button to OFF and the main gas flame should extinguish, but the pilot light will remain on.
- 4. Slide the button to RS (the center position), then press the ON button on transmitter to turn the system ON. The main gas flame should ignite and blower should come on after the On Delay Time is reached and fan speed you desire is selected.
- 5. Press the OFF button on transmitter to turn the system to OFF. The flame should extinguish (the pilot light will remain on) and blower should be off after the Off Delay Time you set.

**NOTE:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help,

**NARNING** 

Turn off gas before servicing fireplace. It is recommended that a qualified service technician perform these check-ups at the beginning of each heating season

#### **BURNER, PILOT AND CONTROL COMPARTMENT**

Keep the control compartment, logs, and burner areas surrounding the logs clean by vacuuming or brushing at least twice a year. Make sure the burner porting, pilot air opening and burner air opening are free of obstructions at all times.

#### **PILOT FLAME**

The flames from the pilot should be visually checked as soon as the heater is installed and periodically during normal operation. **The pilot flame must always be present when the fireplace is in operation.** *See Figure 79.* The pilot flame has three distinct flames, one engulfing the thermopile, one engulfing the thermocouple, and the other reaching to the main burner.

# Thermopile

Thermocouple

Figure 79 - Pilot Flame

#### **BURNER**

Inspect area around the injector. Remove any lint or foreign material with a brush or vacuum

#### **BURNER FLAME**

The flames from the burner should be visually checked as soon as the heater is installed and periodically during normal operation. In normal operation, at full rate, and after operating for about 15 to 30 minutes, the flame should be yellow and slightly taller than the rear log. *See Figure 80*.

If the flame is blue and only in the center, turn off unit and let cool. After unit is cool, remove logs and check to make sure rock wool is placed correctly. Replace logs.

NOTE: The type of installation, vent system configuration, and wind effects may cause the flame patterns to vary.




Figure 80 - Burner Flame Appearance

#### **CLEANING AND MAINTENANCE**

#### **VENT SYSTEM**

The fireplace and venting system should be inspected before initial use and at least annually by a qualified field service person. Inspect the external vent cap on a regular basis to make sure that no debris is interfering with the airflow. Inspect entire venting system to ensure proper function.

#### **GLASS DOOR**

Thoroughly clean the inside of the glass door after using the fireplace for ten hours. Periodically clean the glass door as necessary.

When cleaning the glass, remember:

- **Do not remove the glass when hot.** Allow glass to cool before removal.
- NEVER use abrasive materials.
- Keep children and pets a safe distance away.
- Never operate the fireplace without the glass door properly secured.
- Never operate the fireplace if the glass is broken.
- Replace any glass that is chipped, cracked, or broken. Replacement glass door assemblies MUST be supplied by the fireplace manufacturer No substitute materials may be used.
- Handle glass door with care to avoid striking or scratching it on hard objects.

To clean glass door, follow "Glass Removal" procedure outlined in the *Final Installation* section. Film deposit on the inside of the glass should be cleaned off using a nontoxic, non-corrosive, non-abrasive, mild cleaning solution. Simply apply an adequate amount to the glass and wipe off with a damp cloth. After all maintenance has been completed, re-install glass door.

#### **LOGS**

Leave logs installed in the fireplace for cleaning. Vacuum surface of the logs with a brush attachment. If logs must be removed for cleaning, handle carefully by holding gently at each end. Gloves are recommended to prevent skin irritation from ceramic fibers. If skin becomes irritated, wash gently with soap and water. Vacuum surface of logs with brush attachment or brush logs with a soft bristle brush (i.e. clean, dry paintbrush). To place logs back in the fireplace, see "Log Placement" found in the *Final Installation* section.


NOTE: Do not use cleaning fluid to clean logs.

#### **ROCK WOOL**


Replace or add rock wool as required following installation instructions in the *Final Installation* section of this manual.

#### LOGS


Item	Description	Qty	500DVH
1	Rear Log	1	56D3034K
2	Bottom Left Log	1	56D3035K
3	Bottom Right Log	1	56D3036K
4	Left Top Log	1	56D3037K
5	Right Top Log	1	56D3038K
6	Left Mid Log	1	56D3039K
7	Right Mid Log	1	56D3040K
8	Center Log	1	56D3041K



#### VENT COMPONENTS FOR 4"x65/8"




	Qty/		Simpson Duravent	Selkirk
Item	Вох	Description	MHS	C P/N
1	1	Horizontal High Wind Termination Cap	985	4DT-HC
1	1	Horizontal Square Termination Cap with Built-In Vinyl Siding Standoff, Heat Deflector and Firestop	ВНІ	RTK
1	1	Horizontal Rigid Pipe Termination Kit with Horizontal Termination Cap with Built-In Vinyl Siding Standoff, Heat Deflector, Firestop, 90° Elbow and 11"x14 <sup>5</sup> /8" Adjustable Pipe	BHS	STK
1	1	Horizontal Flexible Pipe Termination Kit with Horizontal Termination Cap with Built-In Vinyl Siding Standoff, Heat Deflector, Firestop, 20" to 40" Flexible Pipe Adapter	BHS	FTK
2	1	Vertical Termination	980	4DT-VC
3	6	6" Pipe Length	908	4DT-06
3	6	9" Pipe Length	907	4DT-09
3	6	12" Pipe Length	906	4DT-12
3	6	24" Pipe Length	904	4DT-24
3	6	36" Pipe Length	903	4DT-36
3	6	48" Pipe Length	902 4DT-48	
4	6	11" To 14 5/8" Pipe, Adjustable	911	4DT-AJ
4	6	17" To 24" Pipe, Adjustable	917	4DT-AJ14
5	6	45° Elbow	945	4DT-EL45
5	6	45° Swivel Elbow	945G	4DT-EL45
6	6	90° Elbow	990	4DT-EL90
6	6	90° Swivel Elbow	990G	4DT-EL90
7	6	Flashing, 0/12 To 6/12 Roof Pitch	943	4DT-AF6
8	6	Storm Collar	953	4DT-SC
9	6	Firestop	963	4DT-FS
10	1	Vinyl Siding Standoff	950	4DT-VS
11	1	Reducer to 4"x6 <sup>5</sup> /8"	122	2DA



	Qty/		Simpson Duravent	Selkirk	
Item	Box	Description	MHSC P/N		
1	1	Horizontal High Wind Termination Cap	1285	5DT-HC	
1	1	Horizontal Termination Cap with Built-In Vinyl Siding Standoff, Heat Deflector, Firestop and Adjustable Pipe 7" to 11"	BHF	R8TK	
1	1	Horizontal Termination Cap Built-In Vinyl Siding Standoff, Heat Deflector, Firestop, 90° Elbow and Adjustable Pipe 7" to 11"	BHS8TK		
1	1	Horizontal Termination Cap with Built-In Vinyl Siding Standoff, Heat Deflector, Firestop and Flexible Pipe 24" to 48"	BHS	F8TK	
2	1	Vertical Termination	1280	5DT-VC	
3	4	6" Pipe Length	1208	5DT-06	
3	4	9" Pipe Length	1207	5DT-09	
3	4	12" Pipe Length	1206	5DT-12	
3	4	24" Pipe Length	1204	5DT-24	
3	4	36" Pipe Length	1203	5DT-36	
3	4	48" Pipe Length	1202	5DT-48	
4	4	11" To 14 5/8" Pipe, Adjustable	1211	5DT-AJ	
4	4	17" To 24" Pipe, Adjustable	1217	N/A	
5	4	45° Elbow	1245	5DT-EL45	
5	4	45° Swivel Elbow	1245G	5DT-EL45	
6	4	90° Elbow	1290	5DT-EL90S	
6	4	90° Swivel Elbow	1290G	5DT-EL90S	
7	6	Flashing, 0/12 To 6/12 Roof Pitch	1243	5DT-AF6	
8	6	Storm Collar	1253	5DT-SC	
9	4	Firestop	1263	5DT-FS	
10	1	Vinyl Siding Standoff	1250	5DT-VS	

#### **FIREBOX COMPONENTS**




#### **FIREBOX COMPONENTS**

Item	Description	Qty	500DVH		
Standard	Standard Features				
1	Junction Box Assembly	1	26D2128K		
2	Top Louver Assembly	1	56D2134K		
3	Bottom Louver Door Assembly	1	56D2135K		
4	Glass Frame Assembly	1	56D3050		
5	Canopy	1	56D2056K		
6	Firebrick Floor	1	56D3055		
7	Insulation Board	1	56D2156K		
8	Firebrick Center	1	56D2034K		
9	Firebrick Right	1	56D2035K		
10	Firebrick Left	1	56D2036K		
Accesso	Accessories/Field Installed Options				
11	Blower*	2	56D2162K		
12	Thermostat Sensor*	1	26D2870K		
13	Speed Control*	1	26D0746K		
11,12,13	T-stat Blower with Speed Control*	1	BLOTSDV		

<sup>\*</sup> Blower is a standard feature in 500DVHRNV and 500DVHRPV units.


#### **ADDITIONAL ACCESSORIES**



#### ADDITIONAL ACCESSORIES/FIELD INSTALLED OPTIONS AVAILABLE


Item	Description	Qty	500DVH
1	Metal Trim - Brass	1	BRMTK500
1	Metal Trim - Pewter	1	PWMTK500
1	Metal Trim - Black	1	BLMTK500
2	Brass Louvers	8	L36BRM
2	Pewter Louvers	8	L36PWM
3	Screen Frame - Black	1	SDV500SDC
4	Cabinet Door Frame - Black	1	VSDVC500CDFB
4	Cabinet Door Frame - Iron Age	1	VSDVC500CDFIA
4	Cabinet Doors with Screen - Black	1	VSDVC500CDB
4	Cabinet Doors with Screen - Iron Age	1	VSDVC500CDIA
5	Arched Front with Lower Control Door - Black	1	VSDVC500AFB
5	Arched Front with Lower Control Door - Iron Age	1	VSDVC500AFIA

#### STANDING PILOT — MILLIVOLT CONTROL



#### STANDING PILOT - MILLIVOLT CONTROL


Item	Description	Qty	500DVHNV	500DVHPV
1	Gas Valve Assembly	1	37D0117	37D0118
2	Pilot Assembly	1	20H2048	20H2049
2C	Replacement Thermocouple	1	37D1067	37D1067
21	Replacement Igniter and Wire	1	37D1069	37D1069
2T	Replacement Thermopile	1	37D1068	37D1068
3A	Valve/Tee Tube	1	56D3045	56D3045
3B 3C	Front Burner Tube	1 1	56D3046	56D3046
30	Rear Burner Tube	<u>'</u>	56D3047	56D3047
4	Flex Hose with Shutoff Valve	1	69D0030	69D0030
5	Rocker Switch	1	41D0048	41D0048
6	Piezo Igniter	1	14D0503	14D0503
7A	Front Injector	1	56D3059	62D3005
7B	Rear Injector	1	62D3003	20H3143
8A	Front Burner Assembly	1	56D3051	56D3051
8B	Rear Burner Assembly	1	56D3052	56D3052
9	Venturi	1	45D0600	45D0600
10	Wire Assembly (Switch)	1	44D0500	44D0500
10	Wire Assembly (Remote)	1	44D0501	44D0501
Acce	ssories			
11	Thermostatic Remote Control	1	RCT/TRC	RCT/TRC
12	Remote Control On/Off	1	RCM/MRC	RCM/MRC
13	Remote Control Basic	1	RCB/RCBE	RCB/RCBE
14	Wireless Wall Thermostat	1	WWTD/WWTA	WWTD/WWTA
15	Wall Switch Kit	1	MVWS	MVWS
16	Wall Thermostat Kit	1	MVWTS	MVWTS
Conv	ersion Kit (Not Shown)			
	500 Conversion NG to LPG	1	HCK500CKP	_
	500 Conversion LPG to NG	1	_	HCK500CKN



#### **ELECTRONIC IGNITION**

Item	Description	Qty	500DVHNE	500DVHPE	
1	Gas Valve Assembly	1	37D0016	37D0017	
2	Pilot Assembly	1	54D2004	54D2005	
3A	Valve/Tee Tube	1	56D3045	56D3045	
3B	Front Burner Tube	1	56D3046	56D3046	
3C	Rear Burner Tube	1	56D3047	56D3047	
4	Flex Hose with Shutoff Valve	1	69D0030	69D0030	
5	Rocker Switch	1	41D0048	41D0048	
6A	Front Injector	1	56D3059	62D3005	
6B	Rear Injector	1	62D3003	20H3143	
7A	Front Burner Assembly	1	56D3051	56D3051	
7B	Rear Burner Assembly	1	56D3052	56D3052	
8	Venturi	1	45D0600	45D0600	
9	Wire Assembly	1	54D2007	54D2007	
10	Ignition Module	1	37D0325	37D0325	
11	Transformer	1	022788	022788	
Conv	Conversion Kit (Not Shown)				
	500 Conversion NG to LPG	1	HCK500CKEP		
	500 Conversion LPG to NG	1	_	HCK500CKEN	

#### STANDING PILOT — REMOTE HI/LO WITH BLOWER



#### **REMOTE HI/LO WITH BLOWER**

Item	Description	Qty	500DVHRNV	500DVHRPV
1	Gas Valve Assembly	1	56D3074	56D3075
2	Pilot Assembly	1	20H2048	20H2049
2C	Replacement Thermocouple	1	37D1067	37D1067
21	Replacement Igniter and Wire	1	37D1069	37D1069
2T	Replacement Thermopile	1	37D1068	37D1068
3A	Valve/Tee Tube	1	56D3045	56D3045
3B	Front Burner Tube	1	56D3046	56D3046
3C	Rear Burner Tube	1	56D3047	56D3047
4	Flex Hose with Shutoff Valve	1	69D0030	69D0030
5	Transmitter	1	RCSITE-TX	RCSITE-TX
6	Piezo Igniter	1	14D0503	14D0503
7A	Front Injector	1	56D3059	62D3005
7B	Rear Injector	1	62D3003	20H3143
8A	Front Burner Assembly	1	56D3051	56D3051
8B	Rear Burner Assembly	1	56D3052	56D3052
9	Venturi	1	45D0600	45D0600
10	Accessory Packet:	1		
	Covers, Wires, Screws		RCSITE-AP	RCSITE-AP
11	Receiver with A/C Adaptor	1	RC-RS	RC-RS
Conv	ersion Kit (Not Shown)			
	500 Conversion NG to LPG	1	HCK500CKRP	_
	500 Conversion LPG to NG	1	<u> </u>	HCK500CKRN

### MASSACHUSETTS RESIDENTS ONLY: PLEASE READ AND FOLLOW THESE SPECIAL REQUIREMENTS

#### NOTE REGARDING VENTED PRODUCTS

This product must be installed by a licensed plumber or gas fitter when installed within the Commonwealth of Massachusetts.

Any residence with a direct vent product must have a CO detector installed in the residence.

Installation of the fireplace or vented gas log in the State of Massachusetts requires the damper to be permanently removed or welded in the fully open position.

In addition, a naturally vented gas log may not be installed in a bedroom or bathroom in the State of Massachusetts.

Flex line installation must not exceed 36 inches and must have a T shutoff valve.

#### NOTE REGARDING VENT FREE PRODUCTS

This product must be installed by a licensed plumber or gas fitter when installed within the Commonwealth of Massachusetts.

In addition, vent free products may not be installed in a bedroom or bathroom regardless of size or type in the State of Massachusetts.

Flex line installation must not exceed 36 inches and must have a T shutoff valve.

#### CARBON MONOXIDE DETECTOR REQUIREMENTS

- (2) Revise 10.8.3 by adding the following additional requirements:
- (a) For all side wall horizontally vented gas fueled equipment installed in every dwelling, building or structure used in whole or in part for residential purposes, including those owned or operated by the Commonwealth and where the side wall exhaust vent termination is less than seven (7) feet above finished grade in the area of the venting, including but not limited to decks and porches, the following requirements shall be satisfied:
  - 1. INSTALLATION OF CARBON MONOXIDE DETECTORS. At the time of installation of the side wall horizontal vented gas fueled equipment, the installing plumber or gas fitter shall observe that a hard wired carbon monoxide detector with an alarm and battery back-up is installed on the floor level where the gas equipment is to be installed. In addition, the installing plumber or gas fitter shall observe that a battery operated or hard wired carbon monoxide detector with an alarm is installed on each additional level of the dwelling, building or structure served by the side wall horizontal vented gas fueled equipment. It shall be the responsibility of the property owner to secure the services of qualified licensed professionals for the installation of hard wired carbon monoxide detectors
    - a. In the event that the side wall horizontally vented gas fueled equipment is installed in a crawl space or an attic, the hard wired carbon monoxide detector with alarm and battery back-up may be installed on the next adjacent floor level.
    - b. In the event that the requirements of this subdivision can not be met at the time of completion of installation, the owner shall have a period of thirty (30) days to comply with the above requirements; provided, however, that during said thirty (30) day period, a battery operated carbon monoxide detector with an alarm shall be installed.

#### SPECIAL REQUIREMENTS CONTINUED

- 2. APPROVED CARBON MONOXIDE DETECTORS. Each carbon monoxide detector as required in accordance with the above provisions shall comply with NFPA 720 and be ANSI/UL 2034 listed and IAS certified.
- 3. SIGNAGE. A metal or plastic identification plate shall be permanently mounted to the exterior of the building at a minimum height of eight (8) feet above grade directly in line with the exhaust vent terminal for the horizontally vented gas fueled heating appliance or equipment. The sign shall read, in print size no less than one-half (1/2) inch in size, "GAS VENT DIRECTLY BELOW. KEEP CLEAR OF ALL OBSTRUCTIONS."
- 4. INSPECTION. The state or local gas inspector of the side wall horizontally vented gas fueled equipment shall not approve the installation unless, upon inspection, the inspector observes carbon monoxide detectors and signage installed in accordance with the provisions of 248 CMR 5.08(2)(a)1 through 4.
- (b) EXEMPTIONS: The following equipment is exempt from 248 CMR 5.08(2)(a)1 through 4:
  - 1. The equipment listed in Chapter 10 entitled "Equipment Not Required To Be Vented" in the most current edition of NFPA 54 as adopted by the Board; and
  - 2. Product Approved side wall horizontally vented gas fueled equipment installed in a room or structure separate from the dwelling, building or structure used in whole or in part for residential purposes.
- (c) MANUFACTURER REQUIREMENTS GAS EQUIPMENT VENTING SYSTEM PROVIDED. When the manufacturer of Product Approved side wall horizontally vented gas equipment provides a venting system design or venting system components with the equipment, the instructions provided by the manufacturer for installation of the equipment and the venting system shall include:
  - 1. Detailed instructions for the installation of the venting system design or the venting system components; and
  - 2. A complete parts list for the venting system design or venting system.
- (d) MANUFACTURER REQUIREMENTS GAS EQUIPMENT VENTING SYSTEM NOT PROVIDED. When the manufacturer of a Product Approved side wall horizontally vented gas fueled equipment does not provide the parts for venting the flue gases, but identifies "special venting systems," the following requirements shall be satisfied by the manufacturer:
  - 1. The referenced "special venting system" instructions shall be included with the appliance or equipment installation instructions; and
  - 2. The "special venting systems" shall be Product Approved by the Board, and the instructions for that system shall include a parts list and detailed installation instructions.
- (e) A copy of all installation instructions for all Product Approved side wall horizontally vented gas fueled equipment, all venting instructions, all parts lists for venting instructions, and/or all venting design

#### TROUBLESHOOTING

#### **GENERAL TROUBLESHOOTING**

SYMPTOM	POSSIBLE CAUSE	ACTION
1. Glass Soots	A.Flame impingement on logs	A. Install log set per the instructions Inspect the injector and air intake area. Make sure this area does not have any blockage from debris and clean. Check gas supply.
2. Flame burn blue and lifts off burner (ghosting)	A.Insufficient oxygen being supplied	A.Ensure that the vent cap is installed properly and free of debris. Ensure that the vent system joints are tight and have no leaks. Ensure that no debris has been blocking the inner air intake at the bottom back of the combustion chamber. Ensure that the glass is properly secure and latch.

#### **STANDING PILOT IGNITION**

SYMPTOM	POSSIBLE CAUSE	ACTION
1. Spark ignitor	A. Wire disconnected.	A.Open door and check to make sure wire is connected to ignitor.
will not light pilot after	B. Defective ignitor.	B. Check for spark at electrode and pilot. If no spark and electrode wire is properly connected, replace pilot assembly.
repeated triggering of piezo.	C. No gas or low gas pressure.	C.Check remote/manual shut off valve from fireplace. Low pressure can be caused by bent lines, restricted lines, low pressure line pressure. Consult with plumber or gas supplier.
	D. No Propane/LPG in tank	D.Check Propane/LPG tank. Refill tank.
2. Pilot will not stay lit after carefully following lighting instructions.	A. Defective thermocouple	A.Check that thermocouple flame impinges on thermocouple. Clean and/or adjust pilot for maximum flame impingement. Ensure that the thermocouple connection at the gas valve is fully inserted and tight.  Disconnect the thermocouple from the valve, place one millivolt lead wire on the tip of the thermocouple and the other meter lead wire on the thermocouple copper lead. Start the pilot and hold the valve knob in. If the millivolt reading is less than 15 mV, replace pilot assembly.
	B. Defective valve	B. If thermocouple is producing more than 15 mV, replace faulty valve.
3. Pilot burning, valve knob turned to "ON", switch is turned to	A. Defective switch, wall switch, remote control or wire	A.Check switch and wire for proper connection. Place jumper wires across terminals of switch. If burner comes on, replace defective switch. If the switch is OK, repeat the same procedure on remote control If burner comes on, replace remote control.  Place jumper wire across wire at gas valves (terminals marked TH and TP/TH). If burner comes on, wires are faulty or connections are bad. Replace wire.
"ON" or	B. Pilot flame too small	B. If pilot flame is not close enough to the thermopile, adjust pilot flame.
"RS", but burner will not ignite.	C. Defective or malfunctioning thermopile	C. Check thermopile wire connections to make sure all are tight and that the thermopile is fully inserted into pilot assembly. Check thermopile with a millivolt meter. Connect leads to TP and TP/TH terminals on the control valve. If meter reading is below 325 mV, replace pilot assembly.
	D. Defective valve	D. Turn valve knob to "On" and switch to "ON." Take a reading at the thermopile leads (TP & TP/TH) on the valve. If the meter reads greater than 175 mV and the burner does not light, replace defective valve
		A.Clean and adjust the pilot flame for maximum flame impingement on thermocouple.
5. The pilot and main burner	A. Inner vent pipe leaking exhaust gases back into system	A.Check for flue product leak. Replace defective pipe section.
extinguish while in	B. Horizontal vent improperly pitched	B. Check horizontal-venting piping is running upward 1/4" per foot. Do not run the pipe level or downward.
operation	C. Improper vent cap installation	C. Check for proper installation and freedom from debris or blockage

#### TROUBLESHOOTING REMOTE SYSTEM


SYMPTOM	POSSIBLE CAUSE	ACTION
1. Battery icon on LCD on transmitter.	1. Low Battery	1. Replace batteries. Change batteries every 6 months.
2. LCD display is blank	]	2. Check battery installation or replace batteries.
3. LCD display shows "funny" display		3. Press Reset button at the back of the transmitter.
4. Appliance does not come on.	1. Wiring / Electrical Connections	1. Slide the switch to ON, if appliance comes ON, wiring is not the cause.
		2. If appliance does not come on,
	2. Privacy (DIP) switch setting on transmitter does not match receiver	1. Make sure the transmitter and receiver have the same DIP switch settings.
	3. Transmitter measures temperature exceeding 99°F and shows "HI" on LCD	1. Move transmitter to a cooler place and wait until temperature drops below 99°F.
	4. Distance between the transmitter and receiver is more than 30 feet	1. Make sure the operating distance is less than 30 feet
5. Receiver cannot receive signal.	Receiver is     installed in an     enclosure	Make sure the receiver is not located inside to tight of an enclosure.
6. Blower is not on after the fireplace is turned on	1. Blower setting is off	1. Press FAN key to select Fan speed you desire.
	2. Blower delay setting is set too high	2. Press and hold FAN key to set desired ON/OFF delays. This is done in minutes.

MARNING

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

#### **TROUBLESHOOTING**

#### ELECTRONIC IGNITION START



#### LIMITED LIFETIME WARRANTY POLICY

#### LIFETIME WARRANTY

The following components are warranted for life to the original owner, subject to proof of purchase: Firebox, Combustion Chamber, Heat Exchanger, Grate and Stainless Steel Burners.

#### **FIVE YEAR WARRANTY**

The following components are warranted five (5) years to the original owner, subject of proof of purchase: Ceramic Fiber Logs.

#### **BASIC WARRANTY**

MHSC warrants the components and materials in your gas appliance to be free from manufacturing and material defects for a period of two years from date of installation. After installation, if any of the components manufactured by MHSC in the appliance are found to be defective in materials or workmanship, MHSC will, at its option, replace or repair the defective components at no charge to the original owner. MHSC will also pay for reasonable labor costs incurred in replacing or repairing such components for a period of two years from date of installation. Any products presented for warranty repair must be accompanied by a dated proof of purchase.

This Limited Lifetime Warranty will be void if the appliance in not installed by a qualified installer in accordance with the installation instructions. The Limited Lifetime Warranty will also be void if the appliance is not operated and maintained according to the operating instructions supplied with the appliance, and does not extend to (1) firebox/burner assembly damage by accident, neglect, misuse, abuse, alterations, negligence of others, including the installation thereof by unqualified installers, (2) the costs of removal, reinstallation or transportation of defective parts on the appliance, or (3) incidental or consequential damage. All service work must be performed by an authorized service representative.

This warranty is expressly in lieu of other warranties, express or implied, including the warranty of merchantability of fitness for purpose and of all other obligations or liabilities. MHSC does not assume for it any other obligations or liabilities in connection with sale or use of the appliance. It states that do not allow limitations on how long an implied warranty lasts, or do not allow exclusion of indirect damage, those limitations of exclusions may not apply to you. You may also have additional rights not covered in the Limited Lifetime Warranty.

MHSC reserves the right to investigate any and all the claims against the Limited Lifetime Warranty and decide upon method of settlement.

#### IF WARRANTY SERVICE IS NEEDED...

- 1. Contact your supplier. Make sure you have your warranty, your sales receipt and the model/serial number of your MHSC product.
- 2. DO NOT ATTEMPT TO DO ANY SERVICE WORK YOURSELF.