

This Owner's Manual is provided and hosted by [Appliance Factory Parts](#).



# Monessen Hearth HDV500PV Owner's Manual

[Shop genuine replacement parts for Monessen Hearth  
HDV500PV](#)



[Find Your Monessen Hearth Fireplace Parts - Select From 701 Models](#)

----- Manual continues below part list -----

## Available Replacement Parts for Monessen Hearth HDV500PV

|                            |                           |
|----------------------------|---------------------------|
| <a href="#">37D0118</a>    | VALVE SIT MV HI/LO LP (05 |
| <a href="#">SRV14D0503</a> | PIEZO IGNITER-snap in     |
| <a href="#">SRV41D0048</a> | SWITCH ON/OFF/RS          |




## HDV Series Direct Vent Gas Fireplace

Installation and Operating Instructions

Models:

HDV500NV/PV, NSC/PSC



### WARNING

IF THE INFORMATION IN THESE INSTRUCTIONS IS NOT FOLLOWED EXACTLY, A FIRE OR EXPLOSION MAY RESULT CAUSING PROPERTY DAMAGE, PERSONAL INJURY OR LOSS OF LIFE.

- Do not store or use gasoline or other flammable vapors and liquids in the vicinity of this or any other appliance.
- **WHAT TO DO IF YOU SMELL GAS**
  - Do not try to light any appliance.
  - Do not touch any electrical switch; do not use any phone in your building.
  - Immediately call your gas supplier from a neighbor's phone. Follow the gas supplier's instructions.
  - If you cannot reach your gas supplier, call the fire department.
- Installation and service must be performed by a qualified installer, service agency or the gas supplier.

**WARNING:** Improper installation, adjustment, alteration, services or maintenance can cause injury or property damage. Refer to this manual. For assistance or additional information consult a qualified installer, service agency or the gas supplier.

This appliance may be installed in an aftermarket\*, permanently located, manufactured home (USA only) or mobile home, where not prohibited by local codes. This appliance is only for use with the type of gas indicated on the rating plate. This appliance is not convertible for use with other gases, unless a certified kit is used.

\* Aftermarket: Completion of sale, not for purpose of resale, from the manufacturer.



### WARNING

**DUE TO HIGH TEMPERATURES, THE APPLIANCE SHOULD BE LOCATED OUT OF TRAFFIC AND AWAY FROM FURNITURE AND DRAPERIES.**

**CHILDREN AND ADULTS SHOULD BE ALERTED TO THE HAZARDS OF HIGH SURFACE TEMPERATURE AND SHOULD STAY AWAY TO AVOID BURNS OR CLOTHING IGNITION.**

**YOUNG CHILDREN SHOULD BE SUPERVISED WHEN THEY ARE IN THE SAME ROOM AS THE APPLIANCE.**

**CLOTHING OR OTHER FLAMMABLE MATERIAL SHOULD NOT BE PLACED ON OR NEAR THE APPLIANCE.**

**KEEP THE ROOM AREA CLEAR AND FREE FROM COMBUSTIBLE MATERIALS, GASOLINE, AND OTHER FLAMMABLE VAPORS AND LIQUIDS.**

**INSTALLER:** Leave this manual with the appliance.

**CONSUMER:** Retain this manual for future reference.

**Thank you and congratulations on your purchase of a  
Monessen Fireplace.**

**PLEASE READ THE INSTALLATION AND OPERATION INSTRUCTIONS BEFORE USING THE APPLIANCE!**

**IMPORTANT: Read all instructions and warnings carefully before starting installation.**

**Failure to follow these instructions may result in a possible fire hazard and will void the warranty.**

|  |           |  |           |
|--|-----------|--|-----------|
| <b>Important Safety Information .....</b>        | <b>3</b>  | <b>Check Gas Pressure -</b>                            |           |
| <b>Code Approval .....</b>                       | <b>4</b>  | <b>Signature Command System .....</b>                  | <b>34</b> |
| <b>Product Features .....</b>                    | <b>5</b>  | <b>Electrical Wiring - Signature Command .....</b>     | <b>34</b> |
| High Elevations .....                            | 5         | <b>Command Center Wall Installation .....</b>          | <b>35</b> |
| Gas Pressures .....                              | 5         | <b>Optional Fan/Blower System -</b>                    |           |
| Gas Specifications & Orifice Sizes.....          | 5         | <b>Signature Command.....</b>                          | <b>36</b> |
| <b>Fireplace &amp; Framing Dimensions.....</b>   | <b>6</b>  | <b>Operating Instructions - Signature Command.....</b> | <b>37</b> |
| <b>Preinstallation Information .....</b>         | <b>7</b>  | Operating Instructions.....                            | 38        |
| Before You Start.....                            | 7         | To Turn Off Gas to Appliance .....                     | 38        |
| Fireplace Framing .....                          | 7         | <b>Signature Command System</b>                        |           |
| Fireplace Location.....                          | 8         | <b>Operating Instructions .....</b>                    | <b>39</b> |
| <b>Clearances .....</b>                          | <b>9</b>  | <b>Canopy Installation .....</b>                       | <b>42</b> |
| <b>Secure Fireplace.....</b>                     | <b>10</b> | <b>Glass Removal.....</b>                              | <b>42</b> |
| <b>Finishing Material .....</b>                  | <b>10</b> | <b>Floor Brick Installation.....</b>                   | <b>43</b> |
| <b>Optional Top Vent Application.....</b>        | <b>11</b> | <b>Log and Rockwool Installation.....</b>              | <b>43</b> |
| <b>Venting Installation.....</b>                 | <b>12</b> | <b>Cleaning and Maintenance .....</b>                  | <b>47</b> |
| Installation Precautions.....                    | 12        | Burner, Pilot and Control Compartment .....            | 47        |
| Installation Clearances.....                     | 13        | Burner Flame .....                                     | 47        |
| Installation Planning.....                       | 14        | Vent System.....                                       | 48        |
| Installation for Vertical Termination .....      | 14        | Glass Door.....  | 48        |
| For Horizontal Termination .....                 | 15        | Logs .....   | 48        |
| How to Use a Vent Graph .....                    | 16        | Rock Wool .....  | 48        |
| Rear Wall Vent Installation .....                | 17        | <b>Troubleshooting .....</b>                           | <b>49</b> |
| Horizontal (Through-the-Wall) Termination        |           | <b>Replacement Parts .....</b>                         | <b>52</b> |
| Configurations.....                              | 18        | Firebox Components.....                                | 52        |
| Horizontal with Vertical Rise                    |           | Standing Pilot - Millivolt Control .....               | 53        |
| (Through-the-Wall) Applications.....             | 20        | Signature Command System .....                         | 55        |
| Below Grade Installation .....                   | 21        | Logs .....   | 57        |
| Vertical Through-the-Roof Installation.....      | 22        | Accessories.....                                       | 58        |
| Installation for Vertical Termination .....      | 23        | 4" x 6 <sup>5/8</sup> " Vent Components .....          | 59        |
| Flat Ceiling Installation .....                  | 23        | 5" x 8" Vent Components .....                          | 60        |
| Flex Venting Installation .....                  | 25        | <b>For Massachusetts Residents Only.....</b>           | <b>62</b> |
| <b>Fireplace Installation.....</b>               | <b>27</b> | <b>Warranty .....</b>                                  | <b>63</b> |
| Check Gas Type.....                              | 27        | <b>Efficiencies.....</b>                               | <b>64</b> |
| Installing Gas Piping to Fireplace/Burner.....   | 27        |  |           |
| <b>Checking Gas Pressure - Millivolt.....</b>    | <b>29</b> |  |           |
| <b>Electrical Installation - Millivolt .....</b> | <b>29</b> |  |           |
| Electrical Wiring .....                          | 29        |  |           |
| Remote Wall Mounted Switch - Millivolt.....      | 30        |  |           |
| <b>Operating Instructions - Millivolt .....</b>  | <b>31</b> |  |           |
| What to do If You Smell Gas.....                 | 31        |  |           |
| Lighting Pilot for First Time .....              | 31        |  |           |
| Lighting Pilot .....                             | 32        |  |           |
| Lighting Burner.....                             | 33        |  |           |
| To Turn Off Gas.....                             | 33        |  |           |

**INSTALLER**

Please leave these instructions with the appliance.

**OWNER**

Please retain these instructions for future reference.

|         |   |
|---------|---|
| WARNING | <ul style="list-style-type: none"> <li>• <b>Read this owner’s manual carefully and completely before trying to assemble, operate, or service this fireplace.</b></li> <li>• <b>Any change to this fireplace or its controls can be dangerous.</b></li> <li>• <b>Improper installation or use of this fireplace can cause serious injury or death from fire, burns, explosions, electrical shock and carbon monoxide poisoning.</b></li> </ul> |
|---------|---|

This fireplace is a vented product. This fireplace must be properly installed by a qualified service person. The glass door must be properly seated and sealed. If this unit is not properly installed by a qualified service person with glass door properly seated and sealed, combustion leakage can occur.

**CARBON MONOXIDE POISONING:** Early signs of carbon monoxide poisoning are similar to the flu with headaches, dizziness and/or nausea. If you have these signs, the fireplace may not have been installed properly. Get fresh air at once! Have the fireplace inspected and serviced by a qualified service person. Some people are more affected by carbon monoxide than others. These include pregnant women, people with heart or lung disease or anemia, those under the influence of alcohol, and those at high altitudes.

Propane/LP gas and natural gas are both odorless. An odor-making agent is added to each of these gases. The odor helps you detect a gas leak. However, the odor added to these gases can fade. Gas may be present even though no odor exists.

Make certain you read and understand all warnings. Keep this manual for reference. It is your guide to safe and proper operation of this fireplace.

1. This appliance is only for use with the type of gas indicated on the rating plate. This appliance is not convertible for use with other gases unless a certified kit is used.
2. For propane/LP fireplace, do not place propane/LP supply tank(s) inside any structure. Locate propane/LP supply tank(s) outdoors. To prevent performance problems, do not use propane/LP fuel tank of less than 100 lbs. capacity.
3. If you smell gas
  - shut off gas supply.
  - do not try to light any appliance.
  - do not touch any electrical switch; do not use any phone in your building .
  - immediately call your gas supplier from a neighbor’s phone. Follow the gas supplier’s instructions.

4. Never install the fireplace
  - in a recreational vehicle
  - where curtains, furniture, clothing, or other flammable objects are less than 42" from the front, top, or sides of the fireplace
  - in high traffic areas
  - in windy or drafty areas
5. **This fireplace reaches high temperatures. Keep children and adults away from hot surfaces to avoid burns or clothing ignition. Fireplace will remain hot for a time after shutdown. Allow surfaces to cool before touching.**
6. **Carefully supervise young children when they are in the room with fireplace.**
7. Do not modify fireplace under any circumstances. Any parts removed for servicing must be replaced prior to operating fireplace.
8. Turn fireplace off and let cool before servicing, installing, or repairing. Only a qualified service person should install, service, or repair the fireplace. Have burner system inspected annually by a qualified service person.
9. You must keep control compartments, burners, and circulating air passages clean. More frequent cleaning may be needed due to excessive lint and dust from carpeting, bedding material, pet hair, etc. Turn off the gas valve and pilot light before cleaning fireplace.
10. Have venting system inspected annually by a qualified service person. If needed, have venting system cleaned or repaired. Refer to Cleaning and Maintenance, *Page 47*.
11. Keep the area around your fireplace clear of combustible materials, gasoline, and other flammable vapor and liquids. Do not run fireplace where these are used or stored. Do not place items such as clothing or decorations on or around fireplace.
12. Do not use this fireplace to cook food or burn paper or other objects.
13. Never place anything on top of fireplace.

14. Do not use any solid fuels (wood, coal, paper, cardboard, etc.) in this fireplace. Use only the gas type indicated on rating plate.
15. This appliance, when installed, must be electrically grounded in accordance with local codes or in the absence of local codes, with the National Electrical Code, ANSI/NFPA 70, or the Canadian Electrical Code, CSA C22.1.
16. Do not obstruct the flow of combustion and ventilation air in any way. Provide adequate clearances around air openings into the combustion chamber along with adequate accessibility clearance for servicing and proper operation.
17. When the appliance is installed directly on carpeting, tile or other combustible material other than wood flooring, you must set appliance on a metal or wood panel or hearth pad extending the full width and depth of the appliance.
18. Do not use fireplace if any part has been exposed to or has been under water. Immediately call a qualified service person to arrange for replacement of the unit.
19. Do not operate fireplace if any log is broken.
20. Do not use a blower insert, heat exchanger insert, or any other accessory not approved for use with this fireplace.
21. Do not operate the fireplace with glass door removed, cracked, or broken.
22. **For Massachusetts residents only refer to Page 62.**

**IMPORTANT:  
PLEASE READ THE FOLLOWING  
CAREFULLY**

It is normal for fireplaces fabricated of steel to give off some expansion and/or contraction noises during the start up or cool down cycle. Similar noises are found with your furnace heat exchanger or car engine.

**IMPORTANT:  
PLEASE READ THE FOLLOWING  
CAREFULLY**

It is not unusual for gas fireplace to give off some odor the first time it is burned. This is due to the manufacturing process.

**Please ensure that your room is well ventilated during burn off — open all windows.**

It is recommended that you burn your fireplace for at least ten (10) hours the first time you use it. Place the fan switch in the “OFF” position during this time.

**WARNING**

**Never connect unit to private (non-utility) gas wells. This gas is commonly known as wellhead gas.**

**! WARNING**



HOT GLASS WILL CAUSE BURNS.  
DO NOT TOUCH GLASS UNTIL COOLED.  
NEVER ALLOW CHILDREN TO TOUCH GLASS.



We recommend that our gas hearth products be installed and serviced by professionals who are certified in the U.S. by the National Fireplace Institute® (NFI) as NFI Gas Specialists.

**CODE APPROVAL**

Direct Vent type appliances draw all combustion air from outside of the dwelling through the vent pipe. These appliances have been tested by CSA and found to comply with the established standards for DIRECT VENT GAS FIREPLACE HEATERS in the USA and Canada as follows:

**LISTED VENTED GAS FIREPLACE HEATER**  
TESTED TO: ANSI Z21.88b-2008 / CSA 2.33b-2008 STANDARDS

A manufactured home (USA only) or mobile home OEM installation must conform with the **Manufactured Home Construction and Safety Standard, Title 24 CFR, Part 3280**, or when such a standard is not applicable, the **Standard for Manufactured Home Installations, ANSI/NCSCBS A225.1**, or **Standard for Gas Equipped Recreational Vehicles and Mobile Housing, CSA Z240.4**.

**PRODUCT SPECIFICATIONS**

- This appliance has been certified for use with either natural or propane gas. See appropriate data plates.
- This appliance is not for use with solid fuels.
- The appliance is approved for bedroom or bedsitting room installations.
- The appliance must be installed in accordance with local codes if any. If none exist use the current installation code. ANSI Z223.1/NFPA 54 in the USA, CSA B149 in Canada.
- This appliance is mobile home approved.
- The appliance must be properly connected to a venting system.
- The appliance is not approved for closet or recessed installations.

|                |  |
|----------------|--|
| <b>WARNING</b> | <b>Do not remove insulation board.</b> |
|----------------|--|

**HIGH ELEVATIONS**


Input ratings are shown in BTU per hour and are certified without deration for elevations up to 4,500 feet (1,370 m) above sea level.

For elevations above 4,500 feet (1,370 m) in USA, installations must be in accordance with the current ANSI Z223.1/NFPA 54 and/or local codes having jurisdiction.

In Canada, please consult provincial and/or local authorities having jurisdiction for installations at elevations above 4,500 feet (1,370 m).

**GAS PRESSURES**


|                   | Natural    | Propane (LP) |
|-------------------|------------|--------------|
| Inlet Minimum     | 4.0" w.c.  | 11.0" w.c.   |
| Inlet Maximum     | 10.5" w.c. | 13.0" w.c.   |
| Manifold Pressure | 3.5" w.c.  | 10.0" w.c.   |



**Figure 1 - HDV500 Fireplace**  
*(Millivolt Unit Shown - Also Available with Signature Command System)*

**GAS SPECIFICATIONS & ORIFICE SIZE**

| Model     | Fuel | Max. Input BTU/h | Min. Input BTU/h | Front Burner Orifice Size | Rear Burner Orifice Size |
|-----------|------|------------------|------------------|---------------------------|--------------------------|
| HDV500NV  | Nat. | 41,000           | 28,000           | 2.30 mm                   | #37                      |
| HDV500PV  | LP   | 40,000           | 32,000           | #55                       | #53                      |
| HDV500NSC | Nat. | 41,000           | 28,000           | 2.30 mm                   | #37                      |
| HDV500PSC | LP   | 40,000           | 32,000           | #55                       | #53                      |



**Figure 2 -  
Fireplace and Framing Dimensions**

**WARNING**

**Do not fill spaces around firebox with insulation or other materials. This could cause a fire.**

**BEFORE YOU START**

Read this homeowner manual thoroughly and follow all instructions carefully. Inspect all contents for shipping damage and immediately inform your dealer if any damage is found. Do not install any unit with damaged, incomplete, or substitute parts. Check your packing list to verify that all listed parts have been received. You should have the following:

- Fireplace (Firebox and Burner System)
- Log Set
- White Toggle Switch
- Non-Combustible Panel
- Switch Cover Plate
- Restrictor Plate/Disc (2)
- Front Floor Brick (2 pcs)
- Rock Wool
- Canopy

**ITEMS REQUIRED FOR INSTALLATION**

- Phillips Screwdriver
- Hammer
- Saw and/or saber saw
- Measuring Tape
- Tee Joint
- Square
- Fireplace Surround Material (Noncombustible)
- Piping Complying with Local Codes
- Pipe Sealant Approved for use with Propane/LPG (Resistant to Sulfur Compounds)
- Framing Materials
- Wall Finishing Materials
- Level
- Electric Drill and Bits
- Pliers
- Pipe Wrench

**FIREPLACE FRAMING**

Firebox framing can be built before or after the appliance is set in place. Refer to *Figure 2* for firebox and framing dimensions. The framing headers may rest on the top of the firebox standoffs.

The firebox may be installed directly on a combustible floor or raised on a platform of an appropriate height. When the firebox is installed directly on carpeting, tile, or other combustible material, other than wood flooring, the firebox shall be installed on a metal or wood panel extending the full width and depth of the enclosure.

**NOTE**

**COLD CLIMATE INSULATION**


If you live in a cold climate, seal all cracks around your appliance, and wherever cold air could enter the room, with noncombustible material. It is especially important to insulate the outside chase cavity between the studs and under the floor on which the appliance rests, if the floor is above ground level.

### FIREPLACE LOCATION

Plan for the installation of your appliance. This includes determining where the unit is to be installed, the vent configuration to be used, framing and finishing details, and whether any optional accessories (i.e. blower, wall switch, or remote control) are desired. Consult your local building code agency to ensure compliance with local codes, including permits and inspections.

The following factors should be taken into consideration:

- Clearance to side-wall, ceiling, woodwork, and windows. Minimum clearances to combustibles **must be maintained**.
- This fireplace may be installed along a wall, across a corner, or use an exterior chase. Refer to *Figure 3* for suggested locations.
- Location should be out of high traffic areas and away from furniture and draperies due to heat from appliance.
- Never obstruct the front opening of the fireplace.
- Do **not** install in the vicinity where gasoline or other flammable liquids may be stored.
- Vent pipe routing. Refer to the *Venting* section found in this manual for allowable venting configurations.
- These units can be installed in a bedroom. See National Fuel Gas Code ANSI Z233.1/ NFPA 54 — (current edition), the Uniform Mechanical Code — (current edition), and Local Building Codes for specific installation requirements.



**Figure 3 -  
Locating Gas Fireplace**

- A Flat on Wall
- B Cross Corner
- C Island\*\*
- D Room Divider\*
- E Flat on Wall Corner\*
- F Chase Installation
- Y 4" Minimum

\*\* Island (C) and room divider (D) installation is possible as long as the horizontal portion of vent system (X) does not exceed 20'. Refer to *Installing Horizontal Termination Configuration* on Page 13.


\* When you install your fireplace in (D) room divider or (E) flat on wall corner positions (Y), a minimum of 6" clearance must be maintained from perpendicular wall and front of fireplace.

**CLEARANCES TO COMBUSTIBLES**

**WARNING**

Follow these instructions carefully to ensure safe installation. Failure to follow instructions exactly can create a fire hazard.

The appliance cannot be installed on a carpet, tile or other combustible material other than wood flooring. If installed on carpet or vinyl flooring, the appliance shall be installed on a metal, wood or noncombustible material panel extending full width and depth of the appliance.




**Figure 4 - Clearances from the Mantel, Ceiling, and Side Wall**


FP2282

**MANTEL CLEARANCES**

**NOTE:** The combustible area around the fireplace must not protrude more than 3/4" from the facing. If it does, it is considered a mantel and must meet the mantel requirements listed in this manual.



**Side View**




**Top View**

**Figure 5 - Mantel Clearances**

**WARNING**

Never obstruct or modify the air inlet or outlet grilles (louvers). This may create a fire hazard.

The fireplace must be secured to the floor and/or to framing studs as shown in *Figure 6*. Use two (2) wood screws or masonry/ concrete screws to secure fireplace to the floor. Use four (4) screws to attach fireplace to framing. The side brackets or nailing flanges are designed to accommodate two thickness of wall boards (1/2" or 5/8").



**Figure 6 -  
Securing Fireplace to Floor and Framing Studs**

**WARNING**

**Do not remove insulation board.**

**FINISHING MATERIAL**

**NOTE:** Any remote wiring (i.e. remote control, wall switch, and optional fan) must be done prior to final finishing to avoid costly reconstruction.

Only noncombustible materials (i.e. brick, tile, slate, steel, or other materials with a UL fire rating of Zero) may be used to cover the black surface of the appliance. A 300°F minimum adhesive may be used to attach facing materials to the black surface. If joints between the finished wall and the fireplace surround are sealed, a 300°F minimum sealant material (General Electric RTV103 or equivalent) must be used.

**WARNING**


After conversion to top vent configuration the 5" (127 mm) flue pipe should be concentric with the 8" (203 mm) outer collar within 1/4".

**OPTIONAL TOP VENT APPLICATION**

The appliance is shipped as a rear vent unit. If the installation layout requires the unit to be a top vent configuration the appliance can be converted by following the steps below.


When removing and refitting the plates and adapter be sure the associated gaskets are undamaged and refitted as required.

1. Remove the eight (8) screws securing the flue pipe adapter to the fireplace body. *Figure 7*
2. Set the flue pipe adapter aside, complete with the gasket. Do not damage the gaskets as the adapter and gasket must be refitted.
3. Remove the eight (8) screws securing the flue pipe cover to the top of the intake box and remove the cover and gasket. *Figure 7*




**Figure 7 - Remove 16 Screws from Flue Pipe Adapter and Flue Pipe Cover**

4. Remove six (6) screws securing the flue pipe to the back of the intake box and remove the pipe and gasket. *Figure 8*
5. Replace flue pipe to top of firebox. Ensure the gasket is in place and undamaged. Secure with six (6) screws. *Figure 9*
6. Place the flue pipe cover and gasket removed in step 3 over the flue opening in bottom of the intake box.



**Figure 8 - Remove Flue Pipe**

7. Refit the flue pipe adapter and gasket to the top of fireplace. Secure the adapter with six (6) screws removed in step 1.



**Figure 9 - Attach Flue Pipe to Top Vent Configurations**

**WARNING**

**Read all instructions completely and thoroughly before attempting installation. Failure to do so could result in serious injury, property damage or loss of life. Operation of improperly installed and maintained venting system could result in serious injury, property damage or loss of life.**

**NOTICE**

**Failure to follow these instructions will void the warranty.**

**INSTALLATION PRECAUTIONS**

Consult local building codes before beginning the installation. The installer must make sure to select the proper vent system for installation. Before installing vent kit, the installer must read this fireplace manual and vent kit instructions.

Only a qualified installer/service person should install the venting system. The installer must follow these safety rules:

- Wear gloves and safety glasses for protection.
- Use extreme caution when using ladders or when on rooftops.
- Be aware of electrical wiring locations in walls and ceilings.

The following actions will void the warranty on your venting system:

- Installation of any damaged venting component.
- Unauthorized modification of the venting system.
- Installation of any component part not manufactured or approved by MHSC
- Installation other than permitted by these instructions.


**WARNING**

Horizontal sections of this vent system require a minimum of 3" clearances to combustibles at the top of the flue and 1" clearance at the sides and bottom until the flue penetrates the outside wall. A minimum 1" clearance all around the flue is acceptable at this point of penetration. If vertical rise is 7½" feet or higher when top venting, the clearance to combustibles is 1" on all sides of the horizontal run.

Vertical sections of this vent system require a minimum of 1" clearance to combustibles on all sides of the pipe.

**WARNING**

This fireplace must be vented to the outside. The venting system must **NEVER** be attached to a chimney serving a separate solid fuel burning appliance. Each gas appliance must use a separate vent system. Do not use common vent systems.



**Figure 10 -  
Combustible Clearance to Venting Pipes**

\* A Minimum of 3" Clearance to the Top Is Required Along Horizontal Length until Flue Pipe Penetrates Outside Wall.

\*\* A Minimum 1" Clearance to Combustibles Permitted All Around Flue at Outside Wall.

**INSTALLATION PLANNING**

There are two basic types of direct-vent installation:

- Horizontal Termination
- Vertical Termination

It is important to select the proper length of vent pipe for the type of termination you choose. It is also important to note the wall thickness.

**WARNING**

**Never run the vent pipe down. This may cause excessive temperatures which could cause a fire.**

**FOR HORIZONTAL TERMINATION**

Select the amount of vertical rise desired. All horizontal run of venting must have 1/4" rise for every 12" of run towards the termination below 7½ feet of vertical rise. With 7½ feet or more vertical rise off top of fireplace, the horizontal run may be level. NEVER run vent piping down.

You may use up to three 90° elbows in this vent configuration. Refer to *Horizontal Termination Configurations* on Pages 15 and 16.

**FOR VERTICAL TERMINATION**

Measure the distance from the fireplace floor to the ceiling. Add the ceiling thickness, the vertical rise in an attic or second story, and allow for sufficient vent height above the roof line.

**NOTE:** You may use two 45° elbows in place of a 90° elbow. You must follow rise to run ratios when using 45° elbows. The appliance is approved for use with three 90° elbows maximum or a combination of 90° and 45° elbows up to a maximum of 270°.

For two-story applications, firestops are required at each floor level. If an offset is needed in the attic, additional pipe and elbows will be required.

You may use a chase with a vent termination with exposed pipe on the exterior of the house. Refer to *Installing Vent System in a Chase* below. If pipe is enclosed in chase, it is not exposed.

It is very important that the venting system maintain its balance between the combustion air intake and the flue gas exhaust. Certain limitations apply to vent configurations and must be strictly followed.

**INSTALLING A VENT SYSTEM IN AN OUTSIDE CHASE**

A chase is a vertical boxlike structure built to enclose venting that runs along the outside of a building. A chase is required for such venting.

**NOTICE**

**When installing in a chase, you should insulate the chase as you would the outside walls of your home. This is especially important in cold climates. Insulation should be considered a combustible material. Maintain proper clearances to all combustible materials.**

**NOTICE**

**Treatment of firestops and construction of the chase may vary from building type to building type. These instructions are not substitutes for the requirements of local building codes. You must follow all local building codes.**

FOR HORIZONTAL TERMINATION




Figure 11 - Horizontal Vent Termination Location

MINIMUM DISTANCES

- A = Clearance above the grade, a veranda, porch, deck, or balcony [\*12" (305 mm) minimum].
  - B = Clearance to window or door that may be opened [\*12" (305 mm) minimum].
  - C = Clearance to permanently closed window [\*minimum 12" (305 mm) recommended to prevent condensation on window]
  - D = Vertical clearance to ventilated soffit located above the terminal within a horizontal distance of two (2) feet (610 mm) from the centerline of the terminal [18" (457 mm) minimum].
  - E = Clearance to unventilated soffits [12" (305 mm) minimum]. **Clearance to vinyl soffit [30" (762mm)].**
  - F = Clearance to an outside corner. *Page 16, Figure 12*
  - G = Clearance to an inside corner. *Page 16, Figure 12*
  - H = \*Not to be installed above a gas meter/regulator assembly within three (3) feet (914 mm) horizontally from the centerline of the regulator.
  - I = Clearance to service regulator vent outlet [\*3' (914 mm) minimum].
  - J = Clearance to non-mechanical air supply inlet to building or the combustion air inlet to any other appliance [\*12" (305mm) minimum].
  - K = Clearance to a mechanical air supply inlet [\*6' (1829 mm) minimum].
  - L = Clearance above a paved sidewalk or paved driveway located on public property [\*7' (2133 mm) minimum].
  - M = Clearance under veranda, porch, deck, or balcony. **Page 16, Figure 12.** [For Canada \*12" (305 mm) minimum\*\*\*].
  - N = Clearance above a roof shall extend a minimum of 24" (610 mm) above the highest point when it passes through the roof surface and any other obstruction within a horizontal distance of 18" (457 mm).
- \* As specified in CSA B149 Installation Codes. **NOTE:** Local codes or regulations may require different clearances.
- \*\* A vent must not terminate directly above a sidewalk or paved driveway, which is located between two single-family dwellings and serves both dwellings.
- \*\*\* Only permitted if veranda, porch, deck, or balcony is fully open on a minimum of two sides beneath the floor.

**WARNING**

**Always maintain minimum clearances around vent systems. The minimum clearance to combustibles for horizontal vent pipe are 3" at the top and 1" at the sides and bottom of the vent system until the pipe penetrates the nearest vertical wall (1" required). A 1" minimum clearance all around the pipe must be maintained at outside wall and on vertical runs. Do not pack the open air spaces with insulation or other materials. This could cause high temperatures and may present a fire hazard.**

**\*Unless the vertical run is 7½ feet or higher (top vent units only), the clearances for the horizontal run is 1" at the top.**

**TERMINATION CLEARANCES FOR BUILDINGS WITH COMBUSTIBLE AND NONCOMBUSTIBLE EXTERIORS**




Figure 12 - Allowable Venting Chart

**HOW TO USE THE VENT GRAPH**

The Vent Graph should be read in conjunction with the following vent installation instructions to determine the relationship between the vertical and horizontal dimensions of the vent system.

1. Determine the height of the center of the horizontal vent pipe exiting through the outer wall. Using this dimension on the Sidewall Vent Graph below, locate the point intersecting with the slanted graph line.
2. From the point of this intersection, draw a vertical line to the bottom of the graph.
3. Select the indicated dimension, and position the fireplace in accordance with same.

*Example A: If the vertical dimension from the floor of the fireplace is 11' (3.4m) the horizontal run to the face of the outer wall must not exceed 14' (4.3m).*

*Example B: If the vertical dimension from the floor of the unit is 7' (2.14m), the horizontal run to the face of the outer wall must not exceed 8½' (2.6m).*

Sidewall Vent Graph showing the relationship between vertical and horizontal dimensions for a Direct Vent flue system.





Figure 13 - Rear Wall Venting Graph

**REAR WALL VENT INSTALLATION (5" x 8" VENTING ONLY)**

When installed as a rear vent unit this appliance may be vented directly to a termination located on the rear wall behind the appliance

- The maximum horizontal distance between the rear of the appliance and the termination is 20" (508 mm). *Figure 14*
- Only one 45° elbow is allowed in these installations.




**Figure 14 - Rear Vent Application, Maximum Horizontal Distance**

1. Rigid vent pipes and fittings have special twist-lock connections. Assemble the desired combination of pipe and elbows to the appliance adaptor.

**Twist-lock Procedure:** The female ends of the pipes and fittings have three locking lugs (indentations). These lugs will slide straight into matching slots on the male end of adjacent pipes and fittings. Push the pipe sections together and twist one section clockwise approximately one-quarter turn until the sections are fully locked. *Figure 15*

2. Refer to venting and termination instructions for further instructions.



**NOTE:** Horizontal runs of vent must be supported every 3' (914 mm). Use wall straps for this purpose.

**Figure 15 - Rigid Vent Pipe Connections**



3. Locate and cut the vent opening in the wall. For combustible walls first frame in opening.

**Combustible Interior Walls:** Cut a 12½"H x 10½" W hole through the interior wall.

**Combustible Exterior Walls:** Cut a 10½"H x 10½"W square hole through the exterior wall frame. *Figure 16*

**Noncombustible Walls:** Hole opening should be 8½" (216 mm) in diameter.

4. The center of the hole should align with the center line of the horizontal rigid vent pipe end. Allow 1/4" minimum rise per foot. *Figure 16*




VO584-100

**Figure 16 - Exterior Wall Framing Dimensions**

5. Apply a bead of non-hardening mastic around the outside edge of vent cap. Position the vent cap in the center of hole on the exterior wall with the word "UP" on the vent cap facing up. Insure proper clearance of 1" to combustibles is maintained. Attach the vent cap with four wood screws supplied. *Figure 17*

**NOTE:** Replace the wood screws with appropriate fasteners for stucco, brick, concrete, or other types of siding.


For vinyl siding, stucco, or wood exterior use vinyl siding standoffs between vent cap and exterior wall for Simpson or Selkirk Terminations only. The vinyl siding standoff prevents excessive heat from melting the vinyl siding material. **NOTE:** MHSC Terminations do not require standoff. Bolt the vent cap to the standoff or wall. Apply non-hardening mastic around outside edge of the standoff instead of the vent cap assembly. Use wood screws provided to attach the standoff. *Figure 18*



**Figure 17 -  
Install Horizontal Vent Cap**

**WARNING**

**Do not recess vent termination into any wall. This will cause a fire hazard.**




**Figure 18 -  
Installing Vinyl Siding Standoff and Termination**

**NOTICE**

**For more information, refer to the instructions supplied with the termination.**

6. Slide the wall thimble over the vent pipe before connecting the horizontal run to the vent cap. *Figure 19*
7. Carefully move the fireplace with vent assembly attached toward the wall and insert the vent pipe into the horizontal termination. The pipe overlap should be a minimum of 1¼". Apply silicone to the outer pipe connection. Fasten all vent connections with screws provided.
8. Slide the wall thimble against the interior wall surface and attach with screws. *Figure 19*



**Figure 19 -  
Connect Vent Cap with Horizontal Vent Pipe**

**HORIZONTAL WITH VERTICAL RISE (THROUGH-THE-WALL) TERMINATION CONFIGURATIONS**

Since it is very important that the venting system maintain its balance between the combustion air intake and the flue gas exhaust, certain limitations as to vent configurations apply and must be strictly adhered to.

The Vent Graph, showing the relationship between vertical and horizontal side wall venting, will help to determine the various dimensions allowable. *Page 16*

**Minimum clearance between vent pipes and combustible materials is 3" on top and 1" from bottom and sides unless otherwise noted (Exception: Outside wall with firestop: 1" all around pipes are allowed).**

When vent termination exits through foundations less than 20" below siding outcrop, the vent pipe must flush up with the siding.


It is best to locate the fireplace in such a way that minimizes the number of offsets and horizontal vent length.

The horizontal vent run refers to the total length of vent pipe from the flue collar of the fireplace (or the top of the transition elbow) to the face of the outer wall or the mounting flange of the termination.


**WARNING**

When installing the appliance as a rear vent unit, the 90°, 45° transition elbow attached directly to the rear of the unit is NOT INCLUDED in the following criteria and calculations, and unless specifically mentioned should be ignored when calculating venting layouts.

- The maximum number of 90° elbows per side wall installation is three (3). *Figure 20*
- If a 90° elbow is fitted directly on top of the fireplace flange, the maximum horizontal vent run before the termination or a vertical rise is 36" (914 mm). *Figure 21*




**Figure 20 -**  
Maximum Three (3) 90° Elbows  
Per Installation



**Figure 21 -**  
Maximum Horizontal Run with No Rise

- If a 90° elbow is used in the horizontal vent run (level height maintained) the horizontal vent length is reduced by 36" (914 mm) (Fig. 21 A and B) This does not apply if the 90° elbows are used to increase or redirect a vertical rise. *Figure 22*




**Figure 22 -**  
Maximum Vent Run with Elbows

FP1959


*Example: According to the vent graph (page 17) the maximum horizontal vent length in a system with a 7.5' vertical rise is 20' (6 m) and if a 90° elbow is required in the horizontal vent it must be reduced to 17' (5.2 m).*

*In Figures 22 and 24, Dimension A plus B must not be greater than 17' (5.2 m).*



**Figure 23 -**  
Horizontal Run Reduction

- The maximum number of 45° elbows permitted per side wall installation is two (2). These elbows can be installed in either the vertical or horizontal run.
- For each 45° elbow installed in the horizontal run, the length of the horizontal run MUST be reduced by 18" (45 cm). This does not apply if the 45° elbows are installed on the vertical part of the vent system.
- The maximum number of elbow degrees in a system is 270°. *Figure 24*



**Figure 24 -**  
**Maximum Elbow Usage**

**HORIZONTAL WITH VERTICAL RISE (THROUGH-THE-WALL) APPLICATIONS**



1. Locate and cut the vent opening in the wall. For combustible walls first frame in opening.

**Combustible Interior Walls:** Cut a 12½"H x 10½" W hole through the interior wall.

**Combustible Exterior Walls:** Cut a 10½"H x 10½"W square hole through the exterior wall frame. *Figure 25*

**Noncombustible Walls:** Hole opening should be 8½" (216mm) in diameter.

2. The center of the hole should align with the center line of the horizontal rigid vent pipe end. Allow 1/4" minimum rise per foot. *Figure 25*



VO584-100

**Figure 25 -**  
**Exterior Wall Framing Dimensions**

**WARNING**

You may use a reducer from 5" x 8" to 4" x 6<sup>5</sup>/<sub>8</sub>" for horizontal with vertical rise application. **ONLY** use framing instructions below when using 4" x 6<sup>5</sup>/<sub>8</sub>" venting.

If the reducer is installed at the rear of the unit, you must immediately follow with a 90° elbow for a vertical rise before continuing with any horizontal run.



1. Locate and cut the vent opening in the wall. For combustible walls first frame in opening.

**Combustible Interior Walls:** Cut a 11½"H x 9½" W hole through the interior wall.

**Combustible Exterior Walls:** Cut a 9½"H x 9½"W square hole through the exterior wall frame. *Figure 26*

**Noncombustible Walls:** Hole opening should be 7½" (190 mm) in diameter.

2. The center of the hole should line up with the center line of the horizontal rigid vent pipe end. Allow ¼" minimum rise per foot. *Figure 26*



**Figure 26 - Exterior Wall Framing Dimensions for 4 x 6<sup>5</sup>/<sub>8</sub>" Venting**

**NOTE:** #1222DA reducer must be used when 4 x 6<sup>5</sup>/<sub>8</sub>" venting is preferred. Reducer must be installed directly onto unit at pipe adaptor before vertical rise.


**BELOW GRADE INSTALLATIONS**

When it is not possible to meet the required vent terminal clearances of 12" above grade level, a snorkel kit is recommended. It allows installation depth down to 7" (178 mm) below grade level. The 7" (178 mm) is measured from the center of the horizontal vent pipe as it penetrates through the wall.

**Ensure the sidewall venting clearances are observed. If venting system is installed below ground, we recommend a window well with adequate and proper drainage to be installed around the termination area.**


If installing a snorkel, a minimum 24" vertical rise is necessary. The maximum horizontal run with the 24" vertical pipe is 36". This measurement is taken from the collar of the fireplace (or transition elbow) to the face of the exterior wall. See the Sidewall Venting Graph for extended horizontal run if the vertical exceeds 24".

1. Establish vent hole through the wall. *Page 17, Figure 16*
2. Remove soil to a depth of approximately 16" below base of snorkel. Install drain pipe. Install window well (not supplied). Refill hole with 12" of coarse gravel leaving a clearance of approximately 4" below snorkel. *Figure 27*
3. Install vent system.
4. Ensure a watertight seal is made around the vent pipe coming through the wall.
5. Apply high temperature sealant caulking (supplied) around the 5" and 8" snorkel collars.
6. Slide the snorkel into the vent pipes and secure to the wall.
7. Level the soil so as to maintain a 4" clearance below snorkel. *Figure 27*



**Figure 27 - Below Grade Installation**

If the foundation is recessed, use recess brackets (not supplied) for securing lower portion of the snorkel. Fasten brackets to wall first, then secure to snorkel with self drilling #8 x 1/2 sheet metal screws. It will be necessary to extend vent pipes out as far as the protruding wall face.



**Figure 28 - Snorkel Installation, Recessed Foundation**

**WARNING**

- Do not back fill around snorkel.
- A clearance of at least 4" must be maintained between the snorkel and the soil.

**VERTICAL THROUGH-THE-ROOF APPLICATIONS**

**WARNING**


A restrictor disc must be installed on any vertical termination that is higher than 12'. Simpson DuraVent 58DVA-VC/1280 Vertical Cap cannot be used with this fireplace.

Install restrictor disc as shown in *Figure 30* for vertically vented applications.

Up to three (3) restrictor discs may be needed for 40' installation.

The two (2) restrictor discs supplied will work for most installations. If a third disc is needed order Part No. 56D3027.

You may use a reducer to 4" x 6 5/8" in vertically vented applications.



**Figure 29 - Install Restrictor Disc into Stove Collar**



This Gas Fireplace has been approved for,

- Vertical installations up to 40' (12 m) in height. Up to a 10' (3 m) horizontal vent run can be installed within the vent system using a maximum of two 90° elbows. See *Figure 30*
- Up to two 45° elbows may be used within the horizontal run. For each 45° elbow used on the horizontal plane, the maximum horizontal length must be reduced by 18" (450 mm).

*Example:* Maximum horizontal length


|                |                |
|----------------|----------------|
| No elbows      | = 10' (3 m)    |
| 1 x 45° elbows | = 8.5' (2.6 m) |
| 2 x 45° elbows | = 7' (2.1 m)   |

- A minimum of an 8' (2.5 m) vertical rise is required.
- Two sets of 45° elbows offsets may be used within the vertical sections. From 0 to a maximum of 8' (2.5 m) of vent pipe can be used between elbows. *Figure 31*
- Determine the roof pitch and use the appropriate starter kit for offset installation.



**Figure 30 - Support Straps for Horizontal Runs**

- The maximum angular variation allowed in the system is 270°. *Figure 31*
- The minimum height of the vent above the highest point of penetration through the roof is 1' (305 mm).




**Figure 31 -**  
**Maximum Elbow Usage**

## INSTALLATION FOR VERTICAL TERMINATION

1. Determine the route your vertical venting will take. If ceiling joist, roof rafters or other framing will obstruct the venting system, consider an offset. Refer to *Figure 32* to avoid cutting load bearing members.

**NOTE:** Pay special attention to these installation instructions for required clearances (air space) to combustibles when passing through ceilings, walls, roofs, enclosures, attic rafters, etc. Do not pack air spaces with insulation. Also note maximum vertical rise of the venting system and any maximum horizontal offset limitations. Offsets must fall within the parameters shown in *Page 16, Figure 13*.


2. Set fireplace in desired location. Drop a line plumb down from the ceiling to the position of the flue exit. Mark the center point where the vent will penetrate the ceiling. Drill a small locating hole at this point.  
Drop a plumb line from the inside of the roof to the ceiling locating hole in the ceiling. Mark the center point where the vent will penetrate the roof. Drill a small locating hole at this point.




**Figure 32 -**  
**Offset with Wall Strap and 45° Elbows**

## FLAT CEILING INSTALLATION

1. Cut a 10½" (267mm) square hole in the ceiling using the locating hole as a center point. The opening should be framed to 10½" x 10½" (267 x 267 mm) inside dimensions as shown in *Figure 34* using framing lumber the same size as the ceiling joist. If the area above the ceiling is an insulated ceiling or a room, nail firestop from the top side. This prevents loose insulation from falling into the required clearance space. *Figure 33*. Otherwise, install firestop below the framed hole. The firestop should be installed with no less than three nails per side. *Figure 33*
2. Assemble the desired lengths of pipe and elbows necessary to reach from the burner system flue up through the firestop. Be sure pipe and elbow connections are fully twist-locked. *Page 17, Figure 15*
3. Cut a hole in the roof using the locating hole as a center point. (Cover any exposed open vent pipes before cutting hole in roof). The 10½" x 10½" (26 x 267 mm) hole must be measured on the horizontal. Actual length may be larger depending on the pitch of the roof. There must be a 1" minimum clearance from the vent pipe to combustible materials. (Insulation should be considered a combustible material) Frame the opening as shown on *Page 17, Figure 16*
4. Connect a section of pipe and extend up through the hole.



**Figure 33 -**  
If area above is a room, install firestop above framed hole as shown




**Figure 34 -**  
If area above is not a room, install firestop below framed hole as shown

**NOTE:** If an offset is needed to avoid obstructions, you must support the vent pipe every three (3) feet. Use wall straps for this purpose. See Figure 33, page 26. Whenever possible, use 45° elbows instead of 90° elbows. The 45° elbow offers less restriction to the flow of the flue gases and intake air.

5. Place the flashing over the pipe section(s) extending through the roof. Secure the base of the flashing to the roof and framing with roofing nails. Be sure roofing material overlaps the top edge of the flashing. There must be a 1" clearance from the vent pipe to combustible materials.
6. Continue to add pipe sections until the height of the vent cap meets the minimum requirements below.

**NOTE:** You must increase vent height for steep roof pitches. Nearby trees, adjoining roof lines, steep pitched roofs, and other similar factors may cause poor draft or down-drafting in high winds. Increasing the vent height may solve this problem.

**NOTE:** If the vent pipe passes through any occupied areas above the first floor, including storage spaces and closets, you must enclose pipe. You may frame and sheetrock the enclosure with standard construction material. Make sure to meet the minimum allowable clearances to combustibles. Do not fill any of the required clearance spaces with insulation.



**Figure 35 -**  
Minimum Chimney Clearance

| Roof Pitch          | H Feet | Meters |
|---------------------|--------|--------|
| Flat to 7/12        | 1.0    | .3     |
| Over 7/12 to 8/12   | 1.5    | .46    |
| Over 8/12 to 9/12   | 2.0    | .61    |
| Over 9/12 to 10/12  | 2.5    | .76    |
| Over 10/12 to 11/12 | 3.25   | .99    |
| Over 11/12 to 12/12 | 4.0    | 1.22   |
| Over 12/12 to 14/12 | 5      | 1.52   |

\*H - Minimum height from roof to lowest discharge opening of vent


**NOTE**

When using a 1222DA reducer, 5" x 8" to 4" x 6<sup>5</sup>/<sub>8</sub>", the flex adapter starter kit DVFA/8 is used to start the 4" x 6<sup>5</sup>/<sub>8</sub>" flex venting at the adapter. All restrictions and allowances that pertain to 5" x 8" flex venting apply to 4" x 6<sup>5</sup>/<sub>8</sub>" flex venting.


**NOTE**

**Flex vent pipe spacers:** Refer to manufacturer's specifications for correct positioning of the spacer springs to maintain proper distance between inside and outside pipe.

1. Flexible UL1777 listed venting may be used in any venting application where rigid direct vent components can be used. **All restrictions, clearances and allowances that pertain to the rigid piping apply to the flexible venting.** Flex kits may not be modified. Flex kits may be added to the end of a vent run made of rigid vent sections using pipe manufacturer's approved flex to pipe adapters. This may occur only if doing so does not violate any of the venting length, height, routing, horizontal to vertical ratio requirements or clearance considerations detailed in this manual.
2. The flex adapter starter kit (DVFA/8) is used to attach flex venting to the appliance starting collar. It includes 5" inner and 8" outer adapter rings. *Figure 36*




**Figure 36 - Typical Appliance Connection**




**Figure 37 - Minimum Radius for Flex Vent Section**


- The inner and outer adapter rings are required to start all flex runs.
  - Never install damaged or torn flexible venting.
  - Over tightening clamps may rip, tear, or otherwise damage flexible venting.
  - The adapter kit does not include individual pipe sections which may be purchased separately. (UL1777 listed type venting only.)
3. Start the flexible vent as follows:
    - A. Installing the inner flex adapter and pipe. *Figure 38*
      1. Insert the long side of the 5" inner ring into exhaust pipe, gently tap to seat into place, and secure with screws.
      2. Slide the small gear clamp over the inner flexible vent pipe, and push out of the way.
      3. Pull and extend the inner flexible vent.
      4. Slide the inner vent onto the adapter collar, for a minimum 1<sup>3</sup>/<sub>4</sub>" overlap.
      5. Locate the clamp at approximately 3/4" from the flex end and tighten.
      6. Secure the clamped inner section with three self-tapping screws, drilled equidistant, just above the clamp perimeter.
    - B. Installing the outer flex pipe. *Figure 36*
      1. Firmly insert the 8" outer adapter ring into the outer appliance starting collar and secure with screws.
      2. Slide the large gear clamp over the outer flexible vent pipe, and push out of the way.
      3. Pull and extend the outer flexible vent.
      4. Slide the outer vent onto the appliance collar outer adapter for a minimum 1<sup>3</sup>/<sub>4</sub>" overlap.
      5. Locate the clamp at approximately 3/4" from the flex end and tighten.
      6. Secure the clamped outer section with three self-tapping screws, drilled equidistant, just above the clamp perimeter.
    - C. Routing UL1777 flex pipe.
      1. Always maintain the required clearance when routing the flex vent assembly.



**Figure 38 - Typical Vertical Flex Vent Installation**



**Figure 39 - Typical Pipe Connection**



**Figure 40 - Typical Horizontal Flex Vent Installation**

2. Install firestop spacers, *Figure 38*, when penetrating ceiling, attic spaces, or walls.
  3. Do not allow the flexible vent to bend in radius tighter than 5" (127 mm). *Figure 37*
  4. Horizontal runs of flexible vent shall be supported at maximum 2 foot intervals; vertical runs, five feet intervals. Metal strapping, properly secured, is an acceptable means to support the flexible vent.
  5. Flexible vent spacers are to be installed at intervals prescribed by the flexible vent manufacturer; and in such a way as to maintain concentric inner and outer vent spacing.
- D. Attaching flexible venting to vertical termination assemblies.
1. When using Simpson pipe, an MHSC flex-to-pipe adapter and/or rigid pipe section(s) is required to connect the flexible vent assembly to the vertical termination by using three self-penetrating screws.
  2. Review *Figure 39* and corresponding instructions for proper overlap, clamp and screw placement.
  3. Three each self-penetrating screws are drilled opposite one another and below the gear clamp.

4. Use only listed and approved terminations and accessories, installed per the installation instructions and *Figure 38*.
- E. Installing flexible venting to horizontal termination assemblies.
1. Connect the 5" flexible vent to the horizontal termination as in *Figure 40*.
  2. Connect the 8" flexible vent to the termination ring as in *Figure 40*.
  3. Review *Figure 40* for proper overlap and clamp placement.
  4. Three each self-penetrating screws are drilled opposite one another and below the gear lamp.
  5. Use only listed an approved terminations and accessories, installed per the termination instructions and *Figure 40*.

**CHECK GAS TYPE**

Use proper gas type for the fireplace you are installing. If you have conflicting gas type, do not install fireplace. See dealer where you purchased the fireplace for proper fireplace according to your gas type.

**INSTALL GAS PIPING TO FIREPLACE LOCATION**

**WARNING** A qualified installer or service person must connect appliance to gas supply. Follow all local codes.

**CAUTION** For propane/LP units, never connect fireplace directly to the propane/LP supply. This burner system requires an external regulator (not supplied). Install the external regulator between the burner system and propane/LP supply.


**INSTALLATION ITEMS NEEDED**

Before installing fireplace and burner system, make sure you have the items listed below.

- External regulator (supplied by installer)
- Tee joint
- Piping (check local codes)
- Pipe wrench
- approved flexible gas line with gas connector (if allowed by local codes — not provided)
- Sealant (resistant to propane/LP gas)
- Test gauge connection\*
- Sediment trap (optional but recommended)

\* A CSA design-certified equipment shutoff valve with 1/8" NPT tap is an acceptable alternative to test gauge connection. Purchase the CSA design-certified equipment shutoff valve from your dealer.

For propane/LP connections only, the installer must supply an external regulator. The external regulator will reduce incoming gas pressure. You must reduce incoming gas pressure to between 11 and 13 inches of water. If you do not reduce incoming gas pressure, burner system regulator damage could occur. Install external regulator with the vent pointing down as shown in *Figure 41*. Pointing the vent down protects it from freezing rain or sleet.



**Figure 41 - External Regulator with Vent Pointing Down (Propane/LP Only)**

**CAUTION** Use only new black iron or steel pipe. Internally tinned copper or copper tubing can be used per National Fuel Code, Section 2.6.3, providing gas meets hydrogen sulfide limits, and where permitted by local codes. Gas piping system must be sized to provide minimum inlet pressure (listed on data plate) at the maximum flow rate (BTU/hr). Undue pressure loss will occur if the pipe is too small.

**WARNING** External regulators may be necessary for natural gas. One- or two-pound systems will damage this appliance and may cause fire hazard.

When using copper or flex connectors use only fittings approved for gas connections. The gas control inlet is 3/8" NPT.

**WARNING** Only persons licensed to work with gas piping may make the necessary gas connections to this appliance.

**CAUTION** A manual shutoff valve must be installed upstream of the appliance. Union tee and plugged 1/8" NPT pressure tapping point should be installed upstream of the appliance. See *Figure 38*.

**NOTE :** The gas line connection may be made using 1/2" rigid tubing or an approved flex connector. Since some municipalities have additional local codes it is always best to consult your local authorities and the current edition of the National Fuel Gas Code ANSI.Z223.1, NFPA54. In Canada CSA-B149 (1 or 2) Installation Code.

A listed manual shutoff valve must be installed upstream of the appliance. Union tee and plugged 1/8" NPT pressure tapping point should be installed upstream of the appliance. *Figure 42*


**CAUTION** Use pipe joint sealant that is resistant to liquid petroleum (LP) gas.

**IMPORTANT:** Install main gas valve (equipment shutoff valve) in an accessible location. The main gas valve is for turning on or shutting off the gas to the fireplace.

Check your building codes for any special requirements for locating equipment shutoff valve to fireplaces.

Apply pipe joint sealant lightly to male threads. This will prevent excess sealant from going into pipe. Excess sealant in pipe could result in clogged burner system valves.

We recommend that you install a sediment trap/drip leg in supply line as shown in *Figure 42*. Locate sediment trap/drip leg where it is within reach for cleaning. Install in piping system between fuel supply and burner system. Locate sediment trap/drip leg where trapped matter is not likely to freeze. A sediment trap traps moisture and contaminants. This keeps them from going into the burner system gas controls. If sediment trap/drip leg is not installed or is installed wrong, burner system may not run properly.




**Figure 42 - Gas Connection**

## CHECK GAS PRESSURE and ELECTRICAL INSTALLATION - MILLIVOLT

1. Check gas type. The gas supply must be the same as stated on the appliance's rating decal. If the gas supply is different from the fireplace, **STOP!** Do not install the appliance. Contact your dealer immediately.
2. To ease installation, a 18" (457 mm) flex line with manual shut-off valve has been provided with on this appliance. Install and attach 1/2" gas line onto shut-off valve.
3. After completing gas line connection, purge air from gas line and test all gas joints from the gas meter to the fireplace for leaks. Use a solution of 50/40 water and soap or a gas sniffer.
4. To adjust flame height, turn HI/LO knob to HI to get maximum pressure to burner. Turn HI/LO knob to LO to get minimum pressure.
5. To check gas pressures at valve, turn captured screw counter clockwise 2 or 3 turns and then place tubing to pressure gauge over test point. Turn unit to high. *Figure 43.* After taking pressure reading, be sure and turn captured screw clockwise firmly to reseal. Do not over torque. Check test points for gas leaks.

**NOTE:** Captured screws for pressure reading are located in the same place in all three valve types: Millivolt, Electronic and Remote Hi/Lo.



**Figure 43 -  
Gas Pressure Check at Gas Valve**

**WARNING**

**Do not use open flame to check for gas leaks.**

## ELECTRICAL WIRING

This fireplace will work without any electrical supply except to operate blowers, electronic ignition system and Hi/Lo remote control receiver.

**NOTE:** If installed in mobile home, fireplace must be bolted securely to floor.

**WARNING**

**Electrical connections should only be performed by a qualified, licensed electrician. Main power must be off when connecting to main electrical power supply or performing service. All wiring shall be in compliance with all local, city and state codes. The appliance, when installed, must be electrically grounded in accordance with local codes or in the absence of local codes, with the National Electrical Code ANSI/NFPA 70 (latest edition) and Canadian Electrical Code, CSA C22.1.**

**CAUTION**

**Label all wires before disconnecting when servicing controls. Wiring errors can cause improper and dangerous operation.**


Verify proper operation after servicing.

**REMOTE WALL MOUNTED SWITCH FOR MILLIVOLT VALVES ONLY**

A remote wall switch and up to fifteen (15) feet of 18 Ga. wire may be used with this appliance. Attach the wall switch in a junction box at the desired location on the wall. *Figure 44*. Do not extend beyond the wall switch wire length provided.

**NOTE:** Extended lengths of wire may cause the fireplace not to function properly. Longer length of wire is permitted if the wire is made out of larger gauge (diameter) wire. Always check with local code.

**WARNING** Do not connect wall switch to (110 V) circuit.



**Figure 44 -**  
**Wiring Diagram for Wall Switch**  
**(Millivolt Units Only)**

**FOR YOUR SAFETY READ BEFORE LIGHTING****WARNING**

If you do not follow these instructions exactly, a fire or explosion may result causing property damage, personal injury or loss of life.

- A. This appliance is equipped with a pilot which must be lit with built-in ignitor while following these instructions exactly.
- B. BEFORE OPERATING smell all around the appliance area for gas. Be sure to smell next to the floor because some gas is heavier than air and will settle on the floor.

**WHAT TO DO IF YOU SMELL GAS:**

- Turn off all gas to the appliance.
  - Open windows.
  - Do not attempt to light any appliance.
  - Do not touch any electric switch; do not use any phone in your building.
  - Immediately call your gas supplier from a neighbor's phone. Follow the gas supplier's instructions.
  - If you cannot reach your gas supplier, call the fire department.
- C. Use only your hand to push in, or turn the gas control knob. Never use tools. If the knob will not push in or turn by hand, don't try to repair it. Call a qualified service technician. Force or attempted repair may result in a fire or explosion.
  - D. Do not use this appliance if any part of it has been under water. Immediately call a qualified service technician to inspect the appliance and to replace any part of the control system and any gas control that has been under water.

**LIGHTING PILOT FOR THE FIRST TIME****INITIAL LIGHTING**

Purge air from the supply line as follows:

- Open main shutoff valve.
- Unscrew main pressure test point.
- Leave inlet test screw open until gas comes in.
- When gas is flowing, tighten inlet screw immediately.

**WARNING**

Never use an open flame to check for gas leaks.

**LEAK TESTING**

1. Follow the pipe from the gas supply line connection to the gas valve. Check connection for leaks with soap and water mixture.
2. Next check for gas leaks at the burner with soap and water mixture.
3. Check the pilot for gas leaks with soap and water mixture.

## LIGHTING PILOT FOR THE FIRST TIME - MILLIVOLT

### APPROVED LEAK TESTING METHOD

You may check for gas leaks with the following methods only:

- Soap and water solution
- An approved leak testing spray
- Electronic sniffer

**WARNING**

If using a soap and water solution to test for leaks, DO NOT spray solution onto control body.

**NOTE:** Remove any excessive pipe compound from the connections. Excessive pipe compound can set off electronic sniffers.


**DANGER**

Never check for gas leak with open flame!

Check for gas leaks in each of the following locations:

- Pipe from the gas supply line connection to the gas valve
- Burner connections
- Pilot
- Each joint or connection
- Field made joints / gas shutoff valve
- Factory made joints
- All joints on valve and control body

## LIGHTING PILOT - MILLIVOLT

1. Depress and turn knob counterclockwise  to pilot position.
2. Depress fully and hold pilot gas knob. Depress piezo ignitor as many times as needed to ignite the pilot. Keep knob fully depressed for a few seconds. Release and check that pilot continues to burn.

If the pilot does not stay lit, repeat steps 1 and 2.





Figure 45 - Pilot Position

## LIGHTING BURNER - MILLIVOLT


### MAIN BURNER SWITCH


The "ON/OFF/RS" switch for the main burner can be found behind door of the fireplace. This switch allows you to turn on and to turn off the main burner without using the gas valve knob. Make sure the button is in the "ON" position to light the main burner. *Figure 46*



*Figure 46 - On/Off/RS Switch*

### LIGHTING THE BURNER


Depress and turn the knob counterclockwise  to the "ON" position. *Figure 47*. It will take less than four (4) seconds for the burner to ignite.



*Figure 47 - On Position*

### PILOT POSITION

Depress and turn knob to pilot position to keep burner off while maintaining the pilot light. *Figure 48*




*Figure 48 - Pilot Position*

## TO TURN OFF GAS - MILLIVOLT

Depress and turn knob clockwise  to "OFF" position. *Figure 49*

**WARNING**


The control is fitted with a safety interlock device which prevents unsafe ignition of the pilot burner after the control knob has been turned to the OFF position. The knob may only be rotated back to the PILOT position after the safety magnet has been released (approximately 60 seconds). You will hear a "click" when the safety magnet releases.



*Figure 49 - Off Position*

## SIGNATURE COMMAND - CHECK GAS PRESSURE and ELECTRICAL INSTALLATION

1. Check gas type. The gas supply must be the same as stated on the appliance's rating decal. If the gas supply is different from the fireplace, **STOP!** Do not install the appliance. Contact your dealer immediately.
2. To ease installation, a 24" (610 mm) flex line with manual shut-off valve has been provided with on this appliance. Install and attach 1/2" gas line onto shut-off valve.
3. After completing gas line connection, purge air from gas line and test all gas joints from the gas meter to the fireplace for leaks. Use a solution of 50/50 water and soap solution or a gas sniffer.
4. To check gas pressures at valve, turn captured screw counter clockwise 2 or 3 turns and then place tubing to pressure gauge over test point. Turn unit to high. *Figure 50.* After taking pressure reading, be sure and turn captured screw clockwise firmly to reseal. Do not over torque. Check test points for gas leaks.



**Figure 50 -  
Signature Command Valve**

**WARNING**

**Do not use open flame to check for gas leaks.**

### ELECTRICAL WIRING

This fireplace will work without any electrical supply. Electricity is only needed to operate blower.

**NOTE: If installed in mobile home, fireplace must be bolted securely to floor.**


**WARNING**

**Electrical connections should only be performed by a qualified, licensed electrician. Main power must be off when connecting to main electrical power supply or performing service. All wiring shall be in compliance with all local, city and state codes. The appliance, when installed, must be electrically grounded in accordance with local codes or in the absence of local codes, with the National Electrical Code ANSI/NFPA 70 (latest edition) and Canadian Electrical Code, CSA C22.1.**

**CAUTION**

**Label all wires before disconnecting when servicing controls. Wiring errors can cause improper and dangerous operation.**

Verify proper operation after servicing.



**Figure 51 -  
Signature Command Wiring Diagram**

**CAUTION** Electrical connections should only be performed by a qualified, licensed electrician. Main power supply must be turned off before connecting fans to the main electrical power supply or performing service.

**WARNING** Before installing the blower, turn off the fireplace and allow to cool. Only a qualified service person should service and repair the fireplace. A qualified service person should connect and disconnect the fireplace to gas supply. Follow all local codes.

**COMMAND CENTER WALL INSTALLATION**

The command center may be mounted on the wall with the use of the SCSWEK Kit (15ft. cable, junction box, wall cover).

Mount the junction box provided at the desired location on the wall. Do not extend beyond the 15 ft. wire cable provided.


Route the wire from junction box to lower control area at bottom of fireplace. Unplug the 12" cable from control box and command center. Plug the 15 ft. extension cable into the control box. Remove command center from the fireplace and plug the other end of the extension cable into the command center. Snap on wall cover provided and screw to junction box.

**OPTIONAL FAN/BLOWER SYSTEM  
(BLOTBLDVSC)**


**Installation Instructions**

**Wiring**

1. Before installing the blower, wire the receptacle into an electrical circuit. This should be done before framing the fireplace. Wire with minimum 60° C wire in accordance with prevailing codes.
2. Remove the external junction box cover by removing the screw from the left side of the outside firebox wall. Junction box was installed at the factory.
3. The junction box cover has a factory installed “romex” style strain relief connector. After connecting the wires, route the wire leads through this connector. Refer to the wiring diagram in *Figure 52*.



**Figure 52 -  
Junction Box Wiring Diagram**



**Figure 53 -  
Blower Wiring Diagram**

**WARNING**

**Electrical Grounding Instructions:** This appliance is equipped with a three-prong (grounding) plug for your protection against shock hazard and should be plugged directly into a properly grounded three-prong receptacle.

**WARNING**

Electrical connections should only be performed by a qualified licensed electrician. Main power supply must be turned off before connecting the fan to the main electrical power supply or performing service.

**FOR YOUR SAFETY READ BEFORE LIGHTING****WARNING**

If you do not follow these instructions exactly, a fire or explosion may result causing property damage, personal injury or loss of lie.

- A. This appliance is equipped with an ignition device which automatically lights the pilot. Refer to the instructions for match lighting.
- B. BEFORE OPERATING smell all around the appliance area for gas. Be sure to smell next to the floor because some gas is heavier than air and will settle on the floor.


**WHAT TO DO IF YOU SMELL GAS:**

- Do not attempt to light any appliance.
  - Do not touch any electric switch; do not use any phone in your building.
  - Immediately call your gas supplier from a neighbor's phone. Follow the gas supplier's instructions.
  - If you cannot reach your gas supplier, call the fire department.
- C. Use only your finger to push in the master switch. Never use tools. If the switch will not function by hand, do not try to repair it. Call a qualified service technician. Force or attempted repair may result in a fire or explosion.
  - D. Do not use this appliance if any part of it has been under water. Immediately call a qualified service technician to inspect the appliance and to replace any part of the control system and any gas control that has been under water.


*continued on next page*

## OPERATING INSTRUCTIONS

1. **STOP!** Read the safety information above.
2. This appliance is equipped with an ignition device which automatically lights the burner. Do not try to light the burner by hand.
3. With five (5) minutes to clear out any gas. Then smell for gas, including near the floor. If you smell gas, **STOP!** Follow "B" in the safety information on page 38. If you do not smell gas, go to next step.
4. Install four (4) "AA" batteries (provided in your Homeowner's Manual bag) into the command center box. Make sure the batteries orientation match.
5. Press the master switch to the "ON" (-) position. Within eight (8) seconds it will beep once. This indicates the system is ready.
6. Press "ON " button. Sparker will spark and pilot flame will light.
7. Once pilot flame is established, the main burner flame will light automatically.
8. If the pilot will not stay lit after several tries, turn the master switch to "OFF" and call your service technician or gas supplier.



Switch Box



## TO TURN OFF GAS TO APPLIANCE

1. Turn master switch to "OFF".
2. Turn off all electrical power to the appliance if service is to be performed.

# SIGNATURE COMMAND SYSTEM OPERATION INSTRUCTIONS

## FEATURES

### Command Center

- Easy Access Function Operation and System Configuration
- Operation Confirmation/Fault Diagnostic Indications (LED/ Buzzer)
- ON/OFF/Hi/Low Operation

### Control Board

- Electronic Ignition
- Pilot Lockout safety feature
- Electric Power Regeneration from Thermopile to save battery
- 6-hour Automatic Shut Down Option
- Convenient NG/LP Gas Type Conversion
- Standing Pilot/Intermittent pilot Conversion
- Previous settings Restoration Ability
- Uninterrupted Operation During Power Outage (Automatic Battery Backup)
- ON/OFF RF Remote Receiver
- Optional Transmitter Learn Capability

### AC Interface Board (Optional)

- Easy Snap-on Design
- Embedded Compact 120 VAC Adapter with Auto Battery Back up Feature
- Remote Controlled Blower, Lighting, and Auxiliary AC Outputs

### Transmitter (Optional)


|  | RFSC | RTSC | RMSC |
|--|------|------|------|
| Three Flame Height Settings                  | X    | X    | X    |
| Low battery Indication for Transmitter       | X    | X    | X    |
| Child Proof Lock-out                         | X    | X    | X    |
| LCD Backlight                                | X    | X    | X    |
| Security Codes                               | X    | X    | X    |
| Thermostatic Control Mode                    | X    | X    | --   |
| Three Brightness Settings for Lights         | X    | --   | --   |
| Three Speed Control for Blower               | X    | --   | --   |
| On/Off Auxiliary                             | X    | --   | --   |
| Programmable Timer to turn blower on and off | X    | --   | --   |

### BATTERY INSTALLATION

The Command Center uses four (4) "AA" batteries.

#### To Install Batteries:

1. Press down the battery door tabs and pull out to remove battery door.
2. Install the batteries as indicated on Command Center.
3. Close battery door by snapping in place.
4. When the four (4) batteries are installed the system is ready for use.
5. The batteries should be replaced when the LED indicates low battery.



**Figure 54 - Signature Command System Components**

## SYSTEM CONFIGURATION/SETUP

System configuration/setup is done on the Command Center.

### Intermittent/Standing Pilot Setup (Default intermittent)

1. Holding the ON button on the Command Center while turning on the master switch will toggle between standing pilot and intermittent pilot.
2. After the above operation, one beep (for standing pilot) or two beeps (for intermittent pilot) will be given as confirmation.

### Six-hour Safety Shutdown Option (Default ON)

1. The system comes preset from the factory with a six (6) hour shutdown from its last command of operation. This is done to prevent the fireplace from continuing to operate if unattended. You may disable this feature if you wish.

**NOTE:** By disabling this feature, your fireplace may continue to operate unattended.

2. When the master switch is in the ON position ("–"), pressing the ON button and the OFF button on the Command Center simultaneously will toggle between enabling and disabling the six-hour shutdown option.
3. After the above operation, one beep (for enabling the six-hour shutdown option) or two beeps (for disabling the six-hour shutdown option) will be given as confirmation.

### Remote Transmitter Learn Function (Default OFF)

1. The RF receiver button located on the control board must be in the on position before the learn function can begin. Use paper clip to depress button. One beep for RF receiver ON or two beeps for RF receiver OFF will be given as confirmation.
2. After the RF receiver is on, holding the OFF button on the Command Center while turning on the master switch will activate the learn function for the transmitter.
3. After the above operation, two beeps will be given and the green LED on the Command Center will flash for 10 seconds.
4. During the 10 seconds, press the OFF button on a transmitter to learn. Another two beeps will be given to confirm a successful learning.

### Shutting Off the Standing Pilot

To shut off the standing pilot for service or summer shut down, press and hold the ON button on the Command Center for 3 seconds when the master switch is in the ON position ("–") and the main burner is off.

**Note:** Pilot will resume the next time system is turned on.

### Key Combinations for System Settings

| Function                          | Operation  | Default Setting    |
|-----------------------------------|--|--------------------|
| Intermittent/Standing Pilot Setup | Hold the ON ▲ button while turning on the master switch (Beep once for standing pilot, twice for intermittent pilot) | Intermittent Pilot |
| Standing Pilot Temp. Shutoff      | Hold the ON ▲ button 3 seconds (when the master switch on the main burner is off)                                    |                    |
| RF Remote Receiver On/Off         | Push the RF receiver On/Off button on the control board<br>Beep once for ON and beep twice for OFF                   | RF OFF             |
| Learn Remote Transmitter          | Hold the OFF ▼ button while turning on the master switch (Beep twice then press any handheld remote button)          |                    |
| 6-hour safety shutdown setup      | Press the ON ▲ button and OFF ▼ button simultaneously (Beep once for ON, twice for OFF)                              | ON                 |

# SIGNATURE COMMAND SYSTEM OPERATION INSTRUCTIONS

## FUNCTIONS/OPERATION

### Turning on the fireplace

1. Turn on the master switch and wait for a beep.
2. Press the ON button on the Command Center. Pilot will light and burner will come on High setting.

### Pilot Safety Lockout Function

1. If the pilot doesn't light after sparking for 30 seconds, pilot trial lockout happens. The LED on the Command Center flashes Green once every 2 seconds, until reset.
2. If the pilot flame is lost during normal operation, flame loss lockout happens. The LED on the Command Center flashes Red-Green once every 2 seconds, until reset.
3. Turning the master switch OFF, then ON again will reset the system.

### Flame Height Control

1. Press the ON button (on the Command Center) once to turn on the main burner with maximum flame height.
2. Press the OFF button to decrease flame height. The first two presses will decrease the flame height to medium and low.
3. The third press on OFF will turn off the main burner. In standing pilot configuration, the pilot will stay; in intermittent pilot configuration, the pilot will be shut off.

### Turning the Fireplace Off

There are three ways to turn the fireplace off.

1. Flip the master switch to the off ("O") position. (This will turn the entire system OFF.)
2. Press the OFF button to Medium, Low, then Off.
3. Hold the OFF button anytime for three seconds. This command of OFF will remember all last settings before turning off. The next time the fireplace is turned on, all settings will resume.

### Command Center Operations:

The following functions are available on the Command Center.

| Function          | Operation   |
|-------------------|---|
| Power Up          | Flip the master switch to the ON (" ") position to power up the system  |
| Fireplace ON      | Press the ON ▲ button on the Command Center to turn the fireplace on  |
| Fireplace OFF     | Flip the master switch to the OFF ("o") position OR press the OFF ▼ button 3 times OR hold the OFF ▼ button 3 seconds |
| Flame Height Up   | Press the ON ▲ button once to turn on the fireplace with maximum flame height   |
| Flame Height Down | Press the OFF ▼ button to lower the flame height to Medium and Low  |

### Self Diagnostics Chart:


The Command Center has a self-diagnostic LED enabling you to troubleshoot problems and potentially avoid a service call. Please refer to the charts below for indicator reference.

| Fault                      | LED Indication                                   |
|----------------------------|--|
| Conversion Cover Missing   | One RED (1 time)                                 |
| Spark Fail                 | Two RED (1 time)                                 |
| No Sensor Signal           | Three RED (1 time)                               |
| Pilot Lockout - trial      | One GREEN, every 2 sec. (until manual reset)     |
| Pilot Lockout - flame loss | One RED-GREEN, every 2 sec. (until manual reset) |
| Low Battery                | One RED, every 10s (continuously)                |
| No or Low Thermopile Power | Two RED, every 10s (continuously)                |
| Learning                   | GREEN Flashes, every 1 sec. (for 10 sec.)        |
| AC Power On                | GREEN solid                                      |


**CANOPY INSTALLATION**

Remove top louver assembly before installing canopy.

1. Unhook top louver assembly. Set aside. *Figure 55*
2. Attach canopy to underside of top outer shell with three (3) screws provided. *Figure 56*
3. Hook top louver assembly back into place.




**Figure 55 - Remove Top Louver Assembly**



**Figure 56 - Install Canopy**

**GLASS FRAME REMOVAL**

1. Remove louver assembly from the top.
2. Release three (3) clamps on bottom of fireplace. *Figure 57*
3. Tilt glass frame out and lift glass frame up until it clears hook on top of fireplace.
4. Set glass frame aside.



**Figure 57 - Glass Frame Removal**

**CAUTION**


Each clamp has a quick spring force. When reinstalling clamps, keep fingers clear.

**FLOOR BRICK INSTALLATION**

Install floor brick before installing logs or rock wool.

1. Remove floor brick from packaging.
2. Put left and right brick pieces together as shown in *Figure 58*.
3. Match two (2) firebox tabs with two (2) slots on bottom of brick. *Figure 58*
4. Push brick down until it makes contact with bottom of firebox.

**NOTE:** Remove floor brick to install brick walls. Remove floor brick for cleaning.




**Figure 58 -  
Installing Floor Brick**

FP2486

**INSTALL LOGS AND ROCK WOOL (EMBER MATERIAL) IN FIREBOX**


1. Carefully remove logs from wrapping.
2. Remove glass frame. *Refer to Glass Frame Removal, Page 42.*
3. Break rock wool into dime-sized pieces. Cover rear burner completely with rock wool. On front burner, only cover the ports. Do not exceed 1/2" depth of coverage. *Figure 59*




**Figure 59 -  
Place Rock Wool**

LG686

- Place bottom right log (#3) on two pins against right side of firebox. *Figure 60*




**Figure 60 -  
Place Bottom Right Log**



**Figure 61 -  
Place Rear Log**


- Place rear log (#1) on two pins against back side of firebox. *Figure 61*




**Figure 62 -  
Place Bottom Left Log**

- Place bottom left log (#2) on two pins against left side of firebox. *Figure 62*


7. Place right mid log (#7) on two right pins on burner assembly. *Figure 63*
8. Place left mid log (#6) on two left pins on burner assembly. *Figure 63*




9. Place right top log (#5) on top of right mid log and top of bottom right log. *Figure 64*
10. Place top left log (#4) on top of left mid log and top of bottom left log. *Figure 64*




11. Place top center log (#8) across rear log (#1) and left mid log (#6). *Figure 65*



12. Cover any exposed burner surface with rock wool. For best flame and glow, do not block air space between burners and logs with rock wool. *Figures 66 and 67*



**Figure 67 -  
Rock Wool Placement after Logs are All  
Logs are Placed (Top View)**



**Figure 66 -  
All Logs on Burner with Rock Wool**

**WARNING**

Turn off gas before servicing fireplace. It is recommended that a qualified service technician perform these check-ups at the beginning of each heating season

**BURNER, PILOT AND CONTROL COMPARTMENT**

Keep the control compartment, logs, and burner areas surrounding the logs clean by vacuuming or brushing at least twice a year. Make sure the burner porting, pilot air opening and burner air opening are free of obstructions at all times.

**PILOT FLAME**

The flames from the pilot should be visually checked as soon as the heater is installed and periodically during normal operation. **The pilot flame must always be present when the fireplace is in operation.** *Figure 68.* The pilot flame has three distinct flames, one engulfing the thermopile, one engulfing the thermocouple, and the other reaching to the main burner.

**BURNER**


Inspect area around the injector. Remove any lint or foreign material with a brush or vacuum.

**BURNER FLAME**


The flames from the burner should be visually checked as soon as the heater is installed and periodically during normal operation. In normal operation, at full rate, and after operating for about 15 to 30 minutes, the flame should be yellow and slightly taller than the rear log. *Figure 69*

If the flame is blue and only in the center, turn off unit and let cool. After unit is cool, remove logs and check to make sure rock wool is placed correctly. Replace logs.


**NOTE:** The type of installation, vent system configuration, and wind effects may cause the flame patterns to vary.



**Figure 68 - Pilot Flame**



**Signature Command System Pilot**



**Figure 69 - Burner Flame Appearance**

LG695

## VENT SYSTEM

The fireplace and venting system should be inspected before initial use and at least annually by a qualified field service person. Inspect the external vent cap on a regular basis to make sure that no debris is interfering with the airflow. Inspect entire venting system to ensure proper function.

## GLASS DOOR

Thoroughly clean the inside of the glass door after using the fireplace for ten hours. Periodically clean the glass door as necessary.

When cleaning the glass, remember:

- **Do not remove the glass when hot.** Allow glass to cool before removal.
- NEVER use abrasive materials.
- Keep children and pets a safe distance away.
- Never operate the fireplace without the glass door properly secured.
- Never operate the fireplace if the glass is broken.
- Replace any glass that is chipped, cracked, or broken. Replacement glass door assemblies **MUST** be supplied by the fireplace manufacturer – **No substitute materials may be used.**
- Handle glass door with care to avoid striking or scratching it on hard objects.

To clean glass door, follow “Glass Removal” procedure outlined in the *Final Installation* section. Film deposit on the inside of the glass should be cleaned off using a nontoxic, non-corrosive, non-abrasive, mild cleaning solution. Simply apply an adequate amount to the glass and wipe off with a damp cloth. After all maintenance has been completed, re-install glass door.

## LOGS

Leave logs installed in the fireplace for cleaning. Vacuum surface of the logs with a brush attachment. If logs must be removed for cleaning, handle carefully by holding gently at each end. Gloves are recommended to prevent skin irritation from ceramic fibers. If skin becomes irritated, wash gently with soap and water. Vacuum surface of logs with brush attachment or brush logs with a soft bristle brush (i.e. clean, dry paintbrush). To place logs back in the fireplace, see “Log Placement” found in the *Final Installation* section.

**NOTE: Do not use cleaning fluid to clean logs.**

## ROCK WOOL

Replace or add rock wool as required following installation instructions in the *Final Installation* section of this manual.


**STANDING PILOT IGNITION**


| <b>SYMPTOM</b>   | <b>POSSIBLE CAUSE</b>                                    | <b>ACTION</b>  |
|--|--|--|
| 1. Spark ignitor will not light pilot after repeated triggering of piezo.                                  | A. Wire disconnected.                                    | A. Open door and check to make sure wire is connected to ignitor.  |
|  | B. Defective ignitor.                                    | B. Check for spark at electrode and pilot. If no spark and electrode wire is properly connected, replace pilot assembly.   |
|  | C. No gas or low gas pressure.                           | C. Check remote/manual shut off valve from fireplace. Low pressure can be caused by bent lines, restricted lines, low pressure line pressure. Consult with plumber or gas supplier.  |
|  | D. No Propane/LPG in tank                                | D. Check Propane/LPG tank. Refill tank.  |
| 2. Pilot will not stay lit after carefully following lighting instructions.                                | A. Defective thermocouple                                | A. Check that thermocouple flame impinges on thermocouple. Clean and/or adjust pilot for maximum flame impingement. Ensure that the thermocouple connection at the gas valve is fully inserted and tight. Disconnect the thermocouple from the valve, place one millivolt lead wire on the tip of the thermocouple and the other meter lead wire on the thermocouple copper lead. Start the pilot and hold the valve knob in. If the millivolt reading is less than 15 mV, replace pilot assembly. |
|  | B. Defective valve                                       | B. If thermocouple is producing more than 15 mV, replace faulty valve.   |
| 3. Pilot burning, valve knob turned to "ON", switch is turned to "ON" or "RS", but burner will not ignite. | A. Defective switch, wall switch, remote control or wire | A. Check switch and wire for proper connection. Place jumper wires across terminals of switch. If burner comes on, replace defective switch. If the switch is OK, repeat the same procedure on remote control. If burner comes on, replace remote control. Place jumper wire across wire at gas valves (terminals marked TH and TP/TH). If burner comes on, wires are faulty or connections are bad. Replace wire.   |
|  | B. Pilot flame too small                                 | B. If pilot flame is not close enough to the thermopile, adjust pilot flame.   |
|  | C. Defective or malfunctioning thermopile                | C. Check thermopile wire connections to make sure all are tight and that the thermopile is fully inserted into pilot assembly. Check thermopile with a millivolt meter. Connect leads to TP and TP/TH terminals on the control valve. If meter reading is below 325 mV, replace pilot assembly.  |
|  | D. Defective valve                                       | D. Turn valve knob to "On" and switch to "ON." Take a reading at the thermopile leads (TP & TP/TH) on the valve. If the meter reads greater than 175 mV and the burner does not light, replace defective valve.  |

**STANDING PILOT IGNITION**

| <b>SYMPTOM</b>   | <b>POSSIBLE CAUSE</b>   | <b>ACTION</b>  |
|--|---|--|
| 4. Frequent pilot outage problem.                          | A. Pilot flame may be too high or too low, causing pilot safety to drop out | A. Clean and adjust the pilot flame for maximum flame impingement on thermocouple.   |
| 5. The pilot and main burner extinguish while in operation | A. Inner vent pipe leaking exhaust gases back into system                   | A. Check for flue product leak. Replace defective pipe section.  |
|  | B. Horizontal vent improperly pitched                                       | B. Check horizontal-venting piping is running upward 1/4" per foot. Do not run the pipe level or downward.   |
|  | C. Improper vent cap installation   | C. Check for proper installation and freedom from debris or blockage.  |
| 6. Glass Soots   | A. Flame impingement on logs  | A. Install log set per the instructions<br>Inspect the injector and air intake area. Make sure this area does not have any blockage from debris and clean.<br>Check gas supply.  |
| 7. Flame burn blue and lifts off burner (ghosting)         | A. Insufficient oxygen being supplied                                       | A. Ensure that the vent cap is installed properly and free of debris. Ensure that the vent system joints are tight and have no leaks. Ensure that no debris has been blocking the inner air intake at the bottom back of the combustion chamber. Ensure that the glass is properly secure and latch. |

**SIGNATURE COMMAND SYSTEM**






**FIREBOX COMPONENTS**

| Ref.   | Description                     | Qty. | HDV500     |
|--|---------------------------------|------|------------|
| 1.   | Junction Box Assy.              | 1    | 26D2128K   |
| 2.   | Top Louver Assy.                | 1    | 56D2140K   |
| 3.   | Bottom Louver Door Assy.        | 1    | 56D2141K   |
| 4.   | Glass Frame Assy.               | 1    | 56D3050    |
| 5.   | Canopy                          | 1    | 56D2056K   |
| 6.   | Firebrick Floor                 | 1    | 56D3055    |
| 7.   | Insulation Board                | 1    | 56D2156K   |
| 8.   | Firebrick Center                | 1    | 56D2030K   |
| 9.   | Firebrick Right                 | 1    | 56D2031k   |
| 10.  | Firebrick Left                  | 1    | 56D2032K   |
| <b>Accessories / Field Installed Options</b> |                                 |      |            |
| 11.  | Blower*                         | 2    | 56D2162K   |
| 12.  | Thermostat Sensor*              | 1    | 26D2870K   |
| 13.  | Speed Control*                  | 1    | 26D0746K   |
| 11,12,13.                                    | T-Stat Blower w/ Speed Control* | 1    | BLOTSDV    |
| 11.  | SCS Blower                      | 1    | BLOTBLDVSC |

\* Blower is a standard feature in HDV500RNV and HDV500RPV models.

Standing Pilot - Millivolt Parts



**Standing Pilot - Millivolt Parts**

| Ref.        | Description                  | Qty. | HDV500NV                    | HDV500PV |
|-------------|------------------------------|------|-----------------------------|----------|
| 1.          | Gas Valve Assy.              | 1    | 37D0117                     | 37D0118  |
| 2.          | Pilot Assy.                  | 1    | 20H2048                     | 20H2049  |
| 2C.         | Replacement Thermocouple     | 1    | 37D1067                     | 37D1067  |
| 2I.         | Replacement Ignitor and Wire | 1    | 37D1069                     | 37D1069  |
| 2T.         | Replacement Thermopile       | 1    | 37D1068                     | 37D1068  |
| 3a.         | Valve/Tee Tube               | 1    | 56D3045                     | 56D3045  |
| 3b.         | Front Burner Tube            | 1    | 56D3046                     | 56D3046  |
| 3c.         | Rear Burner Tube             | 1    | 56D3047                     | 56D3047  |
| 4.          | Flex Hose w/ Shutoff Valve   | 1    | 69D0030                     | 69D0030  |
| 5.          | Rocker Switch                | 1    | 41D0048                     | 41D0048  |
| 6.          | Piezo Ignitor                | 1    | 14D0503                     | 14D0503  |
| 7a.         | Front Injector               | 1    | 56D3059                     | 62D3005  |
| 7b.         | Rear Injector                | 1    | 62D3003                     | 20H3143  |
| 8a.         | Front Burner Assy.           | 1    | 56D3051                     | 56D3051  |
| 8b.         | Rear Burner Assy.            | 1    | 56D3052                     | 56D3052  |
| 9.          | Venturi                      | 1    | 45D0600                     | 45D0600  |
| 10.         | Wire Assy. - Switch          | 1    | 44D0500                     | 44D0500  |
| 10.         | Wire Assy. - Remote          | 1    | 44D0501                     | 44D0501  |
| Accessories |                              |      |                             |          |
| 11.         | Thermostatic Remote Control  | 1    | RCT/RCST/RCSTE,RCSIT,RCSTEB |          |
| 12.         | Remote Control ON/OFF        | 1    | RCB,RCMT,WMTD               |          |
| 13.         | Wireless Wall Thermostat     | 1    | WWTD/TLT                    |          |
| 14.         | Wall Switch Kit              | 1    | MVWS                        |          |
| 15.         | Wall Thermostat Kit          | 1    | WT                          |          |

**Fuel Conversion Kits - Millivolt**


**Natural Gas to LP**

HDV500 Kit #HCK500CKP

**LP to Natural Gas**

HDV500 Kit #HCK500CKN

SIGNATURE COMMAND SYSTEM



**SIGNATURE COMMAND SYSTEM**

| Ref.               | Description   | Qty. | HDV500NSC | HDV500PSC |
|--------------------|---|------|-----------|-----------|
| 1.                 | Gas Valve Assy.   | 1    | 80D0001   | 80D0002   |
| 2.                 | Pilot Assy.   | 1    | 80D0039   | 80D0040   |
| 3.                 | Control Box   | 1    | 80D0018   | 80D0019   |
| 4.                 | Command Center  | 1    | 80D0005   | 80D0005   |
| 5a.                | Valve/Tee Tube  | 1    | 56D3045   | 56D3045   |
| 5b.                | Front Burner Tube   | 1    | 56D3046   | 56D3046   |
| 5c.                | Rear Burner Tube  | 1    | 56D3047   | 56D3047   |
| 6.                 | Flex Hose w/ Shutoff Valve  | 1    | 69D0030   | 69D0030   |
| 7a.                | Front Injector  | 1    | 56D3059   | 62D3005   |
| 7b.                | Rear Injector   | 1    | 62D3003   | 20H3143   |
| 8a.                | Front Burner Assy.  | 1    | 56D3051   | 56D3051   |
| 8b.                | Rear Burner Assy.   | 1    | 56D3052   | 56D3052   |
| 9.                 | Venturi   | 1    | 45D0006   | 45D0006   |
| 10.                | Wire Valve Control (not shown)  | 1    | 80D0010   | 80D0010   |
| 10.                | Wire Command Ctr. Control Box 2' (not shown)                                  | 1    | 80D0008   | 80D0008   |
| <b>Accessories</b> |   |      |           |           |
| 13.                | Hand Held Remote Control  |      |           | RMSC      |
| 14.                | Hand Held Remote Control w/ Hi/Lo & T-stat                                    |      |           | RTSC      |
| 15.                | Hand Held Remote Control w/ Optional Light, Auxiliary & Blower Control        |      |           | RFSC      |
| 16.                | SCS Wall Mount Extension Kit (15' wire, rough-in box, wall cover) (not shown) |      |           | SCSWEK    |
| 17.                | SCS AC Module (converted battery system to AC power)                          |      |           | SCSADM    |

**Fuel Conversion Kits - Signature Command System**


**Natural Gas to LP**

HDV500 Kit #HDV500CKPS

**LP to Natural Gas**


HDV500 Kit #HDV500CKNS

**LOGS**




**Logs**

| Ref. | Description         | Qty. | HDV500   |
|------|---------------------|------|----------|
| 1.   | Rear Log #1         | 1    | 56D3034K |
| 2.   | Bottom Left Log #2  | 1    | 56D3035K |
| 3.   | Bottom Right Log #3 | 1    | 56D3036K |
| 4.   | Left Top Log #4     | 1    | 56D3037K |
| 5.   | Right Top Log #5    | 1    | 56D3038K |
| 6.   | Left Mid Log #6     | 1    | 56D3039K |
| 7.   | Right Mid Log #7    | 1    | 56D3040K |
| 8.   | Center Log #8       | 1    | 56D3041K |



**Accessories / Field Installed Options**

| Ref. | Description                                  | Qty. | HDV500        |
|------|--|------|---------------|
| 1.   | Metal Trim - Brass                           | 1    | BRMTK500      |
| 1.   | Metal Trim - Pewter                          | 1    | PWMTK500      |
| 1.   | Metal Trim - Black                           | 1    | BLMTK500      |
| 2.   | Brass Louvers                                | 8    | L36BRM        |
| 2.   | Pewter Louvers                               | 8    | L36PWM        |
| 3.   | Screen Frame - Black                         | 1    | SDV500SDC     |
| 4.   | Cabinet Door Frame - Black                   | 1    | VSDVC500CDFB  |
| 4.   | Cabinet Door Frame - Iron Age                | 1    | VSDVC500CDFIA |
| 4.   | Cabinet Door w/Screen - Black                | 1    | VSDVC500CDB   |
| 4.   | Cabinet Door w/Screen - Iron Age             | 1    | VSDVC500CDIA  |
| 5.   | Arched Front w/Lower Control Door - Black    | 1    | BSDVC500AFB   |
| 5.   | Arched Front w/Lower Control Door - Iron Age | 1    | VSDVC500AFIA  |



**VENT COMPONENTS FOR 4" X 6<sup>5</sup>/<sub>8</sub>"**

| Item | Qty./<br>Box | Description   | Current<br>Simpson<br>Duravent<br>or MHSC<br>Part no. | Old<br>Simpson<br>Duravent<br>or MHSC<br>Part no. | Selkirk<br>Part no. |
|------|--------------|---|---|---|---------------------|
| 1    | 1            | Thru-roof Flexible Pipe Termination Kit with flex adapter 24" rigid pipe, roof support 4" x 6 <sup>5</sup> / <sub>8</sub> " and termination cap | TRFK  | --  | --                  |
| 1    | 1            | Horizontal Square Termination Cap with built-in vinyl siding standoff, heat deflector and firestop  | BHRTK   | BHRTK   | --                  |
| 1    | 1            | Square Horizontal Termination Cap   | 46DVA-HC  | 985   | 4DT-HC              |
| 1    | 1            | Round Horizontal Termination Cap  | 46DVS-HRCS  | --  | --                  |
| 1    | 1            | Sconce Termination Cap (aluminum)   | 46DVA-HSC   | --  | --                  |
| 2    | 1            | Low-Profile Vertical Termination Cap  | 46DVA-VC  | 980   | 4DT-VC              |
| 3    | 6            | 6" Pipe Length (galvanized)   | 46DVA-06  | 908   | 4DT-06              |
| 3    | 6            | 9" Pipe Length (galvanized)   | 46DVA-09  | 907   | 4DT-09              |
| 3    | 6            | 12" Pipe Length (galvanized)  | 46DVA-12  | 906   | 4DT-1               |
| 3    | 6            | 24" Pipe Length (galvanized)  | 46DVA-24  | 904   | 4DT-4               |
| 3    | 6            | 36" Pipe Length (galvanized)  | 46DVA-36  | 903   | 4DT-36              |
| 3    | 6            | 48" Pipe Length (galvanized)  | 46DVA-48  | 902   | 4DT-48              |
| 4    | 6            | 8 <sup>1</sup> / <sub>2</sub> " Pipe Extension (galvanized)   | 46DVA-08A   | --  | 4DT-AJ              |
| 4    | 6            | 16" Pipe Extension (galvanized)   | 46DVA-16A   | --  | 4DT-AJ14            |
| 5    | 6            | 45° Elbow (galvanized)  | 46DVA-E45   | 945   | 4DT-EL45            |
| 6    | 6            | 90° Elbow (galvanized)  | 46DVA-E90   | 990   | 4DT-EL90            |
| 7    | 6            | Adjustable Roof Flashing 0/12 - 6/12  | 46DVA-F6  | 943   | 4DT-AF6             |
| 8    | 6            | Storm Collar  | 46DVA-SC  | 953   | 4DT-SC              |
| 9    | 6            | 1" Firestop   | 46DVA-FS  | 963   | 4DT-FS              |
| 9    | 6            | 3" Firestop   | FS3   | --  | --                  |
| 10   | 1            | Vinyl Siding Standoff   | 46DVA-VSS   | 950   | 4DT-VS              |
| 11   | 1            | Restrictor Disk   | 45D0551   | 45D0551   | --                  |
|      | 1            | Attic Insulation Shield   | 46DVA-IS  | --  | --                  |
|      | 6            | Steep Roof Flashing 7/12 - 12/12  | 46DVA-F12   | 943S  | --                  |
|      | 8            | Horizontal Termination with 1" firestop   | BHRT/8  | --  | --                  |
|      | 8            | Flex Adapter Starter  | DVFA/8  | --  | --                  |

**VENT COMPONENTS FOR 5" X 8"**

| Item | Qty./<br>Box | Description  | Current<br>Simpson<br>Duravent<br>or MHSC<br>Part no. | Old<br>Simpson<br>Duravent<br>or MHSC<br>Part no. | Selkirk<br>Part no. |
|------|--------------|--|---|---|---------------------|
| 1    | 1            | Horizontal High Wind Termination Cap   | 58DVA-HC  | 1285  | 5DT-HC              |
| 1    | 1            | Horizontal Termination Cap w/Built-In Vinyl Siding<br>Standoff Heat Deflector, Firestop and Adjustable<br>Pipe 11" to 14 <sup>5</sup> / <sub>8</sub> "           |   | BHR8TK9   |                     |
| 1    | 1            | Horizontal Termination Cap Built-In Vinyl Siding Standoff,<br>Heat Deflector, Firestop, 90° Elbow and Adjustable<br>Pipe 11" to 14 <sup>5</sup> / <sub>8</sub> " |   | BHS8TK  |                     |
| 1    | 1            | Horizontal Termination Cap w/Built-In Vinyl Siding Standoff,<br>Heat Deflector, Firestop, Flexible Pipe 20" to 48", Adapter                                      |   | BHSF8TKA  |                     |
| 1    | 8            | Horizontal Termination w/ 1" Firestop  |   | BHRST/8   |                     |
| 2    | 1            | Vertical Termination   | *see below  | *see below  | 5DT-VC              |
| 3    | 4            | 6" Pipe Length   | 58DVA-06  | 1208  | 5DT-06              |
| 3    | 4            | 9" Pipe Length   | 58DVA-09  | 1207  | 5DT-09              |
| 3    | 4            | 12" Pipe Length  | 58DVA-12  | 1206  | 5DT-12              |
| 3    | 4            | 24" Pipe Length  | 58DVA-24  | 1204  | 5DT-24              |
| 3    | 4            | 36" Pipe Length  | 58DVA-36  | 1203  | 5DT-36              |
| 3    | 4            | 48" Pipe Length  | 58DVA-48  | 1202  | 5DT-48              |
| 4    | 4            | 8 <sup>1</sup> / <sub>2</sub> " Pipe Extension   | 58DVA-08A   | --  | 5DT-AJ              |
| 4    | 4            | 16" Pipe Extension   | 58DVA-16A   | --  | --                  |
| 5    | 4            | 45° Elbow  | 58DVA-E45   | 1245  | 5DT-EL45            |
| 5    | 4            | 45° Swivel Elbow   | --  | --  | 5DT-EL45            |
| 6    | 4            | 90° Elbow  | 58DVA-E90   | 1290  | 5DT-EL90S           |
| 6    | 4            | 90° Swivel Elbow   | --  | 1290G   | 5DT-EL90S           |
| 7    | 6            | Flashing, 0/12 to 6/12 Roof Pitch  | 58DVA-F6  | 1243  | 5DT-AF6             |
| 7    |              | Steep Roof Flashing  | 58DVA-F12   | 1243S   | --                  |
| 8    | 6            | Storm Collar   | 58DVA-SC  | 1253  | 5DT-SC              |
| 9    | 4            | Firestop   | 58DVA-FS  | 1263  | 5DT-FS              |
| 9    |              | 3" Firestop  | FS38  | FS38  | --                  |
| 10   | 1            | Vinyl Siding Standoff  | 58DVA-VSS   | 1250  | 5DT-VS              |
| 11   |              | Attic Insulation Shield (not shown)  | 58DVA-IS  | --  | --                  |
| 12   | 8            | Flex Adapter Starter (not shown)   | DVFF8A/8  | --  | --                  |
| 13   | 1            | Reducer - 5 x 8 to 4 x 6 <sup>5</sup> / <sub>8</sub> (not shown)   | 1222DA  | 1222DA  | --                  |

\* Simpson Duravent 58DV-VC1280 vertical cap cannot be used with this fireplace.

For more information about, or instructions for, the venting components referenced above, please contact the component manufacturer:

Selkirk Corporation: [www.selkirkcorp.com](http://www.selkirkcorp.com) or 800-992-8368  
 Simpson Duravent: [www.duravent.com](http://www.duravent.com) or 800-835-4429



## Massachusetts Residents Only — Please read and follow these special requirements

### NOTE REGARDING VENTED PRODUCTS

This product must be installed by a licensed plumber or gas fitter when installed within the Commonwealth of Massachusetts.

Any residence with a direct vent product must have a CO detector installed in the residence.

Installation of the fireplace or vented gas log in the State of Massachusetts requires the damper to be permanently removed or welded in the fully open position.

In addition, a naturally vented gas log may not be installed in a bedroom or bathroom in the State of Massachusetts.

Flex line installation must not exceed 36 inches and must have a T shutoff valve.

### NOTE REGARDING VENT FREE PRODUCTS

This product must be installed by a licensed plumber or gas fitter when installed within the Commonwealth of Massachusetts.

In addition, vent free products may not be installed in a bedroom or bathroom regardless of size or type in the State of Massachusetts.

Flex line installation must not exceed 36 inches and must have a T shutoff valve.

### CARBON MONOXIDE DETECTOR REQUIREMENTS

(2) Revise 10.8.3 by adding the following additional requirements:

(a) For all side wall horizontally vented gas fueled equipment installed in every dwelling, building or structure used in whole or in part for residential purposes, including those owned or operated by the Commonwealth and where the side wall exhaust vent termination is less than seven (7) feet above finished grade in the area of the venting, including but not limited to decks and porches, the following requirements shall be satisfied:

1. **Installation of carbon monoxide detectors.** At the time of installation of the side wall horizontal vented gas fueled equipment, the installing plumber or gas fitter shall observe that a hard wired carbon monoxide detector with an alarm and battery back-up is installed on the floor level where the gas equipment is to be installed. In addition, the installing plumber or gas fitter shall observe that a battery operated or hard wired carbon monoxide detector with an alarm is installed on each additional level of the dwelling, building or structure served by the side wall horizontal vented gas fueled equipment. It shall be the responsibility of the property owner to secure the services of qualified licensed professionals for the installation of hard wired carbon monoxide detectors

a. In the event that the side wall horizontally vented gas fueled equipment is installed in a crawl space or an attic, the hard wired carbon monoxide detector with alarm and battery back-up may be installed on the next adjacent floor level.

b. In the event that the requirements of this subdivision can not be met at the time of completion of installation, the owner shall have a period of thirty (30) days to comply with the above requirements; provided, however, that during said thirty (30) day period, a battery operated carbon monoxide detector with an alarm shall be installed.

2. **Approved Carbon Monoxide Detectors.** Each carbon monoxide detector as required in accordance with the above provisions shall comply with NFPA 720 and be ANSI/UL 2034 listed and IAS certified.

3. **Signage.** A metal or plastic identification plate shall be permanently mounted to the exterior of the building at a minimum height of eight (8) feet above grade directly in line with the exhaust vent terminal for the horizontally vented gas fueled heating appliance or equipment. The sign shall read, in print size no less than one-half (1/2) inch in size, "GAS VENT DIRECTLY BELOW. KEEP CLEAR OF ALL OBSTRUCTIONS."

4. **Inspection.** The state or local gas inspector of the side wall horizontally vented gas fueled equipment shall not approve the installation unless, upon inspection, the inspector observes carbon monoxide detectors and signage installed in accordance with the provisions of 248 CMR 5.08(2)(a)1 through 4.

(b) **Exemptions:** The following equipment is exempt from 248 CMR 5.08(2)(a)1 through 4:

1. The equipment listed in Chapter 10 entitled "Equipment Not Required To Be Vented" in the most current edition of NFPA 54 as adopted by the Board; and

2. Product Approved side wall horizontally vented gas fueled equipment installed in a room or structure separate from the dwelling, building or structure used in whole or in part for residential purposes.

(c) **Manufacturer requirements — Gas Equipment Venting System Provided.** When the manufacturer of Product Approved side wall horizontally vented gas equipment provides a venting system design or venting system components with the equipment, the instructions provided by the manufacturer for installation of the equipment and the venting system shall include:

1. Detailed instructions for the installation of the venting system design or the venting system components; and

2. A complete parts list for the venting system design or venting system.

(d) **Manufacturer requirements — Gas Equipment Venting System Not Provided.** When the manufacturer of a Product Approved side wall horizontally vented gas fueled equipment does not provide the parts for venting the flue gases, but identifies "special venting systems," the following requirements shall be satisfied by the manufacturer:

1. The referenced "special venting system" instructions shall be included with the appliance or equipment installation instructions; and

2. The "special venting systems" shall be Product Approved by the Board, and the instructions for that system shall include a parts list and detailed installation instructions.

(e) A copy of all installation instructions for all Product Approved side wall horizontally vented gas fueled equipment, all venting instructions, all parts lists for venting instructions, and/or all venting design

# LIMITED LIFETIME WARRANTY POLICY

## LIFETIME WARRANTY

The following components are warranted for life to the original owner, subject to proof of purchase: Firebox, Combustion Chamber, Heat Exchanger, Grate and Stainless Steel Burners.

## FIVE YEAR WARRANTY

The following components are warranted five (5) years to the original owner, subject of proof of purchase: Ceramic Fiber Logs.

## BASIC WARRANTY

MHSC warrants the components and materials in your gas appliance to be free from manufacturing and material defects for a period of two years from date of installation. After installation, if any of the components manufactured by MHSC in the appliance are found to be defective in materials or workmanship, MHSC will, at its option, replace or repair the defective components at no charge to the original owner. MHSC will also pay for reasonable labor costs incurred in replacing or repairing such components for a period of two years from date of installation. Any products presented for warranty repair must be accompanied by a dated proof of purchase.

This Limited Lifetime Warranty will be void if the appliance is not installed by a qualified installer in accordance with the installation instructions. The Limited Lifetime Warranty will also be void if the appliance is not operated and maintained according to the operating instructions supplied with the appliance, and does not extend to (1) firebox/burner assembly damage by accident, neglect, misuse, abuse, alterations, negligence of others, including the installation thereof by unqualified installers, (2) the costs of removal, reinstallation or transportation of defective parts on the appliance, or (3) incidental or consequential damage. All service work must be performed by an authorized service representative.

This warranty is expressly in lieu of other warranties, express or implied, including the warranty of merchantability of fitness for purpose and of all other obligations or liabilities. MHSC does not assume for it any other obligations or liabilities in connection with sale or use of the appliance. It states that do not allow limitations on how long an implied warranty lasts, or do not allow exclusion of indirect damage, those limitations of exclusions may not apply to you. You may also have additional rights not covered in the Limited Lifetime Warranty.

MHSC reserves the right to investigate any and all the claims against the Limited Lifetime Warranty and decide upon method of settlement.

## IF WARRANTY SERVICE IS NEEDED...

1. Contact your supplier. Make sure you have your warranty, your sales receipt and the model/serial number of your MHSC product.
2. DO NOT ATTEMPT TO DO ANY SERVICE WORK YOURSELF.

Canada

**ENERGUIDE**

**Look for the EnerGuide  
Gas Fireplace Energy  
Efficiency Rating in this brochure**

*Based on CSA P.4.1-02*

| <b>Efficiency Ratings</b> |   |
|---------------------------|---|
| <b>Model</b>              | <b>EnerGuide Ratings<br/>Fireplace Efficiency (%)</b> |
| HDV500NV                  | 69.5  |
| HDV500PV                  | 81.3  |
| HDV500NSC                 | 69.5  |
| HDV500PSC                 | 81.3  |