


How to use the washing machine

Important:

Read all instructions before using the appliance.
The machine must be installed by a qualified electrician.
The machine must not be started until the transit
packing has been removed. (It prevents the tub from
shaking while the machine is being transported.)
WARNING—To reduce the risk of fire, electric shock, or
injury to persons, read the **IMPORTANT SAFETY**
INSTRUCTIONS before operating this appliance.

SAVE THESE INSTRUCTIONS!

ASKO
13605



WARNING - Important!

Improper connection of the equipment grounding conductor can result in a risk of electric shock. Check with a qualified electrician or serviceman if you are in doubt as to whether the appliance is properly grounded.

This appliance must be grounded. The plug must be plugged into an appliance outlet that is properly installed and grounded in accordance with all local codes and ordinances.

Do not wash or dry articles that have been previously cleaned in, washed in, soaked in, or spotted with gasoline, dry-cleaning solvents, other flammable or explosive substances as they give off vapors that could ignite or explode.

How to use the machine


Follow the figures in the strip through this booklet for brief instructions on how to use the machine.

Full details and comments can be found below the strip and must be fully read before operating the washing machine.

Contents:

How to use the machine	2
Guide to parts	2
The control panel	3
Opening the door	3
Sorting the washing	4
Detergent	5
Which program should I use?	6
Program examples	6-7
Care of the machine	8
Safety	9
If the machine won't work	9
Technical details	10
Installation	10-11
<i>Removing the transport braces</i>	
<i>Adjusting the feet</i>	
<i>Positioning the machine</i>	
<i>Electrical installation</i>	
<i>Water supply</i>	
<i>Draining connection</i>	
Problems and Solutions	12-13
IMPORTANT SAFETY INSTRUCTIONS	14
Warranty	15
Instructions summary	16
<i>How to use the machine</i>	
<i>Choosing the right program</i>	

Guide to parts



Environment facts

Choose the right program

You can save considerable energy by not using heavier programs than necessary.


- Press the 1/2-button to save time and water.
- Press the "E" economy button and reduce the temperature to save energy (ECO).
- Use the higher spin speed, to reduce the amount of energy and time in a dryer.

Detergent

Using more detergent does not improve the washing performance, but merely imposes an greater pollution on the environment.

Try reducing the amount of detergent you use, and increase it only if the results are unsatisfactory. Be sure to use low sudsing detergent.

1. Press the main On/Off button.



2. Open the door by pressing



If the door does not open, see below.

The control panel

Program control knob
The program control knob must be turned clockwise only.

Program options
allows for the customizing of wash cycles (see below).

Temperature knob
The Temperature knob allows for greater accuracy for washing temperatures.

Spin speed selection
Allows for an adjustable spin speed control of 500 rpm to 1300 rpm.

Indicating lamp
Lights to show that the power is turned on.

ASKO 13605 Made in Sweden

Safety device
Ensures that a child cannot change the temperature setting. Press the button while turning the temperature knob to a higher temperature (clock-wise). See also page 9.

Rinse level
For a normal rinse water level, press the button. To get Super rinse level, release the button.

Main On/Off switch
Must be pressed in when opening the door and operating washer.

No spin
Press this button to omit all spins in all programs. Programs 1-4 will pump water out after the last rinse; programs 6, 7 and 9 will stop with water still in the machine.

Door opening
The door can be opened only when the program control knob is at the end of a program, as shown by the red mark. If it has stopped anywhere else, turn it to position 10 to pump out the water.


Economy button
Pressing the Economy button extends the main wash by 22 minutes. This allows you to reduce the temperature and yet obtain as good a result as if you had used a higher temperature for the shorter period. The Economy button + lower washing temperature reduces pollution, and helps the environment.

5 hr Delayed Start
The main power on/off button must be in the on position for the delayed start time to work. Now, press the 5 hr button. Turn the program knob to the desired program. The machine will start that program five hours from the time the program was selected.

Quick wash
Pressing this button reduces the number of rinses from five to three, and gives a long spin. Use this button when there is only a small load in the machine.


3. Load the washing

...



... and press the door shut.

(It cannot be slammed shut.)



Sort the Clothes.

Sort clothes by color, fiber content, amount of soil, lint shedding clothes (cotton, chenille, and terrycloth shed), lint attracting clothes (permanent press, corduroy, velveteen, flannel and synthetics attract) and those requiring a delicate cycle. Most clothes and other washable items have **permanent care labels**. Read these labels carefully! Care label instructions and warnings should be followed for the best cleaning results.

Load the Washer Properly



The following chart shows how full to load the washer for the best results. The load size depends on what types of fabrics you are washing.

Permanent press and Synthetics need more room to move freely during washing for the most wrinkle-free results. Therefore, fill the machine only **half full** for permanent press and synthetics loads. These items should only have a **short spin** cycle after which they should be promptly removed from the washer for drying. Follow the guidelines on the Program Charts for "permanent press, synthetics".

Machine washable **wool** loads should only be one-third full for the cleanest results in this shortened cycle.

Recommended load sizes

Full load	Half load	Third Load
Cotton Linen	Permanent Press Synthetics Acrylics Special finish cottons	Wool (machine washable) Silk Acetates



How much is in a full load ?

If the drum is filled without packing it tightly, it will hold the equivalent of two sheets, two to four pillow cases and mattress pad of a queen size bed or two king size sheets, and two to four pillow cases.

Water level in the washer

There is no need to set a load size or water level because the Asko ALC (Automatic Level Control) System **automatically selects the correct amount** of water for each load.

Preparing clothes for washing

- Turn delicate items, sweaters and t-shirts inside out to prevent pilling and to protect the prints.
- Empty pockets and turn them inside out.
- Remove any sharp ornaments, pins or buckles to prevent snags.
- Close zippers and hooks to prevent snagging
- Tie sashes and strings to prevent tangling.
- Mend any small rips or tears to prevent them from getting bigger.




New colored items

Read labels carefully! If a label says "Wash Separately", the item may will lose color (excess dye) for the first few washings. To minimize the possibility of this color transferring to white or lighter colored items, wash new colored garments with items of similar color or alone before wearing. Bright reds and oranges on cottons are the dyes most likely to transfer colors to the wash load. Fluorescent colors should always be washed separately.

Prewash or not?

When washing items that are only slightly soiled, the prewash cycle can be omitted. Starting the machine at the main wash stage (Number 3) will save about 25 minutes.

4. Pour detergent (and fabric conditioner if used) into the appropriate sections of the detergent compartment.



Detergents - What kind - How much?

Use only low sudsing laundry detergents!

Detergents are available in low, normal and full sudsing formulas. A detergent's ability to clean is not related, to the amount of suds it produces. Excess suds in a front loading washer actually interfere with cleaning action because they cushion the tumbling of clothes. High sudsing detergents are also more difficult to completely rinse out.

Use 1/4 to 1/2 of the recommended U.S. detergents

Because of the Asko washer's low water consumption and the fact that all the wash water and detergent are completely circulated repeatedly through the laundry, ensuring that all the detergent is fully utilized, detergent usage is cut by 50% to 75%.

Different brands of detergents recommend using different amounts. Read all package labels carefully. The first time you use any detergent, **start with 1/4** of the recommended amount. (For example: If the label says use 1 cup, use 1/4 cup.)

If the detergent produces a good, low level of suds, you may add slightly more detergent if you have **very hard water** or if your clothes are not getting perfectly clean. It is advisable to check your water hardness with the local water department.

Recommended detergents

Avoid normal and full sudsing detergents. The chart below lists several low sudsing detergents that have been successfully tested in the Asko washer, along with the recommended amounts.

Recommended Detergents	Main Wash Detergent Amount
Fab (powder)	1/4 to 1/2 cup
Amway SA8 (powder)	1-2 tablespoons or 1/8 cup
Fresh Start (powder)	2 tablespoons (1/8 cup) to 1/4 cup
Tide HE (powder)	follow box instructions
Wisk Front Load Liquid	follow package instructions

In general, liquid detergents tend to be higher sudsing than powders. Do not use powder detergents that do not wash completely out of the detergent cup as the machine fills with water.

Liquid detergents


Liquid detergents tend to suds more than powder detergents. When trying a detergent for the first time, start out with a very small amount, such as 1 to 2 tablespoons.

Liquid detergent can be used for all programs without pre-wash. Add it into the main wash compartment.

Bleach

The use of bleach is **not necessary** with these machines, nor is it recommended.

Note: Detergents: Using more detergent does not improve the washing performance, but merely imposes an additional pollution on the environment. Try reducing the amount of detergent you use, and increase it only if the results are unsatisfactory.




Fabric softeners

Use 1/3 to 1/2 of the recommended amount of fabric softener, because of the low water usage of the Asko washer. Fabric softeners are available in several concentrations. Read the labels carefully and use only 1/3 to 1/2 of the recommended amount. (For example: If the label says to use 1 capful, use 1/3 capful.) If more softening is desired, try adding slightly more the next time.

Oversudsing


The use of anything other than a low sudsing detergent can cause severe oversudsing. If this happens, run the wash through one or more rinse programs (starting on 4) until items are thoroughly rinsed. Then, run the empty washer through an entire wash program (starting on 1) to clear the machine of any remaining high sudsing detergent. Over sudsing can cause a back-up through the detergent compartment and leave a residue on the floor and the front of the washer.




Clean the detergent compartment regularly

1. Pull out the compartment and remove the fabric conditioner insert.
2. Select any program.
3. Clean the compartment with a brush while water flows through it.
4. When finished, select program 10 to pump the water out of the machine.


5. Set the required temperature on the thermostat . . .



6. Press any required program option buttons



7. Choose centrifugations spin speed....



What the figures on the program knob mean

9 Wool/Hand wash

9. Start wool

10 Pumping out

1-2 Heavy

1. Start Whites/Colors with Prewash


2. Start Whites/Colors** without Prewash

3 Normal

3. Start Normal wash program

4. Start Rinse program

5. Long spin



6-7 Perma press/Synthetics

6. Start long Synthetics wash**

7. Start short Synthetics wash

8. Short spin

The Red lines

indicate program finishing points. The door can be opened only when the pointer is against a red mark.

** When you choose program 2 (6) the knob advances directly to 3 (7). The machine still performs all stages of program 2 (6) .

Quick Wash program


The machine has a special Quick Wash program, which saves both time and energy.

The program can be used at any temperature. If the load is small, you can also press the half-load button and shorten the program up even more.

Which program should I choose?

You can naturally select a standard program or, by combining your preferred temperature setting, program and option selection, produce a program to suit your requirements.

The programs below are suggestions.

Fabric care label	Type of fabric	Fill	Program
Heavy	White Cotton with pre-wash	●	1
	White Cotton no pre-wash	●	2
Normal	White Cotton	●	3
	Cotton Color Fast	●	3
	Cotton Non Color Fast	●	3
Perma Press	Wash & Wear	◐	6
Synthetics	Acrylic knits	◐	7
	Delicates/Wool	○	9

... and start the program 8. The machines starts and works through the stages shown below.



Remember – turn the program knob clockwise only.

If you change your mind . . .


. . . and want a different program:

Turn the program knob and program selector to the required positions, and press any temperature switches that you want.

. . . or want to interrupt the program

Turn the program knob to 10 to make the machine pump out. After about two minutes, you can open the door. If you add more washing and restart the machine, check that there is detergent left in the detergent compartment.

Points to note:

- The Wool program cannot be modified by the option buttons, except for  (no spin).
- The main wash in programs 2 and 6 starts with a wash 4.5 minutes in order to remove stains such as blood.
- The main wash water is always cooled by the admission of cold water before pumping out in order to prevent risk of scalding, shrinking and wrinkling.
- Before starting to spin, the machine checks that the load is evenly distributed in the drum. If not, it redistributes the load by turning at normal drum speed and then makes another attempt to start spinning.
- The heavy wash program number 2, and the permanent press program number 6, have a wash of approximately 4 minutes before the heat comes on. This is to help in removal of stains.

Special Options:

E = Economy Cycle

Saves electricity without sacrificing results by lowering water temp. and extending wash cycle 22 minutes.

 = No Spin

Provides a hand-washed gentleness for delicate fabrics that will be air dried.

5h = Delay Start


Delays the start by five hours.

1/2 = Quick Wash

Shortens the wash cycle. Recommended for lightly soiled clothing.

	Temperature °F	Water-consumption, gallons
	140-205°	17
	140-205°	15
	140-205°	15
	100-140°	15
	85-100°	15
	85-100°	10
	65-100°	10
	65-100°	17

The machine finishes programs 6, 7, and with a short spin.


Press  if you do not want any spin at all.

The machine stops with the final rinse water still in it.

Turn the program knob to 10 to pump out the machine. Or you can turn it to 8 for pumping out followed by a short spin. Most garments can withstand a short, careful spin.

9. When the machine has stopped:

Open the door
by pressing









- After a program that has finished with water left in the machine, turn the program knob to 8 or 10 to pump out the water (8 will give a short spin). You can then open the door.

User -Maintenance Instructions – Care of the machine

Check the needle trap and outlet pump

The machine has a needle trap which will trap needles, hairpins, coins and similar items. Clean it at intervals as follows:

1. Open the lower cover in front of the pump, pull the small drain hose and drain off water into a shallow bowl after removing the plug from the end of the hose (1).
2. Turn the pump cover counter clockwise to the position shown in (2). This un-covers the drain holes and water will run out into the bowl.
3. When the water has finished draining out, turn the pump cover further and pull it off. Clean out the needle trap, and clean the pump rotor at the back of the pump housing (3).
4. Check that there is no grit or small objects in the pump, and replace the pump cover. Turn it clockwise in two stages: when you hear a click, turn it a little more to its end stop, as shown in (4).



Access openings under the drum paddles

If an object has fallen between the drum and the outer container, you can get it out as follows:

1. Undo the screw on top of the paddle with a screwdriver (three turns).
2. Pull the paddle towards you and lift it upwards.
3. Remove the object. Be careful not to bend the immersion heater elements.
4. Locate the paddle in its fixing hole, with the F-mark to the front (i.e. facing you). Slide the paddle backwards as far as it will go. Check that its clips are properly located in the slots in the drum, and retighten the screw.

10. After use:

Turn off the machine at the On/Off button.

NB! Don't close the door after using the machine: leave it ajar.

Safety

The machine incorporates a door safety switch which prevents it from being started if the door is open. The door is also interlocked to prevent it from being opened when the machine is running or when it has stopped with water in the machine.

Safety catch


The machine has a safety catch which prevents children from turning the thermostat position to increasing the temperature. As supplied, the safety catch on the machine is disengaged.

To engage it:

- Press the button beneath the thermostat knob and then release it.

To disengage the safety catch:

- Press the slot in the end of the button with a coin.
- Push and turn the button slightly in the same direction as if screwing in a screw (clockwise).



If the machine won't work

Problem	Response
<p>The door will not open.</p>	<ol style="list-style-type: none"> 1. Check that the main On/Off switch is turned on. 2. If the indicator lamp is not lit, there is no power supply. Check the plug and fuses. The door cannot be opened normally if there is no power supply. 3. If the door cannot be opened in the normal manner, it can be opened as follows. Be sure there is no water in the machine before pulling ring. <ul style="list-style-type: none"> • Remove the lower front panel. • Unscrew the plastic ring and pull. The the door will open. • Replace the ring and the front panel. If the door still cannot be opened in the normal way afterwards, call a service engineer.
<p>The machine does not fill with water when started.</p>	<ol style="list-style-type: none"> 1. Is the faucet in the supply line open? 2. Is the strainer in the inlet connection blocked? Unscrew the hose and check. Remember to turn off the water supply first.
<p>The machine does not start when the program knob is turned to the starting position.</p>	<ol style="list-style-type: none"> 1. Is the door properly closed? Press it shut firmly – don't slam it. 2. Is the main On/Off switch turned on? 3. Has the power supply failed? Check the plug and fuses.
<p>The machine will not spin.</p>	<ol style="list-style-type: none"> 1. Is the pump or outlet hose blocked? Clean if necessary, as described on page 8. 2. Has the power supply failed? Check the plug and fuses. 3. The machine will make up to 30 attempts to start, redistributing the washing if the drum is out of balance. After that, it passes on to the next stage of the program.
<p>A lot of foam in the final rinse water, or water left in the machine after spinning and pumping out.</p>	<ol style="list-style-type: none"> 1. Is anything blocking the outlet hose? A button or a coin can do so. Make sure that no part of the hose (including any joints) is less than 1/2 inch in diameter. 2. Is the pump blocked? Clean it as described on page 8. 3. Is the outlet hose kinked?

Technical data

Dimensions	32 1/4 x 23 1/2 x 23 1/2"
Weight	167 lbs.
Spin speed	1300/500 rpm
Rated load	3465 W
Supply voltage	208-240 V, 60 Hz
Heater rating	3265 W
Material of inner and outer drum	Stainless steel
Material of outer casing	Stove-enamelled hot-dip-galvanised steel sheet
Mounting	Stationary: four adjustable rubber- covered feet
Water supply hose	5 ft pex hose
Supply pressure	15-142 PSI
Outlet hose	5.5 ft of poly- propene hose, 3/4 inch internal diameter

Accessories

The machine is supplied with:

- Operating instructions and installation instructions.
- Guarantee card.
- Type-approved inlet hose for connection to water supply.


Optional extras:

- Decor frames
- Edging frame by stacked machines
- Frame set with pull-out shelf by stacked machines.

Installation Instructions


Removing the shipping brace

The shipping brace consists of two tubes which prevent the outer drum from moving around inside the machine during shipping. The tubes are secured to a shipping brace at the back of the machine.




Remove the shipping brace as follows:

1. Remove the bolts (10 mm) and special lock washers which retain the beam, and remove the beam.




2. Replace the washers on the flattened part of the tubes. Use them as tools to turn the tubes through about 45°, as shown in the drawing, and pull out the tubes.




3. Turn the washers so that they cover the holes where the tubes were fitted and replace the bolts.

Save the tubes and cross beam, which will be needed if the machine has to be transported elsewhere. Fit them in the reverse order to that described above.



Adjusting the feet

It is important that the machine does not move around when it is spinning. This means that it must be standing firmly and level on the floor. The four feet are individually adjustable. Set them carefully so that the machine is standing level, and tighten the locknuts securely.



Positioning the machine

The machine can be installed beneath a worktop with a height of 33 1/2"-35 1/2". There must be a gap of about 1/4" all round the machine, including between the rear edge of the machine top panel and the wall behind. This is important: if no space is left, the machine may hit the wall when it starts to spin.

NOTE
Height adjustment: 32 1/4"-33 1/2"
Do not raise Higher than 33 1/2"

Electrical installation

The washer is delivered from the factory with a 220 V, 20 A electrical cord designed to plug into the matching receptacle on the back of an ASKO dryer. If an ASKO dryer is not being used with an ASKO washer, the washer must have a dedicated 220 V, 20 A single phase wall receptacle.

If the machine is to be used in a wet area, the supply must be protected by a residual current device.

Connection to a permanently wired supply point must be made only by a qualified electrician.

As supplied: 208-240 V, 60 Hz
3265 W heater rating,
15 A fuse required

GROUNDING INSTRUCTIONS

This appliance must be grounded. In the event of malfunction or breakdown, grounding will reduce the risk of electric shock by providing a path of least resistance for electric current. This appliance is equipped with a cord having an equipment-grounding conductor and a grounding plug. The plug must be plugged into an appropriate outlet that is properly installed and grounded in accordance with all local codes and ordinances.

WARNING - Improper connection of the equipment-grounding conductor can result in a risk of electric shock. Check with a qualified electrician or serviceman if you are in doubt as to whether the appliance is properly grounded.

Do not modify the plug provided with the appliance - if it will not fit the outlet, have a proper outlet installed by a qualified electrician.

Water supply connection

The water supply connections must be made by a person having the necessary competence.

Water pressure must be in the range

15–146 PSI.




A faucet shut off/on must be fitted in the supply pipe for the hose.

If a new supply pipe has been installed for the machine, it should be flushed through thoroughly in order to remove any particles of dirt which might otherwise block the strainer in the water inlet of the machine.

Drain outlet connection

The machine is supplied with the outlet hose all ready fitted. The hose should be hung over a suitable sink edge or drain pipe at a height of 15 3/4"–35 1/2" above the floor: the lower height is preferable. Make sure that the hose is not kinked.

NOTE! If the hose is extended, the internal diameter of the coupling must not be less than 1/2 inch.



Problems ?

Try the following remedies. Poor result may not always be caused by the machine. Read through the chart below before contacting your servicer.

Problem	Possible Cause	Suggested Remedy
Door will not open Machine will not start Machine will not fill with water Foam in final rinse, water left in machine		See "If the machine doesn't work", page 9.
Water leaks	Hoses	All hoses, especially the inlet hose should be inspected at least once a year. Replace if they show signs of cracking. Check to see if hose connections at faucets are tight. Properly insert and secure end of drain facility.
Extrem vibration during spin cycle	Shipping braces not removed	Remove shipping braces. See page 10.
	Machine not level	Adjust machine feet and tighten locknuts.
Oversudsing	Wrong detergent	Use only low sudsing detergents. See page 5. Run clothes through extra rinse cycles. Run empty machine through complete cycle
	Too much detergent	Use recommended amounts. See page 5.
Washer stops during cycle	Normal pauses	It is normal for the machine to pause occasionally during operation, especially between cycles and during the delicate wash program.
Greying clothes	Not enough detergent	You may need to add slightly more detergent if clothes are heavily soiled, have oily stains, or if your water is very hard.
	Water not hot enough	Select hot temperature setting for each type of load. See charts page 6 and 16.
	Improperly prewashed or presoaked	Be sure to add a prewash and/or presoak for heavily soiled oily items.
	Washer overloaded	Once wet, the clothes must have room to tumble freely, especially synthetics and permanent press.
	Soap used in hard water areas.	Be sure you use a laundry "detergent" and not a "soap". Soaps react with the minerals in hard water to form a soap curd, which can be deposited on clothes.
Lint, residue left on clothes	Improper sorting of clothes	Separate clothes that shed lint (chenille and terry cloth) from clothes that attract lint (synthetics, corduroy, velveteen).
	Nonphosphate detergent Non-phosphate detergents	can combine with minerals in hard water and form a precipitate which can appear to be lint. Use a low phosphate detergent, if possible. Install a water softener.
	Fabric softener used improperly	Read labels. Most softeners should only be used in the final rinse. Add softener to the softener compartment. If added to the wash cycle, softeners can have a reaction with detergents producing a white residue.
	Pilling	Pilling, which can look like lint, is produced by normal wear on cotton/polyester blend fabrics. To reduce, wash synthetics and cotton /polyester blends inside out. For the best results, wash cotton/polyester knits using the delicate cycle.

Problems ?

Try the following remedies. Poor result may not always be caused by the machine. Read through the chart below before contacting your servicer.

Problem	Possible Cause	Suggested Remedy
Yellowing of clothes	Not enough detergent, water not hot enough	Caused by body oils not completely removed. Use hottest recommended temperature for each type of load and add slightly more detergent.
	Iron or manganese in water	Install a filter to remove iron or manganese from water. A small amount of Calgon or other non-precipitating water conditioner added once a week is advisable in hard water areas.
Shrinkage	Improper washing or drying	Follow garment care label instructions carefully. Some fabrics will shrink no matter how they are washed. Some may be machine washed but not machine dried.
Knit shrinkage	Overheating	Knits tend to shrink more than woven fabrics. If a knit has been heat shaped, wash in cool or warm water. Dry with the low setting.
	Delayed or gradual shrinkage	Can occur when special stabilizing finishes are reduced from wear or repeated washings. Garment may sometimes be reshaped by pressing after washing and drying.
	Poor construction	Shrinkage can occur if the knit fabric was not stretched properly by the manufacturer. Press back into shape each time garment is washed and dried.
Rips,snags,excess wear	Sharp objects in pockets	Empty all pockets and turn inside out before laundering.
	Hooks, snaps, zippers, buckles	Fasten all hooks,snaps and zippers before laundering to avoid snags. Remove sharp buckles. Turn knits inside out.
	Harsh chemicals	Before washing, rinse harsh chemicals, such as battery acid, permanent wave solution, hair bleach, dyes and toilet bowl cleaners, from towels and other articles to avoid holes in fabrics. Do not allow these unrinsed items to contact other fabrics.
	Existing rips and tears	Mend all garments before laundering to prevent enlarging of rips.
	Permanent press items	These items fray at edges from the permanent press process and from normal wear, not from the washer. Only wash in half loads. Do not wash in the same load with very heavy items, such as towels or jeans.
Fading and discoloring	Inproper sorting	Dark clothes, especially cottons, can bleed excess dyes into wash water. White or light colored clothes can absorb the dye and discolor. Separate light from dark items.
	Crayons or pens in pockets.	Empty all pockets before washing.
	Water too hot	Cool or cold water is best for retaining dark or bright colors.
Stains not removed	Incorrect water temperature Protein stains, such as	milk,egg,blood and soy formula should be removed in cold water. Oily stains should be washed in the hottest water recommended for each fabric type.
	Old stains	The longer a stain remains on a fabric, the harder it is to remove. Treat stains promptly. Do not set stains by machine drying or ironing fabrics until stains are completely removed.

IMPORTANT SAFETY INSTRUCTIONS

WARNING – To reduce the risk of fire, electric shock, or injury to persons when using your appliance, follow basic precautions, including the following:

1. Read all instructions before using the appliance.
2. Do not wash or dry articles that have been previously cleaned in, washed in, soaked in, or spotted with gasoline, dry-cleaning solvents, other flammable or explosive substances as they give off vapors that could ignite or explode.
3. Do not allow children to play on or in the appliance. Close supervision of children is necessary when the appliance is used near children.
4. Before the appliance is removed from service or discarded, remove the door to the washing or drying compartment.
5. Do not reach into the appliance if the drum is moving.
6. Do not install or store this appliance where it will be exposed to the weather.
7. Do not tamper with controls.
8. Do not repair or replace any part of the appliance or attempt any servicing unless specifically recommended in the user-repair instructions or in published user-repair instructions that you understand and have the skills to carry out.
9. Do not add gasoline, dry-cleaning solvents, or other flammable or explosive substances to the wash water. These substances give off vapors that could ignite or explode.
10. Under certain conditions, hydrogen gas may be produced in a hot water system that has not been used for 2 weeks or more. **HYDROGEN GAS IS EXPLOSIVE.** If the hot water system has not been used for such a period, before using a washing machine or combination washer-dryer, turn on all water faucets and let the water flow from each for several minutes. This will release any accumulated hydrogen gas. As the gas is flammable, do not smoke or use an open flame during this time.

Save These Instructions

ASKO Product Warranty

Home Clothes Washers and Dryers

For Residential Installations

Length of warranty	ASKO will pay for:
ONE YEAR FULL WARRANTY From date of purchase	ASKO replacement parts and/or repair labor to correct defect in materials or workmanship. Service must be provided by an authorized ASKO service outlet.
FIVE YEAR LIMITED WARRANTY One year full plus second through fifth year limited from date of purchase.	ASKO replacement parts (repair labor costs not included) for any defective solid state controls, timers, motors, pumps.
TWENT-FIVE YEAR LIMITED WARRANTY One year full plus second through twentyfive year limited from date of purchase.	ASKO replacement parts (repair labor costs not included) for the stainless steel inner and outer drum/tub if it fails to hold water due to a manufacturing defect such as cracking or rusting.

For Non-Residential Installations

SIX MONTHS FULL WARRANTY FROM DATE OF PURCHASE	ASKO replacement parts and/or labor to correct defect in materials or workmanship. Service to be provided by an authorized ASKO service outlet.
---	---

ASKO will not pay for:

- A. Service calls to:
 1. Correct the installation of the washer or dryer
 2. Instruct how to use the washer or dryer
 3. Replace house fuses or correct housing wiring
 4. Correct house plumbing
 5. Cleaning or servicing of the button trap, outlet pump of the washer
 6. Cleaning or serving of the lint filter or condensing unit of the dryer
- B. Repair and/or parts for failure of product if washer or dryer is used in other than normal use.
- C. Damage resulting from accident, fire, floods, acts of God, alteration, misuse abuse, improper installation or installation not in accordance with local electrical or plumbing codes.
- D. Any labor or shipping costs for parts during the limited warranty.
- E. Replacement parts or repair labor costs for units operated outside the Continental United States.
- F. Pick-up and delivery. ASKO products are designed to be repaired in the home.

IN NO EVENT SHALL ASKO INC. BE RESPONSIBLE FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES.


Some states will not allow the exclusion or limitation of incidental or consequential damages, so this exclusion or limitation may not apply to you. This warranty gives you specific legal rights and you may also have other rights which vary from state to state.

For warranty service, contact the dealer from whom you purchased the unit or an authorized ASKO service outlet. Service will be provided during normal business hours. Should you have a service problem that is not resolved locally write:


ASKO USA INC.
P O Box 851805
Richardson, TX 75085-1805

Summary of washing instructions


1 Press the main On/Off switch.




2 Open the door by pushing




3 Load the washing and close the door firmly.




4 Pour detergent and fabric conditioner into the detergent compartment.




5 Set the temperature with the thermostat knob.



6 Select any program options




7 Turn the program knob to the required program, and the machine will start.




8 When the machine stops:

- Open the door by pressing
- After a program that has finished by pumping out the water, you can open the door after about two minutes.
- After a program that has finished with water left in the machine, turn the program knob to 9 to pump out the water. You can then open the door after about a further two minutes.

9 After using the machine:
Turn off the main switch, and leave the door ajar.



Choosing the right program

Fabric care label	Type of fabric	Fill	Program	Temperature °F	Water-consumption, gallons
Heavy	White Cotton with pre-wash	●	1	140-205°	17
	White Cotton no pre-wash	●	2	140-205°	15
Normal	White Cotton	●	3	140-205°	15
	Cotton Color Fast	●	3	100-140°	15
	Cotton Non Color Fast	●	3	85-100°	15
Perma Press	Wash & Wear	◐	6	85-100°	10
Synthetics	Acrylic knits	◐	7	65-100°	10
	Delicates/Wool	○	9	65-100°	17