This Owner's Manual is provided and hosted by Appliance Factory Parts.

Appliance Factory Parts
Experts in BBQ, Humidifier, & Appliance Parts
1-800-955-7075

Kenmore 79551029010 Owner's Manual

Shop genuine replacement parts for Kenmore 79551029010

Find Your Kenmore Refrigerator Parts - Select From 665 Models

-------- Manual continues below --------

FAILURE DIAGNOSIS TABLE

Error Code Diagnosis

To check for any error in the display, press and hold ULTRA ICE button and FRZ TEMP button for more than 3 seconds. If all LEDs are illuminated, no error is present; if only certain LEDs are illuminated, an error has occurred. For error listing refer to the table below.



Fig. 1 (Type 1)



Fig. 2 (Type 2)

NOTE: Display type 1 or type 2 are determined by dispenser selection area. For type 1, only a dot will be illuminated above icon; for type 2, icon will be illuminated completly.

ERROR CODES displayed on Freezer Temp. indicator lights.

No.	ITEM	FAILURE CODE INDICATOR (F-Section)	CONTENTS OF FAILURE	PRODUCT OPERATION STATUS IN FAILURE				
				Compressor	Freezer Fan	Cooling Fan	Defrost Heater	STEP MOTOR
1	No Error	ALL LED ON	-	●	●	●	●	●
2	Freezer Sensor	COLDER COLD OFF	Short circuit wire	15min ON / 15min OFF	Standard RPM	●	●	●
3	Refrigerator Sensor (1)	COLDER COLD OFF		●	Standard RPM	●	●	10 min OPEN / 15min CLOSE
4	Refrigerator Sensor (2)	SEE **SECONDARY ERROR INDICATOR LIGHT**		●	●	●	●	●
5	Defrost Sensor	COLDER COLD OFF		●	Standard RPM	●	No Defrost	●
6	Room Temperature Sensor	SEE **SECONDARY ERROR INDICATOR LIGHT**		●	●	●	●	●
7	Ice-maker Sensor	SEE **SECONDARY ERROR INDICATOR LIGHT**		●	●	●	●	●
8	Defrost	COLDER COLD OFF	Defrost heater , fuse melting, short circuit, unplugged connector (error indicated 80 min after trouble).	●	Standard RPM	●	●	●
9	Ice-maker UNIT	SEE **SECONDARY ERROR INDICATOR LIGHT**	Faulty Ice-maker unit; Motor or Hall IC; Lead wire short circuit; Faulty Motor driver.	●	●	●	●	●
10	Freezing BLDC Fan Motor	COLDER COLD OFF	Motor defect, hooked of lead wire to fan, contact of structures with fan, short or open of lead wire (there is no signal of BLDC Motor for more than 115s when fan motor is in operation).	●	Off (Re-check after 30min)	●	●	●
11	Cooling BLDC Fan Motor	COLDER COLD OFF	-	●	●	Off (Re-check after 30min)	●	●

● = Normal Status

Primary Error: Freezer sensor, Refrigerator sensor (1), Defrost sensor, Freezer and Cooling Fan error.
Secondary Error: Refrigerator sensor (2), Room temperature sensor, Ice-maker sensor, Ice-maker unit error.

Primary errors and secondary errors can be checked in display by pressing and holding ULTRA ICE button and FRZ TEMP button simultaneously for more than 3 seconds (Display check mode); except when any primary error is present for more than 3 hours, in this case, error will be showed automatically in display without having to press any button.

SECONDARY ERROR INDICATOR LIGHT:

- REFRIGERATOR SENSOR (2) (LOWER SENSOR IN REFRIGERATOR COMPARTMENT).....**"ULTRA ICE"** INDICATOR WILL NOT BE LIT
- ICE-MAKER SENSOR.....**"CUBE ICE"** INDICATOR WILL NOT BE LIT
- ICE-MAKER UNIT.....**"CRUSH ICE"** INDICATOR WILL NOT BE LIT
- ROOM TEMPERATURE SENSOR.....**"FREEZER TEMPERATURE LOWER"** INDICATOR WILL NOT BE LIT.

PCB TEST BUTT



NOTE: Test mode will not begin if an error code is

NOTE: During the Test mode, display board button

• After finishing the Test mode, always unplug and

MODE	OPERATION	CO
TEST MODE 1	Press once TEST S/W <Forced Freezing Mode>	1. COMP & C Fa 2. Freezer fan in 3. Defrost Heater 4. Stepping Moto 5. Display fully illu
TEST MODE 2	From Test 1 press again TEST S/W	1. COMP & C Fa 2. Freezer fan OF 3. Defrost Heater 4. Stepping Moto 5. Only F & R not (first four bars
NORMAL OPERATION	From Test 2 press again TEST S/W	Compressor will t

* Demonstration MODE:

The OFF icon lights.

IC



1. ICEMAKER

Test Control

• Press and hold the Test
• It operates in the followi

2. CUBE SIZE ADJUSTMENT FUNCTION

⚠ CAUTION

Unplug the power cord from the wall outlet and wai cover, (310 Volts are present in the control panel.)

NOTE: Use chart below to adjust cube size.



• The water supplying time is set at 7 seconds whe
• The amount of water supplied depends on the set
• If the ice cubes are too small, increase the water
• If the ice cubes stick together, decrease the water

⚠ CAUTION

To prevent the ice tray for overflowing adjust the cu

IMPORTANT DO NOT DESTROY

WIRING DIAGRAMS, SERVICE AND PARTS INFORMATION INCLUDED
REPOSITION TO ORIGINAL LOCATION

REFRIGERATOR COMPARTMENT