





Parts List – Model #634626606

No.	Qty.	Description	Part #	No.	Qty.	Description	Part #
A	1	Bottom Shelf	750810	AA	1	Cookbook	720317
B	4	Rails	750805	BB	1	Ignition Button	720701
C	1	Top Cooking	750139	CC	3	"A" Rods	720705
D	1	Bottom Cooking	750140	DD	1	Main Lower Body	720104
E	4	Runners	750805	EE	1	Main Lower Heat Plate	720304
F	1	Grease Drain Tube	750285	FF	1	Main Lower Manifold	720309
G	2	Fire Rails	750142	GG	1	"B" Heat Tent Burner	720306
H	2	Cooking Backpanel	750139	HH	1	Main Lower Left Body	720104
I	1	Manifold	750130	II	1	Main Lower Left Side Rail	720719
J	1	Manifold Cap, Right	750210	JJ	1	Shelf	720309
K	1	Manifold Cap, Left	750210	KK	1	Main Lower Shelf	720304
L	1	Combination Manifold	750213	LL	1	Spindle	720304
M	2	Wheels	750262	MM	1	Hood Frame	720403
N	1	Axle Rod	750141	NN	1	Warming Rack	720701
O	4	Hyperglaze Burner	750281	OO	1	Grate Base	720703
P	1	Manifold Body Assembly	750340	PP	2	Grate Cradle	720703
Q	1	Grease Pan	750140	QQ	1	Knee/Elbow/Plug Ladder	720704
R	1	Manifold Cap Burner	750220	RR	1	Control Panel	720701
S	1	Manifold, Right	750340	SS	1	Ignition Module	720304
T	1	Manifold, Left	750210	TT	1	20" Ignition Wire	720304
U	2	Leg Extension	750220	UU	1	Leg Assembly, Curvy	720304
V	4	Caster Access	750301	VV	1	Leg Assembly, Straight	720304
W	4	Wheels	750210	--	1	Warranty Bag	720129
X	1	Leg + Plate Assembly	6727187				
Y	1	Temperature Gauge	7520301				
Z	1	Temperature Gauge Bezel	6727183