


1		LITERATURE PARTS
	LIT1168163	Tech Sheet
	LIT1165234	Wiring Diagram
	LIT1169191	Use and Care Guide
2	1160970	Overload
3	855199	Bend, Return (6)
4	1162526	Strainer
5	1168637	Tube, Connecting
6	1168623	Tube, Restrictor
7	1158524	Blade, Fan
10	1166119	Motor, Fan
11	488130	Nut, Hex 8-32 (4)
12	1158307	Tube, Discharge
13	1164540	Evaporator
14	950037	Gasket
15	950032	Spring, Overload
16	996773	Anticipator
17	475577	Clip, Anticipator
18	1157926	Base
19	857547	Cable, Tie
20	484136	Harness, Wiring
21	1169018	Condenser
22	950212	Grommet (3)
23	1169761	Bend, Return
24	858122	Locknut (3)
25	950035	Gasket, Terminal Cover
26	489108	Washer (3)
27	1166117	Tube, Suction
28	950213	Cover, Terminal
29	950027	Nut Hex 5 - 8 mm.
30	1165066	Tube, Feeder (Restrictor)
34	1159443	Seal, Foam
35	949634	Clip, Mtg (2) (Cabinet-Front)
36	708532	Bend, Return (11)
37	1164551	Seal, Tube
39	1160969	Compressor Assembly
40	1164650	Wheel, Blower
41	859600	Seal, Condenser Bottom

REFRIGERANT CHARGE 14 OZ.

# AIR FLOW AND CONTROL PARTS


For Model: BHAC0500FS1



2	475841	Insulation, Sleeve
3	488480	Screw, 8 x 1/2
4	1157908	Shroud, Condenser
5	649879	Support, Unit
6	1162595	Capacitor, Running
7	1167611	Bracket, Capacitor
8	1163283	Screw 1/2
13	1158451	Wall, Dividing
14	852451	Clamp, Wiring
15	1168622	Insulation, Motor
16	1164674	Cord, Appliance
17	488624	Screw, ST 8-32 x 3/8
18	856094	Wire, Ground
20	1164655	Shroud, Evaporator
23	1164671	Pan, Evaporator
26	1164670	Hood, Air Housing
28	1165244	Switch, Rotary
29	1159409	Panel, Control
30	488734	Screw, 6-32 x .175
31	852063	Seal, Condensate
32	1158850	Seal, Side
33	1164648	Housing, Air
35	488624	Screw 8 x 3/8
36	1166919	Control, Temp.
40	1159222	Screw
42	1164680	Seal (2)

# CABINET PARTS


For Model: BHAC0500FS1



1	1157939	Cabinet
2	469877	Gasket, Meeting Rail
3	1158294	Clip
4	1168393	Channel, Top
5	1157158	Screw, ST 8-32 x 3/8 (6)
6	1162161	Front, Cabinet
7	488720	Screw (2)
8	1162963	Curtain (L.S.)
	1162961	Curtain (R.S.)
9	1168285	Insulation, Side
10	1157942	Insulation, Top
11	1162158	Filter
12	856990	Seal, Strip
13	1159283	Seal
15	644228	Bracket, Window
16	488255	Screw, 8 x 3/4
17	645684	Link, Louver
18	1158325	Louver, Vertical
19	648626	Handle, Louver
20	641484	Spring, Detent
23	1161561	Screw (4)
24	855238	Seal, Vertical Louver
25	1169287	Escutcheon
26	949090	Seal, Louver
27	476180	Bag, Accessory
28	470036	Spacer, (2)
29	1167617	Knob (2)
30	1157126	Cover, Hole
32	1159222	Screw, Front

# OPTIONAL PARTS (NOT INCLUDED)

For Model: BHAC0500FS1




1	799833	Epoxy, Tube (Aluminum Repair)
2	505168	Tape, No Drip 30'
3	479502	Tape, Vinyl 36'
4	10943	Oil, Turbine 1 Fl. Oz.
5	99243	Oil, Turbine 8 Fl. Oz.
6		Valve, Access
	876764	3/16" Tube O.D.
	978025	1/4" Tube O.D.
	978026	5/16" Tube O.D.
	978027	3/8" Tube O.D.
	978028	1/2" Tube O.D.
	978029	5/8" Tube O.D.
	978030	3/4" Tube O.D.
7	978865	Seal, Ring Access valve (20-Pack)
8		Wire, 25' Roll
	10875	Blue 16 Ga.
	242820	Black 14Ga.
	242825	Red 14 Ga.
	242826	White 14 Ga.
	47261	Black 12 Ga.
	299885	Red 12 Ga.
	47263	White 12 Ga.
9	813684	Adhesive, Insulation (24 Oz. Spray)
10	279368	Adhesive, Insulation (2 Oz. Tube)
11	485426	Paint, Touch-up Starlight Gray 1/2 Pint (Lacquer)
12	212643	Sealer, Permagum 4-1" Strips
13	99344	Sealer, Permagum 1 Lb. Bar
14		Cover, Winter
	484066	28 x 19 x 31"
	484067	19 x 12 x 14"
	484069	27 x 19 x 6 to 27"
	484184	22 x 15 x 3 to 18"
15	813610	Retainer, Cord (Winter Cover)

# INSTALLATION PARTS

For Model: BHAC0500FS1

WINDOW MOUNTING KITS



WMK-M

The Accessory Installation Kits illustrated below may or may not be included with your Air Conditioner. They have been made available only as an accessory to help you install the Air Conditioner where special circumstances may require them. If one of these accessory kits has been installed with your Air Conditioner and repair parts are required at some later date, you may select the correct part number from this listing.

1	485678	Kit, Outside Sill (For Additional Support)
2	488750	Bolt 1/4-20 x 3/4 (6)
3	120393	Washer, Flat (6)
4	645515	Bracket, Sill (2)
5	485466	Bracket, Rail (2)
6	486009	Washer, Lock (6)
7	487541	Nut 1/4-20 (6)
10	994818	Kit, Standard Installation
12	47435	Screw, Wood
13	965173	Screw, Sheet Metal (8)
14		Bracket, Mounting
	645562	(Right Side)
	645563	(Left Side)
15	646988	Angle, Side (2)
16	855265	Seal, Strip
17	644228	Bracket, Window Lock
18	876826	Board, Filler
19	855841	Seal, Meeting Rail
21	995274	Spacer, Block

LITERATURE PARTS

LIT485706	Instructions, Installation (Outside Sill Kit)
LIT1155124	Instructions, Installation (Standard Mounting Kit)