


Model: MC-4620

## BODY ASSEMBLY




Index	Part #	Description
1	P-11325	Buckle
2	P-11326	Suction Inlet
2a	P-11327	Valve Gromet
3	P-11352	Dust Compartment Assy
4	P-11289	Pre-Filter
5	P-11290	Filter Unit
6	P-11328	Cloth Bag
7	P-11329	Filter Holder
8	P-11330	Body Right
9	P-11291	Protector Filter
10	P-11331	Blower Outlet Unit
11	P-11332	Motor Support Rubber Front
12	P-11353	Motor Unit
13	P-111265	Noise Suppressor Unit
14	P-11333	Motor Support Rubber Rear
15	P-11297	Switch
16	P-11334	Thermo Protector
17	P-11335	Fuse Unit - 10A
(17)	P-11336	Fuse Unit - 15A
19	P-11337	Bottom Indicator Plate
20	P-11338	Indicator Unit
20a	P-11291	Protector Filter
21	P-11339	Front Cover
22	P-11340	Suction Inlet Packing
23	P-11292	Filter
24	P-11341	Filter Supporter
25	P-11342	Body Partition Unit
26	P-11343	Brake Lever Unit
27	P-11344	Body Left
28	P-11314	Wheel
29	P-11287	Contact Spring Base Unit - No Fuse
(29)	P-11345	Contact Spring Base Unit - 10A
(29)	P-11346	Contact Spring Base Unit - 15A
30	P-11347	Cord Reel Unit - C2
31	P-111276	Caster Unit
32	P-11288	Power Cord with Plug - C2



Model: MC-4620

## ATTACHMENTS



Index	Part #	Description
1	P-916	Hose Assembly
2	P-11348	Hose Unit
3	P-11296	Curved Wand - Antistatic
(3)	P-11349	Curved Wand
4	P-547	Suction Regulator
5	P-24001	Hose Supporter
6	P-020	Connection Pipe
7	P-11323	Floor Nozzle Assy
(7)	P-11324	Floor Nozzle Assy - 2 pedals
8	P-60010	Crevice Tool
9	P-10504	Dusting Brush
10	P-40120	Extension Wand - Plastic
(10)	P-11350	Extension Wand - Metal

## SCREW LIST

Index	Part #	Description
A	P-111240	Tapping Screw - For Body
(A)	P-111240	Tapping Screw - For Front Cover
(A)	P-111240	Tapping Screw - For Bottom Indicator Plate
B	P-11354	Tapping Screw - For Suction Inlet
C	P-11355	Tapping Screw - For Filter Unit
D	P-11356	Tapping Screw - For Brake Lever Unit
E	P-10500	Tapping Screw - For Cord Reel
F	P-11357	Tapping Screw