

BISSELL Original & Replacement

LITTLE GREEN CLEAN MACHINE Model 1650, 1653

| KEY | PART NO. | DESCRIPTION |
|-----|------------|--|
| 1 | B-803-8844 | Switch |
| 2 | NLA | Cover, Grip Ass'y |
| 3 | NLA | Bottle |
| 4 | NLA | Bottle Insert Ass'y Without Plunger |
| 4 | NLA | Bottle Insert Ass'y With Plunger |
| 5 | NLA | Connector, Bottle |
| 6 | B-010-9452 | Tube (Bottle to Pump) |
| 7 | NLA | Connector, Pump |
| 8 | NLA | Pump Ass'y |
| 9 | B-880-7054 | Screws, Pump |
| 10 | NLA | Rectifier (Order B-803-9166) |
| 11 | NLA | Wires (Order B-803-9166) |
| 12 | NLA | Transformer |
| 13 | B-880-7031 | Screws, Transformer |
| 14 | NLA | Motor, Vac Scroll Ass'y |
| 15 | B-880-7038 | Screws, Vac Motor |
| 16 | B-803-7391 | Collar Ass'y, Vac Hose |
| 17 | B-880-7037 | Screws, Collar |
| 18 | NLA | Flexible Hose Without Solution Tube |
| 19 | B-010-4703 | Hose Guard |
| 20 | NLA | Tube (Grip to Pump) |
| 21 | NLA | Window Ass'y, Spray Grip (Order B-803-4929) |
| 22 | NLA | Cover, Spray Grip (Order B-803-4929) |
| 23 | B-880-7031 | Screws, Spray Grip |
| 24 | NLA | Brush Strip |
| 25 | B-803-8458 | Valve Ass'y |
| 26 | NLA | Spring, Trigger Leaf (Order B-803-4929) |
| 27 | NLA | Button, Trigger |
| 28 | NLA | Tip, Spray |
| 29 | B-803-2472 | Lock, Hose |
| 30 | NLA | Tube, Long (for Handle) |
| 31 | NLA | Tube, Short (for Handle) |
| 32 | B-803-2605 | Connector, Barbed |
| 33 | NLA | Sponge, Anti-Splash |
| 34 | NLA | Tank, Recovery |
| 35 | B-803-4803 | Housing, Base |
| 36 | B-880-7031 | Screws, Housing |
| 37 | B-803-3302 | Housing, Side |
| 38 | NLA | Cord 3 Wire Power |
| 39 | B-010-1271 | Cord Restraint |
| 40 | B-010-2652 | Wire Nut |
| 41 | B-010-1511 | Cable Tie |
| 42 | B-803-4929 | Upholstery Tool Ass'y |

NLA = No Longer Available

