






91 Wand Cap

90 Wand Assy

110 Instruction Pack



Zorb 103

Carpet Cleaning Kit 98

Zorb Groomer 104

Dyzolv 102

Mini Turbine Head Assy 96

Low Reach Floor Tool Assy 97

Hose Assy 92

Brush Tool 95

Stair Tool 94

Crevice Tool 93

1	DY-91227601	CLEANER HEAD ASSEMBLY
2	DY-91128801	CLEANERHEAD WIRING COVER
3	DY-91127901	BRUSH HOUSING
4	DY-91127101	BUMPER STRIP
5	DY-91227801	SOLEPLATE ASSEMBLY
6	DY-90456201	SOLEPLATE WHEEL (2) (SHARED DC07, 14)
7	DY-90013102	AXLE (2) (SHARED DC07, 14,15)
8	DY-90013024	SOLEPLATE FASTENER (3)
9	DY-91240201	FLICKER STRIP
10	DYR-1075	BELT
11	DYR-2010	BRUSHROLL
11	DY-91196101	BRUSH BAR ASSEMBLY
12	DY-91184301	SPRING (2) (BRUSH HOUSING)
13	DY-91160301	BRUSHBAR MOTOR ASSEMBLY
14	DY-91128001	BRUSH BAR MOTOR COVER
15	DY-91128901	CLEANER HEAD WIRING GROMMET
16	DY-91129701	UPRIGHT LOCK
17	DY-91990007	SPRING (UPRIGHT LOCK)
18	DY-90176904	BEARING CLIP (2) (SHARED WITH DC04 / DC07 / DC14)
19	DY-91172101	ROPE SEAL
20	DY-91160601	INTERNAL HOSE ASSEMBLY (INTERNAL HOSE ASSEMBLY TO INCLUDE CUFF)
21	DY-90171613	CLEANERHEAD PIVOT CIRCLIP (SHARED WITH DC14)
22	DY-91070205	SCREW (9)(CLEANERHEAD / BRUSH HOUSING / LMC)
23	DY-91123701	MOTOR MOUNT
24	DY-91160401	PANASONIC ES2 UDS1451VNR 120V MOTOR
25	DY-91159701	FANCASE SEAL
26	DY-91128201	MOTOR BUCKET
27	DY-90004917	GLAMOUR CAP (2)
28	DY-90419312	WHEEL (2)
29	DY-91129901	LMC
30	DY-90027902	AXLE (WHEEL SHARED WITH DC07, 14)
31	DYR-1807	HEPA POST FILTER
32	DY-91123901	MOTOR BUCKET MOUNT (3)
33	DY-91070210	SCREW (PHILIPS - POST FILTER LID)
34	DY-90430301	REAR WHEEL FASTENER RETAINING PACK (SHARED WITH DC07, 14)
35	DY-91146301	UPRIGHT MICROSWITCH
41	DY-91130501	BRUSH BAR ACTUATOR
42	DY-91196401	RESET SWITCH (TCO)
43	DY-91149001	RESET SWITCH LOOM
44	DY-90019921	SPRING
45	DY-91097101	SWITCH (2)
46	DY-91174601	BRUSHBAR RESET ARM
47	DY-91130201	ON/OFF SWITCH BUTTON
48	DY-91130001	SWITCH COVER
49	DY-91130401	CYCLONE RELEASE CATCH
50	DY-91187801	SPRING (CYCLONE RELEASE CATCH)
51	DY-91173001	EXHAUST SEAL
52	DY-91234402	DUCT ASSEMBLY
53	DY-91990006	SPRING (WAND RELEASE CATCH)
54	DY-91104201	WAND RELEASE CATCH
55	DY-91070303	SCREW (4) (10mm SHORT T15 SWITCH)
56	DY-90338201	CABLE PROTECTOR (SHARED WITH DC07)
57	DY-91148901	INTERNAL POWERCORD
58	DY-91150801	INSULATOR BOOT
59	DY-91130601	LOWER CABLE WINDER
60	DY-91236101	VALVE PIPE ASSEMBLY
61	DY-91157401	VALVE PIPE CONNECTOR
62	DY-91157501	DUCT VALVE SEAL
63	DY-91227501	PREFILTER LID ASSEMBLY
64	DYR-1804	PRE-FILTER ASSEMBLY

65	DY-91189501	U-BEND ASSEMBLY
66	DY-91124001	POST FILTER LID
67	FA-3035	POWERCORD
68	DY-91130101	INLET SEAL
69	DY-90776404	CREVICE TOOL CLIP
70	DY-90411108	TOOL CLIP (STAIR TOOL CLIP)
71	DY-91130801	BRUSH TOOL CLIP
72	DY-91123801	PRE-FILTER INLET SEAL
75	DY-91192201	CYCLONE ASSEMBLY
76	DY-91133101	FRONT BIN CATCH
77	DY-90019921	SPRING (FRONT BIN CATCH SPRING)
78	DY-91132801	BIN SEAL
79	DY-91229901	FDC SEAL
80	DY-91192001	BIN ASSEMBLY
81	DY-91192101	BIN BASE ASSEMBLY (INCLUDES IDC SEALS)
90	DY-91164701	WAND ASSEMBLY
91	DY-91113101	WAND CAP
92	DY-91164502	HOSE ASSEMBLY (INC LEAFLET FROM GRAPHICS - SERVICE ASSEMBLY)
93	DY-90776302	CREVICE TOOL
94	DY-91105201	STAIR TOOL
95	DY-91132201	BRUSH TOOL
96	DY-90704918	MINI TURBINE HEAD ASSEMBLY
97	DY-90413639	LOWER REACH FLOOR TOOL ASSEMBLY
98	DY-90497503	CARPET CLEANING KIT
102	DY-90388804	DYZOLV
103	DY-90391407	ZORB
104	DY-90226102	ZORB GROOMER
110	DY-91240001	INSTRUCTION PACK