


This Owner's Manual is provided and hosted by [Appliance Factory Parts](http://www.ApplianceFactoryParts.com).



GE ZX2NY2SS Owner's Manual


[Shop genuine replacement parts for GE ZX2NY2SS](#)



[Find Your GE Grill Parts - Select From 85 Models](#)

----- Manual continues below -----

ZX2 NY2SS » BURNER



(ART NO. WB11771) C6

ZX2NY2SS » BURNER

#	Part Number	Description	Qty
1	WB49X5591	TOP GRATE	1
2	WB02X10463	FLARE T	1
8	WB32X10005	AREATION PAN	1
9	WB07X10105	BURNER COVER	1
10	WB02X8600	VENTURI GASKET	2
18	WB28X10006	HEX BURNER	2
20	WB38X10006	VENTURI LONG	1
21	WB07X7391	BEZEL BLACK	1
23	WB02X10378	FLARED ADAPTER	1
24	WB21X10010	REGULATOR-N.G.	1
28	WB02X10461	MANIFOLD	1
29	WB01X10070	CLIP LOGO	1
29	WB02X10353	MONOGRAM LOGO	1
36	WB36X10024	SIDE PANEL L/H	1
36	WB36X10025	SIDE PANEL R/H	1
37	WB02X10465	SUPPORT BKTS R/H	1
37	WB02X10466	SUPPORT BKTS L/H	1
39	WB02X10462	ELECTRODE ASM	1
44	WB15X10015	DRIP PAN HANDLE	1
48	WB15X10062	COVER HANDLE	1
50	WB03X10191	KNOB ROTARY IGNITOR	1
60	WB21X10015	SMOKER VALVE	1
68	WB38X10007	VENTURI SHORT	1
157	WB02X10947	ROTARY IGNITOR	1
158	WB01X10217	SCREW	2
165	WB03X10015	GRILL KNOB	1
300	WB07X10107	LANDING LEDGE	1
301	WB07X10106	VALVE PANEL	1
317	WB32X10006	DRIP PAN	1
999	49-8842	USE AND CARE	1
3068	WB02X11107	BURNER HANGER	1