


Honeywell

PLUG & CLEAN

AIR CLEANER WITH NIGHT-LIGHT

MODEL 16180 SERIES

OWNER'S GUIDE



M20197



69-3011

Important Safety Instructions

***PLEASE READ THESE SAFETY INSTRUCTIONS BEFORE USING THIS AIR CLEANER.
SAVE THESE INSTRUCTIONS FOR FUTURE REFERENCE.***


***WHEN USING ELECTRICAL APPLIANCES, BASIC PRECAUTIONS SHOULD ALWAYS BE FOLLOWED TO
REDUCE THE RISK OF FIRE, ELECTRIC SHOCK, AND INJURY TO PERSONS, INCLUDING THE FOLLOWING:***

1. Read all instructions before operating the air cleaner.
2. Place air cleaner in a suitable outlet where it can not easily be damaged by persons or objects.
3. Always turn the air cleaner to the **OFF** position and unplug from the wall outlet when not in use.
4. To disconnect the air cleaner, first turn control to the **OFF** position, grip the air cleaner and pull it from the wall outlet.
5. Do not use any product with a damaged plug or if product malfunctions, is dropped or damaged in any manner.
6. Do not use air cleaner outdoors.
7. Never use air cleaner unless it is fully assembled.
8. Do not use air cleaner where combustible gases or vapors are present.
9. Do not expose the air cleaner to rain, or use near water, in a bathroom, laundry area or other damp location.
10. The air cleaner must be used in its upright position.
11. Do not allow foreign objects to enter ventilation or exhaust opening as this may cause electric shock or damage to the air cleaner. Do not block air outlets or intakes.
12. A loose fit between the AC outlet (receptacle) and plug may cause overheating and a distortion of the plug. Contact a qualified electrician to replace loose or worn outlet.
13. Disconnect power supply before servicing.

WARNING: To Reduce The Risk of Fire or Electric Shock, Do Not Use This Air Cleaner With Any Solid-State Speed Control Device.

Parts


Fig. 1



1. FRONT GRILLE
2. AIR INTAKE
3. FILTER
4. NIGHT LIGHT
5. FILTER REPLACEMENT CALENDAR
6. ON/OFF SWITCH
7. AIR DISCHARGE ROTATING PLUG (See Fig 3.)

Using your air cleaner

Fig. 2



1. Unplug the air cleaner and open the front cover of the air cleaner.
2. Remove the filter from the plastic wrap and place the filter into the air cleaner.
3. Close the cover of the air cleaner.
4. Move the filter replacement calendar forward three months.
5. Plug the air cleaner into the electrical outlet as shown in Fig. 2.

Note: Electrical outlets in older homes may not hold the air cleaner securely. If the air cleaner seems loose in the outlet, please contact a qualified electrician to replace the obsolete outlet.

6. Switch the air cleaner on.
The air cleaner is most effective when you locate it closest to the odor. However, the air cleaner may not eliminate strong odors.

Note: Do not block the air discharge area as shown in Fig. 1.


Replacing the filter

The air cleaner is most effective when the filter is replaced every three months.

1. Switch the air cleaner off and unplug it from the outlet.
2. Gently lift the front grille cover off the main body of the air cleaner.
3. Remove the old filter and replace it with a new filter.
4. Snap the front grille cover back onto the main body of the air cleaner.
5. Move the calendar forward three months each time you replace the filter.
6. Plug the unit into a suitable outlet and switch it on.

Rotating the plug

Fig. 3



1. Use a small Phillips head screwdriver to remove the screw on the back of the air cleaner.
2. Rotate the plug 90 degrees counter-clockwise as shown in Fig 3.
3. Replace the screw and tighten it using the screw driver.

Cleaning the air cleaner

1. Unplug the air cleaner before cleaning.
Note: This air cleaner does not disassemble.
2. Wipe the surface using a soft, damp cloth.
Important: Do not immerse the air cleaner in water. Do not use gasoline, paint thinner or other chemicals to clean the air cleaner. Store your air cleaner in a clean, dry place.

1-Year Limited Warranty

Honeywell Plug & Clean

Model 16180 Series

This product has been engineered and crafted with great care for your satisfaction.

A. This limited warranty applies to repair or replacement of product found to be defective in material or workmanship within 1 year of the date of purchase. This warranty does not apply to damage resulting from commercial, abusive, unreasonable use or supplemental damage. Defects that are the result of normal wear and tear will not be considered manufacturing defects under this warranty.

HONEYWELL IS NOT LIABLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES OF ANY NATURE. ANY IMPLIED WARRANTY, INCLUDING MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, ON THIS PRODUCT IS LIMITED IN DURATION TO THE DURATION OF THIS LIMITED WARRANTY. Some regions do not allow the exclusion or limitation of incidental or consequential damages or limitations on how long an implied warranty lasts, so the above limitations or exclusions may not apply to you. This warranty gives you specific legal rights, and you also may have other rights which vary from region to region. This warranty applies only to the original Purchaser of this product.

B. At its option, Honeywell will repair or replace this product if it is found to be defective in material or workmanship within the limited warranty period. Defective product should be returned to the place of purchase in accordance with store policy or to Honeywell.

C. The warranty does not cover damage resulting from unauthorized attempts to repair or from any use not in accordance with this manual.

D. This warranty does not cover the filter except for material or workmanship defects.

E. Return defective product to the following address with a brief description of the problem. Include proof-of-purchase and a U.S. \$5.00/ Canadian \$7.00 check or money order for handling, return packing and shipping charges. Please include your name, address and daytime phone number. You must prepay shipping charges. Mark carton "Attention Returns Department"

Ship to:

In USA:

Honeywell Returns Department
4755 Southpoint Drive
Memphis, TN 38118 U.S.A.

In Canada:

Honeywell
510 Bronte St. South
Milton, Ontario Canada L9T 2X6

If you experience a problem with your Air Cleaner, please see owner's guide for instructions. Please do not attempt to repair the air cleaner yourself. Doing so may void the warranty and could cause damage or personal injury. If the problem still persists, please call:

Honeywell Consumer Relations Dept.
service@honeywell.com
Toll Free 1-800-332-1110.

Mail Questions or Comments to:
Honeywell Consumer Relations Dept.
250 Turnpike Road
Southborough, MA 01772 U.S.A.

Honeywell

Home and Building Control

Honeywell
1985 Douglas Drive North
Golden Valley, MN 55422

Home and Building Control

Honeywell Limited-Honeywell Limitée
35 Dynamic Drive
Scarborough, Ontario
M1V 4Z9