

1 Remove end of rating label located on your grill's back panel (see parts list to identify) and apply to your warranty card in box #5. If label cannot be removed, write the numbers on your warranty card.

OUTDOOR GAS GRILL
 Model Number: 3000000000
 Serial Number: 0000000000

NEVER STORE A SPARE PART NEAR THIS BACK PANEL. NEVER FILL THE TANK WITH GAS. NEVER USE THE GRILL IF YOU SUSPECT A LEAK OR IF YOU SMELL GAS. NEVER USE THE GRILL IF YOU SMELL GAS. NEVER USE THE GRILL IF YOU SMELL GAS.

NE JAMAIS ranger u propane sans le grill c NE JAMAIS ranger la causeur des blessures

This label contains the model and serial number for your grill. You should also write this information on page 2 of your Use and Care Manual in the "Warranty Information" box.

2 Undo legs to position shown, laying grill **ON ITS BACK**. **UNDER** control panel, **BACK** lower control panel on legs, aligning panel holes with leg holes.

3 Attach panel and brace with four bolts and nuts. **BRACE ATTACHES TO RIGHT SIDE.** Do not fully tighten lower nuts.

4 Place containment basket over lower panel bolts, slide into place (see inset). Fully tighten lower nuts.

NOTE: To prevent scratching, lay grill on packing material to assemble.

3 Stand grill upside down and, facing back of grill, attach back panel using four bolts and nuts.

4 Facing back of grill, depress wheel assembly into right legs and attach to all legs. **WORKING WITH NOTCHES IN LEGS.**

4 Position tank, with wire ends, back of left leg, and ends of wire angled upward. Insert ends of wire into holes on inside of left leg and rotate wire downward.

Tank wire correctly installed

Side view

Wire angled upward

Wire angled upward

5 Place 45 briquets into back of grill. Arrange briquets as shown below.

Position Trip Vaporiser Bar as shown supports at each end of grill bottom.

Do not let briquets cover burner port holes.

Briquet Placement

FRONT BACK

BACK FRONT

6 You may have:

- Hinge pin only OR hinge pin
- Spacer
- Washer
- Handle may be press-fitted

1 Place lid onto grill bottom. Attach with two hinge pins.

2 Place bolts through handle, spacers and fiber washers. Attach with two wing nuts.

3 Be sure clips are attached to top plate costs. Strap logo plate into grill lid.

7 Insert pivot wire of lower SwingAway into lid as shown. Flex leg wires to insert into grill bottom (see inset A).

Insert pivot wire of upper SwingAway into lid. Flex leg wires to insert into loops of lower SwingAway (see inset B).

Place cooking grate into grill bottom.

Back of SwingAways pointing forward.

Pivot wire

Leg wires

8 Install side shelves by sliding shelf tubes over ends of leg tubes. Press firmly so that holes are aligned. Secure with four push-fasteners.

9 LP GAS TANK IS SUPPLIED EMPTY. Fill and leak-check tank before attaching to grill and regulator. See Use & Care Manual.

Center base of tank in notches between wheels. Strap tank over collar. Center section of tank wire should be inside of tank collar.

Regulator

Leak-check port

Swarm for clarity

Shap wire over collar

CAUTION

- Tank collar opening must face to front of cart once tank is attached.
- Failure to install tank correctly may allow gas to leak to be ignited, resulting in the risk of fire.

Step 10 on reverse side.

10 See Use & Care Manual to perform "Burner Flame Check" and for important safety instructions before using.