


This Owner's Manual is provided and hosted by [Appliance Factory Parts](http://Appliance Factory Parts).



# COMFORT-AIRE CD-121 Owner's Manual

[Shop genuine replacement parts for COMFORT-AIRE  
CD-121](#)



[Find Your COMFORT-AIRE Air Conditioner Parts - Select From 599 Models](#)

----- Manual continues below -----

HEAT CONTROLLER, INC.

REPLACEMENT  
PARTS


**Room Air Conditioner**

**CD-101-5**

**CD-121**

**Casement-Slider Type**

# Exploded View



Replacement Parts List			
Location	Part No.	CD-101-5	
		DESCRIPTION	
130410	3041A20033N	BASE ASSY, SINGLE	
130910	3091A20014B	CABINET ASSY ,SINGLE	
135314	3530A20056A	GRILL INLET	
135312	3531A20123A	GRILL ASSY ,FRONT	
147581	4758A20032A	LOUVER HORIZONTAL	
147582-1	4758A20017A	LOUVER VERTICAL	
147582-2	4758A20017B	LOUVER VERTICAL	
148000	4800A20001A	BRACE	
149980	4999A20002A	SHROUD	
159830	5231A20012A	FILTER ASSY A/C	
249950	MBN32756804	CONTROL BOX, ASSY	
264110	6411A20056V	POWER CORD ASSY	
267110	6711A20093A	REMOTE CONTROLLER ASSEMBLY	
567480	6323A20004S	THERMISTOR ASSEMBLY	
346811	4681A20069C	MOTOR ASSY,SINGLE	
349001	4900A20006A	DAMPER	
349480	4948A20012A	ORIFICE	
349600	4960A20034A	MOUNT,MOTOR	
352113	5211A20558F	TUBE ASSEMBLY,DISCHARGER SINGLE	
352115	5211A20575C	TUBE ASSEMBLY,EVAPORATOR	
35211A	5211A20579F	TUBE ASSEMBLY,SUCTION	
352380	AEC31876001	AIR GUIDE-LOWER ASSEMBLY	
352390	5239A20007A	AIR GUIDE-ASSY-UPPER	
354210	5421A20115D	EVAPORATOR ASSEMBLY	
559011	5900A20026A	FAN ASSEMBLY,AXIAL	
359012	5900A20019A	FAN,TURBO	
550140	4830AR4335A	ISOLATOR,COMP	
352111	5211A20557P	TUBE ASSEMBLY, CONNECTOR	
554030	5403A20082B	CONDENSER ASSEMBLY,FIRST	
554160	TBZ30744301	COMPRESSOR	
567502	6750U-L031A	O.L.P	
W0CZZ	0CZZA20001N	CAPACITOR ,DRAWING	
W48602	3H02932B	CLAMP,SPRING	
137215	4994A20048C	CASE CONTROL	
268711-2	EBR30851803	PWB(PCB) ASSEMBLY,MAIN	
268711-1	EbR30852601	PWB(PCB) ASSEMBLY,MAIN (DISPLY)	
238310	3831A20087A	ESCUTCHEON	

Replacement Parts List			
Location	Part No.	CD-121	
		DESCRIPTION	
130410	3041A20033N	BASE ASSY, SINGLE	
130910	3091A20014B	CABINET ASSY ,SINGLE	
135314	3530A20056A	GRILL INLET	
135312	3531A20123A	GRILL ASSY ,FRONT	
147581	4758A20032A	LOUVER HORIZONTAL	
147582-1	4758A20017A	LOUVER VERTICAL	
147582-2	4758A20017B	LOUVER VERTICAL	
148000	4800A20001A	BRACE	
149980	4999A20002A	SHROUD	
159830	5231A20012A	FILTER ASSY A/C	
249950	MBN32756805	CONTROL BOX, ASSY	
264110	6411A20056W	POWER CORD ASSY	
267110	6711A20093A	REMOTE CONTROLLER ASSEMBLY	
567480	6323A20004S	THERMISTOR ASSEMBLY	
346811	4681A20069C	MOTOR ASSY,SINGLE	
349001	4900A20006A	DAMPER	
349480	4948A20012A	ORIFICE	
349600	4960A20034A	MOUNT,MOTOR	
352113	5211A20558F	TUBE ASSEMBLY,DISCHARGER SINGLE	
352115-1	5211A20559R	TUBE ASSEMBLY,EVAPORATOR	
352115-2	5211A20559M	TUBE ASSEMBLY,EVAPORATOR	
35211A	5211A20579G	TUBE ASSEMBLY,SUCTION	
352380	AEC31876001	AIR GUIDE-LOWER ASSEMBLY	
352390	5239A20007A	AIR GUIDE-ASSY-UPPER	
354210	5421A20115D	EVAPORATOR ASSEMBLY	
559011	5900A20026A	FAN ASSEMBLY,AXIAL	
359012	5900A20019A	FAN,TURBO	
550140	4830AR4335A	ISOLATOR,COMP	
352111	5211A20557M	TUBE ASSEMBLY, CONNECTOR	
554030	5403A20082A	CONDENSER ASSY	
554160	2520UCBK024	COMPRESSOR	
567502	6750UL029A	O.L.P	
W0CZZ	0CZZA20001N	CAPACITOR ,DRAWING	
W48602	3H02932B	CLAMP,SPRING	
137215	4994A20048C	CASE CONTROL	
268711-2	EBR30851803	PWB(PCB) ASSEMBLY,MAIN	
268711-1	EBR30852601	PWB(PCB) ASSEMBLY,MAIN (DISPLY)	
238310	3831A20087A	ESCUTCHEON	

**Design, material, performance data and components  
subject to change without notice.**

## **HEAT CONTROLLER, INC.**

1900 Wellworth Ave., Jackson, Michigan 49203 • Ph. 517-787-2100 • Fax 517-787-9341

**THE QUALITY LEADER IN CONDITIONING AIR**

**[www.heatcontroller.com](http://www.heatcontroller.com)**