

RG-51-5 Replacement Parts List

LOCATION NO.	DESCRIPTION	PART NO.	REMARK
130410	BASE ASSEMBLY, SINGLE	3041A10040P	
130910	CABINET ASSEMBLY, SINGLE	3091A10055A	
135312	GRILLE ASSEMBLY, FRONT(SINGLE)	3531A10243C	
137215	PANEL,CONTROL	3720A30090A	
148000	BRACE	4800A30012A	
149410	KNOB ASSEMBLY	4941A20003A	
149980	SHROUD	4998A10028B	
152302	FILTER(MECH), A/C	5231A20029B	
159900-1	VANE, VERTICAL	4758A30041A	
159900-2	VANE, VERTICAL	4758A30041B	
249950	CONTROL BOX ASSEMBLY	4995A20343F	
264110	POWER CODE ASSEMBLY	6411A20056A	
266002-1	SWITCH, ROCKER	2H01316H	
266002-2	SWITCH, ROCKER	2H01316J	
269310	THERMOSTAT ASSEMBLY	2H01109X	
346811	MOTOR ASSEMBLY, SINGLE	4681A20116C	
349480	ORIFICE	4948A20031B	
352113	TUBE ASSEMBLY, DISCHARGE	5211A21305A	
352115	TUBE ASSEMBLY, EVAPORATOR IN	5211A25019B	
35211A	TUBE ASSEMBLY, SUCTION SINGLE	5211A21228B	
352380-1	AIR GUIDE	5238A10026A	
352380-2	AIR GUIDE	5238A10025A	
352410	EVAPORATOR ASSEMBLY, FIRST	5421A20176B	
359012	FAN TURBO	5900A20040A	
550140	ISOLATOR, COMPRESSOR	5040AR4195A	
554030	CONDESER ASSEMBLY, FIRST	5403A20174A	
554160	COMPRESSOR	2520UCAA011	
559010	FAN, AXIAL	5900A20042A	
567502	O.L.P	6750U-L050A	
W0CZZ	CAPACITOR, DRAWING	0CZZA20005B	
W48602	CLAMP, SPRING	3H02932B	

Exploded View

