

# COOL MIST EVAPORATIVE HUMIDIFIER



Model: WA-8D

4. Make sure the wick filter is properly positioned in the appliance before use.
5. Always unplug the appliance before removing or replacing the water tank.
6. Remove water tank from the base.
7. Open the water tank cap and fill the water tank with cool, distilled or filtered tap water.
8. Replace the tank cap tightly.
9. Return tank securely to base.
10. Plug the power cord into a 110V/120V AC wall outlet.
11. Rotate the ON / OFF switch on top of the appliance to start the operation.
12. Green LED light indicates that the appliance is turned ON.
13. Rotate the output control to "Low" or "Hi" position for the desired moisture output.

#### Humidity Level Control

A humidistat controls the desired amount of relative humidity (moisture to air). The output control knob is factory preset in the MAX position. Rotate the control knob to select desired humidity level (from 35%-55%). Optimal relative humidity for room comfort is between 40% and 50%. The appliance will cycle on and off automatically to maintain selected humidity level.

#### IMPORTANT

Please note: If the switch is rotated to "Low" or "Hi" position and the appliance does not RUN. Please check the Humidity Level Control setting. If the knob is set to a lower humidity level (30% for example) the unit will not run until the humidity in the room drops below 30%.

#### READ AND SAVE THESE INSTRUCTIONS

When using this electrical appliance, basic safety precautions should always be followed. Failure to follow the important safety and operating instructions in this manual may result in risk of electric shock or fire.

1. Always fill the water tank before operating the appliance.  
Use clean, distilled or filtered tap water only. Use of unfiltered tap water may result in the need for more frequent cleanings due to its high mineral content.
2. Make sure the filling cap of the water tank is firmly tightened before using the appliance.
3. Position the appliance in the room away from children, walls and wood furniture.
4. When removing the water tank, use one hand to hold the Handle and the other hand to hold the bottom of the tank.
5. DO NOT place the appliance near heating source. Keep the power cord away from heated surfaces.
6. Use only 110-120V AC outlet. Be sure the appliance is unplugged after use.
7. Plug and unplug the appliance with dry hands only.
8. Turn the humidifier off and unplug the appliance when it is not in use, or for cleaning.
9. To avoid the risk of fire, shock or personal injury, do not use an extended power cord.
10. **WARNING:** Never operate the appliance with a damaged power cord or plug.
11. Always place the appliance on a flat level surface.
12. Place the appliance AWAY from direct sunlight, computers or other electronic equipment.
13. Do not cover or place anything over the openings of the appliance.
14. Regular cleaning of the appliance is required. (Please refer to the CLEANING section in this manual)

#### CARE AND MAINTENANCE IMPORTANT

1. Clean your humidifier regularly (every 2 weeks) which helps eliminate odors and may prevent bacteria growth.
2. Depending on mineral content of the water and frequency of use, the wick filter will become loaded with mineral deposits.
3. When the filter appears clogged, replace it with a new wick filter to restore your humidifier's efficiency.

**Caution:** Disconnect the power cord before cleaning.

1. Turn OFF and unplug the humidifier.
2. Remove the Upper Housing and carefully remove the wick filter from the base.
3. Clean wick filter by fully submerging it in a vinegar/water solution.
4. Pour all water from the tank. Wipe all surfaces of the Water Tank with a clean cloth or sponge moistened with water or a solution of half water and half vinegar.
5. Rinse the Water Tank thoroughly with clean water.
6. DO NOT USE WATER TO CLEAN THE UPPER HOUSING.. AN ELECTRIC SHOCK MAY RESULT OR THE HUMIDIFIER MAY BE DAMAGED. Clean the grill vents with a soft, dry cloth if they show accumulated dust.
7. Re-install the wick filter into the unit base and replace the upper housing onto the base. Take care to properly align the upper housing to the base for proper fit.

#### Wick filter cleaning instructions:

1. Clean the wick filter every week to extend usage.
2. The Wick Filter should be cleaned as follows:

15. **DANGER:** To guard against electrical shock. NEVER immerse the humidifier motor unit into water or other liquids.
16. Indoor use only.
17. Turn the humidifier OFF if the relative humidity exceeds 60%. For proper humidity reading, please refer to the hygrometer, which is available in the appliance.
18. Do not place the humidifier directly on wood furniture or other surfaces that can be damaged by water.
19. To reduce the risk of electrical shock. Do not attempt to disassemble the appliance.

#### FOR HOUSEHOLD USE ONLY

To reduce the risk of electrical shock, this appliance has a polarized plug (one blade is wider than the other). As safety feature, this type of plug will fit into the outlet only in one way. If the plug does not fit fully into the outlet, try reversing the plug and then plug it in again. If it still does not fit, contact a qualified electrician. Do not attempt to defeat this safety feature.

#### HOW TO USE THE HUMIDIFIER

1. Clean the humidifier base and water tank before the first use. (See cleaning section of this manual)
2. Place the appliance on a stable surface. Do not place the appliance on a soft, unstable carpet or towel
3. The humidifier should be placed at least four ( 4 ) inches away from all walls and any heat sources.
3. Clean using 80 ounces of vinegar mixed with 2 gallons of water and immerse for 15 ~ 20 minutes.
4. All the components must be completely dry before storage.