

This Owner's Manual is provided and hosted by [Appliance Factory Parts](#).



# LG HMH009VB Owner's Manual

[Shop genuine replacement parts for LG HMH009VB](#)




[Find Your LG Air Conditioner Parts - Select From 2328 Models](#)

----- Manual continues below -----

# Wiring Diagram


## (1) 7K, 8K, 9K Btu Cooling Only

### ① Indoor Unit




Indoor unit	Model	Outdoor unit
①	LS-J0761CL/DL LS-J0821CL LS-J0822AL LS-J0962CL LS-J0963CL/AL/DL LS-J0763CL LS-J0964CL/GL	②

### ② Outdoor Unit




## (2) 7K, 9K Btu Cooling & Heating

### ① Indoor Unit



Indoor unit	Model	Outdoor unit
①	LS-J0761HL	②
	LS-0762HL/HM/HN	
	LS-J0763EL/HL	
	LS-J0962HL/EL	③
	LS-J0964EL	

### ② Outdoor Unit



### ③ Outdoor Unit

