


This Owner's Manual is provided and hosted by [Appliance Factory Parts](#).



LG HMC024WA Owner's Manual

[Shop genuine replacement parts for LG HMC024WA](#)

1. Indoor Unit




[Find Your LG Air Conditioner Parts - Select From 2328 Models](#)

----- Manual continues below -----


Wiring Diagram

(1) Indoor Unit


1. LS-D1821CL/CM/CD, LS-D1822CL/CM/CD, LS-D1862CL/CM/CD, LS-D1863CL/CM/CD




2. LS-D1862HL/HM/HD, LS-D1863HL/HM/HD



3. LS-D2422CL/CM/CD/HL/HM/HD, LS-D2663CL/CM/CD/HL/HM/HD




4. LS-D2462CL/CM/CD, LS-D2462HL/HM/HD, LS-D2822CL/CM/CD




(2) Outdoor Unit


1. LS-D1821CL/CM/CD, LS-D1822CL/CM/CD, LS-D1862CL/CM/CD, LS-D1863CL/CM/CD




2. LS-D1862HL/HM/HD, LS-D1863HL/HM/HD




3. LS-D2422CL/CM/CD



4. LS-D2462CL/CM/CD, LS-D2663CL/CM/CD



5. LS-D2422HL/HM/HD, LS-D2462HL/HM/HD, LS-D2663HL/HM/HD



6. LS-D2822CL/CM/CD

