

**1** Remove end of rating label located on your grill's rail (see parts list to identify) and apply to your warranty card in box #5. If label cannot be removed, write the numbers on your warranty card.

**OUTDOOR GAS GRILL**  
 Model Number: 0000000000  
 Serial Number: 0000000000

**⚠ DANGER** NEVER Store a spare near this barbecue. NEVER Fill the tank with fire causing death or occur.  
 NE JAMAIS remiser u propane sous le grill. NE JAMAIS remplir la NE JAMAIS remplir la 80%. Un incendie peut causer des blessures

This label contains the model and serial number for your grill. You should also write this information on page 2 of your Use and Care Manual in the "Warranty Information" box.

**2** Hardware is shown full size in steps

Qty. 3  
 Qty. 1  
 Qty. 4  
 Qty. 3  
 Qty. 3  
 One  
 Two  
 One  
 Rail with Labels  
 Slot on Left

**3**

One  
 One  
 One  
 Two  
 Two  
 Make sure end of Tank Bracket is inside Rails  
 Angle into slot

**4**

Qty. 2  
 Qty. 4  
 Repeat on right legs  
 Hub next to Legs  
 Insert (A) into hole closest to leg

**5**

Qty. 2  
 1st  
 2nd  
 Console lower rests on Casting Seat

**6**

Qty. 2  
 Valve openings point toward back of grill

**7**

Back of grill  
 1ST  
 2ND  
 3RD  
 Middle hole  
 Use an empty soup can (not included) to hang from the grease clip.

**⚠ CAUTION**  
 • Failure to install can in clip will cause hot grease to drip from bottom of grill with risk of fire or property damage.

**8**

Place burner tubes into holes  
 Back of grill  
 Do not attach springs yet

**9**

Qty. 1  
 2ND  
 1ST  
 Line up hole to hole and twist  
 6TH  
 Lip must be UNDER edge of burner  
 Back hole  
 3RD  
 Insert ignitor wire into hole in grill bottom  
 4TH  
 5TH  
 Very Important: Springs must be attached correctly for proper grill function

**10**

Maximum load for side shelf is 10 lbs.  
 Repeat for left side  
 Qty. 12  
 Qty. 12

**11**

Qty. 2  
 Qty. 2  
 Qty. 2  
 Qty. 2  
 Qty. 2  
 Do not over tighten nut or bend bracket  
 Turn Clockwise

**12**

Wires must run underneath SwingAway surface  
 SwingAway will keep food warm while keeping it away from flames. Do not use SwingAway for cooking meats or heavy food items.

**13**

When installing ignitor, do not push on button. This may cause a minor shock.  
 Ignitor wire must not come into contact with grill bottom.  
 See Use & Care manual for valve check

**14**

Insert Tank Wire into Left Legs and rotate Inward

**15**

Curved portion of tank wire should be to inside of tank collar.  
 LP TANK IS SOLD SEPARATELY. Before attaching to grill and regulator, fill and "Leak Check" (see Use & Care for Leak Check).  
**⚠ CAUTION**  
 • Tank collar opening must face to front of cart once tank is attached.  
 • Failure to install tank correctly may allow gas hose to be damaged in operation.  
 Location of bottom ring on LP tank  
 Remove packing from around tank  
 Note: LP tank should lean slightly to the left when properly positioned.

**16**

Top two outer holes

See Use & Care Manual for important safety instructions before using.