

This Owner's Manual is provided and hosted by [Appliance Factory Parts](#).



HOLMES hap706 Owner's Manual

[Shop genuine replacement parts for HOLMES hap706](#)



[Find Your HOLMES Air Cleaner Parts - Select From 78 Models](#)

----- Manual continues below -----

TIPS AND TROUBLESHOOTING

NOTE: Filters can be purchased at a retailer near you or by calling 1-800-546-5637.

Air Cleaner Model Number	Filter Quantity Needed	Filter Model Number	Filter Description
HAP706-U	1	HAPF300 D Filter	True HEPA Filter

TIPS AND TROUBLESHOOTING

ISSUE	SOLUTION
UNIT WILL NOT OPERATE	<ul style="list-style-type: none"> • Make sure unit is properly plugged in and outlet is energized. • Make sure unit turned ON.
DECREASED AIR FLOW	<ul style="list-style-type: none"> • Make sure nothing is blocking air inlet and filtered air outlets. • Check condition of the filter and clean/replace if necessary.
EXCESSIVE NOISE	<ul style="list-style-type: none"> • Make sure parts are firmly positioned in place.

LEARNING MORE

For a wealth of information about your air cleaner and other Holmes® products, visit our website at www.holmesproducts.com.

© 2007 Sunbeam Products, Inc. doing business as Jarden Consumer Solutions. All Rights Reserved. Distributed by Products, Inc. doing business as Jarden Consumer Solutions, Boca Raton, FL 33431.

SERVICE & WARRANTY

5 YEAR LIMITED WARRANTY

Sunbeam Products, Inc. doing business as Jarden Consumer Solutions Limited doing business as Jarden Consumer Solutions, Inc. from the date of purchase, this product will be repaired, replaced or replace this product or any component of this product. Replacement will be made with a new or reworked replacement may be made with a similar product. An attempt to repair or adjust any electrical component. This warranty is valid for the original retail purchaser. Keep the original sales receipt. Proof of purchase at the original or retail stores selling JCS products do not have to be provided for this warranty.

This warranty does not cover normal wear and tear, misuse of the product, use on improper voltage, or repair or alteration by anyone other than a qualified technician. Coverage: Acts of God, such as fire, flood, hurricanes, etc.

What are the limits on JCS's Liability?

JCS shall not be liable for any incidental or consequential damages, statutory warranty or condition.

Except to the extent prohibited by applicable law, the warranty for a particular purpose is limited in duration to the duration of the warranty. JCS disclaims all other warranties, conditions, express or implied, including the warranty of merchantability. JCS shall not be liable for any damages of any kind, including incidental, special, consequential, or otherwise, arising from the use of the product, contract, fundamental or otherwise, or from the use of the product. Some provinces, states or jurisdictions do not recognize limitations on how long an implied warranty lasts. This warranty gives you specific legal rights. The law may vary from state to state or jurisdiction to jurisdiction.

How to Obtain Warranty Service

In the U.S.A.

If you have any question regarding this warranty, please call 1-800-546-5637 and a convenient service center address will be provided.

In Canada

If you have any question regarding this warranty, please call 1-800-546-5637 and a convenient service center address will be provided.

In the U.S.A., this warranty is offered by Sunbeam Products, Inc. doing business as Jarden Consumer Solutions, Inc. in Boca Raton, Florida 33431. In Canada, this warranty is offered by Sunbeam Products, Inc. doing business as Jarden Consumer Solutions, Inc. For any other problem or claim in connection with this product, please call 1-800-546-5637.

NOT RETURN THIS PRODUCT TO ANOTHER ADDRESS

9100040003006

IMPORTANT SAFEGUARDS

SAFETY INSTRUCTIONS

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons. These precautions include:


1. Read all instructions before using the appliance.
2. To avoid fire or shock hazard, plug the appliance directly into a 120V AC electrical outlet.
3. If the filter is covered by a bag when shipped, remove plastic bag before use.
4. Keep the cord out of heavy traffic areas. To avoid fire hazard, NEVER put the cord under rugs, near heat registers, radiators, stoves, or heaters.
5. To protect against electrical hazards, DO NOT immerse the appliance in water or other liquids. Do not use near water.
6. Close supervision is necessary when any appliance is used by or near children, or disabled persons.
7. Always unplug the air cleaner before moving or cleaning the unit, opening the grill, changing the filters and whenever the unit is not in use. To disconnect the unit, be sure to pull the plug and not the cord.
8. NEVER drop or insert any objects into the openings of the unit.
9. Do not operate any appliance with a damaged cord or plug. If the motor fan fails to operate or the unit has been dropped or damaged in any manner, return appliance to manufacturer for examination and/or repair.
10. Use appliance only for intended household use as described in this manual. Any other use not recommended by the manufacturer may cause fire, electric shock, or injury to persons. The use of attachments not recommended or sold by Jarden Consumer Solutions may cause hazards.
11. DO NOT use outdoors.
12. NEVER place on a soft surface such as a bed or sofa as this could cause the unit to tip over and block the air inlet or outlet grills.
13. Keep unit away from heated surfaces and open flames.
14. DO NOT attempt to repair or adjust any electrical or mechanical functions on this unit. Doing so will void your warranty. The inside of the unit contains no user serviceable parts. All servicing should be performed by Jarden Consumer Solutions or an authorized Jarden Consumer Solutions Center.
15. DO NOT place anything on top of unit.
16. NEVER use detergents, gasoline, glass cleaner, furniture polish, paint thinner, or other household solvents to clean any part of the appliance.
17. Always turn the appliance off before unplugging it.
18. The ionizer in this appliance produces less ozone than the UL established limits of 50ppb. However, in high concentrations, ozone can be harmful to birds and small pets. To prevent ozone buildup, we suggest using the ionizer in well ventilated areas with the fan on.
19. This appliance should only be used in a room with temperatures between 40° F and 110° F.
20. WARNING: To reduce the risk of fire or electric shock, DO NOT use this appliance with any solid-state speed control device.

PLEASE SAVE THESE IMPORTANT SAFETY INSTRUCTIONS

PLUG SAFETY

CAUTION: To reduce the risk of electric shock, **THIS PRODUCT HAS A POLARIZED PLUG** (one blade is wider than the other).

This plug will fit into a polarized outlet only one way. If the plug does not fit fully into the outlet, reverse the plug. If it still does not fit, contact qualified personnel to install the proper outlet. **DO NOT ALTER THE PLUG IN ANY WAY.**



CORD SAFETY

- The length of cord used on this appliance was selected to reduce tangling or tripping hazards.
- If a longer cord is necessary, an approved extension cord may be used. The electrical rating of the extension cord must be equal to or greater than the electrical rating of the air cleaner (see rating label marked on product).
- Care must be taken to arrange the extension cord so that it will not drape over the countertop or tabletop where it can be pulled on by children or accidentally tripped over.

GET TO KNOW YOUR AIR CLEANER

Your true HEPA air cleaner removes up to 99.97% of airborne allergens as small as 0.3 microns including ragweed pollen, grass pollen, tree pollen, dust mite debris, mold spores, pet dander, and more from the air passing through the filter.

IONIZER

This appliance has an optional ionizer feature. When turned on, releases negative ions into the air to help the air purification process.

What Are Ions?

Ions are tiny particles that carry a positive or negative charge. They exist naturally around us: in the air, in water, and on the ground. Both positive and negative ions are colorless, odorless, and completely harmless.

How Does The Ionizer Work?

Negative ions help air purification by attaching to very small airborne particles in the room. These particles take on a negative charge and may join with other charged particles such as dust, pollen, smoke, and dander to form larger particles. These larger particles are then more easily captured by the filter system.

Important Notes:

Your ionizer may produce an occasional popping or crackling sound. This is normal and occurs when a buildup of ions is discharged.

After extended use, you may notice dust on the front panel. This is caused by negative ions on the air outlet, evidence of the ionizer's air cleaning effectiveness. You can remove the dust with a dry or clean, damp cloth.

Larger particles may be attracted to positive ions on surfaces throughout the home, like walls and ceiling.

- This may occur more frequently when the ionizer is nearing the end of its useful product life cycle to capture as many charged particles.
- Excessive amounts of pet dander, dust, or smoke may decrease the life expectancy of the ionizer or interfere with the ionization process.