

This Owner's Manual is provided and hosted by [Appliance Factory Parts](#).



COMFORT-AIRE BHD-651-D Owner's Manual

[Shop genuine replacement parts for COMFORT-AIRE
BHD-651-D](#)



[Find Your COMFORT-AIRE Dehumidifier Parts - Select From 129 Models](#)

----- Manual continues below -----

HEAT CONTROLLER, INC.

Replacement Parts List



Portable Dehumidifier Models:


BHD-301-E

BHD-501-D

BHD-651-D

Exploded View

• MODEL: BHD-301-E




BHD-301-E Parts List

PART DESCRIPTION	LOCATION NO.	PART NO.
Base Assembly,Single	130410	3041A10042E
Roller	144410	4441A30001B
Shroud	149980	4998A10034B
Switch Assembly	266010	6600A30003C
Pan Assembly,Drain	330870	3087A10019C
Bracket,Motor	349600	4960A20009D
Washer,Customized	550140	1WZZA31003A
Compressor Set,China	554160	TBZ31986001
Overload Protect	567502	EAF35787201
Cabinet	131400	MBH61853106
Grille Assembly,Front	135312	3531A18012R
Tank Assembly,Bucket	148391	4839A10002F
Knob Assembly	149410	4941A30019B
Filter,Air	152302	5230A20040A
Sensor Assembly	165010	6877A30013R
Cover Assembly,Display	235512	3551A20122A
Escutcheon	238310	MDD30271507
Case Assembly,Control	249950	ABQ36532611
Power Cord Assembly	264110	6411A20001Z
Switch,Rocker	266002	6600FX5001G
Switch Assembly	266003	6601A30006A
PCB Assembly,Display	268711-1	6871A20289B
PCB Assembly,Main	268711-2	EBR39204301
Motor Assembly,AC,Indoor	346811	EAU32357505
Tube Assembly,Discharge	352113	AJR71449801
Tube Assembly,Suction	35211A	AJR71449601
Evaporator Assembly,First	354210	5421A10009X
Fan,Turbo	359012	5900A20007B
Grille,Rear	435300	3530A10193E
Handle	436500	3650A20004D
Tube Assembly,Capillary	552111	AJR71449901
Condenser Assembly,First	554030	5403A10008W
Connector,Hose	752140	5214A20027B
Capacitor,Film,Box	W0CZZ	3H00660V
Capacitor,Film,Box	W0CZZ-2	0CZZA20005J
Harness,Single	W6631	6862A20022Q

Exploded View

• MODEL: BHD-501-D




BHD-501-D Parts List

PART DESCRIPTION	LOCATION NO.	PART NO.
Base Assembly,Single	130410	3041A10042A
Roller	144410	4441A30001B
Shroud	149980	4998A10034B
Switch Assembly	266010	6600A30003C
Pan Assembly,Drain	330870	3087A10019C
Bracket,Motor	349600	4960A20009D
Washer,Customized	550140	4830A30005A
Compressor Set,China	554160	TBZ32067202
Overload Protect	567502	EAF43158802
Cabinet	131400	MBH61853106
Grille Assembly,Front	135312	AEB36976502
Tank Assembly,Bucket	148391	4839A10002F
Knob Assembly	149410	-
Filter,Air	152302	5230A20040A
Sensor Assembly	165010	6877A30013R
Cover Assembly,Display	235512	3551A20109C
Escutcheon	238310	MDD30271508
Case Assembly,Control	249950	ABQ36532606
Power Cord Assembly	264110	6411A20001Z
Switch,Rocker	266002	-
Switch Assembly	266003	-
PCB Assembly,Display	268711-1	6871A20600B
PCB Assembly,Main	268711-2	EBR36909301
Motor Assembly,AC,Indoor	346811	EAU32357501
Tube Assembly,Discharge	352113	MJU60464001
Tube Assembly,Suction	35211A	AJR71453001
Evaporator Assembly,First	354210	5421A10009Q
Fan,Turbo	359012	5900A20007B
Grille,Rear	435300	3530A10193E
Handle	436500	3650A20004D
Tube Assembly,Capillary	552111	AJR32779301
Condenser Assembly,First	554030	5403A10008N
Connector,Hose	752140	5214A20027B
Capacitor,Film,Box	W0CZZ	0CZZA20005N
Capacitor,Film,Box	W0CZZ-2	3H00660V
Harness,Single	W6631	6862A20022Q

Exploded View

• MODEL: BHD-651-D



BHD-651-D Parts List

PART DESCRIPTION	LOCATION NO.	PART NO.
Base Assembly,Single	130410	AAN72934301
Roller	144410	4441A30001E
Shroud	149980	4998A10034C
Switch Assembly	266010	6600A30003C
Pan Assembly,Drain	330870	3087A10019E
Bracket,Motor	349600	4960A20009D
Washer,Customized	550140	4830A30005A
Compressor Set,China	554160	TBZ31951701
Overload Protect	567502	6750U-L048A
Cabinet	131400	MBH61853106
Grille Assembly,Front	135312	AEB36976502
Tank Assembly,Bucket	148391	4839A10002F
Knob Assembly	149410	-
Filter,Air	152302	5230A20040A
Sensor Assembly	165010	6877A30013R
Cover Assembly,Display	235512	3551A20109C
Escutcheon	238310	MDD30271508
Case Assembly,Control	249950	ABQ36532603
Power Cord Assembly	264110	6411A20001Z
Switch,Rocker	266002	-
Switch Assembly	266003	-
PCB Assembly,Display	268711-1	6871A20600B
PCB Assembly,Main	268711-2	EBR36909303
Motor Assembly,AC,Indoor	346811	EAU32357504
Tube Assembly,Discharge	352113	AJR36966901
Tube Assembly,Suction	35211A	5211A10454B
Evaporator Assembly,First	354210	ADL36964801
Fan,Turbo	359012	MDG41709701
Grille,Rear	435300	3530A10193E
Handle	436500	3650A20004D
Tube Assembly,Capillary	552111	AJR36953602
Condenser Assembly,First	554030	5403A20114H
Connector,Hose	752140	5214A20027B
Capacitor,Film,Box	W0CZZ	0CZZA20005J
Capacitor,Film,Box	W0CZZ-2	3H00660V
Harness,Single	W6631	6862A20022Q

Design, material, performance data and components
subject to change without notice.

HEAT CONTROLLER, INC.

1900 Wellworth Ave., Jackson, MI 49203 ♦ Ph. 517-787-2100 ♦ Fax 517-787-9341

THE QUALITY LEADER IN CONDITIONING AIR

www.heatcontroller.com