


This Owner's Manual is provided and hosted by Appliance Factory Parts.




LG GR-822DEF Owner's Manual

[Shop genuine replacement parts for LG GR-822DEF](#)


- ▼ The parts of refrigerator and the shape of each part are subject to change in different localities.
- ▼ Capacitors and fuse are optional parts.



CIRCUIT DIAGRAM



• FUSE SPECIFICATION

NON FUSE	FUSE	
	100V ~ 127V	200V ~ 240V
	250V 15A	250V 9A

- OPTIONS CAN BE APPLIED BY THE REQUEST OF BUYERS.
- CAPACITORS, THE PLUG TYPE, EARTH PART ON CIRCUIT DIAGRAM ARE SUBJECT TO CHANGE IN DIFFERENT LOCALITIES.

WH : WHITE BL : BLUE RD : RED PK : PINK
 BK : BLACK BN : BROWN PR : PURPLE YL : YELLOW
 BO : BRIGHT ORANGE GY : GRAY GN : GREEN **3854JD1020C**