

This Owner's Manual is provided and hosted by [Appliance Factory Parts](#).



LG GR-T542 Owner's Manual


[Shop genuine replacement parts for LG GR-T542](#)



[Find Your LG Refrigerator Parts - Select From 834 Models](#)

----- Manual continues below -----

CIRCUIT DIAGRAM



• FUSE SPECIFICATION

NON FUSE	FUSE	
	100V ~ 127V	200V ~ 240V
	250V 15A	250V 9A

• OPTIONS CAN BE APPLIED BY THE REQUEST OF BUYERS.
 • CAPACITORS, THE PLUG TYPE, EARTH PART ON CIRCUIT DIAGRAM ARE SUBJECT TO CHAGE IN DIFFERENT LOCALITIES.

• F.I.R LAMP'S CAPACITOR SPECIFICATION

F.I.R CAPACITOR	220V ~ 240V		100 ~ 127V
	50Hz	300VAC, 0.33uF	
	60Hz	300VAC, 0.27uF	

WH : WHITE BL : BLUE RD : RED PK : PINK
 BK : BLACK BN : BROWN PR : PURPLE YL : YELLOW
 BO : BRIGHT ORANGE GY : GRAY GN : GREEN

3854JD1010L