



# EXPLODED VIEW

## INTRODUCTION

Model : JE1860WH / JE1860BH  
JE1860CH / JE1860WB  
JE1860GB / JE1860CB  
JE1860SB / JE1860SH  
JES1851GB / JES1851WB  
JES1851AB / JES1851SB




# DOOR PARTS




# CONTROL PANEL PARTS


For Model : JE1860WH  
JE1860BH  
JE1860CH  
JE1860WB  
JE1860GB  
JE1860CB  
JES1851GB  
JES1851WB  
JES1851AB




For Model : JE1860SB  
JE1860SH  
JES1851SB




# OVEN CAVITY PARTS




# LATCH BOARD PARTS



# INTERIOR PARTS



# BASE PLATE PARTS



# SENSOR PARTS

