


# EXPLODED VIEW


## INTRODUCTION

JES638  
JES735  
JES738




P/NO: 3828W5S2191


# DOOR PARTS




# CONTROLLER PARTS



# OVEN CAVITY PARTS




# LATCH BOARD PARTS



# INTERIOR PARTS (I)

Model: JES638WD 01  
JES738WH 01  
JES738BH 01  
JES738PWJ 01  
JES735WH 01


Check the rating label of **Model** and order SVC parts according to the **Model No.**



# INTERIOR PARTS (II)

Model: JES638WD 02  
JES738WH 02  
JES738BH 02  
JES738PWJ 02  
JES735WH 02

Check the rating label of **Model** and order SVC parts according to the **Model No.**



# BASE PLATE PARTS

