



EXPLODED VIEW

DOOR PARTS

For Model :
 JVM1540DMWW
 JVM1540DMBB
 JVM1540DMCC
 JNM1541DMWW
 JNM1541DMBB
 JNM1541DMCC
 HVM1540DMWW
 HVM1540DMBB



For Model :
 JVM1540SMSS
 JVM1540LMCS
 JNM1541SMSS
 HVM1540LMCS
 HVM1540SMSS




P/No: MFL32357701

CONTROLLER PARTS


For Model :
JVM1540MWW
JVM1540DMBB
JVM1540DMCC
JNM1541DMWW
JNM1541DMBB
JNM1541DMCC
HVM1540MWW
HVM1540DMBB

For Model:
JVM1540DMBB
JNM1541DMBB
HVM1540DMBB
WTT027


For Model:
JVM1540MWW
JVM1540DMCC
JNM1541DMWW
JNM1541DMCC
HVM1540MWW
WTT029




For Model :
JVM1540SMSS
JVM1540LMCS
JNM1541SMSS
HVM1540LMCS
HVM1540SMSS




OVEN CAVITY PARTS




LATCH BOARD PARTS




INTERIOR PARTS (I)




INTERIOR PARTS (II)



INSTALLATION PARTS



For Model :
JVM1540DMWW
JVM1540DMBB
JVM1540DMCC
JVM1540SMSS
JVM1540LMCS
HVM1540DMWW
HVM1540DMBB
HVM1540LMCS
HVM1540SMSS



OWNERS
MANUAL

*01

INSTALLATION
MANUAL

*04

COOKING
GUIDE
LABEL

*05

TEMPLATE

*06