


This Owner's Manual is provided and hosted by [Appliance Factory Parts](#).



HOOVER U5223-930 Owner's Manual

[Shop genuine replacement parts for HOOVER
U5223-930](#)



[Find Your HOOVER Vacuum Cleaner Parts - Select From 1456 Models](#)

----- Manual continues below part list -----


Available Replacement Parts for HOOVER U5223-930

H-4010100Z	BAG OEM HOOVER 3 PACK
H-38528040	BELT VACUUM HOOVER OEM (1 PACK)
48414036	HOOVER ELITE BRUSH ROLLER

HOOVER Original

DIMENSION UPRIGHT

Models U5215-930, U5221-930, U5223-930, U5227-930



Original

HOOVER**DIMENSION UPRIGHT****Models U5215-930, U5221-930, U5223-930, U5227-****930**

KEY	PART NO.	DESCRIPTION	KEY	PART NO.	DESCRIPTION
1	H-48663200	Upper Handle Ass'y - ABE (Incl. items 2,3,4)	30	H-38522011	Wheel - Rear - AG (2)
2	H-37911078	Handle Cap - ABE	31	H-42242266	Brushroll Housing - AG (Incl. items 26, 29, 30, 44)
3	N/A	Switch Rod - Upper	32	H-34572002	Cam Actuator Spring - FW
4	N/A	Switch Button	33	H-38718005	Valve Gate - BZ
5	H-46388027	Attachment Cord Ass'y - AG - 35 ft. U5227-930	34	H-36131056	Wheel Retainer - AG (2)
5	H-46388026	Attachment Cord Ass'y - AG - 31 ft. U5215-930, U5221-930,	35	H-38521023	Wheel - AG - (2)
6	H-4010100Z	Throw-Away Bag (3 Pk.)	36	H-36432055	Wheel Support ABE
7	H-37257147	Tool Door- AAN	37	H-37245106	Bottom Plate - AG
8	H-36433125	Tool Holder- ABE	38	H-38528027	Belt
9	H-38355008	Spring	39	H-48414049	Agitator Ass'y Complete - AG
10	H-36151013	Bag Door Latch - ABE	40	H-32563012	Wheel Shaft - AY
11	H-37255021	Main Body - ABE	41	H-38452089	Lever AG
12	H-38458036	Switch Rod - Lower- ABE	42	H-38563013	Nozzle Height Adjustment Cam - BZ
13	H-39464025	Lower Handle - ABE	43	H-38351012	Spring - FW
14	H-40201085	Handle Hardware Ass'y	44	H-13261AY	Rug Nozzle Rib Shoe
15	H-38634077	Extension Tube	45	H-27313105	Dirt Finder Lamp
16	H-43414146	Dusting Brush Ass'y - ABR	46	H-43576142	Motor Ass'y Comp.
17	H-43434024	Hose Comp. - ABXJAG	47	H-36131292	Motor Retainer Cap - L.H. - ABE
18	H-32286025	Hose Adapter - Long - AG	48	H-32252252	Screw - Self Tapping - AY (5)
19	H-32377005	Hose Connector - AG	49	H-82252364	Hood Nameplate
20	H-38614036	Furniture Nozzle - ABR	50	H-43683097	Dirt Finder Lens - BZ
21	H-38617026	Crevice Tool - ABR	51	H-42252298	Hood Ass'y - ABM - U5215-930
22	H-36433113	Lower Hose Support - ABE	51*	H-42252292	Hood Ass'y - ABB - U5221-930
23	H-36425081	Bag Housing Bracket - ABE	51	H-42252252	Hood Ass'y - AAY - U5223-930
24	H-37257211	Bag Housing Door - ABM - U5215-930	51	H-42252364	Hood Ass'y - ABR - U5227-930
24	H-37257212	Bag Housing Door- ABB - U5221-930	52	H-37257175	Air Intake Door Ass'y - ABE
24	H-37257213	Bag Housing Door - AAY - U5223-930	53	H-38351011	Spring
24	H-37257214	Bag Housing Door - ABR - U5227-930	54	H-38784056	Seal - AG
25	H-38784016	Seal - AG	55	H-21362006	Speed Nut
26	H-38458022	Handle Release Lever - AG	56	H-38613029	Air Intake - AG
27	H-38567023	Indicator Knob - ABM - U5215-930	57	H-51151004	Indicator Flag - BZ U5221-930, U5223-930, U5227-930
27	H-38567020	Indicator Knob - ABB - U5221-930	58	H-38733002	Bag Check Diaphragm - U5221-330, U5223-930, U5227-930
27	H-38567019	Indicator Knob - AAY - U5223-930			
27	H-38567025	Indicator Knob - ABR - U5227-930			
28	H-38567009	Cam Actuator - AG			
29	H-31523010	Wheel Shaft - AY (2)			

ITEMS NOT ILLUSTRATED

H-21447220 Screw (Tool Holder)