


This Owner's Manual is provided and hosted by [Appliance Factory Parts](http://ApplianceFactoryParts.com).



# Kenmore 116.39712991 Owner's Manual

[Shop genuine replacement parts for Kenmore  
116.39712991](#)



[Find Your Kenmore Vacuum Cleaner Parts - Select From 746 Models](#)


----- Manual continues below part list -----

## Available Replacement Parts for Kenmore 116.39712991

<a href="#">5286</a>	BELT-DRIVE VA
<a href="#">5240</a>	LIGHT BULB
<a href="#">8192015</a>	AGITATOR VA
<a href="#">KER-1820</a>	SAFETY FILTER
<a href="#">PR-1015</a>	BELT, FLAT, UPRIGHTS, 1 PACK

# KENMORE Original & Replacement

UPRIGHT VACUUM Model 116.39712991




# Original & Replacement **KENMORE** UPRIGHT VACUUM Model 116.39712991

KEY	PART NO.	DESCRIPTION
1	KE-8192561	Cord, power
2	KE-4370396	Lever, on-off switch
3	KE-4368653	On-off switch, above, floor
4	KE-4370400	Holder
5	KE-4370399	Holder, hose
6	KE-4370392	Holder, wand
7	KE-8191534	Pcb assembly
10	KE-8192562	Handle assembly (complete)
11	KE-8192563	Cover, switch
13	KE-4370427	Wire, black lead
14	KE-4370575	Suction inlet packing
15	KE-4370428	Packaging , dust container
16	KER-1468A	Dust bag sears no. 20-50690
17	KE-8192564	Cover, dust
18	KER-1800	Filter sears no. 20-86889
19	KE-4370416	Latch, filter cover
20	KE-8191637	Filter, Motor
21	KE-8192565	Case, motor
22	KE-4370407	Spring ,protector
23	KE-4370408	Cover, protector
24	KE-4370432	Filter - sears no. 20-86884
25	KE-4370240	Cushion, rubber
26	KE-4369564	Stopper, wheel (2)
27	KE-4370177	Wheel, rear
28	KE-4369562	Washer, wheel
29	KE-4369561	Shaft, rear wheel
30	KE-4370404	Support, rubber mount (front)
31	KE-8191638	Motor, fan
32	KE-4370266	Flange, motor
33	KE-8191785	Screw, belt guard
34	KE-4370265	Support, rubber motor (front)
35	KE-4369569	Suppoessor, noise
36	KE-8191914	Compartment, dust
37	SS-3270	Wire Nut
38	KE-4368563	Screw, motor, case mounting
39	KE-4370429	Latch, dust cover
40	NLA	Latch, dust cover
41	KE-4369097	Spring, latch
42	KE-8192566	Cover, filter
43	KE-4370420	Screw, handle
44	KE-4370280	Screw, motor case mounting
45	KE-4368563	Screw, motor, case mounting
46	NLA	Packing, motor case (adhesive back)
47	KE-4370465	Wire, cord
48	KE-8175040	Lead Assly

NLA = No Longer Available

# KENMORE Original & Replacement

UPRIGHT VACUUM Model 116.39712991




# Original & Replacement **KENMORE** UPRIGHT VACUUM Model 116.39712991

KEY	PART NO.	DESCRIPTION
1	KE-4370976	Cover, light
2	KE-4370410	Window
3	KE-8174947	Housing, nozzle
4	KE-8174948	Latch, nozzle left side
4A	NLA	Latch, nozzle right side
5	KE-4368563	Screw, motor, case mounting
6	FA-3515	Bulb, light sears no. 20-5240
7	KE-4369526	Socket, bulb
8	KE-8174976	Cover, agitator, brush
9	KE-8192018	Bearing holder
11	KE-4369527	Shaft, wheel
12	KE-4370263	Bearing, nozzle
13	KE-4369606	Screw, retaining
14	KE-4370425	Wheel
15	KE-4369543	Cam, height adjustment
16	KE-4369499	Shaft, roller (2)
17	KE-4370182	Wheel, cam (2)
18	KE-4370183	Cushion, cam rubber
19	KE-4370394	Pedal
20	KE-4370258	Spring, pedal
21	KE-4370259	Shaft, pedal
22	KE-4370260	Cover, foot pedal
23	NLA	Cover, belt
24	KE-4368563	Screw, motor, case mounting
25	KE-8195180	Shifter, belt
26	KE-4370544	Nozzle, packing
27	KE-4369535	Guard, belt
28	KE-4369542	Sliding knob height adjustment
29	PR-1015	Belt, sears no. 20-5275
30	KE-8174966	Lower plate assembly
31	KE-8174967	Guard, furniture
32	KE-8192015	Agitator assembly
33	KE-8191810	Screw, 8-24 x 1 (2)
34	KE-4370433	Reflector , nozzle

NLA = No Longer Available

# KENMORE Original & Replacement

UPRIGHT VACUUM Model 116.39712991



Original & Replacement **KENMORE**  
UPRIGHT VACUUM Model 116.39712991

<u>KEY</u>	<u>PART NO.</u>	<u>DESCRIPTION</u>
1	KE-4370401	Hose, flexible
2	KE-4368884	Tool, crevice *sears no. 20-52831
3	KE-4369888	Wand, telescopic
4	KE-4368998	Regulatory, suction
5	KE-4368881	Brush, combination
6	KE-4368809	Brush ,combination
7	KE-4368810	Holder, brush
10	KE-8191834	Hose unit

NLA = No Longer Available