


This Owner's Manual is provided and hosted by [Appliance Factory Parts](http://ApplianceFactoryParts.com).



# PANASONIC MC-7310 Owner's Manual

[Shop genuine replacement parts for PANASONIC  
MC-7310](#)



[Find Your PANASONIC Vacuum Cleaner Parts - Select From 605 Models](#)

----- Manual continues below -----

# PANASONIC

Models: MC-7310, MC-7320 , MC-8310, MC-8320, MC-8330


## Dust Cover and Attachments

A1	N/A	Dust Cover
A2	P-125P	Paper Bag, type "C", 3 pack
A2	P-125PT	Paper Bag, type "C", 12 pack
A2	254	Paper Bag, type "C", 3 pack (R)
A2	254-12	Paper Bag, type "C", 12 pack (R)
A3	P-9974	Floor and Wall Brush
A4	P-12342	Attachment Tray A
A5	P-12343	Attachment Tray B
A6	P-882	Dusting Brush
A7	P-862	Upholstery Brush
A8	P-6073	Crevice Tool
A9	P-12344	Floor Nozzle Assembly
A10	P-12345	Pipe, floor nozzle
A11	P-12346	Upper Housing, floor nozzle
A12	P-364	Roller, floor nozzle
A13	P-12347	Roller Shaft, floor nozzle
A14	P-12348	Bumper, floor nozzle
A15	P-12349	Lower Housing, floor nozzle
A16	P-416	Screw, 10 pack
A17	P-12350	Hose Assembly, 7310,7320
A17	P-10465	Hose Assembly, 8310,8320,8330
A18	P-982	Wand, curved, 7320,7310
A19	P-164	Grip Cover
A20	P-9274	Spring Button
A21	P-12353	Suction Regulator, 7310
A21	P-542	Suction Regulator, all except 7310
A22	P-12354	Extension Wand, 7310,8310
A22	P-402	Extension Wand, 7320,8320,8330

A-1





A-2



# PANASONIC

Models: MC-7310, MC-7320, MC-8310, MC-8320, MC-8


## Body Unit



# PANASONIC

Models: MC-7310, MC-7320 , MC-8310, MC-8320, MC-8

## Cord Reel Unit




C1	P-12395	Body Partition
C3	P-12397	Lever Unit, brake
C4	P-12398	Contact Base Unit
C5	P-12399	Rail base Unit / Power Cord
C6	N/A	Cord Reel Assembly
C7	P-416	Screw, 10 pack
C8	P-12400	Screw

## Motor Assembly

# PANASONIC

Models: MC-8310, MC-8320, MC-8330



P-9	Agitator Assembly, 8310
P-921	Agitator Assembly, 8320,8330
3	P-84 Agitator Body, 8310
3	P-12355 Agitator Body, 8320,8330
4	P-85 Brush Insert, sold each
4	P-425 Brush Insert, sold per pair (R)
5	N/A Agitator Pulley
6	P-4101 Agitator Holder
7	P-321 Filter
8	P-00125 End Cap, right
9	P-960 End Cap, left
10	P-57 Shaft, agitator
11	P-05 E-Clip, 30 pk
12	P-74 Spacer

## Power Nozzle

E1	N/A	Top Mark, 8310
E1	P-12408	Top Mark, 8320,8330
E2	P-12409	Body
E3	P-12410	Packing, body
E4	P-12411	Furniture Guard
E5	N/A	Pipe Connector
E6	P-12413	Joint Pipe
E7	P-12414	Filter
E8	N/A	Motor Assembly, power nozzle
E9	P-12416	Motor Support, rubber, upper