


This Owner's Manual is provided and hosted by [Appliance Factory Parts](http://ApplianceFactoryParts.com).



# PANASONIC V5325 Owner's Manual

[Shop genuine replacement parts for PANASONIC  
V5325](#)



[Find Your PANASONIC Vacuum Cleaner Parts - Select From 605 Models](#)


----- Manual continues below -----

Models:

MC-V5305, MC-V5315, MC-V5320, MC-V5325, MC-V5330, MC-V5335, MC-V

## Nozzle Housing

- |         |               |   |
|---------|---------------|---|
| 1.....  | P-1118.....   | Nozzle Housing, V5305                           |
| 1.....  | P-01113.....  | Nozzle Housing, V5315                           |
| 1.....  | P-5445.....   | Nozzle Housing, V5320                           |
| 1.....  | P-3112.....   | Nozzle Housing, V5325                           |
| 1.....  | P-10331.....  | Nozzle Housing, V5330                           |
| 1.....  | P-1106.....   | Nozzle Housing, V5335                           |
| 1.....  | P-5446.....   | Nozzle Housing, V5340                           |
| 1.....  | P-0115.....   | Nozzle Housing, V5355                           |
|         | P-78006.....  | Plastic Holder, V5305, V5315, V5335             |
| 2.....  | P-10105.....  | Window  |
| 2.....  | P-21010.....  | Window, V5305                                   |
| 2.....  | P-000224..... | Window, V5320, V5340                            |
| 2.....  | P-10105.....  | Window, V5330                                   |
| 3.....  | P-2500.....   | Shaft, plastic                                  |
| 4.....  | P-10332.....  | Furniture Guard                                 |
| 4.....  | P-10332.....  | Furniture Guard, V5330                          |
| 4.....  | P-10106.....  | Furniture Guard, V5320, V5340                   |
| 5.....  | P-81.....     | Packing, tight                                  |
| 6.....  | P-000095..... | Frame   |
| 7.....  | P-58.....     | Spring, pedal                                   |
| 8.....  | P-6140.....   | Screw, spring                                   |
| 9.....  | P-47006.....  | Pedal, V5305, V5315, V5335                      |
| 9.....  | P-6074.....   | Pedal, V5325, V5355                             |
| 10..... | P-6140.....   | Screw, frame                                    |
| 11..... | P-2287.....   | Belt, type UB, 2 pack                           |
| 11..... | P-V270B.....  | Belt, type UB8, 2 pack, V5330                   |
| 12..... | P-91107.....  | Bottom Plate Assy, V5305, V5315, V5335          |
| 12..... | P-5447.....   | Bottom Plate Assy, V5320, V5340                 |
| 12..... | P-9197.....   | Bottom Plate Assy, V5325, V5330, V5355          |
| 13..... | P-27107.....  | Bottom Plate Only, V5305, V5315, V5355          |
| 13..... | P-5448.....   | Bottom Plate Only, V5320, V5340                 |
| 13..... | P-2707.....   | Bottom Plate Only, V5325, V5330, V5355          |
| 14..... | P-7500.....   | Packing, bottom plate                           |
| 15..... | P-43.....     | Belt Cover                                      |
| 16..... | P-000015..... | Screw, bottom plate, V5305, V5315, V5335        |
| 16..... | P-6800.....   | Screw, bottom plate, V5325, V5355               |
| 17..... | P-34006.....  | Nozzle Hose, short                              |
| 18..... | P-9862.....   | Reflector                                       |
| 18..... | P-5450.....   | Reflector, V5320, V5340                         |
| 19..... | N/A.....      | Socket, bulb, V5315, V5355                      |
| 19..... | P-0039.....   | Socket, bulb, V5320, V5325, V5330, V5340, V5355 |
| 20..... | P-2810.....   | Bulb  |
| 20..... | P-7550.....   | Bulb, V5330                                     |
|         | P-5449.....   | Reflector Supporter, V5320,                     |





# PANASONIC

V

## Models:

MC-V5305, MC-V5315, MC-V5320, MC-V5325, MC-V5330, MC-V5335, MC-V

1..... P-8860..... Dust Compartment	23..... P-095006..... Motor Case, V5335	47..... P-6110
1..... P-8010..... Dust Compartment, V5305	23..... P-5453..... Motor Case, V5340	47..... P-6013
1..... P-8826..... Dust Compartment, V5315, V5335	23..... P-09505..... Motor Case, V5355	47..... P-5454
2..... P-8913..... On/Off Switch	24..... P-201..... Packing, rear cover	47..... P-6011
3..... N/A..... Cord Stopper	25..... P-00117..... Packing, motor case	47..... P-1033
3..... P-0698..... Cord Stopper, V5330	25..... P-1906..... Packing, motor case, V5320, V5325, V5330, V5340, V5355	47..... P-6006
4..... P-6140..... Screw, cord stopper	26..... P-6140..... Screw, motor case	47..... P-5455
5..... P-97006..... Power Cord, V5305, V5315	27..... P-6096..... Protector, motor	47..... P-6050
5..... P-6079..... Power Cord, V5320, V5325, V5330	28..... P-9832..... Protector Spring	48..... P-8400
5..... P-9706..... Power Cord, V5335	28..... P-70002..... Protector Spring, V5305	48..... P-8460
5..... P-97062..... Power Cord, V5340, V5355	28..... N/A..... Protector Spring, V5315	48..... P-1060
6..... P-000623..... Wire Connector	28..... P-9832..... Protector Spring, V5335	48..... P-2061
7..... P-66106..... Packing, dust container	29..... N/A..... Protector Case	49..... P-6088
7..... P-660106..... Packing, dust container, V5320, V5325, V5330, V5340, V5355	29..... P-6806..... Protector Case, V5320, V5330, V5340	50..... P-6069
8..... N/A..... Switch Cover	30..... P-1806..... Protector Supporter, motor	51..... P-4010
8..... P-5451..... Switch Cover, V5320, V5340	31..... P-2908..... Motor	51..... P-6010
8..... P-30606..... Switch Cover, V5325, V5330, V5355	31..... P-000144..... Motor, V5305	52..... P-5810
9..... P-7306..... Packing, switch cover	31..... P-9833..... Motor, V5315	53..... P-0010
9..... P-73006..... Packing, switch cover, V5320, V5325, V5330, V5340, V5355	31..... P-9225..... Motor, V5325, V5355	54..... P-6106
10..... P-6140..... Screw, switch cover	31..... P-2908..... Motor, V5330	55..... P-3990
11..... P-7301..... Screw, handle	32..... P-27009..... Carbon Brush	56..... P-5860
12..... P-2117..... Nut, handle screw	32..... P-10393..... Carbon Brush, V5305	57..... P-78.....
13..... P-3200..... Filter Supporter	32..... P-2720..... Carbon Brush, V5315	P-5360
14..... P-9829..... Secondary Filter, electrostatic, V5315, V5335	33..... P-0036..... Brush Retainer Bracket	P-5456
14..... P-375..... Secondary Filter, foam, V5305, V5320, V5325, V5330	34..... P-0037..... Screw, brush	P-5457
14..... P-37100..... Secondary Filter, electrostatic, V5340, V5355	35..... P-9931..... Noise Suppressor	
15..... P-0114..... Wheel	35..... P-99300..... Noise Suppressor, V5315, V5335	
16..... P-16005..... Shaft, wheel	36..... P-0293..... Motor Support, front	
17..... P-74009..... Stopper, wheel	37..... P-9911..... Motor Support Rubber, rear	
18..... P-6115..... Washer	38..... P-37020..... Wire Cord	
19..... P-115P..... Paper Bag, 3 pack	38..... P-000504..... Wire Cord, V5315, V5335	
19..... P-141M..... Paper Bag, 3 pack, micron	39..... P-000623..... Wire Connector	
20..... P-6606..... Suction Inlet	40..... P-6412..... Handle	
21..... P-8972..... Cover, suction inlet	40..... P-9835..... Handle, V5330	
22..... P-6140..... Screw, suction inlet	P-50106..... Handle Grip, V5305, V5315, V5335	
23..... P-9782..... Motor Case, V5305	41..... P-9836..... Cord Hook, upper	
23..... P-095013..... Motor Case, V5315	42..... P-9837..... Hose Holder	
23..... P-5452..... Motor Case, V5320	P-550006..... Cord Storage Base, V5315, V5335	
23..... P-09501..... Motor Case, V5325	43..... P-7670..... Spring, cord hook	
23..... N/A..... Motor Case, V5330	44..... P-587..... Washer, cord hook	
	45..... P-9838..... Cord Hook, lower	
	46..... P-43096..... Screw, cord hook	
	46..... P-7551..... Screw, cord hook, V5330	

## Agitator Assembly

