



Models: MC-V5190, MC-V5390

## Nozzle Housing




- 1 ..... P-9009 ..... Nozzle Housing, V5190
- 1 ..... P-000221 ..... Nozzle Housing, V5390
- 2 ..... P-2002 ..... Top Mark, V5190
- 2 ..... P-40201 ..... Top Mark, V5390
- 3 ..... P-2500 ..... Plastic Shaft
- 4 ..... P-78 ..... Plastic Holder
- 5 ..... P-6140 ..... Screw

- 6 ..... P-58 ..... Pedal Spring
- 7 ..... P-10106 ..... Furniture Guard
- 8 ..... P-81 ..... Body Packing

- 9 ..... P-2287 ..... Belt, 2 pack
- 10 ..... P-000075 ..... Bottom Plate Assy
- 11 ..... P-2713 ..... Bottom Plate Only
- 12 ..... P-000015 ..... Screw, coin head
- 13 ..... P-7500 ..... Body Packing
- 14 ..... P-43 ..... Belt Cover
- 15 ..... P-9862 ..... Nozzle Hose, short


## Agitator Assembly

- 1 ..... P-9212 ..... Agitator Unit
- 2 ..... P-0693 ..... End Cap, both ends
- 3 ..... P-0694 ..... Washer
- 4 ..... P-92002 ..... Agitator Assembly, complete




## Fan Replacement

- 2 ..... P-000067 ..... Fan Case
- 3 ..... P-000068 ..... Nut
- 4 ..... P-00621 ..... Washer
- 5 ..... P-000406 ..... Fan
- 6 ..... P-000152 ..... Washer
- 7 ..... P-000500 ..... Spacer
- 8 ..... P-10393 ..... Brush Assy
- 9 ..... P-0036 ..... Bracket
- 10 ..... P-0037 ..... Screw



Models: MC-V5190, MC-V5390

## Motor Housing, Motor, Handle & Body



# PANASONIC

# V-Series Uprights

Models: MC-V5190, MC-V5390

1	P-9009	Dust Compartment Assy, V5190	21	P-8972	Cover, V5190	38	P-3820	Wire Cord
1	P-8826	Dust Compartment Assy, V5390	21	P-000049	Cover, V5390	39	P-000623	Wire Connector
2	P-9804	On/Off Switch	22	P-6140	Screw	40	N/A	Handle Assy, V5190
3	N/A	Cord Stopper	23	P-9008	Motor Case, V5190	40	P-6412	Handle Assy, V5390
4	P-000616	Screw	23	P-95003	Motor Case, V5390	41	P-9836	Upper Cord Storage Hook
5	P-6140	Power Cord, V5190	24	P-201	Packing, rear cover	42	P-9837	Hose Holder
6	P-000623	Wire Connector	25	P-00117	Packing, motor case, V5190		P-550006	Cord Storage Base, V5390
7	P-66106	Dust Container Packing	25	P-19006	Packing, motor case, V5390	43	P-7670	Spring, cord hook
8	N/A	Switch Cover	26	P-6140	Screw	44	P-587	Washer
9	P-7306	Packing, switch cover	27	P-6096	Protector	45	P-9838	Lower Cord Storage Hook
10	P-6140	Screw	28	P-70002	Spring, protector	46	P-43096	Screw
11	P-7301	Screw, handle	29	P-68006	Case, protector	47	P-6209	Dust Cover, V5190
12	P-2117	Nut	30	P-1806	Supporter, protector	47	P-60203	Dust Cover, V5390
13	P-3200	Filter Supporter	31	P-000144	Motor Assy, V5190	48	P-21005	Ornamental Plate, V5190
14	P-375	Secondary Filter	31	P-9833	Motor Assy, V5390	48	P-2156	Ornamental Plate, V5390
15	P-0114	Roller	32	P-10393	Carbon Brush, V5190	49	P-84006	Hose Unit, V5190
16	P-16005	Shaft, roller	32	P-9834	Carbon Brush, V5390	49	P-8460	Nozzle Hose, stretch, V5390
17	P-74009	Wheel Stopper	33	P-0036	Brush Retainer Bracket		P-5360	Hose Hook, V5390
18	P-6115	Washer	34	P-0037	Screw, brush	50	P-6088	Dusting Brush
19	P-115P	Paper Bag, U3, 3 pack	35	P-99300	Noise Suppressor	51	P-6069	Crevice Tool
19	P-115PT	Paper Bag, U3, 12 pack	36	P-0293	Motor Support Rubber, front	52	P-60104	Wand
20	P-6066	Suction Inlet	37	P-9911	Motor Support Rubber, rear			