


Models: MC-V5007, MC-V5027, MC-V5107, MC-V5117

## Nozzle Housing




- 1 ..... P-5485 ..... Nozzle Housing, V5007
- 1 ..... P-10346 ..... Nozzle Housing, V5027
- 1 ..... P-01004 ..... Nozzle Housing, V5107
- 1 ..... P-5486 ..... Nozzle Housing, V5117
- P-78 ..... Plastic Holder, V5107
- 2 ..... P-000224 ..... Window, V5107, V5117
- 3 ..... P-2500 ..... Plastic Shaft
- 3 ..... P-10819 ..... Plastic Shaft, V5027
- 4 ..... P-5484 ..... Furniture Guard
- 4 ..... P-10106 ..... Furniture Guard, V5107
- 5 ..... P-81 ..... Packing, tight
- 6 ..... P-5483 ..... Reflector Supporter, V5117
- 6 ..... P-862104 ..... Reflector Supporter, V5107

- P-8522 ..... Bulb Supporter, V5107
- 7 ..... P-58 ..... Spring, pedal
- 8 ..... P-6140 ..... Screw, spring
- 9 ..... P-5450 ..... Reflector, V5117
- 9 ..... P-8420 ..... Reflector, V5107
- 10 ..... P-6140 ..... Screw, reflector supporter, V5117
- 11 ..... P-2287 ..... Belt, 2 pack
- 11 ..... P-00181 ..... Belt, each
- 12 ..... P-5447 ..... Bottom Plate Assy, V5007, V5027
- 12 ..... P-9100 ..... Bottom Plate Assy, V5107
- 12 ..... P-5487 ..... Bottom Plate Assy, V5117
- 13 ..... P-5488 ..... Bottom Plate Only, V5007
- 13 ..... P-5448 ..... Bottom Plate Only, V5027
- 13 ..... P-000102 ..... Bottom Plate Only, V5107

- 13 ..... P-5489 ..... Bottom Plate Only, V5117
- 14 ..... P-7500 ..... Packing, lower plate
- 15 ..... P-43 ..... Belt Cover
- 16 ..... P-6800 ..... Screw, lower plate, V5007, V5027
- 17 ..... P-9862 ..... Nozzle Hose, short, V5107, V5117
- 18 ..... P-6140 ..... Screw, latch, V5117
- 19 ..... P-00012 ..... Socket, bulb, V5107
- 19 ..... P-0039 ..... Socket, bulb, V5117
- 20 ..... P-2810 ..... Bulb, V5107, V5117
- 21 ..... P-0800 ..... Latch, lower plate, V5117
- 22 ..... P-5490 ..... Top Mark, V5007
- 22 ..... P-10347 ..... Top Mark, V5027
- P-000275 ..... Wire Cord, lead wire black, V5107

## Agitator Assembly



### MODELS V5107, V5117

- P-921 ..... Agitator Assy, V5107
- P-5491 ..... Agitator Assy, V5117
- 2 ..... P-85 ..... Brush Strip (4), V5107
- 2 ..... P-5492 ..... Brush Strip (4), V5117
- 3 ..... P-078 ..... Agitator Pulley, V5107
- 3 ..... P-5918 ..... Agitator Pulley, V5117
- 4 ..... P-881 ..... Agitator Holder, V5107
- 4 ..... P-5919 ..... Agitator Holder, V5117

- 5 ..... P-304 ..... Filter, V5107
- 5 ..... P-10376 ..... Filter, V5117
- 6 ..... N/A ..... End Cap, left, V5107
- 6 ..... P-9708 ..... End Cap, left, V5117
- 7 ..... P-00125 ..... End Cap, right, V5107
- 7 ..... P-9709 ..... End Cap, right, V5117
- 8 ..... P-57 ..... Shaft, V5107
- 8 ..... P-5920 ..... Shaft, V5117
- 9 ..... P-411 ..... E-Clip, V5107


- 9 ..... P-4003 ..... E-Clip, V5117
- 10 ..... P-74 ..... Spacer, V5107
- P-8403 ..... Agitator Body Only, V5117

### MODEL V5007, V5027

- P-8408 ..... Agitator Body Only, V5007
- P-10842 ..... Agitator Body Only, V5027
- P-0693 ..... End Cap, either side
- P-0030 ..... Washer, 2 used

Models: MC-V5007, MC-V5027, MC-V5107, MC-V5117

## Body Assembly




Models: MC-V5007, MC-V5027, MC-V5107, MC-V5117

- 1 .... P-5493 ..... Dust Compartment, V5007
- 1 .... P-10869 ..... Dust Compartment, V5027
- 1 .... P-8826 ..... Dust Compartment, V5107, V5117
- 2 .... P-8913 ..... On/Off Switch
- 3 .... P-10870 ..... Cord Stopper
- 4 .... P-6140 ..... Screw, cord stopper
- 5 .... P-0697 ..... Power Cord
- 5 .... P-10507 ..... Power Cord, V5027
- 6 .... P-000623 ..... Wire Connector
- 7 .... P-660106 ..... Packing, dust container
- 7 .... P-10871 ..... Packing, dust container, V5027
- 7 .... P-66106 ..... Packing, dust container, V5107
- 8 .... P-30606 ..... Switch Cover
- 8 .... P-10872 ..... Switch Cover, V5027
- 8 .... N/A ..... Switch Cover, V5107
- 9 .... P-73006 ..... Packing, switch cover
- 9 .... P-7306 ..... Packing, switch cover, V5107
- 10 .. P-6140 ..... Screw, switch cover
- 11 .. P-7301 ..... Screw, handle
- 12 .. P-2117 ..... Nut, handle screw
- 13 .. P-3200 ..... Filter Supporter
- 14 .. P-375 ..... Secondary Filter, foam
- 14 .. P-37100 ..... Secondary Filter, electrostatic
- 15 .. P-0114 ..... Wheel
- 15 .. P-0062 ..... Wheel, V5107
- 16 .. P-16005 ..... Shaft, wheel
- 17 .. P-74009 ..... Stopper, wheel
- 18 .. P-6115 ..... Washer
- 19 .. P-141M ..... Paper Bag, type U6, 3 pk, micron
- 19 .. P-115P ..... Paper Bag, U3, 3 pk
- 20 .. P-000625 ..... Suction Inlet, V5007
- 20 .. P-10860 ..... Suction Inlet, V5027
- 21 .. P-8915 ..... Cover, suction inlet, V5007, V5027
- 21 .. P-02006 ..... Cover, suction inlet, V5107, V5117
- 22 .. P-6140 ..... Screw, suction inlet
- 23 .. P-5494 ..... Motor Case, V5007
- 23 .. P-10873 ..... Motor Case, V5027
- 23 .. P-0950 ..... Motor Case, V5107
- 23 .. P-5495 ..... Motor Case, V5117
- 24 .. P-201 ..... Packing, rear
- 24 .. P-10913 ..... Packing, rear, V5027
- 25 .. P-1906 ..... Packing, motor case
- 25 .. P-10825 ..... Packing, motor case, V5027
- 25 .. P-00117 ..... Packing, motor case, V5107
- 26 .. P-6140 ..... Screw, motor case
- 26 .. P-8172 ..... Screw, motor case, V5027
- 27 .. P-6096 ..... Protector, V5107, V5117
- 28 .. P-9832 ..... Protector Spring, green, V5107, V5117
- 29 .. P-6806 ..... Protector Case, V5107, V5117
- 30 .. P-1806 ..... Protector Supporter, V5107, V5117
- 31 .. P-92050 ..... Fan Motor Unit, V5007
- 31 .. P-10874 ..... Fan Motor Unit, V5027
- 31 .. P-9833 ..... Fan Motor Unit, V5107, V5117
- 32 .. P-0035 ..... Carbon Brush
- 32 .. P-9834 ..... Carbon Brush, V5107, V5117
- 33 .. P-0036 ..... Brush Retainer Bracket

- 34 .. P-0037 ..... Screw, brush
- 35 .. P-9931 ..... Noise Suppressor
- 35 .. P-99300 ..... Noise Suppressor, V5107
- 35 .. P-10670 ..... Noise Suppressor, V5027
- 36 .. P-0293 ..... Motor Support Rubber, front
- 37 .. P-10338 ..... Motor Support Rubber, rear
- 38 .. P-37020 ..... Wire Cord
- 38 .. P-3820 ..... Wire Cord, V5107
- 39 .. P-000623 ..... Wire Connector
- 40 .. P-6412 ..... Handle
- 40 .. P-9835 ..... Handle, V5027
- 40 .. P-50106 ..... Grip, handle, V5107
- 41 .. P-9836 ..... Upper Cord Storage Hook
- 42 .. P-9837 ..... Hose Holder
- 43 .. P-7670 ..... Spring, cord hook
- 44 .. P-587 ..... Washer, cord storage hook
- 45 .. P-9838 ..... Lower Cord Storage Hook
- 46 .. P-43096 ..... Screw, cord storage hook
- 47 .. P-5921 ..... Dust Cover, V5007
- 47 .. P-10875 ..... Dust Cover, V5027
- 47 .. P-6004 ..... Dust Cover, V5107
- 47 .. P-5922 ..... Dust Cover, V5117
- 48 .. P-34206 ..... Hose, V5007
- 48 .. P-8917 ..... Hose, V5027, V5117
- 49 .. P-6088 ..... Dusting Brush, V5117
- 49 .. P-6088 ..... Dusting Brush, V5107
- 50 .. P-6069 ..... Crevice Tool, V5107, V5117
- 50 .. P-60104 ..... Wand, extension, V5107
- 51 .. P-60104 ..... Wand, extension, V5117
- 52 .. P-00104 ..... Wire Tie
- 53 .. P-6106 ..... Packing, nut, handle screw
- 54 .. P-3990 ..... Packing, right
- 55 .. P-4160 ..... Packing, left
- 55 .. P-5860 ..... Packing, left, V5027
- 56 .. P-78 ..... Plastic Holder
- 57 .. P-9300 ..... Packing, indicator, V5107, V5117
- 58 .. P-000147 ..... Cap, indicator, V5107, V5117
- 59 .. P-0400 ..... Spring, indicator, V5107, V5117
- 60 .. P-000149 ..... Lead, indicator, V5107, V5117
- 61 .. P-000150 ..... Body, indicator, V5107, V5117
- 62 .. P-4104 ..... Screw, indicator, V5107, V5117
- 63 .. P-550006 ..... Cord Storage Base, V5007
- 63 .. P-8916 ..... Cord Hook Base, V5027
- 64 .. P-333 ..... Protector Filter
- 65 .. P-000058 ..... Protector Supporter
- 66 .. P-692 ..... Protector
- 67 .. P-000057 ..... Protector Spring
- 68 .. P-000056 ..... Protector Case

## Motor Repair Parts



- 1 .... P-000067 ..... Fan Case, V5007, V5117
- 2 .... P-000068 ..... Nut, V5007, 5117
- 3 .... P-00621 ..... Washer, V5007, V5117
- 4 .... P-000070 ..... Fan, V5007
- 4 .... P-000152 ..... Fan, V5117
- 5 .... P-6206 ..... Washer, V5117
- 6 .... P-000500 ..... Spacer, V5117
- 7 .... P-0035 ..... Brush Assy, V5007
- 7 .... P-9834 ..... Brush Assy, V5107
- 7 .... P-10393 ..... Brush Assy, V5117
- 8 .... P-0036 ..... Bracket, V5007, V5117
- 9 .... P-0037 ..... Screws, V5007, V5117