


This Owner's Manual is provided and hosted by [Appliance Factory Parts](#).



PANASONIC 7190 Owner's Manual

[Shop genuine replacement parts for PANASONIC 7190](#)



[Find Your PANASONIC Vacuum Cleaner Parts - Select From 605 Models](#)



----- Manual continues below -----

PANASONIC

Models: MC-7190

Main Unit

- 1 P-0204 Upper Body
- 2 P-2402 Cover, rear
- 3 P-4600 Button, cord rewind
- 4 P-7100 Coil Spring
- 5 P-0500 Button, on / off switch
- 6 N/A Switch, on / off
- 7 P-2403 Leaf Spring
- 8 P-1300 Storage Button
- 9 P-1100 Holder, button
- 10 P-0108 Handle
- 11 P-740 Cover, tool storage
- 12 P-0109 Button, release
- 13 N/A Coil Spring
- 14 P-9902 Cord Reel
- 15 P-9851 Power Cord
- 17 P-9600 Body Partition
- 18 P-1478 Cord Guide
- 19 P-9403 Brake Lever
- 21 P-9202 Motor
- 22 P-272 Carbon Brush
- 23 P-0251 Motor Support Rubber, front
- 24 P-12493 Motor Support Rubber, rear
- 25 P-99300 Noise Suppressor
- 26 P-3500 Furniture Guard, right
- 27 P-3405 Furniture Guard, left
- 28 P-0252 Filter, rear
- 29 P-0305 Body, lower
- 30 P-0112 Wheel
- 31 P-0550 Cap, wheel
- 32 P-9503 Caster
- 33 P-2601 Washer, caster
- 34 P-416 Screw, caster, 10 pk
- 36 P-8804 Expander
- 37 P-3801 Spring, bag holder
- 38 P-1400 Bag Holder
- 39 P-3300 Shaft, holder
- 40 P-3121 Frame, filter
- 41 P-3002 Filter
- 42 P-1802 Expander
- 43 P-933 Paper Bag, 2 pack



PANASONIC

Models: MC-7080, MC-7190

Attachments

