


Models: MC-9410, MC-9420, MC-9430, MC-9440

## Dust Cover and Attachments



- A1 ..... P-12429 ..... Indicator Plate, 9410
- A1 ..... P-12430 ..... Indicator Plate, 9420
- A1 ..... P-12431 ..... Indicator Plate, 9430
- A1 ..... P-12432 ..... Indicator Plate, 9440
- A2 ..... P-12433 ..... Indicator Window
- A3 ..... P-4340 ..... Alarm Blade
- A4 ..... P-12434 ..... Packing, indicator
- A5 ..... P-13143 ..... Screw, indicator box
- A6 ..... P-12436 ..... Indicator Box
- A7 ..... P-12437 ..... Indicator Stopper
- A8 ..... P-12438 ..... Spring, indicator
- A9 ..... P-12439 ..... Needle, indicator
- A10 ..... P-12440 ..... Knob
- A11 ..... P-12441 ..... Dust Cover
- A12 ..... P-12442 ..... Protector Support
- A13 ..... P-12443 ..... Protector
- A14 ..... P-12444 ..... Protector Spring, 9410
- A14 ..... P-12445 ..... Protector Spring, 9420,9430,9440
- A15 ..... P-12446 ..... Protector Case
- A16 ..... P-12447 ..... Tool Storage Cover
- A18 ..... P-125P ..... Paper Bag, type "C", 3 pack
- A18 ..... P-125PT ..... Paper Bag, type "C", 12 pack
- A18 ..... 254 ..... Paper Bag, type "C", 3 pack (R)
- A18 ..... 254-12 ..... Paper Bag, type "C", 12 pack (R)
- A19 ..... P-302 ..... Filter, 9410
- A19 ..... P-12448 ..... Filter, 9420,9430,9440
- A20 ..... P-312 ..... Supporter, filter
- A21 ..... P-6073 ..... Crevice Tool
- A22 ..... P-882 ..... Dusting Brush
- A23 ..... P-862 ..... Upholstery Brush
- A24 ..... P-9974 ..... Floor and Wall Brush
- A25 ..... P-10465 ..... Hose Assembly, w/o curved wand
- A26 ..... P-982 ..... Curved Wand, 9410,9420,9430, comes  
suction regulator only
- A26 ..... N/A ..... Curved Wand, 9440 comes with suction  
regulator only
- A27 ..... P-164 ..... Grip Cover, 9410,9420,9430
- A27 ..... P-12452 ..... Grip Cover, 9440
- A28 ..... P-542 ..... Suction Regulator
- A29 ..... P-12453 ..... Retainer, plug
- A30 ..... N/A ..... Curved Wand
- A31 ..... N/A ..... Switch, variable power control, 9440
- A32 ..... P-416 ..... Screw, for grip cover, 10 pack
- A33 ..... P-9274 ..... Spring Button
- A34 ..... P-402 ..... Extension Wand, w/ spring button


Models: MC-9410, MC-9420, MC-9430, MC-9440

## Body Unit

- B1 ..... P-12456 ..... Furniture Guard
- B2 ..... P-12457 ..... Ornamental Plate, 9410
- B2 ..... P-12458 ..... Ornamental Plate, 9420
- B2 ..... P-12459 ..... Ornamental Plate, 9430
- B2 ..... P-12460 ..... Ornamental Plate, 9440
- B3 ..... P-12461 ..... Window, power indicator
- B4 ..... P-12462 ..... Power Indicator P.C.B.
- B5 ..... N/A ..... Button, on/off
- B6 ..... P-082 ..... Spring, switch
- B7 ..... P-152 ..... Activating Spring, switch
- B8 ..... P-12464 ..... Button, cord rewind
- B9 ..... P-872 ..... Spring, cord rewind button
- B11 ..... N/A ..... Screw, upper body
- B12 ..... P-416 ..... Screw, power indicator, 10 pk
- B13 ..... P-9822 ..... Switch, on/off
- B14 ..... P-3874 ..... Screw


- B15 ..... P-9320 ..... Indicator, switch
- B17 ..... P-12467 ..... Main P.C.B.
- B18 ..... P-416 ..... Screw, main P.C.B., 10 pk
- B19 ..... P-282 ..... Blower Cover
- B20 ..... P-12468 ..... Spring, blower cover
- B21 ..... P-12469 ..... Shaft, blower cover
- B22 ..... P-632 ..... Power Head Outlet, 9410, 9420,9430

- B22 ..... P-632 ..... Power Head Outlet, 9440
- B23 ..... N/A ..... Suction Inlet Fitting
- B24 ..... P-12471 ..... Lower Body, 9410,9420,9430
- B24 ..... P-12472 ..... Lower Body, 9440
- B25 ..... P-956 ..... Caster
- B26 ..... P-2601 ..... Washer, caster
- B27 ..... P-416 ..... Screw, 10 pack
- B29 ..... P-12473 ..... Wheel
- B30 ..... N/A ..... Bottom Cover
- B31 ..... P-12393 ..... Screw
- B32 ..... P-12476 ..... Switch, power control
- B34 ..... P-12373 ..... Seal
- B35 ..... P-12479 ..... Filter
- B36 ..... P-7300 ..... Packing, dust box
- B38 ..... P-12481 ..... Upper Body, 9440
- B40 ..... P-12483 ..... Cover Tape
- B41 ..... P-416 ..... Screw, 10 pack




Models: MC-9410, MC-9420, MC-9430, MC-9440

## Cord Reel Unit



- C1 ..... N/A ..... Cord Reel Assembly
- C2 ..... P-416 ..... Screw, cord reel shaft, 10 pk
- C3 ..... P-12399 ..... Rail Base Unit / Power Cord
- C7 ..... P-12398 ..... Contact Base
- C8 ..... P-416 ..... Screw, contact base, 10 pack

## Motor Assembly




- 1 ..... P-026 ..... Motor Support, rubber, front, 9420, 9430
- 1 ..... P-022 ..... Motor Support, rubber, front, 9410, 9440
- 2 ..... N/A ..... Motor Assy, 9410
- 2 ..... P-923 ..... Motor Assy, 9420, 9430
- 2 ..... P-12490 ..... Motor Assy, 9440
- 3 ..... P-12491 ..... Screw, carbon brush
- 4 ..... P-272 ..... Carbon Brush, 9410
- 4 ..... P-273 ..... Carbon Brush, 9420, 9430, 9440
- 5 ..... P-12493 ..... Motor Support, rubber, rear
- 6 ..... P-9920 ..... Noise Suppressor
- 9 ..... P-0632 ..... Motor Cover, 9410
- 10 ..... P-12495 ..... Screw, motor cover
- 11 ..... P-12496 ..... Cap, carbon brush
- 14 ..... P-7411 ..... Spacer
- 15 ..... P-4100 ..... Screw

Models: MC-9410, MC-9420, MC-9430, MC-9440


## Power Nozzle

E1	.....	P-12499	.....	Front Mark, 9410
E1	.....	N/A	.....	Front Mark, 9420
E1	.....	P-12501	.....	Front Mark, 9430
E1	.....	P-12502	.....	Front Mark, 9440
E2	.....	P-12503	.....	Supporter, window
E3	.....	P-12504	.....	Window
E4	.....	P-221	.....	Reflector, window
E5	.....	MP-25K	.....	Bulb, 25 watt (R)
E6	.....	N/A	.....	Lamp Holder
E7	.....	P-12505	.....	Packing, window
E8	.....	P-12506	.....	Partition Board
E9	.....	P-12507	.....	Screw, partition board
E10	.....	P-12508	.....	Body, 9410,9420
E10	.....	P-12509	.....	Body, 9430,9440
E11	.....	P-12510	.....	Furniture Guard
E12	.....	P-394	.....	Power Cord, 9410,9420,9430
E12	.....	P-12512	.....	Power Cord, 9440
E13	.....	SS-34	.....	Bushing, sold each (R)
E14	.....	P-12514	.....	Pedal
E15	.....	N/A	.....	Switch Pedal
E16	.....	P-082	.....	Spring, switch pedal
E17	.....	N/A	.....	Switch, on/off
E18	.....	P-9320	.....	Indicator, switch
E19	.....	P-04	.....	Push Nut
E20	.....	P-152	.....	Activating Spring, switch
E21	.....	P-12414	.....	Filter
E22	.....	N/A	.....	Switch Cover
E23	.....	P-416	.....	Screw, 10 pack
E25	.....	P-12520	.....	Window, indicator
E26	.....	P-813	.....	Tight Packing
E27	.....	P-3401	.....	Connection Hose
E28	.....	P-780	.....	Pipe Connection
E29	.....	P-12428	.....	Screw, bottom cover
E30	.....	P-520	.....	Holding Spring, pipe
E31	.....	N/A	.....	Screw, pipe holding spring
E32	.....	P-160	.....	Shaft, roller
E33	.....	P-08	.....	Stopper, roller shaft
E34	.....	P-430	.....	Screw, roller shaft stopper
E35	.....	P-1001	.....	Roller
E36	.....	P-12415	.....	Motor Assembly
E37	.....	P-03	.....	Motor Support, rubber, rear
E38	.....	P-12525	.....	Motor Support, rubber, upper
E39	.....	P-12526	.....	Cover, motor support
E40	.....	P-12527	.....	Motor Support, rubber, front
E41	.....	P-430	.....	Screw, motor support cover
E42	.....	P-280	.....	Belt, type "CB", 2 pack
E43	.....	P-12528	.....	Packing, belt cover
E44	.....	P-12529	.....	Belt Cover
E45	.....	P-909	.....	Roller, floor nozzle
E46	.....	P-04	.....	Spring Nut
E47	.....	P-503	.....	Shaft, floor nozzle roller
E48	.....	P-12531	.....	Packing, bottom cover, rear
E49	.....	N/A	.....	Packing, bottom cover, front
E50	.....	P-12533	.....	Bottom Plate
E51	.....	N/A	.....	Floor Nozzle Rubber
E52	.....	P-12535	.....	Packing, static discharge



Models: MC-9410, MC-9420, MC-9430, MC-9440

## Agitator Assembly



- F1 ..... P-12536 ..... Agitator Assembly
- F2 ..... N/A ..... End Cap, left
- F3 ..... P-321 ..... Filter
- F4 ..... P-4101 ..... Agitator Holder, w/ bearing
- F5 ..... P-85 ..... Brush Insert, sold each
- F5 ..... P-425 ..... Brush Insert, sold per pair (R)
- F6 ..... P-12538 ..... Agitator Pulley, w/ bearing
- F7 ..... P-9030 ..... Brush Holder
- F8 ..... P-00125 ..... End Cap, right
- F9 ..... P-12540 ..... Shaft, agitator
- F10 ..... P-411 ..... E-Clip
- F11 ..... P-12542 ..... Spacer
- F12 ..... P-12355 ..... Agitator Body