


This Owner's Manual is provided and hosted by [Appliance Factory Parts](http://ApplianceFactoryParts.com).



PANASONIC V9610 Owner's Manual

[Shop genuine replacement parts for PANASONIC V9610](#)




[Find Your PANASONIC Vacuum Cleaner Parts - Select From 605 Models](#)

----- Manual continues below -----

PANASONIC

Models: MC-V9610, MC-V9620, MC-V9635, MC-V9647

Power Nozzle, Agitator & Hose Assembly



PANASONIC

Models: MC-V9610, MC-V9620, MC-V9635, MC-V9647

1	P-73004	Cord & Plug, V9620	20	P-7804	Swivel
1	P-40037	Cord & Plug, V9635	20	N/A	Swivel, V9620
1	P-7304	Cord & Plug, V9647		P-000343	Swivel Catch, V
	P-00084	Cord Assembly, V9610		P-000345	Yoke, swivel, V
2	P-00081	Wand Assy, upper, V9610, V9620	21	P-00128	Seal, swivel
2	P-40097	Wand Assy, upper, V9635	21	P-000346	Seal, swivel, V
2	P-97004	Wand Assy, upper, V9647	22	P-68004	Front Cover, fo
3	P-00080	Wand Assy, lower, V9610, V9620	23	P-747280	Pad, foot peda
3	P-40099	Wand Assy, lower, V9635	24	P-00129	Lever, indicator
3	P-99004	Wand Assy, lower, V9647	25	P-747291	Cam, indicator
4	P-000372	Lock, spring wand	25	P-00079	Cam, indicator
5	P-94014	Light Cover	26	P-00130	Thrust Washer
5	P-00073	Panel Light, V9610	27	P-00131	Washer
5	P-2406	Light Cover, hot stamp, V9620	28	P-00132	Catch, indexing
6	P-21004	Nameplate	29	P-00078	Ratchet, catch
6	N/A	Nameplate, V9620	30	P-00133	Indicator Block
7	P-00126	Lens, front	31	P-00134	Spring, assist
7	P-00069	Lens, front, V9610	32	P-000342	Screw
8	P-21007	Lens, height adjustment	33	P-00135	Bridge, motor
8	N/A	Lens, height adjustment, V9620	34	P-8508	PCB "B" Unit, c
9	P-5355	Extension, button	35	P-6704	Lead Wire "A"
9	P-000127	Extension, button, V9620	36	P-8702	PCB Assembly
10	P-3304	Window, dust sensor	37	P-320B	Belt, type CB5,
11	P-00036	Screw	37	P-270B	Belt, type CB4,
12	P-2014	Cover, nozzle, V9635, V9647		P-00077	Belt Guard, V9
12	P-2006	Cover, nozzle, V9620	38	P-9004	Motor Assembl
12	P-00099	Cover, nozzle, V9610	38	P-00091	Motor Assembl
13	P-10016	Furniture Guard	38	P-9010	Motor Assembl
13	P-00096	Furniture Guard, V9610	39	P-00137	Spring, motor a
14	P-42400	Screw	40	P-00092	Gasket, motor
15	P-6904	Rear Cover	40	P-000349	Gasket, motor,
16	P-3016	Button, wand release		P-000353	Seal, motor sha
17	P-9308	Socket, bulb		P-000354	Seal, motor, V9
17	P-00074	Socket, bulb, V9610, V9620		P-000348	Bracket, motor
18	P-00075	Headlight Bulb	41	P-00068	Overload Prote
19	P-00094	Swivel Cap, V9610	42	P-000623	Wire Connecto
19	P-25006	Swivel Cap, V9620	43	P-47004	Handle Releas
19	P-80014	Swivel Cap, V9635	44	P-00067	Lifter
19	P-25014	Swivel Cap, V9647	45	P-7471	Roller, rear

PANASONIC

Models: MC-V9610, MC-V9620, MC-V9635, MC-V9647

Canister & Motor Assembly

