


# EXPLODED VIEW


## DOOR PARTS

(SCB2000CWW, SCB2000CBB, SCB2000CAA, SCB2000CCC, SCB2001CSS)




# CONTROLLER PARTS

(SCB2000CWW, SCB2000CBB, SCB2000CAA, SCB2000CCC)



# OVEN CAVITY PARTS


(SCB2000CWW, SCB2000CBB, SCB2000CAA,  
SCB2000CCC, SCB2001CSS, ZSC2000CWW, ZSC2000CBB, ZSC2001CSS)




# LATCH BOARD PARTS

(SCB2000CWW, SCB2000CBB, SCB2000CAA,  
SCB2000CCC, SCB2001CSS, ZSC2000CWW, ZSC2000CBB, ZSC2001CSS)

• LEFT




• RIGHT



# INTERIOR PARTS (I)

(SCB2000CWW, SCB2000CBB, SCB2000CAA,  
SCB2000CCC, SCB2001CSS, ZSC2000CWW, ZSC2000CBB, ZSC2001CSS)



# INTERIOR PARTS (II)

(SCB2000CWW, SCB2000CBB, SCB2000CAA,  
SCB2000CCC, SCB2001CSS, ZSC2000CWW, ZSC2000CBB, ZSC2001CSS)

