



# EXPLODED VIEW







# REPLACEMENT PARTS LIST

BLOCK	LOCATION NO.	PART NAME	PATR NO.		BLOCK	LOCATION NO.	PART NAME	PATR NO.		
			V-7515T	V-7513T				V-7515T	V-7513T	
1	130401	BASE, BODY	3040FI1456A	3040FI1456A	2	135504	COVER, MOTOR	3550FI1471B	3550FI1471A	
	131101	CASE, ABSORBER	3110FI12001A	3110FI12001A		252311	FILTER ASS'Y, EXHAUST	5231FI2447A	-	
	133001	PLATE, ROTATE	3300FI1451A	3300FI1451A	252311	FILTER ASS'Y, EXHAUST	-	5231FI3752A		
	136511	HANDLE ASS'Y	3651FI1307B	3651FI1307A	3	135502	COVER, FRONT	3550FI1470A	3550FI1470A	
	139201	PACKING, DUST SEAL	3920FI1277A	3920FI1277A		235503	COVER, EXHAUST FILTER	3550FI2453A	3550FI2453A	
	139202	PACKING, MOTOR MOUNTING	3920FI3732A	3920FI3732A		335211	INDICATOR ASS'Y	3I23019J	3I23019J	
	139204	PACKING, SEAL	3920FI3735A	3920FI3735A		335506	COVER, INDICATOR	3550FI3390B	3550FI3390B	
	143701	SHAFT, WHEEL	4660FI4562A	4660FI4562A		335508	COVER, DUST	3550FI1469B	3550FI1469A	
	146602	WHEEL, LARGE	4660FI3733A	4660FI3733A		340261	LATCH	4026FI3662B	4026FI3662A	
	146811	MOTOR ASS'Y, VC	4681FI2434A	4681FI2434A		340361	SEAL, INDICATOR	4036FI4074A	4036FI4074A	
	148301	BUSHING, CORD	4830FI4640A	4830FI4640A	349701	SPRING, LATCH	4970FI4691A	4970FI4691A		
	149301	HOLDER	4930FI3758A	4930FI3758A	4	235502	COVER, CONTROL	3550FI4658B	3550FI4658A	
	149303	HOLDER, FUSE	4930FI4667A	4930FI4667A		435501	COVER, GRIP HANDLE	3550FI1465B	3550FI1465A	
	149321	CONNECTOR (MECH), NYLON	4H50253B	4H50253B		436501	HANDLE, GRIP	3650FI1467A	3650FI1467A	
	149401	KNOB, REGULATION	4940FI2001A	4940FI2001A		452151	HOSE ASS'Y, FLEXIBLE	5215FI1302B	5215FI1302A	
	149801	SUPPORTER, MOTOR	4980FI3669A	4980FI3669A		41KZZ1	KEY	1KZZFI4002A	1KZZFI4002A	
	149901	HANGER, CORD	4990FI3027A	4990FI3027A		449321	CONNECTOR, HOSE ASM	5215FI2228A	5215FI2228A	
	149902	HANGER, GUIDE	4990FI2001A	4990FI2001A		5	530581	PEDAL, SELECTOR	3058FI3001A	
	152301	FILTER (MECH), MOTOR SAFETY	5230FI3747A	5230FI3747A	LEVER ASSY, SELECTOR		533002	PLATE, BOTTOM (IRON)	3300FI1453A	
	152302	PACKING, ABSORBING	4I23008B	4I23008B	535504		BOARD, HEAD	3500FI2239A		
	152311	FILTER ASS'Y, PAPER	5231FI2391A	5231FI2391A	545101		LEVER, SELECTOR	4510FI3585A		
	164111	POWER CORD ASS'Y	6411FI2422A	6411FI2422B	545111		LEVER ASS'Y, SELECTOR	4511FI3633A		
	166011	SWITCH ASS'Y	6601FI3487A	6601FI3487A	546201		STOPPER, SPRING	4620FI4008A		
	168611	WIRE ASS'Y, CONNECTOR	6861FI2001A	6861FI2001A	549325		CONNECTOR (MECH), SHAFT[LEVER]	4932FI4189A		
	168612	WIRE ASS'Y	6861FI3003A	6861FI3003A	549326		CONNECTOR (MECH), RING	4932FI4192A		
	168772	LEAD WIRE ASS'Y, MOTOR	6861FI3001A	6861FI3001A	549327		CONNECTOR (MECH), PIN	4932FI4193A		
	336501	HANDLE, UPPER	3650FI1468B	3650FI1468A	549741		GUIDE, SELECTOR	4974FI4051A		
	336502	HANDLE, LOWER	3650FI1469A	3650FI1469A	549742		GUIDE, RING	4974FI4052A		
	349702	SPRING, REGULATION	4970FI4693A	4970FI4693A	549751		GUIDE ASS'Y, SELECTOR	4975FI4001A		
	452002	PIPE, CONNECTOR	5200FI1211A	5200FI1211A	549901		HANGER, SELECTOR	4990FI4001A		
	10FZZ1	FUSE	416037W	416037W	C1MP1		SCREW MACHINE, PAN HEAD	1MPC0402418	-	
11BZZ1	BOLT	1BZZFI4002A	1BZZFI4002A	C1MT1	SCREW MACHINE, TRUSS NUT, HEXAGON	1MTC0403318	-			
11WZZ1	WASHER	1WZZFI4002B	1WZZFI4002B	C1NH2	NUT, HEXAGON	1NH0801018	-			
C1NH1	NUT, HEXAGON	1NHB0801018	1NHB0801018	C1WZZ3	WASHER	1WZZFI4002D	-			
				C1WZZ4	WASHER, STOP	1WZZFI4001A	-			
				C43502	RING, E	4080070D				

BLOCK	LOCATION NO.	PART NAME	PATR NO.	
			V-7515T	V-7513T
5	249701	SPRING, BUTTON	4970FI4689A	4970FI4689A
	344001	BELT	4400FI3347A	4400FI3347A
	530402	BASE, HEAD	3040FI1458A	3040FI1458A
	533001	PLATE, BOTTOM	3300FI1452A	3300FI1452A
	535251	BULB	3525FI4001A	3525FI4001A
	535502	COVER, HEAD	3550FI1468B	3550FI1468A
	535503	COVER, LIGHT	3550FI1467A	3550FI1467A
	542711	BAR ASS'Y, AGITATOR	4271FI1001A	4271FI1001A
	542801	BEARING, HEAD	4280FI4040A	4280FI4040A
	543701	SHAFT, AGITATOR	4370FI3656A	4370FI3656A
	545102	LEVER, PLATE	4510FI4666A	4510FI4666A
	546401	STRAP, HEAD[R]	4640FI4001A	4640FI4001A
	546402	STRAP, HEAD[L]	4640FI4002A	4670FI4002A
	546601	WHEEL, SMALL	4660FI3734A	4660FI3734A
	548201	BUMPER, HEAD	4820FI1448A	4820FI1448A
	548741	FIXTURE, AGITATOR[L]	4874FI2002A	4874FI2002A
	548742	FIXTURE, AGITATOR[R]	4874FI2001A	4874FI2001A
	549311	HOLDER ASS'Y, LAMP	4931FI3685A	4931FI3685A
	549324	CONNECTOR (MECH), LEVER	4932FI4190A	4932FI4190A
	549331	CONNECTOR ASS'Y (MECH), BAR	4933FI2003A	4933FI2003A
	550201	BUTTON, RELEASE	5020FI2320A	5020FI2320A
	552151	HOSE ASS'Y, HEAD	5215FI3001A	5215FI3001A
	559731	AGITATOR ASS'Y	5973FI1001A	5973FI1001A
	51PZZ1	PIN	4I22094B	4I22094B
	C1WZZ1	WASHER	1WZZFI4002A	1WZZFI4002A
	C1WZZ2	WASHER	1WZZFI4002C	1WZZFI4002C
	C1TP1	SCREW TAPPING, PAN HEAD	ITPL0403318	ITPL0403318
	C43501	RING, E	4O80070A	4O80070A

BLOCK	LOCATION NO.	PART NAME	PATR NO.	
			V-7515T	V-7513T
6	530401	BASE, NOZZLE	3040FI1465A	3040FI1465A
	535501	COVER, NOZZLE	3550FI1466A	3550FI1466A
	545801	ROLLER	4I30001A	4I30001A
	545802	ROLLER, PIN	4I30002A	4I30002A
	552001	PIPE, SUCTION	5200FI3736A	5200FI3736A
	552491	NOZZLE ASS'Y, FLOOR	5249FI1386A	5249FI1386A
	630711	BODY ASS'Y, BRUSH	3071FI4001A	3071FI4001A
	643501	RING, CONTROL	4350FI3754A	4350FI3754A
	643502	RING, FIXING	4350FI3755A	4350FI3755A
	650581	TOOL, CREVICE	5058FI2212A	5058FI2212A
	650621	WAND, UPPER	5062FI2053A	5062FI2053A
	650622	WAND, LOWER	5062FI2052A	5062FI2052A
	650632	WAND ASS'Y, SUB	5063FI1444A	5063FI1444A
	652001	PIPE, BRUSH	5200FI2452A	5200FI2452A
	652031	BRUSH ASS'Y, DUST	5203FI2067A	5203FI2067A