


This Owner's Manual is provided and hosted by [Appliance Factory Parts](http://ApplianceFactoryParts.com).



LG VC-401N Owner's Manual




[Shop genuine replacement parts for LG VC-401N](#)






[Find Your LG Vacuum Cleaner Parts - Select From 37 Models](#)

----- Manual continues below -----

EXPLODED VIEW







REPLACEMENT PARTS LIST

LOCATION NO.	PART NO.	DESCRIPTION	REMARK
130401	3040FI111D	BODY BASE	
135502	3550FI1113D	FRONT COVER	
139201	3920FI1115A	PACKING, DUST SEAL	
139202	3920FI3600A	MOTOR MOUNT PACKING	
139206	4036FI3036A	PACKING, TERMINAL	
144411	4441FI3605J	CASTER ASSY	
144801	3I23004B	HOOK, FILTER SETTING	
146601	3660FI1114D	WHEEL	
146811	4681FI2373G	MOTOR ASSY	VMC500L2
146871	6411FI1071W	CORD REEL ASSY	A-1
149801	4980FI3702A	SUPPORTER, MOTOR	
150401	5040FI2449A	SOUND RUBBER	
152302	3940FI3646A	ABSORBING SPONGE	
152311	5231FI3018B	FILTER BAG	FOR VC-401N
152311	5231FI2390J	FILTER BAG	FOR 721.21195
152301	5230FI3248A	MOTOR SAFETY FILTER	
168711	6871FX2130C	PWB ASSY	
235501	3550FI1110N	COVER, BODY	
236501	3650FI2132N	HANDLE	BLUE
250202	5020FI3233N	BUTTON, CORD REEL	
335211	3I23019L	INDICATOR ASSY	
335501	3550FI1562A	COVER, FILTER	FOR VC-401N
335501	3550FI1551K	COVER, FILTER	FOR 721.21195
335506	3550FI3307G	COVER, INDICATOR	
340261	4026FI3234A	LATCH	
435501	3550FI1377X	COVER, GRIP HANDLE	BLUE
435507	3550FI2358F	COVER, FITTING PIPE	
444802	3I23013P	HOOK, FITTING	
436501	3650FI1430C	GRIP HANDLE	
449321	4932FI2360C	HOSE CONECTOR ASSY	BLUE
452151	5214FI1453R	FLEXIBLE HOSE ASSY	BLUE
552491	5249FI1399A	NOZZLE ASSY	
552493	5249FI1395Z	NOZZLE ASSY, QUILT	FOR VC-401N
652012	5201FI2442A	TELESCOPIC PIPE ASSY	
649311	4930FI2378B	ACCESSORY HOLDER	
652031	3I22005N	DUSTING, BRUSH	
652481	5248FI2259C	NOZZLE, UPHOLSTERY	