



Ref. No.	Part No.	Description	Ref. No.	Part No.	Description
1	59139222	Handle Assembly	24	59139230	Agitator Motor
2	59139246	Pipe	25	59139232	Belt
3	59139240	Switch Button	26	59139228	Agitator Bearing (2)
4	59139224	Pipe Screw	27		Pulley
5	59139252	Hook	28		Washer
6	59139223	Pipe Screw	29	59139227	Agitator Assm. (Inc. items 26,27,28)
7	59139239	Housing - RH	30	59139237	Dirt Cup/ Nozzle Assm. (Inc. it. 11 thru 35)
8	59139209	Screw	31	59139244	Seal
9	59139209	Screw	32		Rubber Block
10	59139219	Filter	33	12227	Insulated Terminal
11		Delivery Valve	34		Agitator Housing
12		Lead Wire Assembly	35	59139259	Agitator Housing Lens
13		Terminal Holder		59139260	Foam Seal (Lens)
14		Screw	36	59139238	Housing - LH
15		Separator	37	59139241	Dirt Cup Latch
16	59139237	Dirt Cup/ Nozzle Assm. (Inc. items 11 thru 35)	38	59139242	Latch Spring
17		Filter Frame	39	59139220	Fan Motor
18	59139234	Roller Shaft	40		Screw
19	59139233	Roller	41	59139249	Cord Holder (A)
20		Screw	42	59139250	Cord Holder (B)
21		Bottom Cover	43	59139226	PCB Assembly
22		Bottom Plate	44	59139251	Cord Assembly
23	59139245	Seal	45	59139275	Motor Pulley
				56512170	Owner Manual
				59139216	Carton