

This Owner's Manual is provided and hosted by [Appliance Factory Parts](#).



# Coleman 2300A512 Owner's Manual

**[Shop genuine replacement parts for Coleman  
2300A512](#)**



**[Find Your Coleman Camping Parts - Select From 855 Models](#)**

----- Manual continues below -----

## Helpful Hints:

- If using a shower enclosure, please set the **Hot Water on Demand™** on a table outside the enclosure before using.
- It is typical to experience a slight change in water flow & temperature when moving spray adapter from high to low heights.

For information regarding other **Hot Water on Demand™** accessories:

Visit us at  
[www.coleman.com](http://www.coleman.com)



The Coleman Co., Inc. • 3600 N. Hydraulic • Wichita, KS 67219 U.S.A.  
1-800-835-3278 • TDD: 316-832-8707

©2003 The Coleman Company, Inc. All Rights reserved.  
Coleman® is a registered trademark of The Coleman Company, Inc.

2300-051 (05/03)



# SPRAY ADAPTER

## *Instructions for Use*

Model 2300-512




Use the Spray Adapter with **Hot Water on Demand™** for a refreshing hot shower. Easily attaches to faucet with a quick connector.

## Assembly Steps:

Make sure your **Hot Water on Demand™** unit is turned off and that no water is running through the unit. Operate the unit from a camp table or picnic table. Do not set unit on the ground to use.


1. Attach Handled Spray Head to Tubing End. Hand tighten.



2. Rotate Faucet of the **Hot Water on Demand™** unit outward to its usage position.



3. Insert end of Spray Head Adapter into faucet.



4. Hold Spray Adapter in your hand.

5. Turn the **Hot Water on Demand™** on by turning Control Knob counterclockwise to desired temperature range.

